

Lucas

Compatibility Chart

MANUFACTURER	CAR MODEL	YEAR RANGE	POSITION
Abarth	124 1.4 Spider MultiAir 170 (2016-2019)	06/16-12/19	FR DS
Abarth	124 1.4 Spider MultiAir 170 (2016-2019)	06/16-12/19	FR DS
Alfa Romeo	33 1.3 905 (1983-1990)	02/86-05/87	FR DS
Alfa Romeo	33 1.3 905 (1983-1990)	02/86-05/87	FR PS
Alfa Romeo	33 1.3 905 (1983-1990)	02/86-05/87	FR DS
Alfa Romeo	33 1.3 905 (1983-1990)	02/86-05/87	FR PS
Alfa Romeo	33 1.3 905 (1983-1990)	06/83-02/86	FR DS
Alfa Romeo	33 1.3 905 (1983-1990)	06/83-02/86	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	02/86-05/87	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	02/86-05/87	FR DS
Alfa Romeo	33 1.5 905 (1983-1990)	05/85-05/87	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	05/85-05/87	FR DS
Alfa Romeo	33 1.5 905 (1983-1990)	05/87-11/90	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	05/87-11/90	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	05/87-11/90	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	05/87-11/90	FR DS
Alfa Romeo	33 1.5 905 (1983-1990)	05/87-11/90	FR DS
Alfa Romeo	33 1.5 905 (1983-1990)	05/87-11/90	FR DS
Alfa Romeo	33 1.5 905 (1983-1990)	05/87-11/90	FR DS
Alfa Romeo	33 1.5 905 (1983-1990)	06/83-12/86	FR DS
Alfa Romeo	33 1.5 905 (1983-1990)	06/83-12/86	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	06/83-12/86	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	06/83-12/86	FR PS
Alfa Romeo	33 1.5 905 (1983-1990)	06/83-12/86	FR DS
Alfa Romeo	33 1.5 905 (1983-1990)	06/83-12/86	FR DS
Alfa Romeo	33 1.5 Green Cloverleaf 905 (1983-1990)	06/84-05/87	FR PS
Alfa Romeo	33 1.5 Green Cloverleaf 905 (1983-1990)	06/84-05/87	FR DS
Alfa Romeo	33 1.5 IE 907 (1990-1995)	10/90-07/93	FR PS
Alfa Romeo	33 1.5 IE 907 (1990-1995)	10/90-07/93	FR DS
Alfa Romeo	33 1.5 IE 907 (1990-1995)	10/90-07/93	FR PS
Alfa Romeo	33 1.5 IE 907 (1990-1995)	10/90-07/93	FR PS
Alfa Romeo	33 1.5 IE 907 (1990-1995)	10/90-07/93	FR DS
Alfa Romeo	33 1.5 IE 907 (1990-1995)	10/90-07/93	FR DS
Alfa Romeo	33 1.7 905 (1983-1990)	05/87-08/90	FR PS
Alfa Romeo	33 1.7 905 (1983-1990)	05/87-08/90	FR DS
Alfa Romeo	33 1.7 907 (1990-1995)	06/90-07/95	FR DS
Alfa Romeo	33 1.7 907 (1990-1995)	06/90-07/95	FR PS
Alfa Romeo	33 1.7 907 (1990-1995)	06/90-07/95	FR DS
Alfa Romeo	33 1.7 907 (1990-1995)	06/90-07/95	FR PS
Alfa Romeo	33 1.7 IE 907 (1990-1995)	08/90-07/95	FR PS
Alfa Romeo	33 1.7 IE 907 (1990-1995)	08/90-07/95	FR PS
Alfa Romeo	33 1.7 IE 907 (1990-1995)	08/90-07/95	FR DS
Alfa Romeo	33 1.7 IE 907 (1990-1995)	08/90-07/95	FR DS
Alfa Romeo	33 1.7 Permanent 4 907 (1990-1995)	03/91-07/93	FR PS
Alfa Romeo	33 1.7 Permanent 4 907 (1990-1995)	03/91-07/93	FR PS
Alfa Romeo	33 1.7 Permanent 4 907 (1990-1995)	03/91-07/93	FR DS
Alfa Romeo	33 1.7 Permanent 4 907 (1990-1995)	03/91-07/93	FR DS

Alfa Romeo	33 1.7 Sportwagon 905 (1983-1990)	07/87-08/90	FR DS
Alfa Romeo	33 1.7 Sportwagon 905 (1983-1990)	07/87-08/90	FR PS
Alfa Romeo	33 1.7 Sportwagon 905 (1983-1990)	07/87-08/90	FR PS
Alfa Romeo	33 1.7 Sportwagon 905 (1983-1990)	07/87-08/90	FR DS
Alfa Romeo	33 1.7 Sportwagon 905 (1983-1990)	07/87-08/90	FR DS
Alfa Romeo	33 1.7 Sportwagon 905 (1983-1990)	07/87-08/90	FR PS
Alfa Romeo	33 1.7 Sportwagon 907 (1990-1995)	03/91-07/95	FR PS
Alfa Romeo	33 1.7 Sportwagon 907 (1990-1995)	03/91-07/95	FR PS
Alfa Romeo	33 1.7 Sportwagon 907 (1990-1995)	03/91-07/95	FR DS
Alfa Romeo	33 1.7 Sportwagon 907 (1990-1995)	03/91-07/95	FR DS
Alfa Romeo	6 2.5 Carburettor	09/80-02/84	FR PS
Alfa Romeo	6 2.5 Carburettor	09/80-02/84	FR DS
Alfa Romeo	6 2.5 Gold Cloverleaf (Injection)	02/84-03/86	FR DS
Alfa Romeo	6 2.5 Gold Cloverleaf (Injection)	02/84-03/86	FR PS
Alfa Romeo	75 1.8 162 (1986-1992)	06/86-09/89	FR DS
Alfa Romeo	75 1.8 162 (1986-1992)	06/86-09/89	FR DS
Alfa Romeo	75 1.8 162 (1986-1992)	06/86-09/89	FR PS
Alfa Romeo	75 1.8 162 (1986-1992)	06/86-09/89	FR PS
Alfa Romeo	75 1.8 162 (1986-1992)	06/86-09/89	FR PS
Alfa Romeo	75 1.8 162 (1986-1992)	06/86-09/89	FR DS
Alfa Romeo	75 2.0 162 (1986-1992)	09/87-12/92	FR DS
Alfa Romeo	75 2.0 162 (1986-1992)	09/87-12/92	FR DS
Alfa Romeo	75 2.0 162 (1986-1992)	09/87-12/92	FR PS
Alfa Romeo	75 2.0 162 (1986-1992)	09/87-12/92	FR PS
Alfa Romeo	75 3.0 162 (1986-1992)	06/90-12/92	FR PS
Alfa Romeo	75 3.0 162 (1986-1992)	06/90-12/92	FR DS
Alfa Romeo	75 3.0 162 (1986-1992)	10/87-06/90	FR DS
Alfa Romeo	75 3.0 162 (1986-1992)	10/87-06/90	FR PS
Alfa Romeo	75 3.0 162 (1986-1992)	10/87-06/90	FR DS
Alfa Romeo	75 3.0 162 (1986-1992)	10/87-06/90	FR PS
Alfa Romeo	GTV 2.0 916 (1996-2005)	04/96-09/98	FR PS
Alfa Romeo	GTV 2.0 916 (1996-2005)	04/96-09/98	FR PS
Alfa Romeo	GTV 2.0 916 (1996-2005)	09/98-10/03	FR PS
Alfa Romeo	GTV 2.0 JTS 916 (1996-2005)	09/03-12/05	FR PS
Alfa Romeo	GTV 2.0 T Spark 916 (1996-2005)	02/04-12/05	FR PS
Alfa Romeo	GTV 2.0 T Spark 916 (1996-2005)	02/04-12/05	FR PS
Alfa Romeo	GTV 3.0 916 (1996-2005)	09/98-10/03	FR PS
Alfa Romeo	GTV 3.0 916 (1996-2005)	09/98-10/03	FR PS
Alfa Romeo	GTV 3.0 916 (1996-2005)	09/98-12/00	FR PS
Alfa Romeo	GTV 3.0 916 (1996-2005)	09/98-12/00	FR PS
Alfa Romeo	GTV 3.2 916 (1996-2005)	09/03-12/05	FR PS
Alfa Romeo	Spider 2.0 JTS 916 (1996-2005)	09/03-12/04	FR PS
Alfa Romeo	Spider 2.0 JTS 916 (1996-2005)	09/03-12/04	RR
Alfa Romeo	Spider 2.0 TS 916 (1996-2005)	04/96-09/98	FR PS
Alfa Romeo	Spider 2.0 TS 916 (1996-2005)	04/96-09/98	RR
Alfa Romeo	Spider 2.0 TS 916 (1996-2005)	08/00-12/04	FR PS
Alfa Romeo	Spider 2.0 TS 916 (1996-2005)	08/00-12/04	RR
Alfa Romeo	Spider 2.0 TS 916 (1996-2005)	09/98-10/03	RR
Alfa Romeo	Spider 2.0 TS 916 (1996-2005)	09/98-10/03	FR PS
Alfa Romeo	Spider 3.0 916 (1996-2005)	04/01-10/03	RR

Alfa Romeo	Spider 3.0 916 (1996-2005)	04/01-10/03	FR PS
Alfa Romeo	Spider 3.2 916 (1996-2005)	09/03-12/04	RR
Alfa Romeo	Spider 3.2 916 (1996-2005)	09/03-12/04	FR PS
Audi	100 2.0 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.0 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.0 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.0 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.0 C4 (1991-1994)	05/91-12/94	RR
Audi	100 2.0 C4 (1991-1994)	05/91-12/94	RR
Audi	100 2.0 C4 (1991-1994)	05/91-12/94	RR
Audi	100 2.0 C4 (1991-1994)	05/91-12/94	RR
Audi	100 2.1 Carburettor CL-5S C2 (1976-1984)	01/80-07/82	FR DS
Audi	100 2.1 Carburettor CL-5S C2 (1976-1984)	01/80-07/82	FR DS
Audi	100 2.1 Carburettor CL-5S C2 (1976-1984)	01/80-07/82	FR PS
Audi	100 2.1 Carburettor CL-5S C2 (1976-1984)	01/80-07/82	FR DS
Audi	100 2.1 Carburettor CL-5S C2 (1976-1984)	01/80-07/82	FR PS
Audi	100 2.1 Carburettor CL-5S C2 (1976-1984)	01/80-07/82	FR PS
Audi	100 2.1 Carburettor CL-5S C2 (1976-1984)	01/80-07/82	FR PS
Audi	100 2.1 Carburettor CL-5S C2 (1976-1984)	01/80-07/82	FR DS
Audi	100 2.1 Injection CL-5E C2 (1976-1984)	01/80-09/84	FR PS
Audi	100 2.1 Injection CL-5E C2 (1976-1984)	01/80-09/84	FR DS
Audi	100 2.1 Injection CL-5E C2 (1976-1984)	01/80-09/84	FR DS
Audi	100 2.1 Injection CL-5E C2 (1976-1984)	01/80-09/84	FR PS
Audi	100 2.1 Injection CL-5E C2 (1976-1984)	01/80-09/84	FR DS
Audi	100 2.1 Injection CL-5E C2 (1976-1984)	01/80-09/84	FR DS
Audi	100 2.1 Injection CL-5E C2 (1976-1984)	01/80-09/84	FR PS
Audi	100 2.1 Injection CL-5E C2 (1976-1984)	01/80-09/84	FR PS
Audi	100 2.2 S4 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.2 S4 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.2 S4 C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.2 S4 C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.3 Avant C4 (1991-1994)	10/91-12/92	RR
Audi	100 2.3 Avant C4 (1991-1994)	10/91-12/92	RR
Audi	100 2.3 Avant quattro C4 (1991-1994)	10/91-12/92	RR
Audi	100 2.3 C4 (1991-1994)	05/91-12/92	RR
Audi	100 2.3 C4 (1991-1994)	05/91-12/92	RR
Audi	100 2.3 quattro C4 (1991-1994)	05/91-12/92	RR
Audi	100 2.3 quattro C4 (1991-1994)	05/91-12/92	RR
Audi	100 2.5 Avant C4 (1991-1994)	08/93-12/94	RR
Audi	100 2.5 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 C4 (1991-1994)	08/93-12/94	RR
Audi	100 2.5 C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.5 C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.6 Avant C4 (1991-1994)	10/92-12/94	RR
Audi	100 2.6 Avant C4 (1991-1994)	10/92-12/94	RR

Audi	100 2.6 C4 (1991-1994)	10/92-12/94	RR
Audi	100 2.6 C4 (1991-1994)	10/92-12/94	RR
Audi	100 2.8 Avant C4 (1991-1994)	10/91-12/92	RR
Audi	100 2.8 Avant C4 (1991-1994)	10/91-12/92	RR
Audi	100 2.8 C4 (1991-1994)	05/91-12/92	RR
Audi	100 2.8 C4 (1991-1994)	05/91-12/92	RR
Audi	100 2.8 quattro Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.8 quattro Avant C4 (1991-1994)	10/91-12/94	RR
Audi	100 2.8 quattro C4 (1991-1994)	05/91-12/94	RR
Audi	100 2.8 quattro C4 (1991-1994)	05/91-12/94	RR
Audi	200 2.1 Turbo C2 (1980-1984)	04/80-03/83	FR PS
Audi	200 2.1 Turbo C2 (1980-1984)	04/80-03/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-07/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-07/83	FR PS
Audi	80 1.6 B2 (1979-1986)	01/80-07/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-07/83	FR PS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR PS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR PS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR PS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR PS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR PS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR DS
Audi	80 1.6 B2 (1979-1986)	01/80-10/83	FR PS
Audi	80 1.6 B2 (1979-1986)	09/82-07/86	FR PS
Audi	80 1.6 B2 (1979-1986)	09/82-07/86	FR DS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR PS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR DS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR PS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR PS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR PS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR PS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR DS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR DS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR PS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR DS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR DS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR DS
Audi	80 1.6 B2 (1979-1986)	10/83-06/86	FR DS
Audi	80 1.6 B3 (1986-1991)	09/86-11/87	FR PS
Audi	80 1.6 B3 (1986-1991)	09/86-11/87	FR DS
Audi	80 1.6 B3 (1986-1991)	09/86-11/87	FR PS
Audi	80 1.6 B3 (1986-1991)	09/86-11/87	FR DS
Audi	80 1.8 B2 (1979-1986)	02/83-07/86	FR PS
Audi	80 1.8 B2 (1979-1986)	02/83-07/86	FR DS
Audi	80 1.8 B2 (1979-1986)	02/83-07/86	FR PS
Audi	80 1.8 B2 (1979-1986)	02/83-07/86	FR DS

Audi	80 1.8 quattro B2 (1979-1986)	07/85-07/86	FR PS
Audi	80 1.8 quattro B2 (1979-1986)	07/85-07/86	FR DS
Audi	80 1.8 quattro B2 (1979-1986)	07/85-07/86	FR DS
Audi	80 1.8 quattro B2 (1979-1986)	07/85-07/86	FR PS
Audi	80 1.9 B2 (1979-1986)	09/81-10/83	FR PS
Audi	80 1.9 B2 (1979-1986)	09/81-10/83	FR DS
Audi	80 1.9 B2 (1979-1986)	09/81-10/83	FR DS
Audi	80 1.9 B2 (1979-1986)	09/81-10/83	FR PS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR PS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR PS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR DS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR DS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR DS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR DS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR PS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR PS
Audi	80 2.0 B2 (1979-1986)	10/83-05/84	FR DS
Audi	A6 1.8 Avant C4 (4A) (1994-1997)	12/95-08/97	RR
Audi	A6 1.8 Avant C4 (4A) (1994-1997)	12/95-08/97	RR
Audi	A6 1.9 Avant C4 (4A) (1994-1997)	01/95-08/97	RR
Audi	A6 1.9 Avant C4 (4A) (1994-1997)	01/95-08/97	RR
Audi	A6 2.0 Avant C4 (4A) (1994-1997)	06/94-12/96	RR
Audi	A6 2.0 Avant C4 (4A) (1994-1997)	06/94-12/96	RR
Audi	A6 2.5 Avant C4 (4A) (1994-1997)	01/95-08/97	RR
Audi	A6 2.5 Avant C4 (4A) (1994-1997)	01/95-08/97	RR
Audi	A6 2.5 Avant C4 (4A) (1994-1997)	06/94-08/97	RR
Audi	A6 2.5 Avant C4 (4A) (1994-1997)	06/94-08/97	RR
Audi	A6 2.5 Avant C4 (4A) (1994-1997)	06/94-08/97	RR
Audi	A6 2.5 Avant quattro C4 (4A) (1994-1997)	12/95-08/97	RR
Audi	A6 2.5 Avant quattro C4 (4A) (1994-1997)	12/95-08/97	RR
Audi	A6 2.6 Avant C4 (4A) (1994-1997)	06/94-08/97	RR
Audi	A6 2.6 Avant C4 (4A) (1994-1997)	06/94-08/97	RR
Audi	A6 2.8 Avant C4 (4A) (1994-1997)	12/95-08/97	RR
Audi	A6 2.8 Avant C4 (4A) (1994-1997)	12/95-08/97	RR
Audi	A6 2.8 Avant quattro C4 (4A) (1994-1997)	06/94-12/95	RR
Audi	A6 2.8 Avant quattro C4 (4A) (1994-1997)	06/94-12/95	RR
Audi	A6 2.8 Avant quattro C4 (4A) (1994-1997)	06/94-12/95	RR
Audi	A6 2.8 Avant quattro C4 (4A) (1994-1997)	06/94-12/95	RR
Audi	A6 2.8 Avant quattro C4 (4A) (1994-1997)	12/95-08/97	RR
Audi	A6 2.8 Avant quattro C4 (4A) (1994-1997)	12/95-08/97	RR
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR DS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR DS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR PS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR PS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR PS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR DS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR DS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR PS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR DS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR PS
Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR PS

Audi	Coupe 1.8 Carburettor B2 (1981-1988)	10/84-07/86	FR DS
Audi	Coupe 1.8 Injection B2 (1981-1988)	08/86-01/88	FR DS
Audi	Coupe 1.8 Injection B2 (1981-1988)	08/86-01/88	FR PS
Audi	Coupe 1.9 B2 (1981-1988)	08/81-08/83	FR DS
Audi	Coupe 1.9 B2 (1981-1988)	08/81-08/83	FR PS
Audi	Coupe 1.9 B2 (1981-1988)	08/81-08/83	FR PS
Audi	Coupe 1.9 B2 (1981-1988)	08/81-08/83	FR DS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR PS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR PS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR DS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR DS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR PS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR DS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR PS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR DS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR PS
Audi	Coupe 2.0 B2 (1981-1988)	08/83-07/86	FR DS
Audi	Coupe 2.1 B2 (1981-1988)	07/82-08/84	FR PS
Audi	Coupe 2.1 B2 (1981-1988)	07/82-08/84	FR PS
Audi	Coupe 2.1 B2 (1981-1988)	07/82-08/84	FR DS
Audi	Coupe 2.1 B2 (1981-1988)	07/82-08/84	FR DS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR DS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR DS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR PS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR PS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR PS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR PS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR DS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR DS
Audi	Coupe 2.2 B2 (1981-1988)	04/86-09/87	FR PS
Audi	Quattro 2.1 UR (1980-1991)	11/80-12/87	FR DS
Audi	Quattro 2.1 UR (1980-1991)	11/80-12/87	FR PS
Audi	Quattro 2.1 UR (1980-1991)	11/80-12/87	FR PS
Audi	Quattro 2.1 UR (1980-1991)	11/80-12/87	FR DS
Audi	Quattro 2.1 UR (1980-1991)	11/80-12/87	RR
Audi	Quattro 2.1 UR (1980-1991)	11/80-12/87	RR
Audi	Quattro 2.2 UR (1980-1991)	08/89-04/91	RR
Audi	Quattro 2.2 UR (1980-1991)	08/89-04/91	FR DS
Audi	Quattro 2.2 UR (1980-1991)	08/89-04/91	FR PS
Audi	Quattro 2.2 UR (1980-1991)	12/87-08/89	FR PS
Audi	Quattro 2.2 UR (1980-1991)	12/87-08/89	FR DS
Audi	Quattro 2.2 UR (1980-1991)	12/87-08/89	RR
Audi	S6 2.2 Avant quattro C4 (4A) (1994-1997)	06/94-08/97	RR
Audi	S6 2.2 Avant quattro C4 (4A) (1994-1997)	06/94-08/97	RR
BMW	316 1.8 E21	09/80-07/83	FR DS
BMW	316 1.8 E21	09/80-07/83	FR DS
BMW	316 1.8 E21	09/80-07/83	FR PS
BMW	316 1.8 E21	09/80-07/83	FR PS
BMW	316 1.8 E21	12/82-07/83	FR DS
BMW	316 1.8 E21	12/82-07/83	FR PS
BMW	316i 1.6 Compact E36	09/94-01/99	RR
BMW	316i 1.6 Compact E36	09/94-01/99	RR
BMW	316i 1.6 Touring E30	09/91-07/94	RR

BMW	316i 1.6 Touring E30	09/91-07/94	RR
BMW	316i 1.9 Compact E36	01/99-12/01	RR
BMW	316i 1.9 Compact E36	01/99-12/01	RR
BMW	316i 1.9 Compact E36	01/99-12/01	RR
BMW	316i 1.9 Compact E36	01/99-12/01	RR
BMW	316ti 1.8 Compact E46	09/01-04/05	RR
BMW	316ti 1.8 Compact E46	09/01-04/05	RR
BMW	316ti 1.8 Compact E46	09/01-04/05	RR
BMW	316ti 1.8 Compact E46	09/01-04/05	RR
BMW	318i 1.8 Touring E30	04/89-07/94	RR
BMW	318i 1.8 Touring E30	04/89-07/94	RR
BMW	318tds 1.7 Compact E36	09/95-12/01	RR
BMW	318ti 1.8 Compact E36	09/94-04/96	RR
BMW	318ti 1.8 Compact E36	09/94-04/96	RR
BMW	318ti 1.9 Compact E36	04/96-12/01	RR
BMW	318ti 1.9 Compact E36	04/96-12/01	RR
BMW	318ti 2.0 Compact E46	09/01-04/05	RR
BMW	318ti 2.0 Compact E46	09/01-04/05	RR
BMW	318ti 2.0 Compact E46	09/01-04/05	RR
BMW	318ti 2.0 Compact E46	09/01-04/05	RR
BMW	320 2.0 E21	01/80-12/82	FR DS
BMW	320 2.0 E21	01/80-12/82	FR PS
BMW	320 2.0 E21	01/80-12/82	FR PS
BMW	320 2.0 E21	01/80-12/82	FR DS
BMW	320i 2.0 Touring E30	09/88-07/91	RR
BMW	320i 2.0 Touring E30	09/88-07/91	RR
BMW	320td 2.0 Compact E46	01/03-04/05	RR
BMW	320td 2.0 Compact E46	03/03-04/05	RR
BMW	320td 2.0 Compact E46	09/01-04/05	RR
BMW	320td 2.0 Compact E46	09/01-04/05	RR
BMW	320td 2.0 Compact E46	09/01-04/05	RR
BMW	320td 2.0 Compact E46	09/01-04/05	RR
BMW	323i 2.3 E21	01/80-12/82	FR DS
BMW	323i 2.3 E21	01/80-12/82	FR DS
BMW	323i 2.3 E21	01/80-12/82	FR PS
BMW	323i 2.3 E21	01/80-12/82	FR PS
BMW	325i 2.5 Touring E30	04/88-12/93	RR
BMW	325i 2.5 Touring E30	04/88-12/93	RR
BMW	325ti 2.5 Compact E46	09/01-04/05	RR
BMW	325ti 2.5 Compact E46	09/01-04/05	RR
BMW	325ti 2.5 Compact E46	09/01-04/05	RR
BMW	325ti 2.5 Compact E46	09/01-04/05	RR
BMW	518 1.8 E12	01/80-12/81	FR DS
BMW	518 1.8 E12	01/80-12/81	FR DS
BMW	518 1.8 E12	01/80-12/81	FR PS
BMW	518 1.8 E12	01/80-12/81	FR PS
BMW	518 1.8 E28	10/81-01/85	FR PS
BMW	518 1.8 E28	10/81-01/85	FR DS
BMW	518i 1.8 E28	01/85-10/87	FR PS
BMW	518i 1.8 E28	01/85-10/87	FR DS

BMW	520 2.0 E12	01/80-12/81	FR PS
BMW	520 2.0 E12	01/80-12/81	FR DS
BMW	520 2.0 E12	01/80-12/81	FR PS
BMW	520 2.0 E12	01/80-12/81	FR DS
BMW	520 2.0 E12	01/80-12/81	FR DS
BMW	520 2.0 E12	01/80-12/81	FR PS
BMW	520i 2.0 E28	07/83-09/85	FR DS
BMW	520i 2.0 E28	07/83-09/85	FR PS
BMW	520i 2.0 E28	09/85-12/87	FR PS
BMW	520i 2.0 E28	09/85-12/87	FR DS
BMW	520i 2.0 E28	09/85-12/87	FR DS
BMW	520i 2.0 E28	09/85-12/87	FR PS
BMW	520i 2.0 E28	10/81-09/85	FR DS
BMW	520i 2.0 E28	10/81-09/85	FR PS
BMW	520i 2.0 E28	10/81-09/85	FR DS
BMW	520i 2.0 E28	10/81-09/85	FR PS
BMW	520i 2.0 Touring E39	04/97-09/00	RR
BMW	520i 2.0 Touring E39	04/97-09/00	RR
BMW	520i 2.0 Touring E39	04/97-09/00	RR
BMW	520i 2.0 Touring E39	04/97-09/00	RR
BMW	520i 2.0 Touring E39	04/97-09/00	RR
BMW	520i 2.0 Touring E39	04/97-09/00	RR
BMW	520i 2.2 Touring E39	09/00-08/04	RR
BMW	520i 2.2 Touring E39	09/00-08/04	RR
BMW	523i 2.5 Touring E39	04/97-09/00	RR
BMW	523i 2.5 Touring E39	04/97-09/00	RR
BMW	523i 2.5 Touring E39	04/97-09/00	RR
BMW	523i 2.5 Touring E39	04/97-09/00	RR
BMW	525 2.5 E12	01/80-12/81	FR DS
BMW	525 2.5 E12	01/80-12/81	FR PS
BMW	525 2.5 E12	01/80-12/81	FR DS
BMW	525 2.5 E12	01/80-12/81	FR PS
BMW	525 2.5 E12	01/80-12/81	FR DS
BMW	525 2.5 E12	01/80-12/81	FR PS
BMW	525d 2.5 Touring E39	09/00-08/04	RR
BMW	525d 2.5 Touring E39	09/00-08/04	RR
BMW	525d 2.5 Touring E39	09/00-08/04	RR
BMW	525d 2.5 Touring E39	09/00-08/04	RR
BMW	525e 2.7 E28	06/83-09/85	FR DS
BMW	525e 2.7 E28	06/83-09/85	FR PS
BMW	525e 2.7 E28	09/85-12/87	FR PS
BMW	525e 2.7 E28	09/85-12/87	FR DS
BMW	525i 2.5 E28	07/83-10/87	FR DS
BMW	525i 2.5 E28	07/83-10/87	FR PS
BMW	525i 2.5 E28	07/83-10/87	FR PS
BMW	525i 2.5 E28	07/83-10/87	FR DS
BMW	525i 2.5 E28	10/81-10/87	FR PS
BMW	525i 2.5 E28	10/81-10/87	FR DS
BMW	525i 2.5 E28	10/81-10/87	FR DS
BMW	525i 2.5 E28	10/81-10/87	FR DS

BMW	525i 2.5 E28	10/81-10/87	FR PS
BMW	525i 2.5 E28	10/81-10/87	FR PS
BMW	525i 2.5 E28	10/81-10/87	FR PS
BMW	525i 2.5 E28	10/81-10/87	FR DS
BMW	525i 2.5 Touring E39	09/00-08/04	RR
BMW	525i 2.5 Touring E39	09/00-08/04	RR
BMW	525i 2.5 Touring E39	09/00-08/04	RR
BMW	525i 2.5 Touring E39	09/00-08/04	RR
BMW	528i 2.8 E12	01/80-12/81	FR DS
BMW	528i 2.8 E12	01/80-12/81	FR DS
BMW	528i 2.8 E12	01/80-12/81	FR PS
BMW	528i 2.8 E12	01/80-12/81	FR PS
BMW	528i 2.8 E12	01/80-12/81	FR DS
BMW	528i 2.8 E28	10/81-11/87	FR DS
BMW	528i 2.8 E28	10/81-11/87	FR DS
BMW	528i 2.8 E28	10/81-11/87	FR PS
BMW	528i 2.8 E28	10/81-11/87	FR PS
BMW	528i 2.8 E28	10/84-11/87	FR PS
BMW	528i 2.8 E28	10/84-11/87	FR DS
BMW	528i 2.8 Touring E39	01/97-09/00	RR
BMW	528i 2.8 Touring E39	01/97-09/00	RR
BMW	528i 2.8 Touring E39	01/97-09/00	RR
BMW	528i 2.8 Touring E39	01/97-09/00	RR
BMW	530d 3.0 Touring E39	09/00-08/04	RR
BMW	530d 3.0 Touring E39	09/00-08/04	RR
BMW	530d 3.0 Touring E39	09/98-09/00	RR
BMW	530d 3.0 Touring E39	09/98-09/00	RR
BMW	530i 3.0 Touring E39	09/00-08/04	RR
BMW	530i 3.0 Touring E39	09/00-08/04	RR
BMW	530i 3.0 Touring E39	09/00-08/04	RR
BMW	530i 3.0 Touring E39	09/00-08/04	RR
BMW	535i 3.4 E28	01/85-11/87	FR PS
BMW	535i 3.4 E28	01/85-11/87	FR DS
BMW	535i 3.4 E28	01/85-11/87	FR DS
BMW	535i 3.4 E28	01/85-11/87	FR PS
BMW	540i 4.4 Touring E39	09/97-08/04	RR
BMW	540i 4.4 Touring E39	09/97-08/04	RR
BMW	540i 4.4 Touring E39	09/97-08/04	RR
BMW	540i 4.4 Touring E39	09/97-08/04	RR
BMW	540i 4.4 Touring E39	09/97-08/04	RR
BMW	628CSi 2.8 E24	07/82-05/87	FR DS
BMW	628CSi 2.8 E24	07/82-05/87	FR PS
BMW	628CSi 2.8 E24	09/80-05/87	FR PS
BMW	628CSi 2.8 E24	09/80-05/87	FR PS
BMW	628CSi 2.8 E24	09/80-05/87	FR DS
BMW	628CSi 2.8 E24	09/80-05/87	FR DS
BMW	633CSi 3.2 E24	01/80-12/80	FR PS
BMW	633CSi 3.2 E24	01/80-12/80	FR DS

BMW	633CSi 3.2 E24	01/80-12/80	FR PS
BMW	633CSi 3.2 E24	01/80-12/80	FR DS
BMW	635CSi 3.5 E24	01/80-06/82	FR DS
BMW	635CSi 3.5 E24	01/80-06/82	FR PS
BMW	635CSi 3.5 E24	01/80-06/82	FR PS
BMW	635CSi 3.5 E24	01/80-06/82	FR DS
BMW	728i 2.8 E23	01/80-05/86	FR PS
BMW	728i 2.8 E23	01/80-05/86	FR PS
BMW	728i 2.8 E23	01/80-05/86	FR DS
BMW	728i 2.8 E23	01/80-05/86	FR DS
BMW	728i 2.8 E23	07/82-05/86	FR DS
BMW	728i 2.8 E23	07/82-05/86	FR PS
BMW	732i 3.2 E23	01/80-02/86	FR DS
BMW	732i 3.2 E23	01/80-02/86	FR PS
BMW	732i 3.2 E23	01/80-02/86	FR PS
BMW	732i 3.2 E23	01/80-02/86	FR DS
BMW	732i 3.2 E23	07/82-02/86	FR DS
BMW	732i 3.2 E23	07/82-02/86	FR PS
BMW	735i 3.4 E23	09/82-03/86	FR PS
BMW	735i 3.4 E23	09/82-03/86	FR DS
BMW	735i 3.4 E23	09/82-03/86	FR PS
BMW	735i 3.4 E23	09/82-03/86	FR DS
BMW	735i 3.5 E23	01/80-09/82	FR PS
BMW	735i 3.5 E23	01/80-09/82	FR DS
BMW	735i 3.5 E23	01/80-09/82	FR DS
BMW	735i 3.5 E23	01/80-09/82	FR PS
BMW	M5 3.5 E28	07/86-11/87	FR DS
BMW	M5 3.5 E28	07/86-11/87	FR PS
BMW	M535i 3.4 E28	01/85-11/87	FR PS
BMW	M535i 3.4 E28	01/85-11/87	FR PS
BMW	M535i 3.4 E28	01/85-11/87	FR DS
BMW	M535i 3.4 E28	01/85-11/87	FR DS
BMW	M535i 3.5 E12	01/80-12/81	FR DS
BMW	M535i 3.5 E12	01/80-12/81	FR PS
BMW	M635CSi 3.5 E24	01/85-09/89	FR PS
BMW	M635CSi 3.5 E24	01/85-09/89	FR DS
BMW	X5 3.0 d E53	09/03-12/06	RR
BMW	X5 3.0 d E53	09/03-12/06	RR
BMW	X5 3.0 d E53	09/03-12/06	RR
BMW	X5 3.0 d E53	09/03-12/06	RR
BMW	X5 3.0 d E53	09/03-12/06	RR
BMW	X5 3.0 d E53	09/03-12/06	RR
BMW	X5 3.0 i E53	10/00-08/04	RR
BMW	X5 3.0 i E53	10/00-08/04	RR
BMW	X5 3.0 i E53	10/00-12/06	RR
BMW	X5 3.0 i E53	10/00-12/06	RR
BMW	X5 3.0 i E53	10/00-12/06	RR
BMW	X5 3.0 i E53	10/00-12/06	RR
BMW	X5 3.0d E53	01/02-09/03	RR
BMW	X5 3.0d E53	03/01-09/03	RR

BMW	X5 3.0d E53	03/01-09/03	RR
BMW	X5 3.0d E53	03/01-09/03	RR
BMW	X5 4.4 i E53	03/00-09/03	RR
BMW	X5 4.4 i E53	03/00-09/03	RR
BMW	X5 4.4 i E53	03/00-09/03	RR
BMW	X5 4.4 i E53	03/00-09/03	RR
BMW	X5 4.4 i E53	09/03-05/07	RR
BMW	X5 4.4 i E53	09/03-05/07	RR
BMW	X5 4.4 i E53	09/03-05/07	RR
BMW	X5 4.4 i E53	09/03-05/07	RR
BMW	X5 4.6 i E53	09/01-03/04	RR
BMW	X5 4.6 i E53	09/01-03/04	RR
BMW	X5 4.8 i E53	05/04-09/06	RR
Chevrolet	Cruze 1.4 J300 (2009-2015)	06/12-04/15	FR PS
Chevrolet	Cruze 1.4 J300 (2009-2015)	06/12-04/15	FR PS
Chevrolet	Cruze 1.4 J300 (2009-2015)	11/13-04/15	FR PS
Chevrolet	Cruze 1.4 J300 (2009-2015)	11/13-04/15	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	01/14-04/15	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	01/14-04/15	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	01/14-04/15	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	02/11-05/12	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	02/11-05/12	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	06/11-12/14	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	06/11-12/14	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	07/09-06/11	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	07/09-06/11	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	09/12-12/14	FR PS
Chevrolet	Cruze 1.6 J300 (2009-2015)	09/12-12/14	FR PS
Chevrolet	Cruze 1.7 VCDi 110 J300 (2009-2015)	11/13-04/15	FR PS
Chevrolet	Cruze 1.7 VCDi 110 J300 (2009-2015)	11/13-04/15	FR PS
Chevrolet	Cruze 1.7 VCDi 110 J300 (2009-2015)	11/13-04/15	FR PS
Chevrolet	Cruze 1.7 VCDi 130 J300 (2009-2015)	01/12-04/15	FR PS
Chevrolet	Cruze 1.7 VCDi 130 J300 (2009-2015)	09/12-04/15	FR PS
Chevrolet	Cruze 1.7 VCDi 130 J300 (2009-2015)	11/12-04/15	FR PS
Chevrolet	Cruze 1.8 J300 (2009-2015)	02/11-05/12	FR PS
Chevrolet	Cruze 1.8 J300 (2009-2015)	02/11-05/12	FR PS
Chevrolet	Cruze 1.8 J300 (2009-2015)	06/11-04/15	FR PS
Chevrolet	Cruze 1.8 J300 (2009-2015)	06/11-04/15	FR PS
Chevrolet	Cruze 1.8 J300 (2009-2015)	09/12-04/15	FR PS
Chevrolet	Cruze 1.8 J300 (2009-2015)	09/12-09/14	FR PS
Chevrolet	Cruze 2.0 VCDi 125 J300 (2009-2015)	07/09-06/11	FR PS
Chevrolet	Cruze 2.0 VCDi 150 J300 (2009-2015)	07/09-06/11	FR PS
Chevrolet	Cruze 2.0 VCDi 150 J300 (2009-2015)	07/09-06/11	FR PS
Chevrolet	Cruze 2.0 VCDi 163 J300 (2009-2015)	02/11-04/13	FR PS
Chevrolet	Cruze 2.0 VCDi 163 J300 (2009-2015)	02/11-04/13	FR PS
Chevrolet	Cruze 2.0 VCDi 163 J300 (2009-2015)	06/11-09/14	FR PS
Chevrolet	Cruze 2.0 VCDi 163 J300 (2009-2015)	06/11-09/14	FR PS
Chevrolet	Cruze 2.0 VCDi 163 J300 (2009-2015)	10/12-09/14	FR PS
Chevrolet	Cruze 2.0 VCDi 163 J300 (2009-2015)	10/12-09/14	FR PS
Chrysler	Neon 1.8 (1996-1999)	03/98-10/99	FR PS

Chrysler	Neon 2.0 (1996-1999)	06/96-10/99	FR PS
Chrysler	Neon 2.0 (1996-1999)	06/96-10/99	FR PS
Citroen	C15 1.1 (1985-2006)	01/85-12/94	FR DS
Citroen	C15 1.1 (1985-2006)	01/85-12/94	FR DS
Citroen	C15 1.4 (1985-2006)	12/86-12/89	FR DS
Citroen	C15 1.4 (1985-2006)	12/86-12/89	FR DS
Citroen	C15 1.8 (1985-2006)	01/85-01/01	FR DS
Citroen	C15 1.9 (1985-2006)	01/01-12/06	FR DS
Citroen	C15 1.9 (1985-2006)	01/01-12/06	FR DS
Citroen	C2 1.1 (2003-2010)	09/03-12/10	FR PS
Citroen	C2 1.1 (2003-2010)	09/03-12/10	FR PS
Citroen	C2 1.4 (2003-2010)	07/07-12/10	FR PS
Citroen	C2 1.4 (2003-2010)	09/03-03/06	FR PS
Citroen	C2 1.4 (2003-2010)	09/03-12/10	FR PS
Citroen	C2 1.4 (2003-2010)	12/05-12/09	FR PS
Citroen	C2 1.4 HDi (2003-2010)	09/03-12/10	FR PS
Citroen	C2 1.4 HDi (2003-2010)	09/03-12/10	FR PS
Citroen	C2 1.4 HDi Enterprise (2003-2010)	02/05-03/10	FR PS
Citroen	C2 1.4 HDi Enterprise (2003-2010)	02/05-03/10	FR PS
Citroen	C2 1.6 HDi (2003-2010)	09/07-12/09	FR PS
Citroen	C2 1.6 VTR/GT (2003-2010)	09/03-12/09	FR PS
Citroen	C2 1.6 VTR/GT (2003-2010)	09/03-12/09	FR PS
Citroen	C2 1.6 VTS (2003-2010)	08/04-12/10	FR PS
Citroen	C3 1.1 Mk1 (2002-2010)	01/07-12/10	FR PS
Citroen	C3 1.1 Mk1 (2002-2010)	08/02-12/10	FR PS
Citroen	C3 1.4 HDi Mk1 (2002-2010)	04/02-08/10	FR PS
Citroen	C3 1.4 HDi Mk1 (2002-2010)	04/02-08/10	FR PS
Citroen	C3 1.4 HDi Mk1 (2002-2010)	06/02-10/05	FR PS
Citroen	C3 1.4 Mk1 (2002-2010)	02/04-03/10	FR PS
Citroen	C3 1.4 Mk1 (2002-2010)	04/02-08/10	FR PS
Citroen	C3 1.4 Mk1 (2002-2010)	04/02-08/10	FR PS
Citroen	C3 1.4 Mk1 (2002-2010)	04/02-12/06	FR PS
Citroen	C3 1.4 Mk1 (2002-2010)	04/05-03/09	FR PS
Citroen	C3 1.4 Mk1 (2002-2010)	04/05-03/09	FR PS
Citroen	C3 1.4 Mk1 (2002-2010)	05/04-03/09	FR PS
Citroen	C3 1.6 HDi Mk1 (2002-2010)	11/05-03/10	FR PS
Citroen	C3 1.6 HDi Mk1 (2002-2010)	11/05-10/08	FR PS
Citroen	C3 1.6 Mk1 (2002-2010)	04/02-08/10	FR PS
Citroen	C3 1.6 Mk1 (2002-2010)	12/02-12/08	FR PS
Citroen	C3 1.6 Mk1 (2002-2010)	12/07-08/10	FR PS
Citroen	C3 Pluriel 1.4 (2003-2010)	05/03-12/10	FR PS
Citroen	C3 Pluriel 1.4 (2003-2010)	05/03-12/10	FR PS
Citroen	C3 Pluriel 1.4 HDi (2003-2010)	04/04-12/10	FR PS
Citroen	C3 Pluriel 1.6 (2003-2010)	05/03-03/09	FR PS
Citroen	C3 Pluriel 1.6 (2003-2010)	05/03-12/10	FR PS
Citroen	C3 XTR 1.4 HDi Mk1 (2002-2010)	03/04-06/06	FR PS
Citroen	C3 XTR 1.4 Mk1 (2002-2010)	05/04-04/07	FR PS
Citroen	C3 XTR 1.6 HDi Mk1 (2002-2010)	05/05-04/07	FR PS
Citroen	Saxo 1.0 (1996-1999)	06/97-10/99	FR PS
Citroen	Saxo 1.0 (1999-2004)	10/99-12/00	FR PS

Citroen	Saxo 1.1 (1996-1999)	05/96-10/99	FR PS
Citroen	Saxo 1.1 (1996-1999)	05/96-10/99	FR PS
Citroen	Saxo 1.1 (1996-1999)	05/96-10/99	FR PS
Citroen	Saxo 1.1 (1996-1999)	05/96-10/99	FR PS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR PS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR PS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR PS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR PS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR PS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR PS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR PS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.5 (1996-1999)	10/96-10/99	FR PS
Citroen	Saxo 1.5 (1996-1999)	10/96-10/99	FR PS
Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR PS
Citroen	Saxo 1.6 (1996-1999)	09/96-10/99	FR PS
Citroen	Saxo 1.6 (1996-1999)	09/96-10/99	FR PS
Citroen	Saxo 1.6 (1996-1999)	09/96-10/99	FR PS
Citroen	Saxo 1.6 (1996-1999)	09/96-10/99	FR PS
Citroen	Saxo 1.6 VTR (1999-2004)	09/00-02/04	FR PS
Citroen	Saxo 1.6 VTR (1999-2004)	10/99-09/00	FR PS
Citroen	Saxo 1.6 VTS (1996-1999)	01/97-10/99	FR PS
Citroen	Saxo 1.6 VTS (1999-2004)	10/99-02/04	FR PS
Citroen	Visa 0.7 (1978-1988)	01/80-12/85	FR DS
Citroen	Visa 0.7 (1978-1988)	01/80-12/85	FR DS
Citroen	Visa 1.0 (1978-1988)	09/85-10/87	FR DS
Citroen	Visa 1.1 (1978-1988)	10/80-10/87	FR DS
Citroen	Visa 1.1 (1978-1988)	10/80-10/87	FR DS
Citroen	Visa 1.1 (1978-1988)	10/83-09/85	FR DS
Citroen	Visa 1.2 (1978-1988)	04/81-10/82	FR DS
Citroen	Visa 1.2 (1978-1988)	04/81-10/82	FR DS
Citroen	Visa 1.4 (1978-1988)	09/84-07/86	FR DS
Citroen	Visa 1.4 GT (1978-1988)	07/82-12/85	FR DS
Citroen	Visa 1.6 GTi (1978-1988)	07/85-10/87	FR DS
Citroen	Visa 1.7 (1978-1988)	04/85-12/88	FR DS

Citroen	Xsara 1.6 (1997-2000)	03/98-10/00	RR
Citroen	Xsara 1.6 (1997-2000)	03/98-10/00	RR
Citroen	Xsara 1.6 (1997-2000)	11/97-10/00	RR
Citroen	Xsara 1.6 (1997-2000)	11/97-10/00	RR
Citroen	Xsara 1.6 (2000-2004)	10/00-12/04	RR
Citroen	Xsara 1.6 (2000-2004)	10/00-12/04	RR
Citroen	Xsara 1.6 (2000-2004)	10/00-12/04	RR
Citroen	Xsara 1.8 (1997-2000)	03/98-10/00	RR
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	RR
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	RR
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	RR
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	RR
Citroen	Xsara 1.9 (1997-2000)	10/98-05/01	RR
Citroen	Xsara 1.9 (1997-2000)	10/98-05/01	RR
Citroen	Xsara 1.9 (1997-2000)	10/99-10/00	RR
Citroen	Xsara 1.9 (1997-2000)	10/99-10/00	RR
Citroen	Xsara 1.9 (1997-2000)	11/97-10/99	RR
Citroen	Xsara 1.9 Turbo (1997-2000)	10/98-10/00	RR
Citroen	Xsara 1.9 Turbo (1997-2000)	11/97-07/99	RR
Citroen	Xsara 2.0 (1997-2000)	03/98-10/00	RR
Citroen	Xsara 2.0 (2000-2004)	10/00-04/02	RR
Citroen	Xsara 2.0 (2000-2004)	10/00-12/04	RR
Citroen	Xsara 2.0 HDi (1997-2000)	06/99-10/00	RR
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	RR
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	RR
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	RR
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	RR
Citroen	Xsara 2.0 HDi 90 (2000-2004)	10/00-12/04	RR
Citroen	ZX 1.4 Carburettor (1991-1997)	06/91-12/92	RR
Citroen	ZX 1.4 Carburettor (1991-1997)	06/91-12/92	RR
Citroen	ZX 1.4 Injection (1991-1997)	04/92-12/97	RR
Citroen	ZX 1.4 Injection (1991-1997)	04/92-12/97	RR
Citroen	ZX 1.4 Injection (1991-1997)	04/92-12/97	RR
Citroen	ZX 1.4 Injection (1991-1997)	04/92-12/97	RR
Citroen	ZX 1.4 Injection (1991-1997)	04/92-12/97	RR
Citroen	ZX 1.4 Injection (1991-1997)	04/92-12/97	RR
Citroen	ZX 1.6 (1991-1997)	06/91-07/93	RR
Citroen	ZX 1.6 (1991-1997)	06/91-07/93	RR
Citroen	ZX 1.6 (1991-1997)	06/91-07/93	RR
Citroen	ZX 1.6 (1991-1997)	06/91-07/93	RR
Citroen	ZX 1.8 (1991-1997)	10/92-12/97	RR
Citroen	ZX 1.8 (1991-1997)	10/92-12/97	RR
Citroen	ZX 1.8 (1991-1997)	10/92-12/97	RR
Citroen	ZX 1.9 (1991-1997)	11/91-10/98	RR
Citroen	ZX 1.9 (1991-1997)	11/91-10/98	RR
Citroen	ZX 1.9 (1991-1997)	11/91-10/98	RR
Citroen	ZX 1.9 (1991-1997)	11/91-10/98	RR
Citroen	ZX 1.9 Turbo (1991-1997)	07/92-10/98	RR
Citroen	ZX 1.9 Turbo (1991-1997)	07/92-10/98	RR
Citroen	ZX 1.9 Volcane (1991-1997)	06/91-07/94	RR

Citroen	ZX 2.0 Volcane (1991-1997)	10/92-07/96	RR
Citroen	ZX 2.0 Volcane (1991-1997)	10/92-07/96	RR
Citroen	ZX 2.0 Volcane (1991-1997)	10/92-07/96	RR
Daewoo	Korando 2.3 (1999-2002)	03/99-03/02	FR DS
Daewoo	Korando 2.3 (1999-2002)	03/99-03/02	FR PS
Daewoo	Korando 2.3 (1999-2002)	03/99-03/02	FR PS
Daewoo	Korando 2.3 (1999-2002)	03/99-03/02	FR DS
Daewoo	Korando 2.9 (1999-2002)	03/99-03/02	FR DS
Daewoo	Korando 2.9 (1999-2002)	03/99-03/02	FR PS
Daewoo	Musso 2.3 (1999-2002)	03/99-12/02	FR PS
Daewoo	Musso 2.3 (1999-2002)	03/99-12/02	FR PS
Daewoo	Musso 2.9 (1999-2002)	03/99-12/02	FR PS
Daewoo	Musso 2.9 (1999-2002)	03/99-12/02	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	RR
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	RR
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	RR
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	RR
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	RR
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	RR
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	RR
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Nexia 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Nubira 1.6 (1997-2002)	09/97-12/02	RR
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	RR
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	RR
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	RR
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	RR
Daihatsu	Applause 1.6 Carburettor A101	01/90-12/91	FR DS
Daihatsu	Applause 1.6 Carburettor A101	01/90-12/91	FR PS
Daihatsu	Applause 1.6 Carburettor A101	01/90-12/91	FR PS
Daihatsu	Applause 1.6 Carburettor A101	01/90-12/91	FR DS

Daihatsu	Charade 1.0 (1979-1987)	04/83-12/86	FR PS
Daihatsu	Charade 1.0 (1979-1987)	04/83-12/86	FR PS
Daihatsu	Charade 1.0 (1979-1987)	04/83-12/86	FR PS
Daihatsu	Charade 1.0 (1979-1987)	04/83-12/86	FR DS
Daihatsu	Charade 1.0 (1979-1987)	04/83-12/86	FR DS
Daihatsu	Charade 1.0 (1979-1987)	04/83-12/86	FR DS
Daihatsu	Charade 1.0 (1979-1987)	04/83-12/86	FR PS
Daihatsu	Charade 1.0 (1979-1987)	04/83-12/86	FR DS
Daihatsu	Charade 1.0 (1979-1987)	10/83-02/86	FR PS
Daihatsu	Charade 1.0 (1979-1987)	10/83-02/86	FR DS
Daihatsu	Charade 1.0 (1987-1993)	05/87-07/93	FR PS
Daihatsu	Charade 1.0 (1987-1993)	05/87-07/93	FR DS
Daihatsu	Charade 1.0 (1987-1993)	05/87-07/93	FR DS
Daihatsu	Charade 1.0 (1987-1993)	05/87-07/93	FR PS
Daihatsu	Charade 1.0 (1987-1993)	05/87-07/93	FR DS
Daihatsu	Charade 1.0 (1987-1993)	05/87-07/93	FR DS
Daihatsu	Charade 1.0 (1987-1993)	05/87-07/93	FR PS
Daihatsu	Charade 1.0 (1987-1993)	05/87-07/93	FR PS
Daihatsu	Charade 1.0 Turbo (1979-1987)	03/84-05/87	FR PS
Daihatsu	Charade 1.0 Turbo (1979-1987)	03/84-05/87	FR DS
Daihatsu	Charade 1.0 Turbo (1979-1987)	03/84-05/87	FR DS
Daihatsu	Charade 1.0 Turbo (1979-1987)	03/84-05/87	FR PS
Daihatsu	Charade 1.0 Turbo (1979-1987)	07/85-05/87	FR PS
Daihatsu	Charade 1.0 Turbo (1979-1987)	07/85-05/87	FR DS
Daihatsu	Charade 1.0 Turbo (1987-1993)	05/87-06/89	FR DS
Daihatsu	Charade 1.0 Turbo (1987-1993)	05/87-06/89	FR DS
Daihatsu	Charade 1.0 Turbo (1987-1993)	05/87-06/89	FR PS
Daihatsu	Charade 1.0 Turbo (1987-1993)	05/87-06/89	FR PS
Daihatsu	Charade 1.0 Turbo (1987-1993)	05/87-07/93	FR DS
Daihatsu	Charade 1.0 Turbo (1987-1993)	05/87-07/93	FR DS
Daihatsu	Charade 1.0 Turbo (1987-1993)	05/87-07/93	FR PS
Daihatsu	Charade 1.0 Turbo (1987-1993)	05/87-07/93	FR PS
Daihatsu	Charade 1.3 (1993-2000)	06/93-10/00	FR PS
Daihatsu	Charade 1.3 (1993-2000)	06/93-10/00	FR PS
Daihatsu	Charade 1.3 (1993-2000)	06/93-10/00	FR PS
Daihatsu	Charade 1.3 (1993-2000)	06/93-10/00	FR PS
Daihatsu	Charade 1.3 Carbuettor (1987-1993)	04/89-07/93	FR PS
Daihatsu	Charade 1.3 Carbuettor (1987-1993)	04/89-07/93	FR PS
Daihatsu	Charade 1.3 Carbuettor (1987-1993)	04/89-07/93	FR DS
Daihatsu	Charade 1.3 Carbuettor (1987-1993)	04/89-07/93	FR DS
Daihatsu	Charade 1.3 Injection (1987-1993)	05/91-07/93	FR PS
Daihatsu	Charade 1.3 Injection (1987-1993)	05/91-07/93	FR DS
Daihatsu	Charade 1.3 Injection (1987-1993)	05/91-07/93	FR PS
Daihatsu	Charade 1.3 Injection (1987-1993)	05/91-07/93	FR DS
Daihatsu	Charade 1.5 (1993-2000)	10/94-10/00	FR PS
Daihatsu	Charade 1.5 (1993-2000)	10/94-10/00	FR PS
Daihatsu	Charade 1.6 (1993-2000)	07/93-03/96	FR PS
Daihatsu	Copen 0.7 (2003-2010)	11/03-06/07	FR DS
Daihatsu	Copen 1.3 (2003-2010)	03/07-12/10	FR DS
Daihatsu	Cuore 850 (1997-2003)	06/97-12/98	FR DS

Daihatsu	Cuore 850 (1997-2003)	06/97-12/98	FR DS
Daihatsu	Move 850 (1997-2000)	03/97-10/00	FR DS
Daihatsu	Move 850 (1997-2000)	03/97-10/00	FR DS
Daihatsu	Move 850 (1997-2000)	03/97-10/00	FR DS
Daihatsu	Move 850 (1997-2000)	03/97-10/00	FR DS
Daihatsu	Sirion 1.0 (1998-2005)	06/98-10/00	FR PS
Daihatsu	Sirion 1.0 (1998-2005)	06/98-10/00	FR PS
Daihatsu	Sirion 1.0 (1998-2005)	10/00-03/05	FR PS
Daihatsu	Sirion 1.0 (1998-2005)	10/00-03/05	FR PS
Daihatsu	Sirion 1.3 (1998-2005)	10/00-03/05	FR PS
Daihatsu	Sirion 1.3 (1998-2005)	10/00-03/05	FR PS
Daihatsu	Sirion 1.3 4trak (1998-2005)	06/02-03/05	FR PS
Daihatsu	Sirion 1.3 4trak (1998-2005)	06/02-03/05	FR PS
Daihatsu	Terios 1.5 (2006-2010)	05/06-12/10	FR PS
Daihatsu	Terios 1.5 (2006-2010)	05/06-12/10	FR PS
Fiat	124 1.4 Spider MultiAir 140 (2016-2019)	06/16-12/19	FR DS
Fiat	124 1.4 Spider MultiAir 140 (2016-2019)	12/16-12/19	FR DS
Fiat	128 1.3 (1976-1982)	01/80-12/82	RR
Fiat	128 1.3 (1976-1982)	01/80-12/82	RR
Fiat	Croma 2.0 Carburettor 154 (1986-1993)	07/89-07/92	RR
Fiat	Croma 2.0 Carburettor 154 (1986-1993)	09/86-07/89	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/90	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/90	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/92	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/92	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/89-05/92	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/89-05/92	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	RR
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	RR
Fiat	Croma 2.0 Turbo 154 (1986-1993)	05/86-07/92	RR
Fiat	Croma 2.0 Turbo 154 (1986-1993)	05/86-07/92	RR
Fiat	Doblo 1.2 119 (2001-2004)	06/01-05/04	FR PS
Fiat	Doblo 1.2 119 (2004-2011)	04/04-12/05	FR PS
Fiat	Doblo 1.3 Multijet 119 (2004-2011)	01/06-03/11	FR PS
Fiat	Doblo 1.3 Multijet 119 (2004-2011)	05/04-12/05	FR PS
Fiat	Doblo 1.4 119 (2004-2011)	01/06-03/11	FR PS
Fiat	Doblo 1.9 119 (2001-2004)	06/01-05/04	FR PS
Fiat	Doblo 1.9 JTD 119 (2001-2004)	06/01-05/04	FR PS
Fiat	Doblo 1.9 JTD 119 (2001-2004)	06/01-05/04	FR PS
Fiat	Doblo 1.9 JTD 119 (2004-2011)	01/06-03/11	FR PS
Fiat	Doblo 1.9 JTD 119 (2004-2011)	04/04-03/11	FR PS
Fiat	Doblo 1.9 JTD 119 (2004-2011)	04/04-03/11	FR PS
Fiat	Doblo Cargo 1.2 223 (2001-2004)	02/01-05/04	FR PS
Fiat	Doblo Cargo 1.3 Multijet 223 (2004-2010)	05/04-12/05	FR PS
Fiat	Doblo Cargo 1.3 Multijet 223 (2004-2010)	12/05-10/10	FR PS
Fiat	Doblo Cargo 1.4 223 (2004-2010)	01/06-10/10	FR PS
Fiat	Doblo Cargo 1.9 223 (2001-2004)	02/01-05/04	FR PS
Fiat	Doblo Cargo 1.9 JTD 223 (2001-2004)	06/01-05/04	FR PS

Fiat	Doblo Cargo 1.9 JTD 223 (2004-2010)	04/04-10/10	FR PS
Fiat	Doblo Cargo 1.9 JTD 223 (2004-2010)	04/04-10/10	FR PS
Fiat	Fiorino 1.3 (1988-1992)	07/88-01/92	FR DS
Fiat	Fiorino 1.3 (1992-2001)	01/92-09/95	FR DS
Fiat	Fiorino 1.4 (1992-2001)	09/95-08/01	FR DS
Fiat	Fiorino 1.4 (1992-2001)	09/95-08/01	FR DS
Fiat	Fiorino 1.7 (1988-1992)	11/89-01/92	FR DS
Fiat	Fiorino 1.7 (1988-1992)	11/89-01/92	FR DS
Fiat	Fiorino 1.7 (1992-2001)	01/92-04/94	FR DS
Fiat	Fiorino 1.7 (1992-2001)	01/92-04/94	FR DS
Fiat	Fiorino 1.7 (1992-2001)	04/94-02/97	FR DS
Fiat	Fiorino 1.7 (1992-2001)	04/94-02/97	FR DS
Fiat	Fiorino 1.7 (1992-2001)	10/94-02/97	FR DS
Fiat	Fiorino 1.7 Eco diesel (1992-2001)	02/97-08/98	FR DS
Fiat	Fiorino 1.7 Turbo (1992-2001)	10/97-08/00	FR DS
Fiat	Fiorino 1.7 Turbo (1992-2001)	10/97-08/01	FR DS
Fiat	Fullback 2.4 180 503 (2016-2020)	05/16-04/20	FR PS
Fiat	Fullback 2.4 180 503 (2016-2020)	05/16-04/20	FR PS
Fiat	Punto 1.2 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.2 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.2 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.2 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.2 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.2 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.2 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.2 188 (2001-2004)	01/01-05/04	FR PS
Fiat	Punto 1.2 188 (2003-2007)	08/03-05/05	FR PS
Fiat	Punto 1.2 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.2 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.2 188 (2003-2007)	08/03-07/07	FR PS
Fiat	Punto 1.2 188 (2003-2007)	08/03-07/07	FR PS
Fiat	Punto 1.2 188 (2004-2007)	01/04-12/05	FR PS
Fiat	Punto 1.3 Multijet 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.3 Multijet 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.3 Multijet 188 (2004-2007)	01/04-12/05	FR PS
Fiat	Punto 1.3 Multijet 188 (2004-2007)	01/04-12/05	FR PS
Fiat	Punto 1.4 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.4 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.4 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.8 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.8 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.8 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.9 188 (2001-2004)	01/01-05/04	FR PS
Fiat	Punto 1.9 D 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.9 D 188 (1999-2003)	10/99-08/03	FR PS
Fiat	Punto 1.9 HGT JTD 188 (2003-2007)	08/03-05/06	FR PS
Fiat	Punto 1.9 JTD 188 (1999-2003)	05/02-08/03	FR PS
Fiat	Punto 1.9 JTD 188 (1999-2003)	05/02-08/03	FR PS
Fiat	Punto 1.9 JTD 188 (1999-2003)	10/99-05/02	FR PS
Fiat	Punto 1.9 JTD 188 (1999-2003)	10/99-05/02	FR PS

Fiat	Punto 1.9 JTD 188 (2003-2007)	08/03-10/05	FR PS
Fiat	Punto 1.9 JTD 188 (2003-2007)	08/03-10/05	FR PS
Fiat	Uno 0.9 146 (1983-1995)	05/83-06/85	FR DS
Fiat	Uno 0.9 146 (1983-1995)	05/83-06/85	FR DS
Fiat	Uno 1.0 Carburettor 146 (1983-1995)	06/85-12/92	FR DS
Fiat	Uno 1.0 Carburettor 146 (1983-1995)	06/85-12/92	FR DS
Fiat	Uno 1.0 Carburettor 146 (1983-1995)	06/85-12/92	FR DS
Fiat	Uno 1.0 Carburettor 146 (1983-1995)	06/85-12/92	FR DS
Fiat	Uno 1.0 Carburettor 146 (1983-1995)	06/85-12/92	FR DS
Fiat	Uno 1.0 Carburettor 146 (1983-1995)	06/85-12/92	FR DS
Fiat	Uno 1.0 Carburettor 146 (1983-1995)	06/85-12/92	FR DS
Fiat	Uno 1.0 Carburettor 146 (1983-1995)	06/85-12/92	FR DS
Fiat	Uno 1.0 Injection 146 (1983-1995)	01/93-07/95	FR DS
Fiat	Uno 1.0 Injection 146 (1983-1995)	01/93-07/95	FR DS
Fiat	Uno 1.1 146 (1983-1995)	05/83-08/85	FR DS
Fiat	Uno 1.1 146 (1983-1995)	05/83-08/85	FR DS
Fiat	Uno 1.1 146 (1983-1995)	08/85-01/90	FR DS
Fiat	Uno 1.1 146 (1983-1995)	08/85-01/90	FR DS
Fiat	Uno 1.1 Carburettor 146 (1983-1995)	01/90-07/92	FR DS
Fiat	Uno 1.1 Carburettor 146 (1983-1995)	01/90-07/92	FR DS
Fiat	Uno 1.1 Injection 146 (1983-1995)	07/92-07/94	FR DS
Fiat	Uno 1.1 Injection 146 (1983-1995)	07/92-07/94	FR DS
Fiat	Uno 1.3 Turbo 146 (1983-1995)	02/88-01/90	FR DS
Fiat	Uno 1.3 Turbo 146 (1983-1995)	07/85-02/88	FR DS
Fiat	Uno 1.4 146 (1983-1995)	01/90-12/94	FR DS
Fiat	Uno 1.4 146 (1983-1995)	01/90-12/94	FR DS
Fiat	Uno 1.4 146 (1983-1995)	01/90-12/94	FR DS
Fiat	Uno 1.4 Turbo 146 (1983-1995)	01/90-12/94	FR DS
Fiat	Uno 1.7 146 (1983-1995)	06/87-12/94	FR DS
Fiat	Uno 1.7 146 (1983-1995)	06/87-12/94	FR DS
Ford	Cortina 1.6 Ghia MK 5	01/80-12/82	FR DS
Ford	Cortina 1.6 Ghia MK 5	01/80-12/82	FR PS
Ford	Cortina 1.6 Ghia MK 5	01/80-12/82	FR PS
Ford	Cortina 1.6 Ghia MK 5	01/80-12/82	FR DS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR DS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR PS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR PS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR DS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR DS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR DS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR DS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR PS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR PS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR DS
Ford	Cortina 1.6 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.0 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.0 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.0 MK 5	01/80-12/82	FR DS
Ford	Cortina 2.0 MK 5	01/80-12/82	FR DS
Ford	Cortina 2.0 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.0 MK 5	01/80-12/82	FR DS

Ford	Cortina 2.0 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.0 MK 5	01/80-12/82	FR DS
Ford	Cortina 2.3 MK 5	01/80-12/82	FR DS
Ford	Cortina 2.3 MK 5	01/80-12/82	FR DS
Ford	Cortina 2.3 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.3 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.3 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.3 MK 5	01/80-12/82	FR PS
Ford	Cortina 2.3 MK 5	01/80-12/82	FR DS
Ford	Cortina 2.3 MK 5	01/80-12/82	FR DS
Ford	Escort 1.1 MK 3 (1980-1986)	01/83-02/86	RR
Ford	Escort 1.1 MK 3 (1980-1986)	01/83-02/86	FR PS
Ford	Escort 1.1 MK 3 (1980-1986)	01/83-02/86	FR PS
Ford	Escort 1.1 MK 3 (1980-1986)	01/83-02/86	RR
Ford	Escort 1.1 MK 3 (1980-1986)	01/83-02/86	FR DS
Ford	Escort 1.1 MK 3 (1980-1986)	01/83-02/86	FR DS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	RR
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR DS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR PS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR DS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR PS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR DS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	RR
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR PS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR DS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	RR
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	RR
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	RR
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR PS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR PS
Ford	Escort 1.1 MK 3 (1980-1986)	09/80-02/86	FR DS
Ford	Escort 1.1 MK 4 (1986-1991)	02/86-01/91	FR DS
Ford	Escort 1.1 MK 4 (1986-1991)	02/86-01/91	RR
Ford	Escort 1.1 MK 4 (1986-1991)	02/86-01/91	FR PS
Ford	Escort 1.1 MK 4 (1986-1991)	02/86-09/88	FR PS
Ford	Escort 1.1 MK 4 (1986-1991)	02/86-09/88	FR DS
Ford	Escort 1.3 MK 3 (1980-1986)	01/83-02/86	RR
Ford	Escort 1.3 MK 3 (1980-1986)	01/83-02/86	FR PS
Ford	Escort 1.3 MK 3 (1980-1986)	01/83-02/86	RR
Ford	Escort 1.3 MK 3 (1980-1986)	01/83-02/86	FR DS
Ford	Escort 1.3 MK 3 (1980-1986)	01/83-02/86	FR DS
Ford	Escort 1.3 MK 3 (1980-1986)	01/83-02/86	FR PS
Ford	Escort 1.3 MK 3 (1980-1986)	02/82-02/86	RR
Ford	Escort 1.3 MK 3 (1980-1986)	02/82-02/86	RR
Ford	Escort 1.3 MK 3 (1980-1986)	02/82-02/86	FR DS
Ford	Escort 1.3 MK 3 (1980-1986)	02/82-02/86	FR DS
Ford	Escort 1.3 MK 3 (1980-1986)	02/82-02/86	FR PS

Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	FR PS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	FR PS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	FR PS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	RR
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	FR PS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	FR DS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	FR DS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	FR DS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-07/83	RR
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-12/84	FR PS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-12/84	FR PS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-12/84	RR
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-12/84	FR DS
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-12/84	RR
Ford	Escort 1.6 MK 3 (1980-1986)	09/80-12/84	FR DS
Ford	Escort 1.6 MK 4 (1986-1991)	02/86-10/90	FR DS
Ford	Escort 1.6 MK 4 (1986-1991)	02/86-10/90	FR PS
Ford	Escort 1.6 MK 4 (1986-1991)	07/89-10/90	FR PS
Ford	Escort 1.6 MK 4 (1986-1991)	07/89-10/90	FR DS
Ford	Escort 1.6 RS Turbo MK 3 (1980-1986)	02/85-07/86	FR PS
Ford	Escort 1.6 RS Turbo MK 3 (1980-1986)	02/85-07/86	FR DS
Ford	Escort 1.6 RS Turbo MK 3 (1980-1986)	02/85-07/86	RR
Ford	Escort 1.6 RS Turbo MK 4 (1986-1991)	07/86-07/91	FR PS
Ford	Escort 1.6 RS Turbo MK 4 (1986-1991)	07/86-07/91	RR
Ford	Escort 1.6 RS Turbo MK 4 (1986-1991)	07/86-07/91	FR DS
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	02/82-01/83	RR
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	02/82-01/83	FR DS
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	02/82-01/83	FR PS
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	08/82-01/83	RR
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	08/82-01/83	FR PS
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	08/82-01/83	FR DS
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	09/80-01/83	FR PS
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	09/80-01/83	FR DS
Ford	Escort 1.6 XR3 MK 3 (1980-1986)	09/80-01/83	RR
Ford	Escort 1.6 XR3i MK 3 (1980-1986)	01/83-02/86	FR DS
Ford	Escort 1.6 XR3i MK 3 (1980-1986)	01/83-02/86	FR DS
Ford	Escort 1.6 XR3i MK 3 (1980-1986)	01/83-02/86	FR PS
Ford	Escort 1.6 XR3i MK 3 (1980-1986)	01/83-02/86	FR PS
Ford	Escort 1.6 XR3i MK 3 (1980-1986)	01/83-02/86	RR
Ford	Escort 1.6 XR3i MK 3 (1980-1986)	01/83-02/86	RR
Ford	Escort RS 1600i MK 3 (1980-1986)	11/82-09/83	FR DS
Ford	Escort RS 1600i MK 3 (1980-1986)	11/82-09/83	RR
Ford	Escort RS 1600i MK 3 (1980-1986)	11/82-09/83	FR PS
Ford	Granada 2.0 MK 2 (1977-1985)	01/80-02/85	FR PS
Ford	Granada 2.0 MK 2 (1977-1985)	01/80-02/85	FR DS
Ford	Granada 2.0 MK 2 (1977-1985)	01/80-02/85	FR PS
Ford	Granada 2.0 MK 2 (1977-1985)	01/80-02/85	FR PS
Ford	Granada 2.0 MK 2 (1977-1985)	01/80-02/85	FR DS
Ford	Granada 2.0 MK 2 (1977-1985)	01/80-02/85	FR PS
Ford	Granada 2.0 MK 2 (1977-1985)	01/80-02/85	FR DS

Ford	Orion 1.6 Injection MK 1 (1983-1986)	09/83-02/86	FR PS
Ford	Orion 1.6 Injection MK 1 (1983-1986)	09/83-02/86	FR PS
Ford	Orion 1.6 Injection MK 1 (1983-1986)	09/83-02/86	FR DS
Ford	Orion 1.6 Injection MK 2 (1986-1990)	02/86-10/90	FR PS
Ford	Orion 1.6 Injection MK 2 (1986-1990)	02/86-10/90	FR DS
Ford	Orion 1.6 Injection MK 2 (1986-1990)	02/86-10/90	FR PS
Ford	Orion 1.6 Injection MK 2 (1986-1990)	02/86-10/90	FR DS
Ford	Orion 1.6 Injection MK 2 (1986-1990)	05/89-10/90	FR PS
Ford	Orion 1.6 Injection MK 2 (1986-1990)	05/89-10/90	FR DS
Ford	Orion 1.6 Injection MK 2 (1986-1990)	05/89-10/90	FR DS
Ford	Orion 1.6 Injection MK 2 (1986-1990)	05/89-10/90	FR PS
Ford	Orion 1.6 MK 1 (1983-1986)	04/84-02/86	FR PS
Ford	Orion 1.6 MK 1 (1983-1986)	04/84-02/86	FR DS
Ford	Orion 1.6 MK 2 (1986-1990)	02/86-09/88	FR PS
Ford	Orion 1.6 MK 2 (1986-1990)	02/86-09/88	FR DS
Ford	Orion 1.8 MK 2 (1986-1990)	09/88-10/90	FR DS
Ford	Orion 1.8 MK 2 (1986-1990)	09/88-10/90	FR PS
Ford	Orion 1.8 MK 2 (1986-1990)	09/88-10/90	FR DS
Ford	Orion 1.8 MK 2 (1986-1990)	09/88-10/90	FR PS
Ford	Ranger 2.5 (1999-2006)	03/02-11/06	FR PS
Ford	Ranger 2.5 (1999-2006)	03/02-11/06	FR DS
Ford	Ranger 2.5 (1999-2006)	05/99-03/02	FR PS
Ford	Ranger 2.5 (1999-2006)	05/99-03/02	FR DS
Ford	Ranger 2.5 Dual Cab (1999-2006)	03/02-11/06	FR DS
Ford	Ranger 2.5 Dual Cab (1999-2006)	03/02-11/06	FR PS
Ford	Ranger 2.5 Dual Cab (1999-2006)	05/99-03/02	FR PS
Ford	Ranger 2.5 Dual Cab (1999-2006)	05/99-03/02	FR DS
Ford	Ranger 2.5 Dual Cab Turbo (1999-2006)	05/99-11/06	FR PS
Ford	Ranger 2.5 Dual Cab Turbo (1999-2006)	05/99-11/06	FR DS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/10	FR DS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/10	FR PS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/12	FR DS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/12	FR PS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/12	FR PS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/12	FR DS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/12	FR DS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/12	FR PS
Ford	Ranger 2.5 TDCi (2006-2012)	07/06-03/12	FR DS
Ford	Ranger 2.5 TDCi (2006-2012) Dual Cab	01/09-03/12	FR DS
Ford	Ranger 2.5 TDCi (2006-2012) Dual Cab	01/09-03/12	FR PS
Ford	Ranger 2.5 TDCi (2006-2012) Dual Cab	07/06-03/12	FR PS
Ford	Ranger 2.5 TDCi (2006-2012) Dual Cab	07/06-03/12	FR PS
Ford	Ranger 2.5 TDCi (2006-2012) Dual Cab	07/06-03/12	FR DS
Ford	Ranger 2.5 TDCi (2006-2012) Dual Cab	07/06-03/12	FR DS
Ford	Ranger 2.5 TDCi (2006-2012) Dual Cab	07/06-03/12	FR PS
Ford	Ranger 2.5 TDCi (2006-2012) Dual Cab	07/06-03/12	FR DS
Ford	Ranger 2.5 Turbo (1999-2006)	05/99-11/06	FR DS
Ford	Ranger 2.5 Turbo (1999-2006)	05/99-11/06	FR PS
Ford	Ranger 3.0 TDCi Dual Cab (2006-2012)	07/07-03/12	FR PS

Honda	Civic 1.6 VTi MK 6 (1995-2001)	01/99-03/01	FR PS
Honda	Civic 1.8 Aerodeck VTi MK 6 (1995-2001)	02/98-03/01	FR PS
Honda	Civic 1.8 I-VTEC MK 9 (2012-2017)	12/13-12/17	FR PS
Honda	Civic 1.8 I-VTEC MK 9 (2012-2017)	12/13-12/17	FR PS
Honda	Civic 1.8 VTi MK 6 (1995-2001)	05/97-03/01	FR PS
Honda	Civic 2.0 Turbo intercooled MK 6 (1995-2001)	07/98-05/99	FR PS
Honda	Civic 2.0 Turbo intercooled MK 6 (1995-2001)	07/98-05/99	FR PS
Honda	Civic 2.0 Turbo MK 6 (1995-2001)	05/97-07/98	FR PS
Honda	Civic 2.0 Type-R MK 10 (2017-2023)	06/17-04/22	FR PS
Honda	Civic CRX 1.5 (1984-1992)	02/84-04/86	FR DS
Honda	Civic CRX 1.5 (1984-1992)	02/84-04/86	FR PS
Honda	Civic CRX 1.6 (1984-1992)	04/86-08/87	FR PS
Honda	Civic CRX 1.6 (1984-1992)	04/86-08/87	FR DS
Honda	Civic CRX 1.6 ESi (1992-1997)	02/96-02/98	FR PS
Honda	Civic CRX 1.6 ESi (1992-1997)	02/96-02/98	FR PS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR PS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR PS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR PS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR PS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR PS
Honda	Civic CRX 1.6 VTi (1992-1997)	06/92-02/95	FR PS
Honda	Civic Shuttle 1.4 (1988-1991)	04/88-01/91	FR PS
Honda	Civic Shuttle 1.4 (1988-1991)	04/88-01/91	FR PS
Honda	Civic Shuttle 1.5 (1984-1988)	02/84-03/88	FR DS
Honda	Civic Shuttle 1.5 (1984-1988)	02/84-03/88	FR PS
Honda	Civic Shuttle 1.5 (1984-1988)	02/84-03/88	FR PS
Honda	Civic Shuttle 1.5 (1984-1988)	02/84-03/88	FR PS
Honda	Civic Shuttle 1.5 (1984-1988)	02/84-03/88	FR PS
Honda	Civic Shuttle 1.5 (1984-1988)	02/84-03/88	FR DS
Honda	Civic Shuttle 1.5 (1984-1988)	02/84-03/88	FR DS
Honda	Civic Shuttle 1.5 (1984-1988)	02/84-03/88	FR DS
Honda	Civic Shuttle 1.5 (1984-1988)	03/85-04/88	FR PS
Honda	Civic Shuttle 1.5 (1984-1988)	03/85-04/88	FR DS
Honda	Civic Shuttle 1.5 (1984-1988)	03/85-04/88	FR DS
Honda	Civic Shuttle 1.5 (1984-1988)	03/85-04/88	FR PS
Honda	Civic Shuttle 1.6 (1988-1991)	04/88-01/90	FR PS
Honda	Civic Shuttle 1.6 (1988-1991)	04/88-01/90	FR PS
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	RR
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	RR
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	RR
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	FR PS
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	FR PS
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	FR PS
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	RR
Honda	Concerto 1.4 (1989-1994)	10/89-12/91	FR PS
Honda	Concerto 1.5 (1989-1994)	01/92-12/94	FR DS
Honda	Concerto 1.5 (1989-1994)	01/92-12/94	FR PS

Honda	Concerto 1.6 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	RR
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	FR PS
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	RR
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	FR PS
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	RR
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	FR PS
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	RR
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.6 (1989-1994)	10/89-12/91	FR DS
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	FR PS
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	FR PS
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	FR DS
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	RR
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	FR DS
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	RR
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	RR
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	FR PS
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	FR DS
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	FR DS
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	RR
Honda	Concerto 1.6 (1989-1994)	10/91-12/94	FR PS
Honda	Insight 1.0 IMA Hybrid (2000-2005)	03/00-12/05	FR PS
Honda	Prelude 2.0 (1983-1992)	10/87-07/92	FR PS
Honda	Prelude 2.0 (1983-1992)	10/87-07/92	FR PS
Honda	Prelude 2.0 4WS (1983-1992)	10/87-07/92	FR PS
Honda	Prelude 2.0 4WS (1983-1992)	10/87-07/92	FR PS
Honda	Prelude 2.0 Injection (1983-1992)	11/85-07/87	FR PS
Hyundai	Accent 1.3 (1994-2000)	01/00-12/00	FR PS
Hyundai	Accent 1.3 (1994-2000)	01/00-12/00	FR PS
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	FR PS
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	FR PS
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	FR PS
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	FR PS
Hyundai	Accent 1.3 (1994-2000)	10/94-03/97	FR PS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR PS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR PS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR PS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR PS
Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	FR PS
Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	FR PS
Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	FR PS
Hyundai	Accent 1.3 (2003-2006)	02/03-12/06	FR PS
Hyundai	Accent 1.3 (2003-2006)	02/03-12/06	FR PS
Hyundai	Accent 1.3 (2003-2006)	02/03-12/06	FR PS
Hyundai	Accent 1.4 (2006-2010)	07/06-03/10	FR PS
Hyundai	Accent 1.4 (2006-2010)	07/06-03/10	FR PS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR PS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR PS

Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR PS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR PS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR PS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR PS
Hyundai	Accent 1.5 (1994-2000)	10/94-03/97	FR PS
Hyundai	Accent 1.5 (1994-2000)	10/94-03/97	FR PS
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	FR PS
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	FR PS
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	FR PS
Hyundai	Accent 1.5 (1994-2000)	10/98-01/99	FR PS
Hyundai	Accent 1.5 (2000-2003)	01/00-03/03	FR PS
Hyundai	Accent 1.5 (2000-2003)	01/00-03/03	FR PS
Hyundai	Accent 1.5 (2000-2003)	01/00-03/03	FR PS
Hyundai	Accent 1.5 (2000-2003)	07/02-03/03	FR PS
Hyundai	Accent 1.5 (2003-2006)	02/03-11/05	FR PS
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	FR PS
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	FR PS
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	FR PS
Hyundai	Accent 1.5 MVi (2000-2003)	06/00-03/03	FR PS
Hyundai	Accent 1.6 (2003-2006)	02/03-03/04	FR PS
Hyundai	Accent 1.6 (2003-2006)	02/03-12/06	FR PS
Hyundai	Accent 1.6 (2003-2006)	02/03-12/06	FR PS
Hyundai	Coupe 1.6 (1996-2002)	01/00-05/01	FR PS
Hyundai	Coupe 1.6 (1996-2002)	01/00-05/01	FR PS
Hyundai	Coupe 1.6 (1996-2002)	01/00-12/01	FR PS
Hyundai	Coupe 1.6 (1996-2002)	01/00-12/01	FR PS
Hyundai	Coupe 1.6 (1996-2002)	06/97-01/00	FR PS
Hyundai	Coupe 1.6 (1996-2002)	06/97-01/00	FR PS
Hyundai	Coupe 1.6 (1996-2002)	06/97-01/00	FR PS
Hyundai	Coupe 1.6 (1996-2002)	06/97-01/00	FR PS
Hyundai	Coupe 1.6 (2002-2005)	01/02-02/05	FR PS
Hyundai	Coupe 1.6 (2005-2007)	01/05-03/07	FR PS
Hyundai	Coupe 1.6 SIII (2007-2009)	01/07-12/09	FR PS
Hyundai	Coupe 2.0 (1996-2002)	01/00-12/01	FR PS
Hyundai	Coupe 2.0 (1996-2002)	01/00-12/01	FR PS
Hyundai	Coupe 2.0 (1996-2002)	01/00-12/01	FR PS
Hyundai	Coupe 2.0 (1996-2002)	01/00-12/01	FR PS
Hyundai	Coupe 2.0 (1996-2002)	09/96-01/00	FR PS
Hyundai	Coupe 2.0 (1996-2002)	09/96-01/00	FR PS
Hyundai	Coupe 2.0 (2002-2005)	01/02-02/05	FR PS
Hyundai	Coupe 2.0 (2002-2005)	01/02-02/05	FR PS
Hyundai	Coupe 2.0 (2005-2007)	01/05-03/07	FR PS
Hyundai	Coupe 2.0 (2005-2007)	01/05-03/07	FR PS
Hyundai	Coupe 2.0 F2 Evolution (1996-2002)	05/99-12/01	FR PS
Hyundai	Coupe 2.0 F2 Evolution (1996-2002)	05/99-12/01	FR PS
Hyundai	Coupe 2.7 (2002-2005)	01/02-02/05	FR PS
Hyundai	Coupe 2.7 (2002-2005)	01/02-02/05	FR PS
Hyundai	Coupe 2.7 (2005-2007)	01/05-03/07	FR PS
Hyundai	Coupe 2.7 (2005-2007)	01/05-03/07	FR PS
Hyundai	Elantra 1.6 (2001-2006)	03/01-05/04	FR PS

Hyundai	Elantra 1.6 (2001-2006)	03/01-05/04	FR PS
Hyundai	Elantra 1.6 (2001-2006)	03/01-06/04	FR PS
Hyundai	Elantra 1.6 (2001-2006)	03/01-06/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	02/02-12/06	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-05/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-05/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-05/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-05/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR PS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR PS
Hyundai	Lantra 1.6 (1995-1998)	11/95-06/98	FR PS
Hyundai	Lantra 1.6 (1995-1998)	11/95-06/98	FR PS
Hyundai	Lantra 1.6 (1995-1998)	11/95-06/98	FR PS
Hyundai	Lantra 1.6 (1995-1998)	11/95-06/98	FR PS
Hyundai	Lantra 1.8 (1995-1998)	11/95-02/97	FR PS
Hyundai	Lantra 1.8 (1995-1998)	11/95-02/97	FR PS
Hyundai	Lantra 1.8 (1995-1998)	11/95-02/97	FR PS
Hyundai	Lantra 1.8 (1995-1998)	11/95-02/97	FR PS
Hyundai	Lantra 2.0 (1995-1998)	02/97-06/98	FR PS
Hyundai	Lantra 2.0 (1995-1998)	02/97-06/98	FR PS
Hyundai	Lantra 2.0 (1995-1998)	11/95-06/98	FR PS
Hyundai	Lantra 2.0 (1995-1998)	11/95-06/98	FR PS
Hyundai	Lantra 2.0 (1998-2001)	06/98-03/01	FR PS
Hyundai	Lantra 2.0 (1998-2001)	06/98-03/01	FR PS
Hyundai	Lantra 2.0 (1998-2001)	06/98-03/01	FR PS
Hyundai	Lantra 2.0 (1998-2001)	06/98-03/01	FR PS
Hyundai	Pony X2 1.3 (1990-1994)	10/92-12/94	FR DS
Hyundai	Pony X2 1.3 (1990-1994)	10/92-12/94	FR PS
Hyundai	Pony X2 1.3 (1990-1994)	10/92-12/94	FR DS
Hyundai	Pony X2 1.3 (1990-1994)	10/92-12/94	FR DS
Hyundai	Pony X2 1.3 (1990-1994)	10/92-12/94	FR DS
Hyundai	Pony X2 1.3 (1990-1994)	10/92-12/94	FR DS
Hyundai	Pony X2 1.3 (1990-1994)	10/92-12/94	FR DS
Hyundai	Pony X2 1.3 (1990-1994)	10/92-12/94	FR PS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/93	FR PS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/93	FR PS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/93	FR PS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/93	FR DS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/93	FR PS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/93	FR DS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/93	FR DS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/93	FR DS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/94	FR DS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/94	FR DS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/94	FR DS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/94	FR DS
Hyundai	Pony X2 1.5 (1990-1994)	09/90-12/94	FR DS
Hyundai	S Coupe 1.5 MVi (1990-1996)	10/92-10/95	FR PS
Hyundai	S Coupe 1.5 MVTi (1990-1996)	10/92-03/95	FR PS

Hyundai	Santa Fe 2.2 CM (2006-2010)	04/06-08/06	FR PS
Hyundai	Santa Fe 2.2 CM (2006-2010)	04/06-08/06	FR PS
Hyundai	Santa Fe 2.2 CM (2006-2010)	08/06-12/10	FR PS
Hyundai	Santa Fe 2.2 CM (2006-2010)	08/06-12/10	FR PS
Hyundai	Santa Fe 2.2 CM (2010-2013)	01/10-05/13	FR PS
Hyundai	Santa Fe 2.2 CM (2010-2013)	01/10-05/13	FR PS
Hyundai	Santa Fe 2.7 CM (2006-2010)	04/06-12/09	FR PS
Hyundai	Veloster 1.6 GDi 140 (2011-2015)	11/11-09/15	FR PS
Hyundai	Veloster 1.6 GDi 140 (2011-2015)	11/11-09/15	FR PS
Hyundai	Veloster 1.6 Turbo (2011-2015)	08/12-09/15	FR PS
Infiniti	FX30 3.0 d (2009-2014)	06/10-05/14	FR PS
Infiniti	FX37 3.7 (2009-2014)	04/09-05/14	FR PS
Infiniti	FX50 5.0 (2009-2014)	04/09-05/14	FR PS
Infiniti	FX50 5.0 Vettel Edition (2009-2014)	04/12-08/13	FR PS
Jeep	Cherokee 2.0 (2014-2019)	04/14-04/16	FR PS
Jeep	Cherokee 2.0 (2014-2019)	04/14-04/18	FR PS
Jeep	Cherokee 2.0 (2014-2019)	04/14-04/18	FR PS
Jeep	Cherokee 2.2 (2014-2019)	06/15-04/19	FR PS
Jeep	Cherokee 2.2 (2014-2019)	06/15-04/19	FR PS
Jeep	Cherokee 2.5 (1993-2001)	03/95-01/01	FR PS
Jeep	Cherokee 2.5 (1993-2001)	03/95-01/01	FR PS
Jeep	Cherokee 2.5 (1993-2001)	03/95-01/01	FR PS
Jeep	Cherokee 2.5 (1993-2001)	03/95-01/01	FR DS
Jeep	Cherokee 2.5 (1993-2001)	03/95-01/01	FR DS
Jeep	Cherokee 2.5 (1993-2001)	03/95-01/01	FR DS
Jeep	Cherokee 2.5 (1993-2001)	04/97-10/99	FR DS
Jeep	Cherokee 2.5 (1993-2001)	04/97-10/99	FR PS
Jeep	Cherokee 2.5 (1993-2001)	10/99-01/01	FR DS
Jeep	Cherokee 2.5 (1993-2001)	10/99-01/01	FR PS
Jeep	Cherokee 4.0 (1993-2001)	04/97-09/00	FR DS
Jeep	Cherokee 4.0 (1993-2001)	04/97-09/00	FR PS
Jeep	Commander 3.0 CRD (2006-2010)	03/06-12/10	FR DS
Jeep	Commander 3.0 CRD (2006-2010)	03/06-12/10	FR PS
Jeep	Commander 5.7 Hemi (2006-2010)	03/06-10/07	FR DS
Jeep	Commander 5.7 Hemi (2006-2010)	03/06-10/07	FR PS
Jeep	Compass 1.4 MultiAir II (2017-)	07/18-04/21	FR PS
Jeep	Compass 1.4 MultiAir II (2017-)	11/17-12/22	FR PS
Jeep	Compass 1.6 MultiJet II (2017-)	11/17-12/21	FR PS
Jeep	Compass 2.0 MultiJet II (2017-)	11/17-04/21	FR PS
Kia	Optima 1.6 CRDi ISG (2016-2020)	07/18-04/20	FR PS
Kia	Optima 1.6 CRDi ISG (2016-2020)	07/18-04/20	FR PS
Kia	Optima 1.6 CRDi ISG (2016-2020)	07/18-12/20	FR PS
Kia	Optima 1.6 CRDi ISG (2016-2020)	07/18-12/20	FR PS
Kia	Optima 1.7 CRDi (2011-2016)	12/11-08/16	FR PS
Kia	Optima 1.7 CRDi (2011-2016)	12/11-08/16	FR PS
Kia	Optima 1.7 CRDi ISG 139 (2016-2020)	01/16-12/18	FR PS
Kia	Optima 1.7 CRDi ISG 139 (2016-2020)	01/16-12/18	FR PS
Kia	Optima 1.7 CRDi ISG 139 (2016-2020)	06/16-12/18	FR PS
Kia	Optima 1.7 CRDi ISG 139 (2016-2020)	06/16-12/18	FR PS
Kia	Optima 2.0 GDi PHEV (2016-2020)	06/16-04/18	FR PS

Kia	Optima 2.0 GDi PHEV (2016-2020)	07/17-04/20	FR PS
Kia	Optima 2.0 T-GDI (2016-2020)	07/18-12/20	FR PS
Kia	Pride 1.1 (1991-2000)	06/91-09/94	FR PS
Kia	Pride 1.1 (1991-2000)	06/91-09/94	FR DS
Kia	Pride 1.3 (1991-2000)	03/92-12/94	FR PS
Kia	Pride 1.3 (1991-2000)	03/92-12/94	FR DS
Kia	Pride 1.3 (1991-2000)	06/91-11/94	FR PS
Kia	Pride 1.3 (1991-2000)	06/91-11/94	FR PS
Kia	Pride 1.3 (1991-2000)	06/91-11/94	FR DS
Kia	Pride 1.3 (1991-2000)	06/91-11/94	FR DS
Kia	Pride 1.3 (1991-2000)	06/99-07/00	FR DS
Kia	Pride 1.3 (1991-2000)	06/99-07/00	FR PS
Kia	Pride 1.3 (1991-2000)	06/99-07/00	FR PS
Kia	Pride 1.3 (1991-2000)	06/99-07/00	FR DS
Kia	Pride 1.3 (1991-2000)	11/94-06/99	FR PS
Kia	Pride 1.3 (1991-2000)	11/94-06/99	FR PS
Kia	Pride 1.3 (1991-2000)	11/94-06/99	FR DS
Kia	Pride 1.3 (1991-2000)	11/94-06/99	FR DS
Kia	Pride 1.3 Injection (1991-2000)	12/94-12/98	FR PS
Kia	Pride 1.3 Injection (1991-2000)	12/94-12/98	FR DS
Kia	Rio 1.3 DC (2001-2005)	07/01-07/05	FR PS
Kia	Rio 1.3 DC (2001-2005)	07/01-07/05	FR PS
Kia	Rio 1.5 DC (2001-2005)	07/01-03/04	FR PS
Kia	Rio 1.5 DC (2001-2005)	07/01-03/04	FR PS
Kia	Sedona 2.5 (1999-2006)	09/99-12/01	RR
Kia	Sedona 2.5 (1999-2006)	09/99-12/01	RR
Kia	Sedona 2.5 (1999-2006)	09/99-12/01	RR
Kia	Sedona 2.5 (1999-2006)	09/99-12/01	RR
Kia	Sedona 2.5 (1999-2006)	10/01-10/06	RR
Kia	Sedona 2.5 (1999-2006)	10/01-10/06	RR
Kia	Sedona 2.9 CRD (1999-2006)	10/01-10/06	RR
Kia	Sedona 2.9 CRD (1999-2006)	10/01-10/06	RR
Kia	Sedona 2.9 CRD (1999-2006)	10/01-10/06	RR
Kia	Sedona 2.9 CRD (1999-2006)	10/01-10/06	RR
Kia	Sedona 2.9 CRD (1999-2006)	10/01-10/06	RR
Kia	Sedona 2.9 CRD (1999-2006)	10/01-10/06	RR
Kia	Sedona 2.9 TD (1999-2006)	09/99-12/01	RR
Kia	Sedona 2.9 TD (1999-2006)	09/99-12/01	RR
Kia	Shuma 1.5 (1999-2002)	06/99-02/01	RR
Kia	Shuma 1.5 (1999-2002)	06/99-02/01	RR
Kia	Shuma 1.6 MK 2 (2002-2004)	03/02-03/02	RR
Kia	Shuma 1.6 MK 2 (2002-2004)	03/02-03/02	RR
Kia	Shuma 1.8 (1999-2002)	06/99-02/01	RR
Kia	Shuma 1.8 (1999-2002)	06/99-02/01	RR
Kia	Sorento 2.5 (2002-2006)	12/02-10/06	FR PS
Kia	Sorento 2.5 (2002-2006)	12/02-10/06	FR PS
Kia	Sorento 2.5 (2002-2006)	12/04-10/06	FR PS
Kia	Sorento 2.5 (2006-2010)	08/06-08/10	FR PS
Kia	Sorento 2.5 (2006-2010)	08/06-08/10	FR PS
Kia	Sorento 3.3 (2006-2010)	08/06-12/09	FR PS

Kia	Sorento 3.5 (2002-2006)	03/03-10/06	FR PS
Kia	Sorento 3.5 (2002-2006)	12/04-10/06	FR PS
Kia	Stinger GT 2.0 GDi CK (2017-2022)	07/17-04/20	FR PS
Kia	Stinger GT 2.2 CRDi CK (2017-2022)	07/17-04/20	FR PS
Kia	Stinger GT 3.3 GDi CK (2017-2022)	07/17-09/22	FR PS
Lancia	Delta 1.3	06/83-12/91	FR PS
Lancia	Delta 1.3	06/83-12/91	RR
Lancia	Delta 1.3	06/83-12/91	FR DS
Lancia	Delta 1.3	06/83-12/91	FR DS
Lancia	Delta 1.3	06/83-12/91	RR
Lancia	Delta 1.3	06/83-12/91	FR PS
Lancia	Delta 1.5	07/80-03/84	FR DS
Lancia	Delta 1.5	07/80-03/84	RR
Lancia	Delta 1.5	07/80-03/84	FR PS
Lancia	Delta 1.5	07/80-03/84	RR
Lancia	Delta 1.5	07/80-03/84	FR PS
Lancia	Delta 1.5	07/80-03/84	FR DS
Lancia	Delta 1.6 GT	06/83-06/86	RR
Lancia	Delta 1.6 GT	06/83-06/86	FR DS
Lancia	Delta 1.6 GT	06/83-06/86	FR PS
Lancia	Delta 1.6 GTie	06/86-12/91	RR
Lancia	Delta 1.6 GTie	06/86-12/91	FR DS
Lancia	Delta 1.6 GTie	06/86-12/91	FR PS
Lancia	Delta 1.6 HF Turbo ie	06/86-12/91	FR DS
Lancia	Delta 1.6 HF Turbo ie	06/86-12/91	FR PS
Lancia	Delta 1.6 HF Turbo ie	06/86-12/91	RR
Lancia	Prisma 1.6	05/83-06/86	FR DS
Lancia	Prisma 1.6	05/83-06/86	FR PS
Lancia	Prisma 1.6 ie	06/86-12/91	FR DS
Lancia	Prisma 1.6 ie	06/86-12/91	FR PS
Lancia	Y10 1.0	06/85-12/91	FR DS
Lancia	Y10 1.0	06/85-12/91	FR DS
Lancia	Y10 1.0	06/85-12/91	FR DS
Lancia	Y10 1.1	07/89-12/91	FR DS
Lancia	Y10 1.1	07/89-12/91	FR DS
Lancia	Y10 1.1	07/89-12/91	FR DS
Lancia	Y10 1.1	07/89-12/91	FR DS
Land Rover	Discovery 2.0 MK 1 (1989-1998)	06/93-12/97	FR DS
Land Rover	Discovery 2.0 MK 1 (1989-1998)	06/93-12/97	FR PS
Land Rover	Discovery 2.0 MK 1 (1989-1998)	06/93-12/97	FR DS
Land Rover	Discovery 2.0 MK 1 (1989-1998)	06/93-12/97	FR PS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR PS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR DS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR PS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR PS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR PS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR DS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR DS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR DS
Land Rover	Discovery 2.5 TDi MK 1 (1989-1998)	06/93-12/98	FR PS

Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	FR PS
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	RR
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	FR PS
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	FR DS
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	RR
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	FR DS
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	FR PS
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	FR PS
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	FR PS
Land Rover	Range Rover 3.9 Injection MK 1 (1970-1995)	10/89-10/92	FR DS
Land Rover	Range Rover 4.4 MK 3 L322 (2002-2013)	02/02-07/05	RR
Land Rover	Range Rover 4.4 MK 3 L322 (2002-2013)	02/02-07/05	RR
Land Rover	Range Rover 4.4 MK 3 L322 (2002-2013)	05/05-04/08	RR
Land Rover	Range Rover 4.4 TDV8 MK 3 L322 (2002-2013)	09/10-12/13	RR
Land Rover	Range Rover 5.0 Supercharged MK 3 L322 (2002-2013)	04/09-12/13	RR
Maserati	Ghibli 3.0 D M157 (2013-)	08/13-04/21	FR PS
Maserati	Ghibli 3.0 M157 (2013-)	08/13-04/19	FR PS
Maserati	Ghibli 3.0 S M157 (2013-)	08/13-04/19	FR PS
Mazda	121 1.1 (1988-1991)	02/88-12/90	FR PS
Mazda	121 1.1 (1988-1991)	02/88-12/90	FR PS
Mazda	121 1.1 (1988-1991)	02/88-12/90	FR DS
Mazda	121 1.1 (1988-1991)	02/88-12/90	FR DS
Mazda	121 1.3 (1988-1991)	02/88-12/91	FR DS
Mazda	121 1.3 (1988-1991)	02/88-12/91	FR PS
Mazda	3 1.5 105 BN (2016-2019)	04/16-04/19	FR PS
Mazda	3 1.5 SKYACTIV-D 105 BM (2013-2017)	12/15-04/17	FR PS
Mazda	3 1.5 SKYACTIV-D 105 BM (2013-2017)	12/15-04/17	FR PS
Mazda	3 2.0 120 BN (2016-2019)	04/16-04/19	FR PS
Mazda	3 2.0 SKYACTIV-G 120 BM (2013-2017)	10/13-04/17	FR PS
Mazda	3 2.0 SKYACTIV-G 120 BM (2013-2017)	10/13-04/17	FR PS
Mazda	3 2.2 150 BN (2016-2019)	04/16-04/19	FR PS
Mazda	3 2.2 SKYACTIV-D 150 BM (2013-2017)	10/13-04/17	FR PS
Mazda	323 1.1 (1981-1985)	09/85-03/86	FR PS
Mazda	323 1.1 (1981-1985)	09/85-03/86	FR DS
Mazda	323 1.3 (1981-1985)	03/81-12/83	FR DS
Mazda	323 1.3 (1981-1985)	03/81-12/83	FR PS
Mazda	323 1.3 (1981-1985)	03/81-12/83	FR PS
Mazda	323 1.3 (1981-1985)	03/81-12/83	FR DS
Mazda	323 1.3 (1981-1985)	03/81-12/83	FR DS
Mazda	323 1.3 (1981-1985)	03/81-12/83	FR PS
Mazda	323 1.3 (1981-1985)	03/83-12/85	FR PS
Mazda	323 1.3 (1981-1985)	03/83-12/85	FR PS
Mazda	323 1.3 (1981-1985)	03/83-12/85	FR PS
Mazda	323 1.3 (1981-1985)	03/83-12/85	FR DS
Mazda	323 1.3 (1981-1985)	03/83-12/85	FR DS
Mazda	323 1.3 (1981-1985)	03/83-12/85	FR DS
Mazda	323 1.3 (1981-1985)	03/83-12/85	FR DS
Mazda	323 1.3 (1985-1989)	07/87-04/90	FR PS
Mazda	323 1.3 (1985-1989)	07/87-04/90	FR PS
Mazda	323 1.3 (1985-1989)	09/85-09/87	FR PS
Mazda	323 1.3 (1985-1989)	09/85-09/87	FR PS

Mazda	323 1.3 (1985-1989)	09/85-09/87	FR DS
Mazda	323 1.3 (1985-1989)	09/85-09/87	FR DS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR PS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR PS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR PS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR PS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR PS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR PS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR PS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR PS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR PS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR PS
Mazda	323 1.3 (1998-2003)	06/01-11/03	FR PS
Mazda	323 1.3 (1998-2003)	10/98-06/01	FR PS
Mazda	323 1.5 (1985-1989)	05/86-07/87	FR PS
Mazda	323 1.5 (1985-1989)	05/86-07/87	FR PS
Mazda	323 1.5 (1985-1989)	05/86-07/87	FR PS
Mazda	323 1.5 (1985-1989)	07/87-10/89	FR PS
Mazda	323 1.5 (1985-1989)	07/87-10/89	FR DS
Mazda	323 1.5 (1985-1989)	07/87-10/89	FR PS
Mazda	323 1.5 (1985-1989)	07/87-10/89	FR DS
Mazda	323 1.5 (1985-1989)	07/87-12/89	FR PS
Mazda	323 1.5 (1985-1989)	07/87-12/89	FR PS
Mazda	323 1.5 (1985-1989)	07/87-12/89	FR PS
Mazda	323 1.5 (1985-1989)	09/85-07/87	FR PS
Mazda	323 1.5 (1985-1989)	09/85-07/87	FR PS
Mazda	323 1.5 (1985-1989)	09/85-07/87	FR DS
Mazda	323 1.5 (1985-1989)	09/85-07/87	FR DS
Mazda	323 1.5 (1989-1994)	01/90-12/91	FR PS
Mazda	323 1.5 (1989-1994)	01/90-12/91	FR PS
Mazda	323 1.5 (1989-1994)	01/90-12/91	FR PS
Mazda	323 1.5 (1998-2003)	10/98-10/01	FR PS
Mazda	323 1.5 (1998-2003)	10/98-10/01	FR PS
Mazda	323 1.5 GT (1981-1985)	03/81-12/84	FR DS
Mazda	323 1.5 GT (1981-1985)	03/81-12/84	FR PS
Mazda	323 1.5 GT (1981-1985)	03/81-12/85	FR PS
Mazda	323 1.5 GT (1981-1985)	03/81-12/85	FR DS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR PS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR PS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR PS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR PS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR PS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR PS
Mazda	323 1.6 (1998-2003)	06/01-11/03	FR PS
Mazda	323 1.6 (1998-2003)	06/01-11/03	FR PS
Mazda	323 1.6 Injection (1985-1989)	11/85-09/87	FR PS
Mazda	323 1.6 Injection (1985-1989)	11/85-09/87	FR DS
Mazda	323 1.6 Turbo (1985-1989)	10/86-09/87	FR PS
Mazda	323 1.6 Turbo (1985-1989)	10/86-09/87	FR DS
Mazda	323 1.6 Turbo Intercooled (1985-1989)	09/88-12/89	FR DS

Mazda	323 1.6 Turbo Intercooled (1985-1989)	09/88-12/89	FR PS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR PS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR PS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR PS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR PS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR PS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR PS
Mazda	323 1.8 GTi (1989-1994)	10/89-06/91	FR PS
Mazda	323 1.8 GTi (1989-1994)	10/89-06/91	FR PS
Mazda	323 1.8 GTi (1989-1994)	10/89-06/91	FR PS
Mazda	323 1.8 GTi (1989-1994)	10/89-06/91	FR PS
Mazda	323 2.0 (1998-2003)	08/01-11/03	FR PS
Mazda	323 2.0 (1998-2003)	08/01-11/03	FR PS
Mazda	323 2.0 Di (1998-2003)	06/01-12/01	FR PS
Mazda	323 2.0 Di (1998-2003)	06/01-12/01	FR PS
Mazda	323 2.0 Di (1998-2003)	07/00-06/01	FR PS
Mazda	323 2.0 Di (1998-2003)	12/01-11/03	FR PS
Mazda	323 2.0 Di (1998-2003)	12/01-11/03	FR PS
Mazda	6 1.8 GG (2002-2008)	03/02-06/08	FR PS
Mazda	6 1.8 GG (2002-2008)	03/02-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-03/03	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-04/06	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-04/06	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	FR PS
Mazda	6 2.0 GG (2002-2008)	08/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	08/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	08/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	08/05-06/08	FR PS
Mazda	6 2.0 GG (2002-2008)	08/05-06/08	FR PS
Mazda	6 2.3 GG (2002-2008)	03/02-04/06	FR PS
Mazda	6 2.3 GG (2002-2008)	04/05-06/08	FR PS
Mazda	6 2.3 GG (2002-2008)	11/02-08/05	FR PS

Mazda	6 2.3 GG (2002-2008)	11/03-08/05	FR PS
Mazda	6 2.3 MPS GG (2002-2008)	12/05-06/08	FR PS
Mazda	626 1.6 (1983-1987)	05/83-12/87	FR PS
Mazda	626 1.6 (1983-1987)	05/83-12/87	FR PS
Mazda	626 1.6 (1983-1987)	05/83-12/87	FR DS
Mazda	626 1.6 (1983-1987)	05/83-12/87	FR DS
Mazda	626 2.0 (1983-1987)	05/83-11/85	FR PS
Mazda	626 2.0 (1983-1987)	05/83-11/85	FR DS
Mazda	626 2.0 (1983-1987)	05/83-11/85	FR DS
Mazda	626 2.0 (1983-1987)	05/83-11/85	FR PS
Mazda	626 2.0 (1983-1987)	05/83-11/85	FR PS
Mazda	626 2.0 (1983-1987)	05/83-11/85	FR PS
Mazda	626 2.0 (1983-1987)	05/83-11/85	FR DS
Mazda	626 2.0 (1983-1987)	05/83-11/85	FR DS
Mazda	626 2.0 Injection (1983-1987)	11/85-12/87	FR PS
Mazda	626 2.0 Injection (1983-1987)	11/85-12/87	FR DS
Mazda	626 2.0 Injection (1983-1987)	11/85-12/87	FR DS
Mazda	626 2.0 Injection (1983-1987)	11/85-12/87	FR PS
Mazda	626 2.0 Injection (1983-1987)	11/85-12/87	FR PS
Mazda	626 2.0 Injection (1983-1987)	11/85-12/87	FR DS
Mazda	626 2.0 Injection (1983-1987)	11/85-12/87	FR DS
Mazda	626 2.0 Injection (1983-1987)	11/85-12/87	FR PS
Mazda	Atenza 1.8 (2002-2008)	06/02-08/08	FR PS
Mazda	Atenza 2.0 (2002-2008)	04/05-08/08	FR PS
Mazda	Atenza 2.0 (2002-2008)	06/02-04/06	FR PS
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	FR PS
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	FR PS
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	FR PS
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	FR PS
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	FR PS
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	FR PS
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	FR PS
Mazda	Atenza 2.3 (2002-2008)	04/05-08/08	FR PS
Mazda	Atenza 2.3 (2002-2008)	04/05-08/08	FR PS
Mazda	Atenza 2.3 (2002-2008)	06/02-04/06	FR PS
Mazda	Atenza 2.3 (2002-2008)	06/02-04/06	FR PS
Mazda	B1800 1.8	01/85-02/86	FR DS
Mazda	B1800 1.8	01/85-02/86	FR PS
Mazda	B1800 1.8	01/85-02/86	FR DS
Mazda	B1800 1.8	01/85-02/86	FR PS
Mazda	B2000 2.0	02/86-12/94	FR DS
Mazda	B2000 2.0	02/86-12/94	FR DS
Mazda	B2000 2.0	02/86-12/94	FR PS
Mazda	B2000 2.0	02/86-12/94	FR PS
Mazda	B2200 2.2	02/86-12/96	FR PS
Mazda	B2200 2.2	02/86-12/96	FR DS
Mazda	B2500 2.5 (1998-2003)	03/98-02/03	FR PS
Mazda	B2500 2.5 (1998-2003)	03/98-02/03	FR DS
Mazda	B2500 2.5 (1998-2003)	03/98-02/03	FR DS
Mazda	B2500 2.5 (1998-2003)	03/98-02/03	FR PS

Mazda	B2500 2.5 (2003-2007)	02/03-05/07	FR DS
Mazda	B2500 2.5 (2003-2007)	02/03-05/07	FR DS
Mazda	B2500 2.5 (2003-2007)	02/03-05/07	FR PS
Mazda	B2500 2.5 (2003-2007)	02/03-05/07	FR PS
Mazda	B2500 2.5 Dual Cab (1998-2003)	03/98-02/03	FR DS
Mazda	B2500 2.5 Dual Cab (1998-2003)	03/98-02/03	FR PS
Mazda	B2500 2.5 Dual Cab (2003-2007)	02/03-05/07	FR PS
Mazda	B2500 2.5 Dual Cab (2003-2007)	02/03-05/07	FR DS
Mazda	B2500 2.5 Dual Cab Turbo (1998-2003)	06/99-02/03	FR DS
Mazda	B2500 2.5 Dual Cab Turbo (1998-2003)	06/99-02/03	FR PS
Mazda	B2500 2.5 Turbo (1998-2003)	06/99-02/03	FR PS
Mazda	B2500 2.5 Turbo (1998-2003)	06/99-02/03	FR DS
Mazda	B2500 2.5 Turbo (2003-2007)	02/03-05/07	FR PS
Mazda	B2500 2.5 Turbo (2003-2007)	02/03-05/07	FR DS
Mazda	B2600 2.6	01/87-12/88	FR PS
Mazda	B2600 2.6	01/87-12/88	FR PS
Mazda	B2600 2.6	01/87-12/88	FR DS
Mazda	B2600 2.6	01/87-12/88	FR DS
Mazda	BT50 2.5 (2006-2010)	08/06-12/10	FR PS
Mazda	BT50 2.5 (2006-2010)	08/06-12/10	FR DS
Mazda	BT50 3.0 (2006-2010)	10/08-12/10	FR PS
Mazda	BT50 3.0 (2006-2010)	10/08-12/10	FR DS
Mazda	CX3 1.5 DK (2015-2020)	04/15-04/20	FR PS
Mazda	CX3 1.5 DK (2015-2020)	04/15-04/20	FR PS
Mazda	CX3 1.5 DK (2015-2020)	04/15-04/20	FR PS
Mazda	CX3 1.8 DK (2015-2020)	08/18-04/20	FR PS
Mazda	CX3 2.0 DK (2015-2020)	04/15-04/19	FR PS
Mazda	CX3 2.0 DK (2015-2020)	04/15-04/19	FR PS
Mazda	CX3 2.0 DK (2015-2020)	04/15-04/20	FR PS
Mazda	CX3 2.0 DK (2015-2020)	06/18-04/20	FR PS
Mazda	CX3 2.0 DK (2015-2020)	06/18-04/20	FR PS
Mazda	CX3 2.0 DK (2015-2020)	06/18-04/20	FR PS
Mazda	CX3 2.0 DK (2015-2020)	06/18-04/20	FR PS
Mazda	CX5 2.0 KE (2012-2018)	04/12-04/18	FR PS
Mazda	CX5 2.2 KE (2012-2018)	04/12-04/18	FR PS
Mazda	CX5 2.2 KE (2012-2018)	04/12-04/18	FR PS
Mazda	CX5 2.2 KE (2012-2018)	04/12-04/18	FR PS
Mazda	CX5 2.2 KE (2012-2018)	04/12-04/18	FR PS
Mazda	CX5 2.2 KE (2012-2018)	04/12-04/18	FR PS
Mazda	CX5 2.2 KE (2012-2018)	04/12-04/18	FR PS
Mazda	Eunos Roadster 1.6	01/89-12/05	FR DS
Mazda	Eunos Roadster 1.6	01/89-12/05	FR PS
Mazda	Eunos Roadster 1.8	01/93-12/05	FR PS
Mazda	Eunos Roadster 1.8	01/93-12/05	FR DS
Mazda	Eunos Roadster 1.8	01/93-12/05	FR DS
Mazda	Eunos Roadster 1.8	01/93-12/05	FR PS
Mazda	MX3 1.6 (1991-1998)	09/91-04/94	FR PS
Mazda	MX3 1.6 (1991-1998)	09/91-04/94	FR PS
Mazda	MX3 1.6 (1991-1998)	09/91-04/94	FR PS
Mazda	MX3 1.6 (1991-1998)	09/91-04/94	FR PS
Mazda	MX3 1.8 (1991-1998)	08/94-12/98	FR PS

Mazda	MX3 1.8 (1991-1998)	08/94-12/98	FR PS
Mazda	MX3 1.8 (1991-1998)	08/94-12/98	FR PS
Mazda	MX3 1.8 (1991-1998)	09/91-08/94	FR PS
Mazda	MX5 1.5 ND (2015-)	06/15-04/19	FR DS
Mazda	MX5 1.5 ND (2015-)	06/15-04/19	FR PS
Mazda	MX5 1.5 ND (2015-)	07/18-	FR DS
Mazda	MX5 1.5 ND (2015-)	07/18-	FR PS
Mazda	MX5 1.6 NA (1990-1998)	01/90-12/94	FR PS
Mazda	MX5 1.6 NA (1990-1998)	01/90-12/94	FR DS
Mazda	MX5 1.6 NA (1990-1998)	04/95-04/98	FR PS
Mazda	MX5 1.6 NA (1990-1998)	04/95-04/98	FR DS
Mazda	MX5 1.6 NA (1990-1998)	04/95-04/98	FR DS
Mazda	MX5 1.6 NA (1990-1998)	04/95-04/98	FR PS
Mazda	MX5 1.6 NB (1998-2005)	04/98-06/01	FR PS
Mazda	MX5 1.6 NB (1998-2005)	04/98-06/01	FR PS
Mazda	MX5 1.6 NB (1998-2005)	04/98-06/01	FR DS
Mazda	MX5 1.6 NB (1998-2005)	04/98-06/01	FR DS
Mazda	MX5 1.6 NB (1998-2005)	06/01-12/05	FR DS
Mazda	MX5 1.6 NB (1998-2005)	06/01-12/05	FR PS
Mazda	MX5 1.6 NB (1998-2005)	06/01-12/05	FR DS
Mazda	MX5 1.6 NB (1998-2005)	06/01-12/05	FR PS
Mazda	MX5 1.8 NA (1990-1998)	05/94-04/98	FR PS
Mazda	MX5 1.8 NA (1990-1998)	05/94-04/98	FR DS
Mazda	MX5 1.8 NB (1998-2005)	04/98-06/01	FR PS
Mazda	MX5 1.8 NB (1998-2005)	04/98-06/01	FR DS
Mazda	MX5 1.8 NB (1998-2005)	06/01-12/03	FR PS
Mazda	MX5 1.8 NB (1998-2005)	06/01-12/03	FR DS
Mazda	MX5 1.8 NB (1998-2005)	06/01-12/05	FR DS
Mazda	MX5 1.8 NB (1998-2005)	06/01-12/05	FR PS
Mazda	MX5 1.8 NB (1998-2005)	06/01-12/05	FR PS
Mazda	MX5 1.8 NB (1998-2005)	06/01-12/05	FR DS
Mazda	MX5 1.8 NC (2005-2016)	11/05-06/16	FR PS
Mazda	MX5 1.8 NC (2005-2016)	11/05-06/16	FR DS
Mazda	MX5 1.8 NC (2005-2016)	11/05-06/16	FR DS
Mazda	MX5 1.8 NC (2005-2016)	11/05-06/16	FR PS
Mazda	MX5 2.0 NC (2005-2016)	01/09-06/16	FR PS
Mazda	MX5 2.0 NC (2005-2016)	01/09-06/16	FR DS
Mazda	MX5 2.0 NC (2005-2016)	11/05-06/16	FR PS
Mazda	MX5 2.0 NC (2005-2016)	11/05-06/16	FR DS
Mazda	MX5 2.0 NC (2005-2016)	11/05-06/16	FR DS
Mazda	MX5 2.0 NC (2005-2016)	11/05-06/16	FR PS
Mazda	MX5 2.0 ND (2015-)	06/15-04/19	FR DS
Mazda	MX5 2.0 ND (2015-)	06/15-04/19	FR PS
Mazda	MX5 2.0 ND (2015-)	07/18-	FR PS
Mazda	MX5 2.0 ND (2015-)	07/18-	FR DS
Mazda	MX5 2.0 ND (2015-)	07/18-	FR PS
Mazda	MX5 2.0 ND (2015-)	07/18-	FR DS
Mazda	MX5 2.0 ND (2015-)	11/16-04/19	FR DS
Mazda	MX5 2.0 ND (2015-)	11/16-04/19	FR PS
Mazda	Proceed 2.6	12/90-02/96	FR DS

Mazda	Proceed 2.6	12/90-02/96	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR PS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR PS
Mercedes Benz	380SL 3.8 R107	10/80-12/82	FR DS
Mercedes Benz	380SL 3.8 R107	10/80-12/82	FR PS
Mercedes Benz	V220 2.2 CDi W638	02/99-02/04	RR
Mercedes Benz	V220 2.2 CDi W638	02/99-02/04	RR
Mercedes Benz	V230 2.3 W638	11/96-02/04	RR
Mercedes Benz	V230 2.3 W638	11/96-02/04	RR
Mercedes Benz	V230 2.3 W638	11/96-02/04	RR
Mercedes Benz	V230 2.3 W638	11/96-02/04	RR
Mercedes Benz	X220 2.3d 470	11/17-04/20	FR PS
Mercedes Benz	X250 2.3d 470	11/17-04/21	FR PS
Mercedes Benz	X350 3.0d 470	09/18-04/21	FR PS
Mini	MINI 1.2 One F55 (2014-2025)	09/14-04/19	FR PS
Mini	MINI 1.2 One F55 (2014-2025)	09/14-04/19	FR PS
Mini	MINI 1.2 One F56 (2014-2025)	01/14-04/19	FR
Mini	MINI 1.2 One F56 (2014-2025)	01/14-04/19	FR
Mini	MINI 1.4 Clubman One R55 (2006-2015)	03/09-08/10	FR DS
Mini	MINI 1.4 Clubman One R55 (2006-2015)	03/09-08/10	FR DS
Mini	MINI 1.4 First R56 (2006-2014)	07/09-08/10	FR DS
Mini	MINI 1.4 One R56 (2006-2014)	03/07-08/10	FR DS
Mini	MINI 1.4 One R56 (2006-2014)	03/07-08/10	FR DS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	08/14-04/19	FR PS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	08/14-04/19	FR PS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	10/17-04/19	FR PS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	12/17-04/19	FR PS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	12/17-04/19	FR PS
Mini	MINI 1.5 Cooper D F56 (2014-2025)	01/14-12/18	FR
Mini	MINI 1.5 Cooper D F56 (2014-2025)	01/14-12/18	FR
Mini	MINI 1.5 Cooper D F56 (2014-2025)	10/17-12/18	FR
Mini	MINI 1.5 Cooper D F56 (2014-2025)	12/17-12/18	FR
Mini	MINI 1.5 Cooper D F56 (2014-2025)	12/17-12/18	FR
Mini	MINI 1.5 Cooper D F57 (2016-2025)	01/16-04/19	FR DS
Mini	MINI 1.5 Cooper D F57 (2016-2025)	01/16-04/19	FR DS
Mini	MINI 1.5 Cooper F55 (2014-2025)	08/14-04/19	FR PS
Mini	MINI 1.5 Cooper F55 (2014-2025)	08/14-04/19	FR PS
Mini	MINI 1.5 Cooper F55 (2014-2025)	08/14-04/19	FR PS
Mini	MINI 1.5 Cooper F55 (2014-2025)	08/14-04/19	FR PS
Mini	MINI 1.5 Cooper F55 (2014-2025)	12/17-04/25	FR PS
Mini	MINI 1.5 Cooper F55 (2014-2025)	12/17-12/23	FR PS
Mini	MINI 1.5 Cooper F56 (2014-2025)	01/14-04/19	FR
Mini	MINI 1.5 Cooper F56 (2014-2025)	01/14-04/19	FR

Mini	MINI 1.5 Cooper F56 (2014-2025)	01/14-04/19	FR
Mini	MINI 1.5 Cooper F56 (2014-2025)	01/14-04/19	FR
Mini	MINI 1.5 Cooper F56 (2014-2025)	12/17-04/25	FR
Mini	MINI 1.5 Cooper F56 (2014-2025)	12/17-12/23	FR
Mini	MINI 1.5 Cooper F57 (2016-2025)	01/16-04/19	FR DS
Mini	MINI 1.5 Cooper F57 (2016-2025)	01/16-04/19	FR DS
Mini	MINI 1.5 Cooper F57 (2016-2025)	05/18-04/25	FR DS
Mini	MINI 1.5 Cooper F57 (2016-2025)	05/18-12/23	FR DS
Mini	MINI 1.5 One D F55 (2014-2025)	08/14-04/19	FR PS
Mini	MINI 1.5 One D F56 (2014-2025)	01/14-04/19	FR
Mini	MINI 1.5 One F55 (2014-2025)	09/17-12/22	FR PS
Mini	MINI 1.5 One F55 (2014-2025)	09/17-12/22	FR PS
Mini	MINI 1.5 One F56 (2014-2025)	09/17-04/19	FR
Mini	MINI 1.5 One F56 (2014-2025)	09/17-12/22	FR
Mini	MINI 1.5 One F56 (2014-2025)	09/17-12/22	FR
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	08/10-09/15	FR DS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	11/07-12/10	FR DS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	11/07-12/10	FR DS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	11/07-12/10	FR DS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	11/07-12/10	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR DS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR DS
Mini	MINI 1.6 Clubman Cooper S R55 (2006-2015)	01/10-09/15	FR DS
Mini	MINI 1.6 Clubman Cooper S R55 (2006-2015)	01/10-09/15	FR DS
Mini	MINI 1.6 Clubman Cooper S R55 (2006-2015)	11/07-08/10	FR DS
Mini	MINI 1.6 Clubman Cooper S R55 (2006-2015)	11/07-08/10	FR DS
Mini	MINI 1.6 Clubman John Cooper Works R55 (2006-2015)	03/12-09/15	FR DS
Mini	MINI 1.6 Clubman John Cooper Works R55 (2006-2015)	06/09-12/13	FR DS
Mini	MINI 1.6 Clubman One D R55 (2006-2015)	08/10-09/15	FR DS
Mini	MINI 1.6 Clubman One R55 (2006-2015)	01/10-09/15	FR DS
Mini	MINI 1.6 Clubman One R55 (2006-2015)	01/10-09/15	FR DS
Mini	MINI 1.6 Clubvan Cooper D R55 (2006-2015)	09/12-09/15	FR DS
Mini	MINI 1.6 Clubvan Cooper R55 (2006-2015)	09/12-09/15	FR DS
Mini	MINI 1.6 Clubvan Cooper R55 (2006-2015)	09/12-09/15	FR DS
Mini	MINI 1.6 Clubvan Cooper R55 (2006-2015)	09/12-09/15	FR DS
Mini	MINI 1.6 Clubvan Cooper R55 (2006-2015)	09/12-09/15	FR DS
Mini	MINI 1.6 Clubvan One R55 (2006-2015)	09/12-09/15	FR DS
Mini	MINI 1.6 Clubvan One R55 (2006-2015)	09/12-09/15	FR DS
Mini	MINI 1.6 Cooper D R56 (2006-2014)	03/07-12/10	FR DS
Mini	MINI 1.6 Cooper D R56 (2006-2014)	03/07-12/10	FR DS
Mini	MINI 1.6 Cooper D R56 (2006-2014)	03/07-12/10	FR DS
Mini	MINI 1.6 Cooper D R56 (2006-2014)	03/07-12/10	FR DS
Mini	MINI 1.6 Cooper D R57 (2009-2016)	08/10-12/16	FR DS
Mini	MINI 1.6 Cooper R50 (2001-2006)	04/01-12/06	FR DS

Mini	MINI 1.6 Cooper R50 (2001-2006)	04/01-12/06	FR DS
Mini	MINI 1.6 Cooper R52 (2004-2009)	01/07-05/09	FR DS
Mini	MINI 1.6 Cooper R52 (2004-2009)	01/07-05/09	FR DS
Mini	MINI 1.6 Cooper R52 (2004-2009)	07/04-12/06	FR DS
Mini	MINI 1.6 Cooper R52 (2004-2009)	07/04-12/06	FR DS
Mini	MINI 1.6 Cooper R56 (2006-2014)	08/06-08/10	FR DS
Mini	MINI 1.6 Cooper R56 (2006-2014)	08/06-08/10	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	01/10-12/16	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	01/10-12/16	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	01/10-12/16	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	01/10-12/16	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR DS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR DS
Mini	MINI 1.6 Cooper S R52 (2004-2009)	01/07-05/09	FR DS
Mini	MINI 1.6 Cooper S R52 (2004-2009)	01/07-05/09	FR DS
Mini	MINI 1.6 Cooper S R52 (2004-2009)	12/06-12/06	FR DS
Mini	MINI 1.6 Cooper S R52 (2004-2009)	12/06-12/06	FR DS
Mini	MINI 1.6 Cooper S R53 (2001-2006)	08/06-04/07	FR DS
Mini	MINI 1.6 Cooper S R53 (2001-2006)	08/06-04/07	FR DS
Mini	MINI 1.6 Cooper S R56 (2006-2014)	08/06-08/10	FR DS
Mini	MINI 1.6 Cooper S R56 (2006-2014)	08/06-08/10	FR DS
Mini	MINI 1.6 Cooper S R57 (2009-2016)	01/10-12/16	FR DS
Mini	MINI 1.6 Cooper S R57 (2009-2016)	01/10-12/16	FR DS
Mini	MINI 1.6 Cooper S R57 (2009-2016)	03/09-08/10	FR DS
Mini	MINI 1.6 Cooper S R57 (2009-2016)	03/09-08/10	FR DS
Mini	MINI 1.6 Cooper S Works GP R53 (2001-2006)	07/06-12/06	FR DS
Mini	MINI 1.6 Cooper S Works R52 (2004-2009)	11/04-07/06	FR DS
Mini	MINI 1.6 John Cooper Works R57 (2009-2016)	03/09-12/13	FR DS
Mini	MINI 1.6 John Cooper Works R57 (2009-2016)	03/12-12/16	FR DS
Mini	MINI 1.6 One R50 (2001-2006)	04/01-03/06	FR DS
Mini	MINI 1.6 One R50 (2001-2006)	04/01-03/06	FR DS
Mini	MINI 1.6 One R52 (2004-2009)	01/07-05/09	FR DS
Mini	MINI 1.6 One R52 (2004-2009)	06/04-03/06	FR DS
Mini	MINI 1.6 One R57 (2009-2016)	01/10-12/16	FR DS
Mini	MINI 1.6 One R57 (2009-2016)	01/10-12/16	FR DS
Mini	MINI 2.0 Clubman Cooper D Auto R55 (2006-2015)	01/11-09/15	FR DS
Mini	MINI 2.0 Clubman Cooper SD R55 (2006-2015)	01/11-09/15	FR DS
Mini	MINI 2.0 Clubman Cooper SD R55 (2006-2015)	01/11-09/15	FR DS
Mini	MINI 2.0 Clubvan Cooper D Auto R55 (2006-2015)	09/12-09/15	FR DS
Mini	MINI 2.0 Cooper D Auto R57 (2009-2016)	01/11-12/16	FR DS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	01/18-12/21	FR PS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	01/18-12/21	FR PS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	01/21-04/25	FR PS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	01/21-12/23	FR PS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	08/14-12/18	FR PS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	08/14-12/18	FR PS
Mini	MINI 2.0 Cooper S F56 (2014-2025)	01/14-12/18	FR
Mini	MINI 2.0 Cooper S F56 (2014-2025)	01/14-12/18	FR

Mini	MINI 2.0 Cooper S F56 (2014-2025)	01/18-12/21	FR
Mini	MINI 2.0 Cooper S F56 (2014-2025)	01/18-12/21	FR
Mini	MINI 2.0 Cooper S F56 (2014-2025)	01/21-04/25	FR
Mini	MINI 2.0 Cooper S F56 (2014-2025)	01/21-12/23	FR
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/16-12/18	FR DS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/16-12/18	FR DS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/18-12/21	FR DS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/18-12/21	FR DS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/21-04/25	FR DS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/21-12/23	FR DS
Mini	MINI 2.0 Cooper S Works 210 F56 (2014-2025)	10/16-12/18	FR
Mini	MINI 2.0 Cooper SD F55 (2014-2025)	08/14-04/18	FR PS
Mini	MINI 2.0 Cooper SD F55 (2014-2025)	08/14-04/18	FR PS
Mini	MINI 2.0 Cooper SD F56 (2014-2025)	06/14-04/18	FR
Mini	MINI 2.0 Cooper SD F56 (2014-2025)	06/14-04/18	FR
Mini	MINI 2.0 Cooper SD R57 (2009-2016)	01/11-12/16	FR DS
Mini	MINI 2.0 Cooper SD R57 (2009-2016)	01/11-12/16	FR DS
Mini	MINI 2.0 John Cooper Works F56 (2014-2025)	04/15-04/19	FR
Mini	MINI 2.0 John Cooper Works F56 (2014-2025)	04/15-04/19	FR
Mini	MINI 2.0 John Cooper Works F56 (2014-2025)	04/15-04/19	FR
Mini	MINI 2.0 John Cooper Works F56 (2014-2025)	04/15-04/19	FR
Mini	MINI 2.0 John Cooper Works F56 (2014-2025)	12/17-04/25	FR
Mini	MINI 2.0 John Cooper Works F56 (2014-2025)	12/17-04/25	FR
Mini	MINI 2.0 John Cooper Works F56 (2014-2025)	12/17-12/23	FR
Mini	MINI 2.0 John Cooper Works F57 (2016-2025)	01/16-12/18	FR DS
Mini	MINI 2.0 John Cooper Works F57 (2016-2025)	01/16-12/18	FR DS
Mini	MINI 2.0 John Cooper Works F57 (2016-2025)	01/18-04/25	FR DS
Mini	MINI 2.0 John Cooper Works F57 (2016-2025)	01/18-12/23	FR DS
Mini	MINI 2.0 John Cooper Works GP F56 (2014-2025)	02/20-04/22	FR
Mitsubishi	Chariot 2.0 (1991-1997)	01/92-12/97	FR PS
Mitsubishi	Chariot 2.0 (1991-1997)	01/92-12/97	FR PS
Mitsubishi	Chariot 2.0 (1991-1997)	01/92-12/97	FR PS
Mitsubishi	Chariot 2.0 (1991-1997)	01/92-12/97	FR PS
Mitsubishi	Chariot 2.0 TD (1991-1997)	01/92-12/97	FR PS
Mitsubishi	Chariot 2.0 TD (1991-1997)	01/92-12/97	FR PS
Mitsubishi	Colt Mirage 1.2 (1984-1988)	06/84-06/88	FR PS
Mitsubishi	Colt Mirage 1.2 (1984-1988)	06/84-06/88	FR DS
Mitsubishi	Colt Mirage 1.2 (1984-1988)	06/84-06/88	RR
Mitsubishi	Colt Mirage 1.3 (1988-1992)	06/88-09/90	FR DS
Mitsubishi	Colt Mirage 1.3 (1988-1992)	06/88-09/90	RR
Mitsubishi	Colt Mirage 1.3 (1988-1992)	06/88-09/90	FR PS
Mitsubishi	Colt Mirage 1.3 (1988-1992)	09/90-04/92	FR DS
Mitsubishi	Colt Mirage 1.3 (1988-1992)	09/90-04/92	FR PS
Mitsubishi	Colt Mirage 1.3 (1988-1992)	09/90-04/92	RR
Mitsubishi	Colt Mirage 1.5 (1984-1988)	06/84-04/89	FR DS
Mitsubishi	Colt Mirage 1.5 (1984-1988)	06/84-04/89	FR DS
Mitsubishi	Colt Mirage 1.5 (1984-1988)	06/84-04/89	FR DS
Mitsubishi	Colt Mirage 1.5 (1984-1988)	06/84-04/89	RR
Mitsubishi	Colt Mirage 1.5 (1984-1988)	06/84-04/89	RR
Mitsubishi	Colt Mirage 1.5 (1984-1988)	06/84-04/89	RR

Mitsubishi	Galant 2.0 (1988-1993)	05/89-12/92	FR PS
Mitsubishi	Galant 2.0 (1988-1993)	05/89-12/92	FR PS
Mitsubishi	Galant 2.0 (1988-1993)	05/89-12/92	FR PS
Mitsubishi	Galant 2.0 (1988-1993)	06/88-12/92	FR PS
Mitsubishi	Galant 2.0 (1997-2003)	03/97-07/03	FR PS
Mitsubishi	Galant 2.0 (1997-2003)	03/97-07/03	FR PS
Mitsubishi	Galant 2.0 (1997-2003)	03/97-07/03	FR PS
Mitsubishi	Galant 2.0 (1997-2003)	03/97-07/03	FR PS
Mitsubishi	Galant 2.4 (1997-2003)	10/99-07/03	FR PS
Mitsubishi	Galant 2.4 (1997-2003)	10/99-07/03	FR PS
Mitsubishi	Galant 2.4 (1997-2003)	10/99-08/03	FR PS
Mitsubishi	Galant 2.4 (1997-2003)	10/99-08/03	FR PS
Mitsubishi	Galant 2.5 (1997-2003)	03/97-03/01	FR PS
Mitsubishi	Galant 2.5 (1997-2003)	03/97-07/03	FR PS
Mitsubishi	L200 2.3 S6 (2019-2021)	06/19-12/21	FR PS
Mitsubishi	L200 2.3 S6 (2019-2021)	06/19-12/21	FR PS
Mitsubishi	L200 2.3 S6 (2019-2021)	06/19-12/21	FR PS
Mitsubishi	L200 2.4 (2015-2020)	05/15-04/20	FR PS
Mitsubishi	L200 2.4 (2015-2020)	05/15-04/20	FR PS
Mitsubishi	L300 1.6 (1985-2001)	01/85-10/86	RR
Mitsubishi	L300 1.6 (1985-2001)	01/85-10/86	RR
Mitsubishi	L300 1.6 (1985-2001)	01/85-10/86	FR PS
Mitsubishi	L300 1.6 (1985-2001)	01/85-10/86	FR DS
Mitsubishi	L300 1.6 (1985-2001)	01/85-10/86	FR DS
Mitsubishi	L300 1.6 (1985-2001)	01/85-10/86	FR PS
Mitsubishi	L300 2.5 (1985-2001)	10/86-12/01	FR PS
Mitsubishi	L300 2.5 (1985-2001)	10/86-12/01	FR DS
Mitsubishi	L300 2.5 (1985-2001)	10/86-12/01	FR DS
Mitsubishi	L300 2.5 (1985-2001)	10/86-12/01	FR PS
Mitsubishi	Lancer 1.3	01/03-12/07	RR
Mitsubishi	Lancer 1.5 (1988-1992)	07/88-09/90	RR
Mitsubishi	Lancer 1.5 (1988-1992)	07/88-09/90	RR
Mitsubishi	Lancer 1.5 (2008-2012)	08/09-03/11	FR PS
Mitsubishi	Lancer 1.5 (2008-2012)	08/09-03/11	FR PS
Mitsubishi	Lancer 1.5 Sportback (2008-2012)	11/08-12/12	FR PS
Mitsubishi	Lancer 1.5 Sportback (2008-2012)	11/08-12/12	FR PS
Mitsubishi	Lancer 1.6 (1988-1992)	07/88-04/90	RR
Mitsubishi	Lancer 1.6 (1988-1992)	07/88-04/90	RR
Mitsubishi	Lancer 1.6 (1988-1992)	07/88-04/90	RR
Mitsubishi	Lancer 1.6 (1992-1995)	10/92-01/96	RR
Mitsubishi	Lancer 1.6 (1992-1995)	10/92-01/96	RR
Mitsubishi	Lancer 1.6 (2004-2008)	12/04-12/08	RR
Mitsubishi	Lancer 1.6 (2004-2008)	12/04-12/08	RR
Mitsubishi	Lancer 1.8 (1988-1992)	04/90-12/92	RR
Mitsubishi	Lancer 1.8 (1988-1992)	08/89-12/92	RR
Mitsubishi	Lancer 1.8 (2008-2012)	02/08-12/11	FR PS
Mitsubishi	Lancer 1.8 (2008-2012)	02/08-12/11	FR PS
Mitsubishi	Lancer 1.8 GTi (1992-1995)	10/92-09/95	RR
Mitsubishi	Lancer 1.8 Sportback (2008-2012)	07/08-12/12	FR PS
Mitsubishi	Lancer 1.8 Sportback (2008-2012)	07/08-12/12	FR PS

Mitsubishi	Lancer 2.0 260 Evolution VIII	02/04-07/05	RR
Mitsubishi	Lancer 2.0 DI-D (2008-2012)	02/08-12/11	FR PS
Mitsubishi	Lancer 2.0 DI-D (2008-2012)	02/08-12/11	FR PS
Mitsubishi	Lancer 2.0 Evolution II	01/94-02/95	FR PS
Mitsubishi	Lancer 2.0 Evolution III	02/95-08/96	FR PS
Mitsubishi	Lancer 2.0 Evolution V	01/98-01/00	RR
Mitsubishi	Lancer 2.0 FQ 300 Evolution X	02/08-03/13	FR PS
Mitsubishi	Lancer 2.0 FQ 330 Evolution X	02/08-03/13	FR PS
Mitsubishi	Lancer 2.0 FQ 360 Evolution X	02/08-03/13	FR PS
Mitsubishi	Lancer 2.0 FQ 400 Evolution X	05/09-12/10	FR PS
Mitsubishi	Lancer 2.0 Sport (2004-2008)	07/06-12/08	RR
Mitsubishi	Lancer 2.0 Sport (2004-2008)	07/06-12/08	RR
Mitsubishi	Lancer 2.0 Sportback DI-D (2008-2012)	07/08-12/12	FR PS
Mitsubishi	Lancer 2.0 Sportback DI-D (2008-2012)	07/08-12/12	FR PS
Mitsubishi	Lancer 2.0 Sportback Ralliart (2008-2012)	04/09-12/12	FR PS
Mitsubishi	Outlander 2.0 Di-D (2007-2013)	03/07-12/10	FR PS
Mitsubishi	Outlander 2.0 MIVEC (2012-2021)	06/18-12/21	FR PS
Mitsubishi	Outlander 2.0 PHEV (2012-2021)	12/13-04/19	FR PS
Mitsubishi	Outlander 2.2 Di-D (2007-2013)	11/07-12/13	FR PS
Mitsubishi	Outlander 2.2 Di-D (2007-2013)	11/07-12/13	FR PS
Mitsubishi	Outlander 2.2 Di-D (2007-2013)	11/08-12/13	FR PS
Mitsubishi	Outlander 2.2 Di-D (2007-2013)	11/08-12/13	FR PS
Mitsubishi	Outlander 2.2 Di-D (2012-2021)	12/12-04/19	FR PS
Mitsubishi	Outlander 2.2 Di-D (2012-2021)	12/12-04/19	FR PS
Mitsubishi	Outlander 2.2 Di-D (2012-2021)	12/12-04/19	FR PS
Mitsubishi	Outlander 2.4 (2003-2007)	10/03-05/07	FR PS
Mitsubishi	Pajero io 1.8	01/99-12/07	FR DS
Mitsubishi	Pajero io 1.8	01/99-12/07	FR DS
Mitsubishi	Pajero io 2.0	01/99-12/07	FR DS
Mitsubishi	Pajero io 2.0	01/99-12/07	FR DS
Mitsubishi	Pajero Pinin 1.8 GDI	01/99-12/06	FR DS
Mitsubishi	Pajero Pinin 1.8 GDI	01/99-12/06	FR DS
Mitsubishi	Pajero Pinin 1.8 MPI	01/99-12/06	FR DS
Mitsubishi	Pajero Pinin 1.8 MPI	01/99-12/06	FR DS
Mitsubishi	Pajero Pinin 2.0	01/99-12/06	FR DS
Mitsubishi	Pajero Pinin 2.0	01/99-12/06	FR DS
Mitsubishi	RVR 1.8	01/92-12/00	FR PS
Mitsubishi	RVR 1.8	01/92-12/00	FR PS
Mitsubishi	Shogun Pinin 1.8 GDI (1999-2006)	09/00-12/05	FR DS
Mitsubishi	Shogun Pinin 1.8 GDI (1999-2006)	09/00-12/05	FR DS
Mitsubishi	Shogun Pinin 1.8 GDI (1999-2006)	12/99-12/06	FR DS
Mitsubishi	Shogun Pinin 1.8 GDI (1999-2006)	12/99-12/06	FR DS
Mitsubishi	Shogun Pinin 1.8 MPI (1999-2006)	09/00-12/05	FR DS
Mitsubishi	Shogun Pinin 1.8 MPI (1999-2006)	09/00-12/05	FR DS
Mitsubishi	Shogun Pinin 1.8 MPI (1999-2006)	12/99-12/06	FR DS
Mitsubishi	Shogun Pinin 1.8 MPI (1999-2006)	12/99-12/06	FR DS
Mitsubishi	Shogun Pinin 1.8 MPI (1999-2006)	12/99-12/06	FR DS
Mitsubishi	Shogun Pinin 1.8 MPI (1999-2006)	12/99-12/06	FR DS
Mitsubishi	Shogun Pinin 1.8 MPI (1999-2006)	12/99-12/06	FR DS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/05	FR DS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/05	FR DS

Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/05	FR DS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/05	FR DS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/06	FR DS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/06	FR DS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/06	FR DS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/06	FR DS
Mitsubishi	Space Runner 1.8 (1991-2000)	08/96-12/00	FR PS
Mitsubishi	Space Runner 1.8 (1991-2000)	08/96-12/00	FR PS
Mitsubishi	Space Runner 1.8 (1991-2000)	10/91-08/96	FR PS
Mitsubishi	Space Runner 1.8 (1991-2000)	10/91-08/96	FR PS
Mitsubishi	Space Star 1.3 (1998-2002)	12/98-08/02	FR PS
Mitsubishi	Space Star 1.3 (1998-2002)	12/98-08/02	FR PS
Mitsubishi	Space Star 1.3 (1998-2002)	12/98-08/02	FR PS
Mitsubishi	Space Star 1.3 (2002-2006)	07/02-12/06	FR PS
Mitsubishi	Space Star 1.3 (2002-2006)	07/02-12/06	FR PS
Mitsubishi	Space Star 1.3 (2002-2006)	07/02-12/06	FR PS
Mitsubishi	Space Star 1.6 (1998-2002)	04/01-08/02	FR PS
Mitsubishi	Space Star 1.6 (1998-2002)	04/01-08/02	FR PS
Mitsubishi	Space Star 1.6 (2002-2006)	07/02-12/06	FR PS
Mitsubishi	Space Star 1.6 (2002-2006)	07/02-12/06	FR PS
Mitsubishi	Space Star 1.8 (1998-2002)	12/98-08/02	FR PS
Mitsubishi	Space Star 1.8 (1998-2002)	12/98-08/02	FR PS
Mitsubishi	Space Star 1.8 (2002-2006)	11/03-07/05	FR PS
Mitsubishi	Space Star 1.9 DI-D (2002-2006)	07/02-12/06	FR PS
Mitsubishi	Space Star 1.9 DI-D (2002-2006)	07/02-12/06	FR PS
Mitsubishi	Space Star 1.9 DI-D S (2002-2006)	11/03-12/06	FR PS
Mitsubishi	Space Star 1.9 DI-D S (2002-2006)	11/03-12/06	FR PS
Mitsubishi	Space Star 1.9 DI-D S (2002-2006)	11/03-12/06	FR PS
Mitsubishi	Space Wagon 1.8 (1991-1998)	10/91-12/92	FR PS
Mitsubishi	Space Wagon 1.8 (1991-1998)	10/91-12/92	FR PS
Mitsubishi	Space Wagon 2.0 (1991-1998)	01/95-03/96	FR PS
Mitsubishi	Space Wagon 2.0 (1991-1998)	01/95-03/96	FR PS
Mitsubishi	Space Wagon 2.0 (1991-1998)	08/92-11/98	FR PS
Mitsubishi	Space Wagon 2.0 (1991-1998)	08/92-11/98	FR PS
Nissan	200SX 2.0 S14	09/94-07/01	RR
Nissan	200SX 2.0 S14	09/94-07/01	RR
Nissan	350Z 3.5 Gran Turismo 4 Z33	02/05-12/05	FR PS
Nissan	350Z 3.5 Roadster Z33	01/05-12/05	FR PS
Nissan	350Z 3.5 Roadster Z33	05/07-12/09	FR PS
Nissan	350Z 3.5 Roadster Z33	05/07-12/09	FR PS
Nissan	350Z 3.5 Roadster Z33	12/05-09/07	FR PS
Nissan	350Z 3.5 Z33	05/07-12/09	FR PS
Nissan	350Z 3.5 Z33	05/07-12/09	FR PS
Nissan	350Z 3.5 Z33	09/03-12/05	FR PS
Nissan	350Z 3.5 Z33	12/05-09/07	FR PS
Nissan	Bluebird 1.6 M910	05/80-12/82	FR DS
Nissan	Bluebird 1.6 M910	05/80-12/82	FR PS
Nissan	Bluebird 1.8 180B M910	05/80-05/84	FR PS
Nissan	Bluebird 1.8 180B M910	05/80-05/84	FR DS
Nissan	Bluebird 1.8 180B M910	05/80-12/82	FR PS

Nissan	Bluebird 1.8 180B M910	05/80-12/82	FR DS
Nissan	Bluebird 1.8 180B M910	12/81-05/84	FR DS
Nissan	Bluebird 1.8 180B M910	12/81-05/84	FR PS
Nissan	Bluebird 1.8 180B MJ910	05/80-05/84	FR DS
Nissan	Bluebird 1.8 180B MJ910	05/80-05/84	FR PS
Nissan	Bluebird 1.8 180B MJ910	05/80-12/82	FR PS
Nissan	Bluebird 1.8 180B MJ910	05/80-12/82	FR DS
Nissan	Bluebird 1.8 180B MJ910	12/81-05/84	FR DS
Nissan	Bluebird 1.8 180B MJ910	12/81-05/84	FR PS
Nissan	Cabstar 2.0 F22	01/85-02/93	FR DS
Nissan	Cabstar 2.0 F22	01/85-02/93	FR PS
Nissan	Cabstar 2.3 F22	05/87-03/90	FR DS
Nissan	Cabstar 2.3 F22	05/87-03/90	FR PS
Nissan	Cabstar 2.5 F22	06/89-03/93	FR PS
Nissan	Cabstar 2.5 F22	06/89-03/93	FR DS
Nissan	Cabstar 2.7 E90	10/00-04/04	FR DS
Nissan	Cabstar 2.7 E90	10/00-04/04	FR PS
Nissan	Cabstar 3.0 (2004-2007)	03/04-02/07	FR DS
Nissan	Cabstar 3.0 (2004-2007)	03/04-02/07	FR PS
Nissan	Cabstar 3.0 (2004-2007)	03/04-02/07	FR DS
Nissan	Cabstar 3.0 (2004-2007)	03/04-02/07	FR PS
Nissan	Cabstar 3.0 E110	10/00-04/04	FR DS
Nissan	Cabstar 3.0 E110	10/00-04/04	FR PS
Nissan	March 1.0 K11	01/93-12/02	FR PS
Nissan	March 1.0 K11	01/93-12/02	FR PS
Nissan	March 1.0 K11	01/93-12/02	FR PS
Nissan	March 1.0 K11	01/93-12/02	FR PS
Nissan	March 1.3 K11	01/93-12/99	FR PS
Nissan	March 1.3 K11	01/93-12/99	FR PS
Nissan	March 1.3 K11	01/93-12/99	FR PS
Nissan	March 1.3 K11	01/93-12/99	FR PS
Nissan	Micra 1.0 K10	06/83-01/91	FR DS
Nissan	Micra 1.0 K10	06/83-01/91	FR DS
Nissan	Micra 1.0 K10	06/83-01/91	RR
Nissan	Micra 1.0 K10	06/83-01/91	RR
Nissan	Micra 1.0 K10	06/83-01/91	FR PS
Nissan	Micra 1.0 K10	06/83-01/91	FR PS
Nissan	Micra 1.0 K10	06/83-12/92	FR PS
Nissan	Micra 1.0 K10	06/83-12/92	FR DS
Nissan	Micra 1.0 K10	06/83-12/92	FR DS
Nissan	Micra 1.0 K10	06/83-12/92	FR DS
Nissan	Micra 1.0 K10	06/83-12/92	FR PS
Nissan	Micra 1.0 K10	06/83-12/92	FR PS
Nissan	Micra 1.0 K10	06/83-12/92	FR DS
Nissan	Micra 1.0 K10	06/83-12/92	RR
Nissan	Micra 1.0 K10	06/83-12/92	FR PS
Nissan	Micra 1.0 K10	06/83-12/92	RR
Nissan	Micra 1.0 K10	06/83-12/92	RR
Nissan	Micra 1.0 K10	06/83-12/92	RR
Nissan	Micra 1.0 K11	01/93-04/98	FR PS

Nissan	Micra 1.0 K11	01/93-04/98	FR PS
Nissan	Micra 1.0 K11	01/93-04/98	FR PS
Nissan	Micra 1.0 K11	01/93-04/98	FR PS
Nissan	Micra 1.0 K11	04/98-07/00	FR PS
Nissan	Micra 1.0 K11	04/98-07/00	FR PS
Nissan	Micra 1.0 K11	04/98-07/00	FR PS
Nissan	Micra 1.0 K11	04/98-07/00	FR PS
Nissan	Micra 1.0 K11	07/00-12/03	FR PS
Nissan	Micra 1.0 K11	07/00-12/03	FR PS
Nissan	Micra 1.0 K11	07/00-12/03	FR PS
Nissan	Micra 1.0 K11	07/00-12/03	FR PS
Nissan	Micra 1.0 K12	10/02-09/05	FR PS
Nissan	Micra 1.0 K12	10/02-09/05	FR PS
Nissan	Micra 1.0 K12	10/02-09/05	FR PS
Nissan	Micra 1.0 K12	10/02-09/05	FR PS
Nissan	Micra 1.2 K10	03/89-12/92	FR PS
Nissan	Micra 1.2 K10	03/89-12/92	RR
Nissan	Micra 1.2 K10	03/89-12/92	FR DS
Nissan	Micra 1.2 K10	03/89-12/92	FR PS
Nissan	Micra 1.2 K10	03/89-12/92	FR DS
Nissan	Micra 1.2 K10	03/89-12/92	FR DS
Nissan	Micra 1.2 K10	03/89-12/92	RR
Nissan	Micra 1.2 K10	03/89-12/92	RR
Nissan	Micra 1.2 K10	03/89-12/92	FR DS
Nissan	Micra 1.2 K10	03/89-12/92	RR
Nissan	Micra 1.2 K10	03/89-12/92	FR PS
Nissan	Micra 1.2 K10	03/89-12/92	FR PS
Nissan	Micra 1.2 K12	06/05-06/10	FR PS
Nissan	Micra 1.2 K12	06/05-06/10	FR PS
Nissan	Micra 1.2 K12	10/02-04/08	FR PS
Nissan	Micra 1.2 K12	10/02-04/08	FR PS
Nissan	Micra 1.2 K12	10/02-04/11	FR PS
Nissan	Micra 1.2 K12	10/02-04/11	FR PS
Nissan	Micra 1.3 K11	01/93-04/98	FR PS
Nissan	Micra 1.3 K11	01/93-04/98	FR PS
Nissan	Micra 1.3 K11	01/93-04/98	FR PS
Nissan	Micra 1.3 K11	01/93-04/98	FR PS
Nissan	Micra 1.3 K11	04/98-07/00	FR PS
Nissan	Micra 1.3 K11	04/98-07/00	FR PS
Nissan	Micra 1.3 K11	04/98-07/00	FR PS
Nissan	Micra 1.3 K11	04/98-07/00	FR PS
Nissan	Micra 1.4 K11	07/00-12/03	FR PS
Nissan	Micra 1.4 K11	07/00-12/03	FR PS
Nissan	Micra 1.4 K11	07/00-12/03	FR PS
Nissan	Micra 1.4 K11	07/00-12/03	FR PS
Nissan	Micra 1.4 K12	10/02-04/08	FR PS
Nissan	Micra 1.4 K12	10/02-04/08	FR PS
Nissan	Micra 1.4 K12	10/02-12/10	FR PS
Nissan	Micra 1.4 K12	10/02-12/10	FR PS
Nissan	Micra 1.5 dCi 65 K12	04/03-08/06	FR PS

Nissan	Micra 1.5 dCi 65 K12	04/03-08/06	FR PS
Nissan	Micra 1.5 dCi 82 K12	08/03-08/06	FR PS
Nissan	Micra 1.5 dCi 82 K12	08/03-08/06	FR PS
Nissan	Micra 1.5 dCi 86 K12	08/06-04/11	FR PS
Nissan	Micra 1.5 dCi 86 K12	08/06-04/11	FR PS
Nissan	Micra 1.6 K12	07/05-12/09	FR PS
Nissan	Micra 1.6 K12	07/05-12/09	FR PS
Nissan	Micra C+C 1.4 K12	09/05-12/09	FR PS
Nissan	Micra C+C 1.6 K12	09/05-12/09	FR PS
Nissan	Micra C+C 1.6 K12	09/05-12/09	FR PS
Nissan	Prairie 1.5 BM10	06/83-09/87	FR DS
Nissan	Prairie 1.5 BM10	06/83-09/87	FR PS
Nissan	Prairie 1.8 PM10	05/84-04/89	FR PS
Nissan	Prairie 1.8 PM10	05/84-04/89	FR DS
Nissan	Silvia 2.0 S15	01/99-12/03	FR PS
Nissan	Silvia 2.0 S15	01/99-12/03	FR PS
Nissan	Silvia 2.0 S15	01/99-12/03	FR DS
Nissan	Silvia 2.0 S15	01/99-12/03	FR DS
Nissan	Silvia 2.0 Turbo S15	01/99-12/03	FR DS
Nissan	Silvia 2.0 Turbo S15	01/99-12/03	FR PS
Nissan	Silvia 2.0 Turbo S15	01/99-12/03	FR PS
Nissan	Silvia 2.0 Turbo S15	01/99-12/03	FR DS
Nissan	Skyline 2.0 GTS R32	05/89-07/93	FR DS
Nissan	Skyline 2.0 GTS R32	05/89-07/93	FR PS
Nissan	Skyline 2.0 GTS R32	05/89-07/93	FR PS
Nissan	Skyline 2.0 GTS R32	05/89-07/93	FR DS
Nissan	Skyline 2.0 GTS-4 R32	05/89-07/93	FR PS
Nissan	Skyline 2.0 GTS-4 R32	05/89-07/93	FR DS
Nissan	Skyline 2.0 GTS-4 R32	05/89-12/94	FR PS
Nissan	Skyline 2.0 GTS-4 R32	05/89-12/94	FR DS
Nissan	Skyline 2.0 GTS-T R32	05/89-07/93	FR DS
Nissan	Skyline 2.0 GTS-T R32	05/89-07/93	FR PS
Nissan	Skyline 2.0 GTS-T R32	05/89-07/93	FR DS
Nissan	Skyline 2.0 GTS-T R32	05/89-07/93	FR PS
Nissan	Skyline 2.0 GTS-T R32	05/89-12/94	FR PS
Nissan	Skyline 2.0 GTS-T R32	05/89-12/94	FR DS
Nissan	Skyline 2.0 GTS-T R32	05/89-12/94	FR PS
Nissan	Skyline 2.0 GTS-T R32	05/89-12/94	FR DS
Nissan	Skyline 2.5 GTS-25 R32	08/91-08/93	FR DS
Nissan	Skyline 2.5 GTS-25 R32	08/91-08/93	FR PS
Nissan	Skyline 2.5 GTS-25 R32	08/91-08/93	FR PS
Nissan	Skyline 2.5 GTS-25 R32	08/91-08/93	FR DS
Nissan	Stanza 1.6 T11	01/82-03/86	RR
Nissan	Stanza 1.6 T11	01/82-03/86	FR DS
Nissan	Stanza 1.6 T11	01/82-03/86	FR PS
Nissan	Stanza 1.6 T11	01/82-04/85	FR DS
Nissan	Stanza 1.6 T11	01/82-04/85	FR PS
Nissan	Stanza 1.6 T11	01/82-07/84	RR
Nissan	Stanza 1.6 T11	01/82-07/84	FR DS
Nissan	Stanza 1.6 T11	01/82-07/84	FR PS

Nissan	Stanza 1.8 T11	01/82-03/86	FR DS
Nissan	Stanza 1.8 T11	01/82-03/86	RR
Nissan	Stanza 1.8 T11	01/82-03/86	FR DS
Nissan	Stanza 1.8 T11	01/82-03/86	RR
Nissan	Stanza 1.8 T11	01/82-03/86	FR PS
Nissan	Stanza 1.8 T11	01/82-03/86	RR
Nissan	Stanza 1.8 T11	01/82-03/86	RR
Nissan	Stanza 1.8 T11	01/82-03/86	FR PS
Nissan	Stanza 1.8 T11	01/82-03/86	FR DS
Nissan	Stanza 1.8 T11	01/82-03/86	FR DS
Nissan	Stanza 1.8 T11	01/82-03/86	FR PS
Nissan	Stanza 1.8 T11	01/82-03/86	FR PS
Nissan	Sunny 1.3 B11	05/82-09/86	FR DS
Nissan	Sunny 1.3 B11	05/82-09/86	FR DS
Nissan	Sunny 1.3 B11	05/82-09/86	FR PS
Nissan	Sunny 1.3 B11	05/82-09/86	FR PS
Nissan	Sunny 1.3 N13	09/86-03/89	RR
Nissan	Sunny 1.3 N13	09/86-03/89	RR
Nissan	Sunny 1.3 N13	09/86-08/88	RR
Nissan	Sunny 1.3 N13	09/86-08/88	RR
Nissan	Sunny 1.5 B11	05/82-09/86	FR DS
Nissan	Sunny 1.5 B11	05/82-09/86	FR PS
Nissan	Sunny 1.5 B11	05/82-09/86	FR PS
Nissan	Sunny 1.5 B11	09/82-09/86	FR DS
Nissan	Sunny 1.5 B11	09/82-09/86	FR PS
Nissan	Sunny 1.5 B11	09/82-09/86	FR DS
Nissan	Sunny 1.5 B11	09/82-09/86	FR PS
Nissan	Sunny 1.6 B12	02/88-03/89	RR
Nissan	Sunny 1.6 B12	02/88-03/89	RR
Nissan	Sunny 1.6 B12	02/88-03/89	RR
Nissan	Sunny 1.6 B12	09/86-02/88	RR
Nissan	Sunny 1.6 B12	09/86-03/89	RR
Nissan	Sunny 1.6 N13	09/86-02/88	RR
Nissan	Sunny 1.6 N13	09/86-02/88	RR
Nissan	Sunny 1.6 N13	09/86-02/88	RR
Nissan	Sunny 1.6 N13	09/86-02/88	RR
Nissan	Sunny 1.6 N14	02/91-12/91	RR
Nissan	Sunny 1.6 N14	02/91-12/91	RR
Nissan	Sunny 1.6 N14	02/91-12/91	RR
Nissan	Sunny 1.6 N14	02/91-12/91	RR
Nissan	Sunny 1.6 Y10	02/91-12/91	RR
Nissan	Sunny 1.7 N13	09/86-12/88	RR
Nissan	Sunny 1.7 N13	09/86-12/91	RR
Nissan	Sunny 1.8 ZX B12	03/89-12/91	RR
Nissan	Tino 1.8 V10	03/03-03/06	FR PS
Nissan	Tino 1.8 V10	07/00-03/06	FR PS
Nissan	Tino 2.0 V10	07/00-05/03	FR PS
Nissan	Tino 2.2 dCi V10	05/03-03/06	FR PS
Nissan	Tino 2.2 dCi V10	05/03-03/06	FR PS
Nissan	Tino 2.2 V10	07/00-05/03	FR PS

Nissan	Urvan E24 2.0	06/87-10/93	FR DS
Nissan	Urvan E24 2.0	06/87-10/93	FR PS
Nissan	Urvan E24 2.0	06/87-10/93	FR DS
Nissan	Urvan E24 2.0	06/87-10/93	FR PS
Nissan	Vanette 1.5	02/86-06/95	FR PS
Nissan	Vanette 1.5	02/86-06/95	FR DS
Nissan	Vanette 1.5	02/86-06/95	FR DS
Nissan	Vanette 1.5	02/86-06/95	FR PS
Nissan	Vanette 2.0	02/86-01/96	FR DS
Nissan	Vanette 2.0	02/86-01/96	FR PS
Nissan	Vanette 2.0	02/86-01/96	FR DS
Nissan	Vanette 2.0	02/86-01/96	FR PS
Nissan	Vanette 2.3 E	05/98-12/02	FR PS
Nissan	Vanette 2.3 E	05/98-12/02	FR DS
Nissan	Vanette Cargo 2.3	06/95-12/02	FR DS
Nissan	Vanette Cargo 2.3	06/95-12/02	FR PS
Opel	Ascona B 1.6 (1975-1981)	01/80-10/80	FR DS
Opel	Ascona B 1.6 (1975-1981)	01/80-10/80	FR DS
Opel	Ascona B 1.6 (1975-1981)	01/80-10/80	FR PS
Opel	Ascona B 1.6 (1975-1981)	01/80-10/80	FR PS
Opel	Ascona B 2.0 (1975-1981)	01/80-10/80	FR DS
Opel	Ascona B 2.0 (1975-1981)	01/80-10/80	FR PS
Opel	Ascona B 2.0 (1975-1981)	01/80-10/80	FR DS
Opel	Ascona B 2.0 (1975-1981)	01/80-10/80	FR PS
Opel	Astra F 1.4 MK 3 (1991-1998)	02/96-12/98	FR PS
Opel	Astra F 1.4 MK 3 (1991-1998)	02/96-12/98	FR PS
Opel	Astra F 1.4 MK 3 (1991-1998)	02/96-12/98	FR PS
Opel	Astra F 1.4 MK 3 (1991-1998)	02/96-12/98	FR DS
Opel	Astra F 1.4 MK 3 (1991-1998)	02/96-12/98	FR DS
Opel	Astra F 1.4 MK 3 (1991-1998)	02/96-12/98	FR PS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR DS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 MPi MK 3 (1991-1998)	10/91-12/98	FR DS
Opel	Astra F 1.4 SPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 SPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 SPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 SPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 SPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 SPi MK 3 (1991-1998)	10/91-12/98	FR DS
Opel	Astra F 1.4 SPi MK 3 (1991-1998)	10/91-12/98	FR PS
Opel	Astra F 1.4 SPi MK 3 (1991-1998)	10/91-12/98	FR DS
Opel	Astra F 1.6 E-Drive MK 3 (1991-1998)	03/93-01/96	FR PS
Opel	Astra F 1.6 E-Drive MK 3 (1991-1998)	03/93-01/96	FR PS
Opel	Astra F 1.6 E-Drive MK 3 (1991-1998)	03/93-01/96	FR DS
Opel	Astra F 1.6 E-Drive MK 3 (1991-1998)	03/93-01/96	FR PS

Opel	Astra F 1.7 D MK 3 (1991-1998)	10/91-12/94	FR PS
Opel	Astra F 1.7 D MK 3 (1991-1998)	10/91-12/94	FR DS
Opel	Astra F 1.7 D MK 3 (1991-1998)	10/91-12/94	FR DS
Opel	Astra F 1.7 D MK 3 (1991-1998)	10/91-12/94	FR PS
Opel	Astra F 1.7 D MK 3 (1991-1998)	10/91-12/94	FR PS
Opel	Astra F 1.7 D MK 3 (1991-1998)	10/91-12/94	FR PS
Opel	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR PS
Opel	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR PS
Opel	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR PS
Opel	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR DS
Opel	Astra F 1.7 TD/TDS (Isuzu) MK 3 (1991-1998)	04/92-12/98	FR PS
Opel	Astra F 1.7 TD/TDS (Isuzu) MK 3 (1991-1998)	04/92-12/98	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	06/93-12/94	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	06/93-12/94	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	06/93-12/94	FR DS
Opel	Astra F 1.8 MK 3 (1991-1998)	06/93-12/94	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR DS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR DS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR PS
Opel	Astra F 1.8 MK 3 (1991-1998)	08/94-07/96	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR DS
Opel	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR DS
Opel	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	10/91-04/95	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR PS
Opel	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR DS
Opel	Corsa B 1.0 (1993-2000)	04/97-12/00	FR PS
Opel	Corsa B 1.0 (1993-2000)	04/97-12/00	FR PS
Opel	Corsa B 1.0 (1993-2000)	04/97-12/00	FR DS
Opel	Corsa B 1.0 (1993-2000)	04/97-12/00	FR DS
Opel	Corsa B 1.2 (1993-2000)	04/93-08/94	FR DS
Opel	Corsa B 1.2 (1993-2000)	04/93-08/94	FR PS
Opel	Corsa B 1.2 (1993-2000)	04/93-08/94	FR PS
Opel	Corsa B 1.2 (1993-2000)	04/93-08/94	FR DS
Opel	Corsa B 1.2 (1993-2000)	04/93-08/94	FR DS
Opel	Corsa B 1.2 (1993-2000)	04/93-08/94	FR PS
Opel	Corsa B 1.2 (1993-2000)	04/93-08/94	FR DS
Opel	Corsa B 1.2 (1993-2000)	04/93-08/94	FR PS
Opel	Corsa B 1.2 (1993-2000)	08/94-12/98	FR DS

Opel	Corsa B 1.5 Turbo (1993-2000)	04/93-12/00	FR DS
Opel	Corsa B 1.5 Turbo (1993-2000)	04/93-12/00	FR PS
Opel	Corsa B 1.5 Turbo (1993-2000)	04/93-12/00	FR PS
Opel	Corsa B 1.5 Turbo (1993-2000)	04/93-12/00	FR PS
Opel	Corsa B 1.5 Turbo (1993-2000)	04/93-12/00	FR DS
Opel	Corsa B 1.6 (1993-2000)	08/93-08/94	FR PS
Opel	Corsa B 1.6 (1993-2000)	08/93-08/94	FR DS
Opel	Corsa B 1.6 (1993-2000)	08/94-12/00	FR PS
Opel	Corsa B 1.6 (1993-2000)	08/94-12/00	FR DS
Opel	Corsa B 1.7 (1993-2000)	02/96-12/00	FR DS
Opel	Corsa B 1.7 (1993-2000)	02/96-12/00	FR PS
Opel	Corsa B 1.7 (1993-2000)	02/96-12/00	FR DS
Opel	Corsa B 1.7 (1993-2000)	02/96-12/00	FR PS
Opel	Corsa B 1.7 (1993-2000)	02/96-12/00	FR DS
Opel	Corsa B 1.7 (1993-2000)	02/96-12/00	FR PS
Opel	Corsa B 1.7 (1993-2000)	02/96-12/00	FR DS
Opel	Corsa B 1.7 (1993-2000)	02/96-12/00	FR PS
Opel	Insignia 1.4 (2008-2014)	06/11-12/14	FR PS
Opel	Insignia 1.4 (2008-2014)	06/11-12/14	FR PS
Opel	Insignia 1.4 (2008-2014)	06/11-12/14	FR PS
Opel	Insignia 1.4 (2013-2017)	08/13-12/17	FR PS
Opel	Insignia 1.4 (2013-2017)	08/13-12/17	FR PS
Opel	Insignia 1.4 (2013-2017)	11/15-12/17	FR PS
Opel	Insignia 1.4 (2013-2017)	12/14-12/17	FR PS
Opel	Insignia 1.4 (2013-2017)	12/14-12/17	FR PS
Opel	Insignia 1.4 Dual Fuel (2008-2014)	06/12-12/14	FR PS
Opel	Insignia 1.4 Dual Fuel (2008-2014)	06/12-12/14	FR PS
Opel	Insignia 1.4 Dual Fuel (2008-2014)	06/12-12/14	FR PS
Opel	Insignia 1.6 (2008-2014)	01/09-12/14	FR PS
Opel	Insignia 1.6 (2008-2014)	01/09-12/14	FR PS
Opel	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Opel	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Opel	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Opel	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Opel	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Opel	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Opel	Insignia 1.6 SIDI (2013-2017)	08/13-03/16	FR PS
Opel	Insignia 1.6 SIDI (2013-2017)	08/13-03/16	FR PS
Opel	Insignia 1.6 SIDI (2013-2017)	08/13-03/16	FR PS
Opel	Insignia 1.6 SIDI (2013-2017)	08/13-03/16	FR PS
Opel	Insignia 1.6 T (2008-2014)	02/09-12/14	FR PS
Opel	Insignia 1.6 T (2008-2014)	02/09-12/14	FR PS
Opel	Insignia 1.6 T (2008-2014)	02/09-12/14	FR PS
Opel	Insignia 1.8 (2008-2014)	11/08-12/13	FR PS
Opel	Insignia 1.8 (2008-2014)	11/08-12/14	FR PS
Opel	Insignia 1.8 (2008-2014)	11/08-12/14	FR PS
Opel	Insignia 1.8 (2013-2017)	04/15-12/17	FR PS
Opel	Insignia 1.8 (2013-2017)	08/13-12/17	FR PS
Opel	Insignia 2.0 (2013-2017)	08/13-12/17	FR PS
Opel	Insignia 2.0 (2013-2017)	08/13-12/17	FR PS

Opel	Midi 2.0	09/88-05/90	FR PS
Opel	Midi 2.0	09/88-05/90	FR DS
Opel	Senator A 2.5 (1980-1984)	01/83-12/84	FR PS
Opel	Senator A 2.5 (1980-1984)	01/83-12/84	FR DS
Opel	Senator A 2.5 (1980-1984)	01/83-12/84	FR DS
Opel	Senator A 2.5 (1980-1984)	01/83-12/84	FR PS
Opel	Senator A 2.5 (1984-1987)	10/84-12/87	FR DS
Opel	Senator A 2.5 (1984-1987)	10/84-12/87	FR PS
Opel	Senator A 2.5 (1984-1987)	10/84-12/87	FR DS
Opel	Senator A 2.5 (1984-1987)	10/84-12/87	FR PS
Opel	Senator A 2.8 (1980-1984)	01/80-12/80	FR PS
Opel	Senator A 2.8 (1980-1984)	01/80-12/80	FR PS
Opel	Senator A 2.8 (1980-1984)	01/80-12/80	FR DS
Opel	Senator A 2.8 (1980-1984)	01/80-12/80	FR DS
Opel	Senator A 3.0 (1984-1987)	10/84-12/87	FR DS
Opel	Senator A 3.0 (1984-1987)	10/84-12/87	FR DS
Opel	Senator A 3.0 (1984-1987)	10/84-12/87	FR PS
Opel	Senator A 3.0 (1984-1987)	10/84-12/87	FR PS
Opel	Senator A 3.0 Carburettor (1980-1984)	01/80-07/83	FR PS
Opel	Senator A 3.0 Carburettor (1980-1984)	01/80-07/83	FR PS
Opel	Senator A 3.0 Carburettor (1980-1984)	01/80-07/83	FR DS
Opel	Senator A 3.0 Carburettor (1980-1984)	01/80-07/83	FR DS
Opel	Senator A 3.0 Injection (1980-1984)	01/80-12/84	FR DS
Opel	Senator A 3.0 Injection (1980-1984)	01/80-12/84	FR PS
Peugeot	1007 1.4 (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.4 (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.4 (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.4 (2005-2009)	12/05-12/07	FR PS
Peugeot	1007 1.4 HDi (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.4 HDi (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.4 HDi (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.4 HDi (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.4 HDi (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.4 HDi (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.6 (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.6 (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.6 (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.6 (2005-2009)	07/05-03/09	FR PS
Peugeot	1007 1.6 (2005-2009)	07/06-03/09	FR PS
Peugeot	1007 1.6 HDi 110 (2005-2009)	08/07-03/09	FR PS
Peugeot	1007 1.6 HDi 110 (2005-2009)	08/07-03/09	FR PS
Peugeot	1007 1.6 HDi 110 (2005-2009)	08/07-03/09	FR PS
Peugeot	106 1.0 (1991-1996)	09/91-12/92	FR PS
Peugeot	106 1.0 (1991-1996)	12/92-06/96	FR PS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.1 Carburettor (1991-1996)	09/91-08/92	FR PS
Peugeot	106 1.1 Carburettor (1991-1996)	09/91-08/92	FR PS
Peugeot	106 1.1 Carburettor (1991-1996)	09/91-08/92	FR PS

Peugeot	106 1.1 Carburettor (1991-1996)	09/91-08/92	FR PS
Peugeot	106 1.1 Injection (1991-1996)	09/91-06/96	FR PS
Peugeot	106 1.1 Injection (1991-1996)	09/91-06/96	FR PS
Peugeot	106 1.1 Injection (1991-1996)	09/91-06/96	FR PS
Peugeot	106 1.1 Injection (1991-1996)	09/91-06/96	FR PS
Peugeot	106 1.3 (1991-1996)	01/94-06/96	FR PS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR PS
Peugeot	106 1.4 Carburettor (1991-1996)	09/91-08/92	FR PS
Peugeot	106 1.4 Carburettor (1991-1996)	09/91-08/92	FR PS
Peugeot	106 1.4 Carburettor (1991-1996)	09/91-08/92	FR PS
Peugeot	106 1.4 Carburettor (1991-1996)	09/91-08/92	FR PS
Peugeot	106 1.4 Injection (1991-1996)	09/91-06/96	FR PS
Peugeot	106 1.4 Injection (1991-1996)	09/91-06/96	FR PS
Peugeot	106 1.4 Injection (1991-1996)	09/91-06/96	FR PS
Peugeot	106 1.4 Injection (1991-1996)	09/91-06/96	FR PS
Peugeot	106 1.4 XSi (1991-1996)	09/91-07/94	FR PS
Peugeot	106 1.5 (1991-1996)	06/94-06/96	FR PS
Peugeot	106 1.5 (1991-1996)	06/94-06/96	FR PS
Peugeot	106 1.5 (1991-1996)	06/94-06/96	FR PS
Peugeot	106 1.5 (1991-1996)	06/94-06/96	FR PS
Peugeot	106 1.5 (1996-2003)	06/96-05/99	FR PS
Peugeot	106 1.5 (1996-2003)	06/96-05/99	FR PS
Peugeot	106 1.5 (1996-2003)	06/96-05/99	FR PS
Peugeot	106 1.5 (1996-2003)	06/96-10/00	FR PS
Peugeot	106 1.5 (1996-2003)	06/96-10/00	FR PS
Peugeot	106 1.5 (1996-2003)	06/96-10/00	FR PS
Peugeot	106 1.5 (1996-2003)	06/96-10/00	FR PS
Peugeot	106 1.5 (1996-2003)	10/00-03/03	FR PS
Peugeot	106 1.5 (1996-2003)	10/00-03/03	FR PS
Peugeot	106 1.5 (1996-2003)	10/00-03/03	FR PS
Peugeot	106 1.5 (1996-2003)	10/00-03/03	FR PS
Peugeot	106 1.6 (1991-1996)	08/94-06/96	FR PS
Peugeot	106 1.6 (1991-1996)	08/94-06/96	FR PS
Peugeot	106 1.6 (1996-2003)	06/96-05/99	FR PS
Peugeot	106 1.6 (1996-2003)	06/96-05/99	FR PS
Peugeot	106 1.6 (1996-2003)	06/96-05/99	FR PS
Peugeot	106 1.6 (1996-2003)	06/96-05/99	FR PS
Peugeot	106 1.6 GTi (1996-2003)	01/97-03/03	FR PS
Peugeot	106 1.6 GTi (1996-2003)	01/97-03/03	FR PS
Peugeot	205 1.0 (1983-1997)	10/83-12/91	RR
Peugeot	205 1.0 (1983-1997)	10/83-12/91	RR
Peugeot	205 1.0 (1983-1997)	10/83-12/91	FR PS
Peugeot	205 1.0 (1983-1997)	10/83-12/91	FR DS

Peugeot	205 1.0 (1983-1997)	10/83-12/91	FR DS
Peugeot	205 1.0 (1983-1997)	10/83-12/91	FR PS
Peugeot	205 1.1 (1983-1997)	01/88-04/90	RR
Peugeot	205 1.1 (1983-1997)	01/88-04/90	FR DS
Peugeot	205 1.1 (1983-1997)	01/88-04/90	RR
Peugeot	205 1.1 (1983-1997)	01/88-04/90	FR DS
Peugeot	205 1.1 (1983-1997)	01/88-04/90	FR PS
Peugeot	205 1.1 (1983-1997)	01/88-04/90	FR PS
Peugeot	205 1.1 (1983-1997)	01/88-12/92	FR DS
Peugeot	205 1.1 (1983-1997)	01/88-12/92	FR DS
Peugeot	205 1.1 (1983-1997)	01/88-12/92	RR
Peugeot	205 1.1 (1983-1997)	01/88-12/92	FR PS
Peugeot	205 1.1 (1983-1997)	01/88-12/92	FR PS
Peugeot	205 1.1 (1983-1997)	01/88-12/92	RR
Peugeot	205 1.1 (1983-1997)	05/85-11/87	FR PS
Peugeot	205 1.1 (1983-1997)	05/85-11/87	FR DS
Peugeot	205 1.1 (1983-1997)	05/85-11/87	FR DS
Peugeot	205 1.1 (1983-1997)	05/85-11/87	FR PS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	FR DS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	FR PS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	RR
Peugeot	205 1.1 (1983-1997)	10/83-01/88	RR
Peugeot	205 1.1 (1983-1997)	10/83-01/88	FR DS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	FR DS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	RR
Peugeot	205 1.1 (1983-1997)	10/83-01/88	FR PS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	FR PS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	FR DS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	FR PS
Peugeot	205 1.1 (1983-1997)	10/83-01/88	RR
Peugeot	205 1.1 (1983-1997)	11/87-04/90	FR PS
Peugeot	205 1.1 (1983-1997)	11/87-04/90	FR DS
Peugeot	205 1.1 (1983-1997)	11/87-12/93	FR DS
Peugeot	205 1.1 (1983-1997)	11/87-12/93	FR PS
Peugeot	205 1.1 Injection (1983-1997)	08/91-02/96	RR
Peugeot	205 1.1 Injection (1983-1997)	08/91-02/96	FR DS
Peugeot	205 1.1 Injection (1983-1997)	08/91-02/96	RR
Peugeot	205 1.1 Injection (1983-1997)	08/91-02/96	FR DS
Peugeot	205 1.1 Injection (1983-1997)	08/91-02/96	FR PS
Peugeot	205 1.1 Injection (1983-1997)	08/91-02/96	FR PS
Peugeot	205 1.4 Carburettor (1983-1997)	05/88-10/91	FR DS
Peugeot	205 1.4 Carburettor (1983-1997)	05/88-10/91	FR PS
Peugeot	205 1.4 Catalyst (1983-1997)	10/91-10/94	FR DS
Peugeot	205 1.4 Catalyst (1983-1997)	10/91-10/94	FR PS
Peugeot	205 1.4 Catalyst (1983-1997)	10/91-10/94	FR DS
Peugeot	205 1.4 Catalyst (1983-1997)	10/91-10/94	RR
Peugeot	205 1.4 Catalyst (1983-1997)	10/91-10/94	FR DS
Peugeot	205 1.4 Catalyst (1983-1997)	10/91-10/94	FR DS
Peugeot	205 1.4 Catalyst (1983-1997)	10/91-10/94	RR
Peugeot	205 1.4 Catalyst (1983-1997)	10/91-10/94	RR

Peugeot	205 1.6 GTi (1983-1997)	12/87-12/92	FR PS
Peugeot	205 1.6 GTi (1983-1997)	12/87-12/92	FR DS
Peugeot	205 1.6 GTi (1983-1997)	12/87-12/92	RR
Peugeot	205 1.6 GTi (1983-1997)	12/87-12/92	RR
Peugeot	205 1.6 GTi (1983-1997)	12/87-12/92	FR PS
Peugeot	205 1.6 GTi (1983-1997)	12/87-12/92	FR DS
Peugeot	205 1.8 (1983-1997)	01/85-12/94	FR PS
Peugeot	205 1.8 (1983-1997)	01/85-12/94	RR
Peugeot	205 1.8 (1983-1997)	01/85-12/94	FR DS
Peugeot	205 1.8 (1983-1997)	10/83-09/96	RR
Peugeot	205 1.8 (1983-1997)	10/83-09/96	FR PS
Peugeot	205 1.8 (1983-1997)	10/83-09/96	FR DS
Peugeot	205 1.8 (1983-1997)	10/83-09/96	FR DS
Peugeot	205 1.8 (1983-1997)	10/83-09/96	FR PS
Peugeot	205 1.8 (1983-1997)	10/83-09/96	RR
Peugeot	205 1.8 Turbo (1983-1997)	12/90-02/96	FR DS
Peugeot	205 1.8 Turbo (1983-1997)	12/90-02/96	FR PS
Peugeot	205 1.8 Turbo (1983-1997)	12/90-02/96	RR
Peugeot	205 1.8 Turbo (1983-1997)	12/90-02/96	FR DS
Peugeot	205 1.8 Turbo (1983-1997)	12/90-02/96	RR
Peugeot	205 1.8 Turbo (1983-1997)	12/90-02/96	FR PS
Peugeot	205 1.9 CTi (Catalyst) (1983-1997)	03/92-07/94	FR DS
Peugeot	205 1.9 CTi (Catalyst) (1983-1997)	03/92-07/94	FR DS
Peugeot	205 1.9 CTi (Catalyst) (1983-1997)	03/92-07/94	FR PS
Peugeot	205 1.9 CTi (Catalyst) (1983-1997)	03/92-07/94	FR PS
Peugeot	205 1.9 CTi (Catalyst) (1983-1997)	03/92-07/94	FR PS
Peugeot	205 1.9 CTi (Catalyst) (1983-1997)	03/92-07/94	FR PS
Peugeot	205 1.9 CTi (Catalyst) (1983-1997)	03/92-07/94	FR DS
Peugeot	205 1.9 CTi (Catalyst) (1983-1997)	03/92-07/94	FR DS
Peugeot	205 1.9 GTi (1983-1997)	01/87-12/92	RR
Peugeot	205 1.9 GTi (1983-1997)	01/87-12/92	FR DS
Peugeot	205 1.9 GTi (1983-1997)	01/87-12/92	FR PS
Peugeot	205 1.9 GTi (Catalyst) (1983-1997)	03/92-07/94	FR PS
Peugeot	205 1.9 GTi (Catalyst) (1983-1997)	03/92-07/94	RR
Peugeot	205 1.9 GTi (Catalyst) (1983-1997)	03/92-07/94	FR DS
Peugeot	309 1.1 (1986-1993)	02/86-10/91	FR DS
Peugeot	309 1.1 (1986-1993)	02/86-10/91	FR DS
Peugeot	309 1.1 (1986-1993)	02/86-10/91	FR PS
Peugeot	309 1.1 (1986-1993)	02/86-10/91	RR
Peugeot	309 1.1 (1986-1993)	02/86-10/91	RR
Peugeot	309 1.1 (1986-1993)	02/86-10/91	FR PS
Peugeot	309 1.1 (1986-1993)	10/91-12/92	RR
Peugeot	309 1.1 (1986-1993)	10/91-12/92	FR PS
Peugeot	309 1.1 (1986-1993)	10/91-12/92	FR DS
Peugeot	309 1.1 (1986-1993)	10/91-12/92	FR DS
Peugeot	309 1.1 (1986-1993)	10/91-12/92	RR
Peugeot	309 1.1 (1986-1993)	10/91-12/92	FR PS
Peugeot	309 1.3 (1986-1993)	02/86-12/91	FR DS
Peugeot	309 1.3 (1986-1993)	02/86-12/91	RR
Peugeot	309 1.3 (1986-1993)	02/86-12/91	RR

Peugeot	309 1.6 Carburettor (1986-1993)	01/89-12/91	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	RR
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR PS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 Injection (1986-1993)	12/91-02/93	FR DS
Peugeot	309 1.6 MPi (1986-1993)	04/87-12/91	FR PS
Peugeot	309 1.6 MPi (1986-1993)	04/87-12/91	FR DS
Peugeot	309 1.6 MPi (1986-1993)	04/87-12/91	FR DS
Peugeot	309 1.6 MPi (1986-1993)	04/87-12/91	FR PS
Peugeot	309 1.6 MPi (1986-1993)	04/87-12/91	RR
Peugeot	309 1.6 MPi (1986-1993)	04/87-12/91	RR
Peugeot	309 1.8 Turbo (1986-1993)	01/90-12/93	FR DS
Peugeot	309 1.8 Turbo (1986-1993)	01/90-12/93	FR PS
Peugeot	309 1.8 Turbo (1986-1993)	01/90-12/93	RR
Peugeot	309 1.9 (1986-1993)	04/87-12/93	RR
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR PS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR PS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	RR

Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR PS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR DS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	RR
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR PS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR DS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	RR
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR DS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR PS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR DS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	RR
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR DS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR PS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	FR DS
Peugeot	309 1.9 (1986-1993)	04/87-12/93	RR
Peugeot	505 2.0 GL (1979-1991)	08/83-10/84	FR PS
Peugeot	505 2.0 GL (1979-1991)	08/83-10/84	FR DS
Peugeot	505 2.0 GL (1979-1991)	08/83-10/84	FR DS
Peugeot	505 2.0 GL (1979-1991)	08/83-10/84	FR PS
Peugeot	505 2.0 GR/Family (1979-1991)	06/82-12/91	RR
Peugeot	505 2.0 GR/Family (1979-1991)	06/82-12/91	RR
Peugeot	505 2.0 GR/Family (1979-1991)	06/82-12/91	FR PS
Peugeot	505 2.0 GR/Family (1979-1991)	06/82-12/91	FR DS
Peugeot	505 2.0 GR/Family (1979-1991)	06/82-12/91	FR PS
Peugeot	505 2.0 GR/Family (1979-1991)	06/82-12/91	FR DS
Peugeot	505 2.0 GR/SR (1979-1991)	01/80-07/88	FR DS
Peugeot	505 2.0 GR/SR (1979-1991)	01/80-07/88	FR PS
Peugeot	505 2.0 GR/SR (1979-1991)	06/82-07/88	FR DS
Peugeot	505 2.0 GR/SR (1979-1991)	06/82-07/88	FR PS
Peugeot	505 2.0 STi (1979-1991)	01/80-12/83	FR PS
Peugeot	505 2.0 STi (1979-1991)	01/80-12/83	FR PS
Peugeot	505 2.0 STi (1979-1991)	01/80-12/83	FR DS
Peugeot	505 2.0 STi (1979-1991)	01/80-12/83	FR DS
Peugeot	505 2.2 GTi (1979-1991)	08/83-05/90	FR DS
Peugeot	505 2.2 GTi (1979-1991)	08/83-05/90	FR PS
Peugeot	505 2.2 GTi (1979-1991)	08/83-05/90	FR DS
Peugeot	505 2.2 GTi (1979-1991)	08/83-05/90	FR PS
Peugeot	505 2.3 (1979-1991)	01/80-12/83	FR PS
Peugeot	505 2.3 (1979-1991)	01/80-12/83	FR DS
Peugeot	505 2.3 Turbo (1979-1991)	10/82-12/85	FR DS
Peugeot	505 2.3 Turbo (1979-1991)	10/82-12/85	FR PS
Peugeot	505 2.5 (1979-1991)	03/82-12/88	FR PS
Peugeot	505 2.5 (1979-1991)	03/82-12/88	FR DS
Peugeot	505 2.5 (1979-1991)	03/82-12/88	FR PS
Peugeot	505 2.5 (1979-1991)	03/82-12/88	FR DS
Peugeot	505 2.5 (1979-1991)	06/82-12/91	RR
Peugeot	505 2.5 (1979-1991)	06/82-12/91	FR DS
Peugeot	505 2.5 (1979-1991)	06/82-12/91	FR PS
Peugeot	505 2.5 (1979-1991)	06/82-12/91	FR DS
Peugeot	505 2.5 (1979-1991)	06/82-12/91	FR PS
Peugeot	505 2.5 (1979-1991)	06/82-12/91	RR

Porsche	944 2.5	04/82-09/88	FR PS
Porsche	944 2.5	04/82-09/88	FR PS
Porsche	944 2.5	04/82-09/88	FR PS
Porsche	944 2.5	04/82-09/88	FR PS
Porsche	944 2.5	04/82-09/88	FR DS
Porsche	944 2.5	04/82-09/88	FR DS
Porsche	944 2.5 S	09/86-06/88	FR DS
Porsche	944 2.5 S	09/86-06/88	FR PS
Porsche	944 2.5 Turbo 951	09/85-09/88	FR DS
Porsche	944 2.5 Turbo 951	09/85-09/88	FR PS
Porsche	944 2.5 Turbo 951	09/85-09/88	FR PS
Porsche	944 2.5 Turbo 951	09/85-09/88	FR DS
Porsche	944 2.5 Turbo 951	09/88-07/92	FR DS
Porsche	944 2.5 Turbo 951	09/88-07/92	FR PS
Porsche	944 2.7	09/88-06/89	FR PS
Porsche	944 2.7	09/88-06/89	FR PS
Porsche	944 2.7	09/88-06/89	FR PS
Porsche	944 2.7	09/88-06/89	FR DS
Porsche	944 2.7	09/88-06/89	FR PS
Porsche	944 2.7	09/88-06/89	FR DS
Porsche	944 2.7	09/88-06/89	FR DS
Porsche	944 2.7	09/88-06/89	FR DS
Porsche	944 3.0 S2	01/89-07/92	FR DS
Porsche	944 3.0 S2	01/89-07/92	FR PS
Porsche	944 3.0 S2	01/89-07/92	FR PS
Porsche	944 3.0 S2	01/89-07/92	FR DS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-07/91	FR PS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-07/91	FR PS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-07/91	FR DS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-07/91	FR PS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-12/91	FR DS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-12/91	FR PS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-12/91	FR PS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-12/91	FR DS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-12/91	FR PS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-12/91	FR DS
Renault	Extra 1.1 Phase 1 (1986-1991)	03/86-12/91	FR DS
Renault	Extra 1.2 Phase 2 (1992-1998)	01/92-12/93	FR DS
Renault	Extra 1.2 Phase 2 (1992-1998)	01/92-12/93	FR DS
Renault	Extra 1.2 Phase 2 (1992-1998)	01/92-12/93	FR PS
Renault	Extra 1.2 Phase 2 (1992-1998)	01/92-12/93	FR PS
Renault	Extra 1.4 Catalyst Phase 1 (1986-1991)	04/90-12/91	FR PS
Renault	Extra 1.4 Catalyst Phase 1 (1986-1991)	04/90-12/91	FR DS
Renault	Extra 1.4 Catalyst Phase 1 (1986-1991)	04/90-12/91	FR DS
Renault	Extra 1.4 Catalyst Phase 1 (1986-1991)	04/90-12/91	FR PS
Renault	Extra 1.4 Catalyst Phase 1 (1986-1991)	04/90-12/91	FR PS
Renault	Extra 1.4 Catalyst Phase 1 (1986-1991)	04/90-12/91	FR DS
Renault	Extra 1.4 Catalyst Phase 1 (1986-1991)	04/90-12/91	FR PS
Renault	Extra 1.4 Catalyst Phase 1 (1986-1991)	04/90-12/91	FR DS

Renault	Megane 2.0 MK 2 (2002-2009)	11/03-06/09	FR PS
Renault	Megane 2.0 MK 2 (2002-2009)	11/03-06/09	FR PS
Renault	Megane 2.0 Renaultsport MK 2 (2002-2009)	12/03-10/05	FR PS
Renault	Megane 2.0 Renaultsport MK 2 (2002-2009)	12/03-10/05	FR PS
Renault	Megane 2.0 T MK 2 (2002-2009)	11/04-10/05	FR PS
Renault	Megane 2.0 T MK 2 (2002-2009)	11/04-10/05	FR PS
Renault	R20 2.0	01/80-11/83	FR PS
Renault	R20 2.0	01/80-11/83	FR DS
Renault	R20 2.0	01/80-11/83	FR PS
Renault	R20 2.0	01/80-11/83	FR DS
Renault	R20 2.2	10/80-11/83	FR PS
Renault	R20 2.2	10/80-11/83	FR DS
Renault	R20 2.2	10/80-11/83	FR PS
Renault	R20 2.2	10/80-11/83	FR DS
Renault	R21 1.7	09/89-12/92	RR
Renault	R21 1.7	09/89-12/92	RR
Renault	R21 1.7 Catalyst	01/92-11/93	RR
Renault	R21 1.7 Catalyst	01/92-11/93	RR
Renault	R21 1.7 Catalyst Savanna	01/92-10/95	RR
Renault	R21 1.7 Catalyst Savanna	01/92-10/95	RR
Renault	R21 1.7 Savanna	10/86-12/92	RR
Renault	R21 1.7 Savanna	10/86-12/92	RR
Renault	R21 1.7 Savanna	10/86-12/92	RR
Renault	R21 1.7 Savanna	10/86-12/92	RR
Renault	R21 1.7 TL Savanna	10/86-08/88	RR
Renault	R21 1.9	09/89-10/94	RR
Renault	R21 1.9 Savanna	09/89-10/95	RR
Renault	R21 2.0	09/89-12/93	RR
Renault	R21 2.0	09/89-12/93	RR
Renault	R21 2.0	09/89-12/93	RR
Renault	R21 2.0	09/89-12/93	RR
Renault	R21 2.0 Quadra Savanna	05/90-12/91	RR
Renault	R21 2.0 Quadra Savanna	05/90-12/91	RR
Renault	R21 2.0 Quadra Savanna	05/90-12/91	RR
Renault	R21 2.0 Quadra Savanna	05/90-12/91	RR
Renault	R21 2.0 Quadra Savanna	05/90-12/91	RR
Renault	R21 2.0 Savanna	07/87-12/89	RR
Renault	R21 2.0 Savanna	07/87-12/89	RR
Renault	R21 2.0 Savanna	07/87-12/89	RR
Renault	R21 2.0 Savanna	07/87-12/89	RR
Renault	R21 2.0 Savanna	09/88-10/95	RR
Renault	R21 2.0 Savanna	09/88-10/95	RR
Renault	R21 2.0 Savanna	09/88-10/95	RR
Renault	R21 2.0 Savanna	09/88-10/95	RR
Renault	R21 2.0 Savanna	10/86-10/95	RR
Renault	R21 2.0 Savanna	10/86-10/95	RR
Renault	R21 2.0 Savanna	10/86-10/95	RR
Renault	R21 2.0 Savanna	10/86-10/95	RR
Renault	R21 2.0 TXi	09/89-01/91	RR

Renault	R21 2.0 TXi	09/89-01/91	RR
Renault	R21 2.1 Savanna	06/86-09/89	RR
Renault	R21 2.1 Turbo Savanna	11/93-10/95	RR
Renault	R21 2.1 Turbo Savanna	11/93-10/95	RR
Renault	R21 2.1 Turbo Savanna	11/93-10/95	RR
Renault	R5 1.1	01/80-03/85	RR
Renault	R5 1.1	01/80-03/85	FR DS
Renault	R5 1.1	01/80-03/85	RR
Renault	R5 1.1	01/80-03/85	FR DS
Renault	R5 1.1	01/80-03/85	FR PS
Renault	R5 1.1	01/80-03/85	RR
Renault	R5 1.1	01/80-03/85	FR PS
Renault	R5 1.1	01/80-03/85	FR PS
Renault	R5 1.1	01/80-03/85	RR
Renault	R5 1.1	01/80-03/85	FR DS
Renault	R5 1.1	01/80-03/85	FR PS
Renault	R5 1.1	01/80-03/85	FR DS
Renault	R5 1.1	01/82-03/85	FR PS
Renault	R5 1.1	01/82-03/85	FR DS
Renault	R5 1.1	01/82-03/85	FR DS
Renault	R5 1.1	01/82-03/85	FR PS
Renault	R5 1.1	01/82-03/85	RR
Renault	R5 1.1	01/82-03/85	RR
Renault	R5 1.1	01/82-03/85	FR DS
Renault	R5 1.1	01/82-03/85	RR
Renault	R5 1.1	01/82-03/85	FR PS
Renault	R5 1.1	01/82-03/85	FR DS
Renault	R5 1.1	01/82-03/85	RR
Renault	R5 1.1	01/82-03/85	FR PS
Renault	R5 1.1	09/86-12/87	FR PS
Renault	R5 1.1	09/86-12/87	FR PS
Renault	R5 1.1	09/86-12/87	FR DS
Renault	R5 1.1	09/86-12/87	FR DS
Renault	R5 1.1	09/86-12/87	FR DS
Renault	R5 1.1	09/86-12/87	FR PS
Renault	R5 1.1	09/86-12/87	FR DS
Renault	R5 1.1	09/86-12/87	FR PS
Renault	R5 1.1	09/86-12/87	FR DS
Renault	R5 1.1	09/86-12/87	FR PS
Renault	R5 1.1	09/86-12/87	FR PS
Renault	R5 1.1	09/86-12/87	FR DS
Renault	R5 1.2	07/87-10/90	FR DS
Renault	R5 1.2	07/87-10/90	FR DS
Renault	R5 1.2	07/87-10/90	FR PS
Renault	R5 1.2	07/87-10/90	FR PS
Renault	R5 1.2	07/87-10/90	FR PS
Renault	R5 1.2	07/87-10/90	FR DS
Renault	R5 1.2	07/87-10/90	FR DS
Renault	R5 1.2	07/87-10/90	FR PS
Renault	R5 1.2	07/87-10/90	FR DS

Renault	R5 1.2	07/87-10/90	FR PS
Renault	R5 1.2	07/87-10/90	FR DS
Renault	R5 1.2	07/87-10/90	FR PS
Renault	R5 1.3	01/80-06/81	FR PS
Renault	R5 1.3	01/80-06/81	RR
Renault	R5 1.3	01/80-06/81	FR DS
Renault	R5 1.3	01/80-06/81	RR
Renault	R5 1.3	01/80-06/81	FR DS
Renault	R5 1.3	01/80-11/81	RR
Renault	R5 1.3	01/80-11/81	FR DS
Renault	R5 1.3	01/80-11/81	FR PS
Renault	R5 1.4	06/81-03/85	FR PS
Renault	R5 1.4	06/81-03/85	FR DS
Renault	R5 1.4	06/81-03/85	RR
Renault	R5 1.4	06/81-03/85	FR PS
Renault	R5 1.4	06/81-03/85	RR
Renault	R5 1.4	06/81-03/85	FR DS
Renault	R5 1.4	11/81-03/85	RR
Renault	R5 1.4	11/81-03/85	FR PS
Renault	R5 1.4	11/81-03/85	FR DS
Renault	R5 1.4	11/81-03/85	FR DS
Renault	R5 1.4	11/81-03/85	RR
Renault	R5 1.4	11/81-03/85	FR PS
Renault	R5 1.4 Gordini Turbo	01/80-10/84	RR
Renault	R5 1.4 Gordini Turbo	01/80-10/84	FR PS
Renault	R5 1.4 Gordini Turbo	01/80-10/84	FR PS
Renault	R5 1.4 Gordini Turbo	01/80-10/84	FR DS
Renault	R5 1.4 Gordini Turbo	01/80-10/84	FR DS
Renault	R5 1.4 Gordini Turbo	01/80-10/84	RR
Renault	R5 1.7	07/87-10/90	FR DS
Renault	R5 1.7	07/87-10/90	FR PS
Renault	R5 1.7	07/87-10/90	FR PS
Renault	R5 1.7	07/87-10/90	FR PS
Renault	R5 1.7	07/87-10/90	FR DS
Renault	R5 1.7	07/87-10/90	FR DS
Renault	R5 1.7	07/87-10/90	FR PS
Renault	R5 1.7	07/87-10/90	FR PS
Renault	R5 1.7	07/87-10/90	FR DS
Renault	R5 1.7	07/87-10/90	FR DS
Renault	R5 1.7	07/87-10/90	FR DS
Renault	R5 1.7	07/87-10/90	FR PS
Renault	R5 1.7	07/87-10/90	FR PS
Renault	R5 1.7	07/87-10/90	FR DS
Renault	R5 1.7	07/87-10/90	FR PS
Renault	R5 1.7	07/87-10/90	FR DS
Rover	200 1.8 (1995-1999) 200vi / BRM	10/96-03/00	FR DS
Rover	200 1.8 (1995-1999) 200vi / BRM	10/96-03/00	FR PS
Rover	200 1.8 (1995-1999) 200vi / BRM	10/96-03/00	RR
Rover	200 1.8 (1995-1999) 200vi / BRM	10/96-03/00	FR PS

Rover	200 1.8 (1995-1999) 200vi / BRM	10/96-03/00	RR
Rover	200 1.8 (1995-1999) 200vi / BRM	10/96-03/00	FR DS
Rover	200 1.8 (1995-1999) BRM	10/96-03/00	RR
Rover	200 1.8 (1995-1999) BRM	10/96-03/00	FR PS
Rover	200 1.8 (1995-1999) BRM	10/96-03/00	FR DS
Rover	211 1.1 (1995-1999)	01/98-03/00	FR DS
Rover	211 1.1 (1995-1999)	01/98-03/00	RR
Rover	211 1.1 (1995-1999)	01/98-03/00	FR PS
Rover	211 1.1 (1995-1999)	01/98-03/00	FR PS
Rover	211 1.1 (1995-1999)	01/98-03/00	FR DS
Rover	211 1.1 (1995-1999)	01/98-03/00	RR
Rover	213 1.3 (1984-1990)	06/84-12/89	FR PS
Rover	213 1.3 (1984-1990)	06/84-12/89	FR DS
Rover	213 1.3 (1984-1990)	06/84-12/89	FR DS
Rover	213 1.3 (1984-1990)	06/84-12/89	FR PS
Rover	213 1.3 (1984-1990)	06/84-12/89	FR PS
Rover	213 1.3 (1984-1990)	06/84-12/89	FR DS
Rover	213 1.3 (1984-1990)	06/84-12/89	FR PS
Rover	213 1.3 (1984-1990)	06/84-12/89	FR DS
Rover	214 1.4 (1989-1996)	04/93-03/96	FR PS
Rover	214 1.4 (1989-1996)	04/93-03/96	FR PS
Rover	214 1.4 (1989-1996)	04/93-03/96	FR PS
Rover	214 1.4 (1989-1996)	04/93-03/96	RR
Rover	214 1.4 (1989-1996)	04/93-03/96	RR
Rover	214 1.4 (1989-1996)	04/93-03/96	FR DS
Rover	214 1.4 (1989-1996)	04/93-03/96	FR DS
Rover	214 1.4 (1989-1996)	04/93-03/96	FR DS
Rover	214 1.4 (1989-1996)	04/93-03/96	FR PS
Rover	214 1.4 (1989-1996)	04/93-03/96	FR DS
Rover	214 1.4 (1989-1996)	04/93-03/96	RR
Rover	214 1.4 (1989-1996)	04/93-03/96	RR
Rover	214 1.4 (1989-1996)	10/89-11/93	FR DS
Rover	214 1.4 (1989-1996)	10/89-11/93	FR PS
Rover	214 1.4 (1989-1996)	10/89-11/93	RR
Rover	214 1.4 (1989-1996)	10/89-11/93	FR DS
Rover	214 1.4 (1989-1996)	10/89-11/93	FR DS
Rover	214 1.4 (1989-1996)	10/89-11/93	RR
Rover	214 1.4 (1989-1996)	10/89-11/93	FR PS
Rover	214 1.4 (1989-1996)	10/89-11/93	FR PS
Rover	214 1.4 (1989-1996)	10/89-11/93	RR
Rover	214 1.4 (1989-1996)	10/89-11/93	FR DS
Rover	214 1.4 (1989-1996)	10/89-11/93	RR
Rover	214 1.4 (1989-1996)	10/89-11/93	FR PS
Rover	214 1.4 (1989-1996)	10/92-03/96	FR DS
Rover	214 1.4 (1989-1996)	10/92-03/96	FR PS
Rover	214 1.4 (1989-1996)	10/92-03/96	RR
Rover	214 1.4 (1989-1996)	10/92-03/96	FR PS
Rover	214 1.4 (1989-1996)	10/92-03/96	FR DS
Rover	214 1.4 (1989-1996)	10/92-03/96	RR
Rover	214 1.4 (1995-1999)	06/99-03/00	FR DS

Rover	214 1.4 (1995-1999)	06/99-03/00	FR PS
Rover	214 1.4 (1995-1999)	06/99-03/00	RR
Rover	214 1.4 (1995-1999)	06/99-03/00	FR DS
Rover	214 1.4 (1995-1999)	06/99-03/00	RR
Rover	214 1.4 (1995-1999)	06/99-03/00	FR PS
Rover	214 1.4 (1995-1999)	11/95-03/00	FR PS
Rover	214 1.4 (1995-1999)	11/95-03/00	RR
Rover	214 1.4 (1995-1999)	11/95-03/00	FR PS
Rover	214 1.4 (1995-1999)	11/95-03/00	FR DS
Rover	214 1.4 (1995-1999)	11/95-03/00	FR DS
Rover	214 1.4 (1995-1999)	11/95-03/00	FR PS
Rover	214 1.4 (1995-1999)	11/95-03/00	RR
Rover	214 1.4 (1995-1999)	11/95-03/00	FR DS
Rover	214 1.4 (1995-1999)	11/95-03/00	RR
Rover	214 1.4 (1995-1999)	11/95-03/00	RR
Rover	214 1.4 (1995-1999)	11/95-03/00	FR DS
Rover	214 1.4 (1995-1999)	11/95-03/00	FR PS
Rover	216 1.6 (1989-1996)	09/90-12/93	FR PS
Rover	216 1.6 (1989-1996)	09/90-12/93	FR PS
Rover	216 1.6 (1989-1996)	09/90-12/93	RR
Rover	216 1.6 (1989-1996)	09/90-12/93	FR DS
Rover	216 1.6 (1989-1996)	09/90-12/93	RR
Rover	216 1.6 (1989-1996)	09/90-12/93	FR DS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR PS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR PS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR PS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR DS
Rover	216 1.6 (1989-1996)	10/89-10/92	RR
Rover	216 1.6 (1989-1996)	10/89-10/92	RR
Rover	216 1.6 (1989-1996)	10/89-10/92	RR
Rover	216 1.6 (1989-1996)	10/89-10/92	FR DS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR PS
Rover	216 1.6 (1989-1996)	10/89-10/92	RR
Rover	216 1.6 (1989-1996)	10/89-10/92	FR DS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR PS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR PS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR DS
Rover	216 1.6 (1989-1996)	10/89-10/92	FR DS
Rover	216 1.6 (1989-1996)	10/89-10/92	RR
Rover	216 1.6 (1989-1996)	10/89-10/92	RR
Rover	216 1.6 (1989-1996)	10/89-10/92	FR DS
Rover	216 1.6 (1989-1996)	10/92-03/96	FR PS
Rover	216 1.6 (1989-1996)	10/92-03/96	FR PS
Rover	216 1.6 (1989-1996)	10/92-03/96	FR DS
Rover	216 1.6 (1989-1996)	10/92-03/96	RR
Rover	216 1.6 (1989-1996)	10/92-03/96	FR DS
Rover	216 1.6 (1989-1996)	10/92-03/96	RR
Rover	216 1.6 (1989-1996)	10/92-03/96	FR DS
Rover	216 1.6 (1989-1996)	10/92-03/96	FR PS
Rover	216 1.6 (1989-1996)	10/92-03/96	RR

Rover	216 1.6 (1992-1999)	10/92-10/95	RR
Rover	216 1.6 (1992-1999)	10/92-10/95	FR PS
Rover	216 1.6 (1992-1999)	10/92-10/95	RR
Rover	216 1.6 (1992-1999)	10/92-10/95	RR
Rover	216 1.6 (1992-1999)	10/92-10/95	FR PS
Rover	216 1.6 (1992-1999)	10/92-10/95	FR DS
Rover	216 1.6 (1992-1999)	10/92-10/95	FR PS
Rover	216 1.6 (1992-1999)	10/92-10/95	FR PS
Rover	216 1.6 (1992-1999)	10/92-10/95	RR
Rover	216 1.6 (1992-1999)	10/92-10/95	FR DS
Rover	216 1.6 (1992-1999)	10/92-10/95	FR DS
Rover	216 1.6 (1992-1999)	10/92-10/95	FR DS
Rover	216 1.6 (1995-1999)	11/95-03/00	FR DS
Rover	216 1.6 (1995-1999)	11/95-03/00	FR PS
Rover	216 1.6 (1995-1999)	11/95-03/00	FR PS
Rover	216 1.6 (1995-1999)	11/95-03/00	RR
Rover	216 1.6 (1995-1999)	11/95-03/00	RR
Rover	216 1.6 (1995-1999)	11/95-03/00	FR DS
Rover	216 1.6 (1995-1999)	11/95-03/00	FR DS
Rover	216 1.6 (1995-1999)	11/95-03/00	RR
Rover	216 1.6 (1995-1999)	11/95-03/00	FR DS
Rover	216 1.6 (1995-1999)	11/95-03/00	FR PS
Rover	216 1.6 (1995-1999)	11/95-03/00	RR
Rover	216 1.6 (1995-1999)	11/95-03/00	FR PS
Rover	216 1.6 Carburettor (1984-1990)	03/85-09/90	FR PS
Rover	216 1.6 Carburettor (1984-1990)	03/85-09/90	FR DS
Rover	216 1.6 Injection (1984-1990)	03/85-09/90	FR DS
Rover	216 1.6 Injection (1984-1990)	03/85-09/90	FR PS
Rover	216 1.6 Injection (1984-1990)	03/85-09/90	FR PS
Rover	216 1.6 Injection (1984-1990)	03/85-09/90	FR DS
Rover	218 1.8 (1995-1999)	06/97-03/00	FR PS
Rover	218 1.8 (1995-1999)	06/97-03/00	RR
Rover	218 1.8 (1995-1999)	06/97-03/00	FR PS
Rover	218 1.8 (1995-1999)	06/97-03/00	RR
Rover	218 1.8 (1995-1999)	06/97-03/00	FR DS
Rover	218 1.8 (1995-1999)	06/97-03/00	FR DS
Rover	218 1.8 Turbo (1989-1996)	03/91-03/96	FR DS
Rover	218 1.8 Turbo (1989-1996)	03/91-03/96	FR PS
Rover	218 1.8 Turbo (1989-1996)	03/91-03/96	RR
Rover	218 1.8 VVC (1992-1999)	03/96-04/99	RR
Rover	218 1.8 VVC (1992-1999)	03/96-04/99	FR DS
Rover	218 1.8 VVC (1992-1999)	03/96-04/99	FR PS
Rover	218 1.9 (1989-1996)	03/91-03/96	FR DS
Rover	218 1.9 (1989-1996)	03/91-03/96	FR PS
Rover	218 1.9 (1989-1996)	03/91-03/96	RR
Rover	220 2.0 (1989-1996)	06/91-11/93	FR PS
Rover	220 2.0 (1989-1996)	06/91-11/93	FR PS
Rover	220 2.0 (1989-1996)	06/91-11/93	RR
Rover	220 2.0 (1989-1996)	06/91-11/93	FR DS
Rover	220 2.0 (1989-1996)	06/91-11/93	RR

Rover	220 2.0 (1989-1996)	06/91-11/93	FR DS
Rover	220 2.0 (1989-1996)	11/93-10/95	RR
Rover	220 2.0 (1989-1996)	11/93-10/95	RR
Rover	220 2.0 (1989-1996)	11/93-10/95	FR PS
Rover	220 2.0 (1989-1996)	11/93-10/95	FR PS
Rover	220 2.0 (1989-1996)	11/93-10/95	FR DS
Rover	220 2.0 (1989-1996)	11/93-10/95	FR DS
Rover	220 2.0 (1992-1999)	10/92-03/96	FR DS
Rover	220 2.0 (1992-1999)	10/92-03/96	FR PS
Rover	220 2.0 (1995-1999)	11/95-03/00	FR PS
Rover	220 2.0 (1995-1999)	11/95-03/00	FR DS
Rover	220 2.0 (1995-1999)	11/95-03/00	RR
Rover	220 2.0 (1995-1999)	11/95-03/00	RR
Rover	220 2.0 (1995-1999)	11/95-03/00	FR DS
Rover	220 2.0 (1995-1999)	11/95-03/00	FR PS
Rover	220 2.0 direct injection (1995-1999)	11/95-03/00	FR DS
Rover	220 2.0 direct injection (1995-1999)	11/95-03/00	FR PS
Rover	220 2.0 direct injection (1995-1999)	11/95-03/00	RR
Rover	220 2.0 direct injection (1995-1999)	11/95-03/00	FR PS
Rover	220 2.0 direct injection (1995-1999)	11/95-03/00	FR DS
Rover	220 2.0 direct injection (1995-1999)	11/95-03/00	RR
Rover	220 2.0 Turbo (1989-1996)	11/93-05/95	FR DS
Rover	220 2.0 Turbo (1989-1996)	11/93-05/95	RR
Rover	220 2.0 Turbo (1989-1996)	11/93-05/95	FR PS
Rover	220 2.0 Turbo (1992-1999)	10/92-03/96	FR DS
Rover	220 2.0 Turbo (1992-1999)	10/92-03/96	FR PS
Rover	25 1.1 (1999-2005)	03/01-12/07	FR PS
Rover	25 1.1 (1999-2005)	03/01-12/07	FR DS
Rover	25 1.1 (1999-2005)	03/01-12/07	FR PS
Rover	25 1.1 (1999-2005)	03/01-12/07	RR
Rover	25 1.1 (1999-2005)	03/01-12/07	RR
Rover	25 1.1 (1999-2005)	03/01-12/07	FR DS
Rover	25 1.1 (1999-2005)	11/99-10/00	RR
Rover	25 1.1 (1999-2005)	11/99-10/00	FR DS
Rover	25 1.1 (1999-2005)	11/99-10/00	FR PS
Rover	25 1.1 (1999-2005)	11/99-10/00	FR DS
Rover	25 1.1 (1999-2005)	11/99-10/00	RR
Rover	25 1.1 (1999-2005)	11/99-10/00	FR PS
Rover	25 1.4 (1999-2005)	11/99-12/07	FR DS
Rover	25 1.4 (1999-2005)	11/99-12/07	RR
Rover	25 1.4 (1999-2005)	11/99-12/07	FR PS
Rover	25 1.4 (1999-2005)	11/99-12/07	FR DS
Rover	25 1.4 (1999-2005)	11/99-12/07	FR PS
Rover	25 1.4 (1999-2005)	11/99-12/07	FR PS
Rover	25 1.4 (1999-2005)	11/99-12/07	FR DS
Rover	25 1.4 (1999-2005)	11/99-12/07	RR
Rover	25 1.4 (1999-2005)	11/99-12/07	FR DS
Rover	25 1.4 (1999-2005)	11/99-12/07	RR
Rover	25 1.4 (1999-2005)	11/99-12/07	FR PS
Rover	25 1.4 (1999-2005)	11/99-12/07	RR

Rover	25 1.6 (1999-2005)	11/99-12/07	RR
Rover	25 1.6 (1999-2005)	11/99-12/07	FR PS
Rover	25 1.6 (1999-2005)	11/99-12/07	FR DS
Rover	25 1.6 (1999-2005)	11/99-12/07	RR
Rover	25 1.6 (1999-2005)	11/99-12/07	FR DS
Rover	25 1.6 (1999-2005)	11/99-12/07	FR DS
Rover	25 1.6 (1999-2005)	11/99-12/07	FR PS
Rover	25 1.6 (1999-2005)	11/99-12/07	RR
Rover	25 1.6 (1999-2005)	11/99-12/07	RR
Rover	25 1.6 (1999-2005)	11/99-12/07	FR PS
Rover	25 1.6 (1999-2005)	11/99-12/07	FR PS
Rover	25 1.6 (1999-2005)	11/99-12/07	FR DS
Rover	25 1.8 (1999-2005)	11/99-12/02	RR
Rover	25 1.8 (1999-2005)	11/99-12/02	FR DS
Rover	25 1.8 (1999-2005)	11/99-12/02	RR
Rover	25 1.8 (1999-2005)	11/99-12/02	FR DS
Rover	25 1.8 (1999-2005)	11/99-12/02	FR PS
Rover	25 1.8 (1999-2005)	11/99-12/02	FR PS
Rover	25 1.8 GTi (1999-2005)	11/99-12/01	FR DS
Rover	25 1.8 GTi (1999-2005)	11/99-12/01	FR DS
Rover	25 1.8 GTi (1999-2005)	11/99-12/01	RR
Rover	25 1.8 GTi (1999-2005)	11/99-12/01	FR PS
Rover	25 1.8 GTi (1999-2005)	11/99-12/01	RR
Rover	25 1.8 GTi (1999-2005)	11/99-12/01	FR PS
Rover	25 2.0 (1999-2005)	11/99-12/07	FR DS
Rover	25 2.0 (1999-2005)	11/99-12/07	FR PS
Rover	25 2.0 (1999-2005)	11/99-12/07	FR DS
Rover	25 2.0 (1999-2005)	11/99-12/07	RR
Rover	25 2.0 (1999-2005)	11/99-12/07	RR
Rover	25 2.0 (1999-2005)	11/99-12/07	FR PS
Rover	414 1.4 (1990-1995)	03/90-10/92	FR DS
Rover	414 1.4 (1990-1995)	03/90-10/92	FR PS
Rover	414 1.4 (1990-1995)	03/90-10/92	FR PS
Rover	414 1.4 (1990-1995)	03/90-10/92	FR DS
Rover	414 1.4 (1990-1995)	10/92-12/95	FR DS
Rover	414 1.4 (1990-1995)	10/92-12/95	FR PS
Rover	414 1.4 (1995-2000)	05/95-07/00	FR PS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR PS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR DS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR PS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR DS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR DS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR DS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR PS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR PS
Rover	416 1.6 (1990-1995)	03/90-10/92	FR PS
Rover	416 1.6 (1990-1995)	03/90-12/91	FR DS
Rover	416 1.6 (1990-1995)	03/90-12/91	FR PS
Rover	416 1.6 (1990-1995)	03/90-12/91	FR DS
Rover	416 1.6 (1990-1995)	03/90-12/91	FR PS
Rover	416 1.6 (1990-1995)	10/92-12/95	FR PS

Rover	416 1.6 (1990-1995)	10/92-12/95	FR DS
Rover	416 1.6 (1990-1995)	10/92-12/95	FR PS
Rover	416 1.6 (1990-1995)	10/92-12/95	FR DS
Rover	416 1.6 (1995-2000)	05/95-07/00	FR PS
Rover	416 1.6 (1995-2000)	05/95-07/00	FR PS
Rover	416 1.6 (1995-2000)	05/95-07/00	FR PS
Rover	416 1.6 (1995-2000)	05/95-07/00	FR PS
Rover	416 1.6 (1995-2000)	05/95-12/99	FR PS
Rover	416 1.6 (1995-2000)	05/95-12/99	FR PS
Rover	416 1.6 Tourer (1990-1996)	06/94-03/96	FR PS
Rover	416 1.6 Tourer (1990-1996)	06/94-03/96	FR DS
Rover	416 1.6 Tourer (1990-1996)	06/94-03/96	FR DS
Rover	416 1.6 Tourer (1990-1996)	06/94-03/96	FR PS
Rover	416 1.6 Tourer (1995-2000)	03/96-12/99	FR PS
Rover	416 1.6 Tourer (1995-2000)	03/96-12/99	FR PS
Rover	416 1.6 Tourer (1995-2000)	03/96-12/99	FR DS
Rover	416 1.6 Tourer (1995-2000)	03/96-12/99	FR DS
Rover	418 1.8 Tourer VVC (1995-2000)	03/96-10/97	FR DS
Rover	418 1.8 Tourer VVC (1995-2000)	03/96-10/97	FR PS
Rover	418 1.8 Turbo (1990-1995)	03/91-12/95	FR PS
Rover	418 1.8 Turbo (1990-1995)	03/91-12/95	FR DS
Rover	418 1.8 Turbo Tourer (1990-1995)	06/94-10/96	FR PS
Rover	418 1.8 Turbo Tourer (1990-1995)	06/94-10/96	FR DS
Rover	418 1.9 (1990-1995)	10/92-03/96	FR DS
Rover	418 1.9 (1990-1995)	10/92-03/96	FR PS
Rover	418 1.9 (1990-1995)	10/92-03/96	FR PS
Rover	418 1.9 (1990-1995)	10/92-03/96	FR DS
Rover	420 2.0 (1990-1995)	11/91-10/95	FR DS
Rover	420 2.0 (1990-1995)	11/91-10/95	FR PS
Rover	420 2.0 (1990-1995)	11/91-10/95	FR DS
Rover	420 2.0 (1990-1995)	11/91-10/95	FR PS
Rover	420 2.0 (1995-2000)	03/96-07/00	FR PS
Rover	420 2.0 (1995-2000)	03/96-07/00	FR PS
Rover	420 2.0 (1995-2000)	11/95-07/00	FR PS
Rover	420 2.0 (1995-2000)	11/95-07/00	FR PS
Rover	420 2.0 Di (1995-2000)	06/97-07/00	FR PS
Rover	420 2.0 Di (1995-2000)	06/97-07/00	FR PS
Rover	420 2.0 Tourer (1990-1996)	06/94-03/96	FR PS
Rover	420 2.0 Tourer (1990-1996)	06/94-03/96	FR DS
Rover	420 2.0 Turbo (1990-1995)	10/92-10/95	FR DS
Rover	420 2.0 Turbo (1990-1995)	10/92-10/95	FR PS
Rover	45 1.4 (1999-2004)	11/99-05/04	RR
Rover	45 1.4 (1999-2004)	11/99-05/04	FR PS
Rover	45 1.4 (2004-2005)	05/04-12/07	FR PS
Rover	45 1.4 (2004-2005)	05/04-12/07	RR
Rover	45 1.6 (1999-2004)	11/99-05/04	RR
Rover	45 1.6 (1999-2004)	11/99-05/04	FR PS
Rover	45 1.6 (1999-2004)	11/99-05/04	FR PS
Rover	45 1.6 (2004-2005)	05/04-12/07	RR
Rover	45 1.6 (2004-2005)	05/04-12/07	FR PS

Rover	45 1.6 (2004-2005)	05/04-12/07	FR PS
Rover	45 1.8 (1999-2004)	11/99-05/04	FR PS
Rover	45 1.8 (1999-2004)	11/99-05/04	FR PS
Rover	45 1.8 (1999-2004)	11/99-05/04	FR PS
Rover	45 1.8 (1999-2004)	11/99-05/04	FR PS
Rover	45 1.8 (1999-2004)	11/99-05/04	RR
Rover	45 1.8 (1999-2004)	11/99-05/04	RR
Rover	45 1.8 (2004-2005)	05/04-12/07	FR PS
Rover	45 1.8 (2004-2005)	05/04-12/07	FR PS
Rover	45 1.8 (2004-2005)	05/04-12/07	RR
Rover	45 1.8 (2004-2005)	05/04-12/07	FR PS
Rover	45 1.8 (2004-2005)	05/04-12/07	RR
Rover	45 1.8 (2004-2005)	05/04-12/07	FR PS
Rover	45 2.0 (1999-2004)	11/99-05/04	FR PS
Rover	45 2.0 (1999-2004)	11/99-05/04	RR
Rover	45 2.0 (1999-2004)	11/99-05/04	FR PS
Rover	45 2.0 (2004-2005)	05/04-12/07	RR
Rover	45 2.0 (2004-2005)	05/04-12/07	FR PS
Rover	45 2.0 (2004-2005)	05/04-12/07	FR PS
Rover	MGZR 1.4 105	06/01-12/07	FR PS
Rover	MGZR 1.4 105	06/01-12/07	RR
Rover	MGZR 1.4 105	06/01-12/07	FR PS
Rover	MGZR 1.4 105	06/01-12/07	RR
Rover	MGZR 1.4 105	06/01-12/07	FR DS
Rover	MGZR 1.4 105	06/01-12/07	FR DS
Rover	MGZR 1.8 120	06/01-12/07	FR PS
Rover	MGZR 1.8 120	06/01-12/07	FR DS
Rover	MGZR 1.8 120	06/01-12/07	FR DS
Rover	MGZR 1.8 120	06/01-12/07	FR DS
Rover	MGZR 1.8 120	06/01-12/07	RR
Rover	MGZR 1.8 120	06/01-12/07	FR PS
Rover	MGZR 1.8 120	06/01-12/07	FR PS
Rover	MGZR 1.8 120	06/01-12/07	RR
Rover	MGZR 1.8 120	06/01-12/07	RR
Rover	MGZR 1.8 160 VVC	06/01-12/07	FR DS
Rover	MGZR 1.8 160 VVC	06/01-12/07	FR PS
Rover	MGZR 1.8 160 VVC	06/01-12/07	RR
Rover	MGZR 1.8 160 VVC	06/01-12/07	RR
Rover	MGZR 1.8 160 VVC	06/01-12/07	FR DS
Rover	MGZR 1.8 160 VVC	06/01-12/07	FR PS
Rover	MGZR 2.0 TD 100	06/01-12/07	FR PS
Rover	MGZR 2.0 TD 100	06/01-12/07	FR PS
Rover	MGZR 2.0 TD 100	06/01-12/07	FR DS
Rover	MGZR 2.0 TD 100	06/01-12/07	RR
Rover	MGZR 2.0 TD 100	06/01-12/07	RR
Rover	MGZR 2.0 TD 100	06/01-12/07	FR DS
Rover	MGZR 2.0 TD 115	12/02-12/07	FR PS

Rover	MGZR 2.0 TD 115	12/02-12/07	RR
Rover	MGZR 2.0 TD 115	12/02-12/07	RR
Rover	MGZR 2.0 TD 115	12/02-12/07	FR PS
Rover	MGZR 2.0 TD 115	12/02-12/07	FR DS
Rover	MGZR 2.0 TD 115	12/02-12/07	FR PS
Rover	MGZR 2.0 TD 115	12/02-12/07	FR DS
Rover	MGZR 2.0 TD 115	12/02-12/07	FR DS
Rover	MGZR 2.0 TD 115	12/02-12/07	FR DS
Rover	MGZR 2.0 TD 115	12/02-12/07	RR
Rover	MGZR 2.0 TD 115	12/02-12/07	FR PS
Rover	MGZR 2.0 TD 115	12/02-12/07	RR
Rover	MGZS 1.6 110	08/03-12/07	FR PS
Rover	MGZS 1.6 110	08/03-12/07	FR PS
Rover	MGZS 1.8 120	06/01-12/07	FR PS
Rover	MGZS 1.8 120	06/01-12/07	FR PS
Rover	MGZS 1.8 120	06/01-12/07	FR PS
Rover	MGZS 1.8 120	06/01-12/07	FR PS
Rover	MGZS 2.0 CDTi 100	08/02-12/07	FR PS
Rover	MGZS 2.0 CDTi 100	08/02-12/07	FR PS
Rover	MGZS 2.0 CDTi 100	08/02-12/07	FR PS
Rover	MGZS 2.0 CDTi 115	12/02-12/07	FR PS
Rover	MGZS 2.0 CDTi 115	12/02-12/07	FR PS
Rover	MGZS 2.0 CDTi 115	12/02-12/07	FR PS
Rover	MGZS 2.0 CDTi 115	12/02-12/07	FR PS
Rover	MGZS 2.0 CDTi 115	12/02-12/07	FR PS
Rover	MGZS 2.0 CDTi 115	12/02-12/07	FR PS
Rover	MGZS 2.5 180	06/01-12/07	FR PS
Rover	MGZS 2.5 180	06/01-12/07	FR PS
Rover	SD1 2300 (2.3) (1976-1986)	01/80-01/87	FR PS
Rover	SD1 2300 (2.3) (1976-1986)	01/80-01/87	FR DS
Rover	SD1 2300 (2.3) (1976-1986)	01/80-01/87	FR PS
Rover	SD1 2300 (2.3) (1976-1986)	01/80-01/87	FR DS
Rover	SD1 2300 (2.3) (1976-1986)	01/80-01/87	FR PS
Rover	SD1 2300 (2.3) (1976-1986)	01/80-01/87	FR PS
Rover	SD1 2300 (2.3) (1976-1986)	01/80-01/87	FR DS
Rover	SD1 2300 (2.3) (1976-1986)	01/80-01/87	FR DS
Rover	SD1 2600 (1976-1986)	10/80-10/86	FR PS
Rover	SD1 2600 (1976-1986)	10/80-10/86	FR DS
Rover	SD1 2600 (1976-1986)	10/80-10/86	FR DS
Rover	SD1 2600 (1976-1986)	10/80-10/86	FR DS
Rover	SD1 2600 (1976-1986)	10/80-10/86	FR PS
Rover	SD1 2600 (1976-1986)	10/80-10/86	FR DS
Rover	SD1 2600 (1976-1986)	10/80-10/86	FR PS
Rover	SD1 2600 (1976-1986)	10/80-10/86	FR PS
Rover	SD1 3500 Injection (1976-1986)	10/82-10/86	FR DS
Rover	SD1 3500 Injection (1976-1986)	10/82-10/86	FR DS
Rover	SD1 3500 Injection (1976-1986)	10/82-10/86	FR DS
Rover	SD1 3500 Injection (1976-1986)	10/82-10/86	FR DS
Rover	SD1 3500 Injection (1976-1986)	10/82-10/86	FR PS
Rover	SD1 3500 Injection (1976-1986)	10/82-10/86	FR PS
Rover	SD1 3500 Injection (1976-1986)	10/82-10/86	FR PS

Rover	SD1 3500 Injection (1976-1986)	10/82-10/86	FR PS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	FR DS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	RR
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	FR PS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	RR
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	RR
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	FR PS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	FR PS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	FR DS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	FR PS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	FR DS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	FR DS
Rover	Streetwise 1.4 (1999-2005)	08/03-12/07	RR
Rover	Streetwise 1.6 (1999-2005)	01/04-12/07	FR DS
Rover	Streetwise 1.6 (1999-2005)	01/04-12/07	RR
Rover	Streetwise 1.6 (1999-2005)	01/04-12/07	FR PS
Rover	Streetwise 2.0 (1999-2005)	08/03-12/07	FR PS
Rover	Streetwise 2.0 (1999-2005)	08/03-12/07	RR
Rover	Streetwise 2.0 (1999-2005)	08/03-12/07	FR PS
Rover	Streetwise 2.0 (1999-2005)	08/03-12/07	FR DS
Rover	Streetwise 2.0 (1999-2005)	08/03-12/07	FR DS
Rover	Streetwise 2.0 (1999-2005)	08/03-12/07	RR
Seat	Ibiza 0.9 021A (1985-1993)	02/87-12/92	RR
Seat	Ibiza 0.9 021A (1985-1993)	02/87-12/92	RR
Seat	Ibiza 0.9 021A (1985-1993)	02/87-12/92	FR DS
Seat	Ibiza 0.9 021A (1985-1993)	02/87-12/92	FR DS
Seat	Ibiza 0.9 021A (1985-1993)	02/87-12/92	RR
Seat	Ibiza 0.9 021A (1985-1993)	02/87-12/92	FR DS
Seat	Ibiza 0.9 021A (1985-1993)	02/87-12/92	FR DS
Seat	Ibiza 0.9 021A (1985-1993)	02/87-12/92	RR
Seat	Ibiza 1.2 021A (1985-1993)	10/85-12/91	FR DS
Seat	Ibiza 1.2 021A (1985-1993)	10/85-12/91	FR DS
Seat	Ibiza 1.2 021A (1985-1993)	10/85-12/91	RR
Seat	Ibiza 1.2 021A (1985-1993)	10/85-12/91	RR
Seat	Ibiza 1.2 Injection 021A (1985-1993)	01/92-12/93	FR DS
Seat	Ibiza 1.2 Injection 021A (1985-1993)	01/92-12/93	RR
Seat	Ibiza 1.2 Injection 021A (1985-1993)	01/92-12/93	FR DS
Seat	Ibiza 1.2 Injection 021A (1985-1993)	01/92-12/93	RR
Seat	Ibiza 1.5 021A (1985-1993)	05/90-12/92	FR DS
Seat	Ibiza 1.5 021A (1985-1993)	05/90-12/92	FR DS
Seat	Ibiza 1.5 021A (1985-1993)	05/90-12/92	RR
Seat	Ibiza 1.5 021A (1985-1993)	05/90-12/92	RR
Seat	Ibiza 1.5 021A (1985-1993)	05/90-12/92	FR DS
Seat	Ibiza 1.5 021A (1985-1993)	05/90-12/92	RR
Seat	Ibiza 1.5 021A (1985-1993)	05/90-12/92	RR
Seat	Ibiza 1.5 021A (1985-1993)	05/90-12/92	FR DS
Seat	Ibiza 1.5 021A (1985-1993)	10/86-05/90	FR DS
Seat	Ibiza 1.5 021A (1985-1993)	10/86-05/90	RR
Seat	Ibiza 1.5 021A (1985-1993)	10/86-05/90	RR
Seat	Ibiza 1.5 021A (1985-1993)	10/86-05/90	FR DS

Seat	Ibiza 1.5 Injection 021A (1985-1993)	07/89-12/93	RR
Seat	Ibiza 1.5 Injection 021A (1985-1993)	07/89-12/93	FR DS
Seat	Ibiza 1.5 Injection 021A (1985-1993)	07/89-12/93	FR DS
Seat	Ibiza 1.5 Injection 021A (1985-1993)	07/89-12/93	RR
Seat	Ibiza 1.7 021A (1985-1993)	06/90-12/93	FR DS
Seat	Ibiza 1.7 021A (1985-1993)	06/90-12/93	RR
Seat	Ibiza 1.7 021A (1985-1993)	06/90-12/93	RR
Seat	Ibiza 1.7 021A (1985-1993)	06/90-12/93	FR DS
Seat	Inca 1.4 (1996-2004)	05/98-10/99	FR PS
Seat	Inca 1.4 (1996-2004)	05/98-10/99	FR PS
Seat	Inca 1.4 (1996-2004)	05/98-10/99	FR PS
Seat	Inca 1.4 (1996-2004)	05/98-10/99	FR PS
Seat	Inca 1.9 (1996-2004)	04/96-10/99	FR PS
Seat	Inca 1.9 SDi (1996-2004)	10/99-03/04	FR PS
Seat	Inca 1.9 SDi (1996-2004)	10/99-03/04	FR PS
Skoda	Favorit 1.3 (1989-1996)	01/93-06/94	FR PS
Skoda	Favorit 1.3 (1989-1996)	01/93-06/94	FR PS
Skoda	Favorit 1.3 (1989-1996)	01/93-06/94	FR DS
Skoda	Favorit 1.3 (1989-1996)	01/93-06/94	FR PS
Skoda	Favorit 1.3 (1989-1996)	01/93-06/94	FR DS
Skoda	Favorit 1.3 (1989-1996)	01/93-06/94	FR DS
Skoda	Favorit 1.3 (1989-1996)	01/93-06/94	FR PS
Skoda	Favorit 1.3 (1989-1996)	01/93-06/94	FR DS
Skoda	Favorit 1.3 136 (1989-1996)	06/89-12/92	FR PS
Skoda	Favorit 1.3 136 (1989-1996)	06/89-12/92	FR DS
Skoda	Favorit 1.3 136 (1989-1996)	06/91-12/92	FR PS
Skoda	Favorit 1.3 136 (1989-1996)	06/91-12/92	FR DS
Skoda	Favorit 1.3 E (1989-1996)	01/93-03/96	FR DS
Skoda	Favorit 1.3 E (1989-1996)	01/93-03/96	FR PS
Skoda	Favorit 1.3 E (1989-1996)	01/93-09/95	FR PS
Skoda	Favorit 1.3 E (1989-1996)	01/93-09/95	FR DS
Skoda	Favorit Forman 1.3 (1989-1996)	01/92-12/94	FR PS
Skoda	Favorit Forman 1.3 (1989-1996)	01/92-12/94	FR DS
Smart	Forfour 1.0 (2004-2007)	10/05-12/07	FR PS
Smart	Forfour 1.0 (2004-2007)	10/05-12/07	FR PS
Smart	Forfour 1.1 (2004-2007)	06/04-12/07	FR PS
Smart	Forfour 1.1 (2004-2007)	06/04-12/07	FR PS
Smart	Forfour 1.1 (2004-2007)	06/04-12/07	FR PS
Smart	Forfour 1.1 (2004-2007)	06/04-12/07	FR PS
Smart	Forfour 1.3 (2004-2007)	06/04-12/07	FR PS
Smart	Forfour 1.3 (2004-2007)	06/04-12/07	FR PS
Smart	Forfour 1.5 (2004-2007)	06/04-12/07	FR PS
Smart	Forfour 1.5 (2004-2007)	06/04-12/07	FR PS
Smart	Forfour 1.5 Brabus (2004-2007)	05/05-12/07	FR PS
Smart	Forfour 1.5 Brabus (2004-2007)	05/05-12/07	FR PS
Smart	Forfour 1.5 CDi (2004-2007)	08/04-12/07	FR PS
Smart	Forfour 1.5 CDi (2004-2007)	08/04-12/07	FR PS
Smart	Forfour 1.5 CDi (2004-2007)	08/04-12/07	FR PS
Smart	Forfour 1.5 CDi (2004-2007)	08/04-12/07	FR PS
Smart	Roadster 0.7 (2003-2006)	06/03-04/07	FR PS

Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR PS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR PS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR PS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR PS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR PS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR PS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR PS
Subaru	Impreza 2.0 (1993-2000)	12/95-03/99	FR PS
Subaru	Impreza 2.0 (1993-2000)	12/95-03/99	FR PS
Subaru	Impreza 2.0 P1 (1993-2000)	04/99-11/00	FR PS
Subaru	Impreza 2.0 P1 (1993-2000)	04/99-11/00	FR PS
Subaru	Impreza 2.0 P1 (1993-2000)	04/99-11/00	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	01/93-03/99	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	01/93-03/99	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	01/93-03/99	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	01/93-03/99	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/94-03/99	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR PS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR PS
Subaru	Justy 1.3 (1996-2001)	03/96-12/01	FR PS
Subaru	Justy 1.3 (1996-2001)	03/96-12/01	FR PS
Suzuki	Alto 1.0 G10B (1997-2002)	02/97-12/02	FR DS
Suzuki	Alto 1.0 G10B (1997-2002)	02/97-12/02	FR DS
Suzuki	Alto 1.0 G10B (1997-2002)	02/97-12/99	FR DS
Suzuki	Alto 1.0 G10B (1997-2002)	02/97-12/99	FR DS
Suzuki	Alto 1.0 G10BB (1997-2002)	01/00-12/02	FR DS
Suzuki	Alto 1.0 G10BB (1997-2002)	01/00-12/02	FR DS
Suzuki	Alto 1.1 (2003-2007)	01/03-03/07	FR DS
Suzuki	Alto 1.1 (2003-2007)	01/03-03/07	FR DS
Suzuki	Baleno 1.0 (2016-2019)	02/16-12/19	FR PS
Suzuki	Baleno 1.0 (2016-2019)	02/16-12/19	FR PS
Suzuki	Baleno 1.2 (2016-2019)	02/16-12/19	FR PS
Suzuki	Baleno 1.2 SHVS (2016-2019)	05/16-12/19	FR PS
Suzuki	Baleno 1.3 (1995-2002)	05/95-01/02	FR PS
Suzuki	Baleno 1.6 (1995-2002)	05/95-08/99	FR PS
Suzuki	Baleno 1.6 (1995-2002)	05/95-08/99	FR PS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR PS

Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR PS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR PS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR PS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR PS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR PS
Suzuki	Baleno 1.8 (1995-2002)	06/99-01/02	FR PS
Suzuki	Baleno 1.8 (1995-2002)	06/99-01/02	FR PS
Suzuki	Baleno 1.8 (1995-2002)	08/00-01/02	FR PS
Suzuki	Baleno 1.8 (1995-2002)	08/96-12/97	FR PS
Suzuki	Ignis 1.2 (2016-2025)	08/16-04/21	FR PS
Suzuki	Ignis 1.2 (2016-2025)	08/16-04/21	FR PS
Suzuki	Ignis 1.2 SHVS (2016-2025)	06/16-04/21	FR PS
Suzuki	Ignis 1.2 SHVS Allgrip (2016-2025)	06/16-04/21	FR PS
Suzuki	Ignis 1.3 (2000-2008)	09/03-08/08	FR PS
Suzuki	Ignis 1.3 (2000-2008)	09/03-08/08	FR PS
Suzuki	Ignis 1.3 (2000-2008)	12/00-06/04	FR PS
Suzuki	Ignis 1.3 (2000-2008)	12/00-06/04	FR PS
Suzuki	Ignis 1.3 (2000-2008)	12/00-06/05	FR PS
Suzuki	Ignis 1.3 (2000-2008)	12/00-06/05	FR PS
Suzuki	Ignis 1.5 (2000-2008)	09/03-06/08	FR PS
Suzuki	Ignis 1.5 4GRIP (2000-2008)	09/03-06/08	FR PS
Suzuki	Ignis 1.5 Sport (2000-2008)	09/03-08/06	FR PS
Suzuki	Ignis 1.5 Sport (2000-2008)	09/03-08/06	FR PS
Suzuki	Jimny 1.3 Hard Top (1998-2018)	01/05-04/18	FR DS
Suzuki	Jimny 1.3 Hard Top (1998-2018)	01/05-04/18	FR DS
Suzuki	Jimny 1.3 Hard Top (1998-2018)	02/01-02/05	FR DS
Suzuki	Jimny 1.3 Hard Top (1998-2018)	02/01-02/05	FR DS
Suzuki	Jimny 1.3 Hard Top (1998-2018)	10/98-02/05	FR DS
Suzuki	Jimny 1.3 Hard Top (1998-2018)	10/98-02/05	FR DS
Suzuki	Jimny 1.3 Soft Top (1998-2018)	01/05-12/06	FR DS
Suzuki	Liana 1.3	01/02-12/06	FR PS
Suzuki	Liana 1.3	01/02-12/06	FR PS
Suzuki	Liana 1.6 (2001-2008)	04/04-03/08	FR PS
Suzuki	Liana 1.6 (2001-2008)	04/04-03/08	FR PS
Suzuki	Liana 1.6 (2001-2008)	04/04-03/08	FR PS
Suzuki	Liana 1.6 (2001-2008)	04/04-03/08	FR PS
Suzuki	Liana 1.6 (2001-2008)	06/01-04/04	FR PS
Suzuki	Liana 1.6 (2001-2008)	06/01-04/04	FR PS
Suzuki	Liana 1.6 (2001-2008)	08/02-04/04	FR PS
Suzuki	Liana 1.6 (2001-2008)	08/02-04/04	FR PS
Suzuki	SA310 1.0 (1984)	03/84-10/84	FR DS
Suzuki	SA310 1.0 (1984)	03/84-10/84	FR DS
Suzuki	SA310 1.0 (1984)	03/84-10/84	FR PS
Suzuki	SA310 1.0 (1984)	03/84-10/84	FR PS
Suzuki	Swift 1.0 (1984-1986)	10/84-12/85	FR DS
Suzuki	Swift 1.0 (1984-1986)	10/84-12/85	FR PS
Suzuki	Swift 1.0 (1984-1986)	10/84-12/85	FR DS
Suzuki	Swift 1.0 (1984-1986)	10/84-12/85	FR PS
Suzuki	Swift 1.0 (1992-2003)	01/95-10/03	FR PS
Suzuki	Swift 1.0 (1992-2003)	01/95-10/03	FR PS

Suzuki	Swift 1.0 (1992-2003)	04/96-12/99	FR PS
Suzuki	Swift 1.2 AZ (2010-2017)	08/10-12/17	FR PS
Suzuki	Swift 1.2 AZ (2010-2017)	08/10-12/17	FR PS
Suzuki	Swift 1.2 AZ (2010-2017)	08/10-12/17	FR PS
Suzuki	Swift 1.3 (1984-1986)	03/85-10/86	FR PS
Suzuki	Swift 1.3 (1984-1986)	03/85-10/86	FR DS
Suzuki	Swift 1.3 (1986-1992)	04/92-07/92	FR PS
Suzuki	Swift 1.3 (1986-1992)	04/92-07/92	FR PS
Suzuki	Swift 1.3 (1986-1992)	10/86-12/88	FR DS
Suzuki	Swift 1.3 (1986-1992)	10/86-12/88	FR PS
Suzuki	Swift 1.3 (1986-1992)	10/86-12/88	FR DS
Suzuki	Swift 1.3 (1986-1992)	10/86-12/88	FR PS
Suzuki	Swift 1.3 (1992-2003)	04/92-04/92	FR PS
Suzuki	Swift 1.3 (1992-2003)	04/92-04/92	FR PS
Suzuki	Swift 1.3 (1992-2003)	04/92-04/92	FR PS
Suzuki	Swift 1.3 (1992-2003)	04/92-04/92	FR PS
Suzuki	Swift 1.3 GTi (1986-1992)	10/86-07/92	FR PS
Suzuki	Swift 1.3 GTi (1986-1992)	10/86-07/92	FR DS
Suzuki	Swift 1.3 GTi (1992-2003)	04/92-12/96	FR PS
Suzuki	Swift 1.6 (1986-1992)	03/90-07/92	FR PS
Suzuki	Swift 1.6 Sport AZ (2010-2017)	10/11-12/17	FR PS
Suzuki	Swift 1.6 Sport AZ (2010-2017)	10/11-12/17	FR PS
Suzuki	Vitara 1.6 JLX SE (1988-2002)	09/91-12/98	FR DS
Suzuki	Vitara 1.6 JLX SE (1988-2002)	09/91-12/98	FR DS
Suzuki	Vitara 1.6 JLX SE (1988-2002)	09/91-12/98	FR PS
Suzuki	Vitara 1.6 JLX SE (1988-2002)	09/91-12/98	FR DS
Suzuki	Vitara 1.6 JLX SE (1988-2002)	09/91-12/98	FR PS
Suzuki	Vitara 1.6 JLX SE (1988-2002)	09/91-12/98	FR DS
Suzuki	Vitara 1.6 JLX SE (1988-2002)	09/91-12/98	FR PS
Suzuki	Vitara 1.6 JLX SE (1988-2002)	09/91-12/98	FR PS
Suzuki	Wagon R+ 1.0 (1997-2000)	10/97-12/00	FR PS
Suzuki	Wagon R+ 1.2 (1997-2000)	08/98-12/00	FR PS
Suzuki	Wagon R+ 1.2 (1997-2000)	08/98-12/00	FR PS
Suzuki	Wagon R+ 1.3 (2000-2008)	05/00-12/03	FR PS
Suzuki	Wagon R+ 1.3 (2000-2008)	05/00-12/03	FR PS
Suzuki	Wagon R+ 1.3 (2000-2008)	10/03-08/06	FR PS
Suzuki	Wagon R+ 1.3 (2000-2008)	10/03-08/06	FR PS
Suzuki	X90 1.6 (1996-1998)	01/97-08/98	FR DS
Suzuki	X90 1.6 (1996-1998)	01/97-08/98	FR PS
Suzuki	X90 1.6 (1996-1998)	05/96-08/98	FR PS
Suzuki	X90 1.6 (1996-1998)	05/96-08/98	FR PS
Suzuki	X90 1.6 (1996-1998)	05/96-08/98	FR DS
Suzuki	X90 1.6 (1996-1998)	05/96-08/98	FR PS
Suzuki	X90 1.6 (1996-1998)	05/96-08/98	FR DS
Suzuki	X90 1.6 (1996-1998)	05/96-08/98	FR DS
Toyota	Avensis 1.6 T220 (1997-2003)	08/00-05/03	FR PS
Toyota	Avensis 1.6 T220 (1997-2003)	08/00-05/03	FR PS
Toyota	Avensis 1.6 T220 (1997-2003)	11/97-04/01	FR PS
Toyota	Avensis 1.6 T220 (1997-2003)	11/97-04/01	FR PS
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	FR PS

Toyota	Carina E 1.8 AT191	03/96-03/98	FR PS
Toyota	Carina E 1.8 AT191	03/96-03/98	FR PS
Toyota	Carina E 1.8 AT191	06/95-03/96	FR PS
Toyota	Carina E 2.0 CT190	03/96-03/98	FR PS
Toyota	Carina E 2.0 CT190	03/96-03/98	FR PS
Toyota	Carina E 2.0 CT190	05/92-03/96	FR PS
Toyota	Carina E 2.0 CT190	05/92-03/96	FR PS
Toyota	Carina E 2.0 GTi ST191	05/92-05/94	FR PS
Toyota	Carina E 2.0 GTi ST191	05/92-06/94	FR PS
Toyota	Carina E 2.0 GTi ST191	06/94-01/96	FR PS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR PS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR PS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR PS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR PS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR PS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR PS
Toyota	Celica 2.0 RA61	02/82-11/85	FR PS
Toyota	Celica 2.0 RA61	02/82-11/85	FR PS
Toyota	Celica 2.0 ST162	03/87-03/88	FR PS
Toyota	Celica 2.0 ST162	03/87-03/88	FR PS
Toyota	Celica 2.0 ST162	11/85-02/90	FR PS
Toyota	Celica 2.0 ST162	11/85-02/90	FR PS
Toyota	Celica 2.8 Supra MA61	08/82-07/86	FR PS
Toyota	Corolla 1.3 (E100) EE101	01/95-07/95	FR PS
Toyota	Corolla 1.3 (E100) EE101	01/95-07/95	RR
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	RR
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	RR
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	RR
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	FR PS
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	FR PS
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	FR PS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR PS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	RR
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	RR
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR PS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	RR
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR PS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR PS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR PS
Toyota	Corolla 1.3 (E110) EE111	06/97-02/00	FR PS
Toyota	Corolla 1.3 (E110) EE111	06/97-02/00	FR PS
Toyota	Corolla 1.3 (E110) EE111	06/97-02/00	FR PS
Toyota	Corolla 1.3 (E110) EE111	06/97-02/00	FR PS
Toyota	Corolla 1.3 (E110) EE111 G6	06/97-02/00	FR PS
Toyota	Corolla 1.3 (E80) EE80	03/85-08/87	FR DS
Toyota	Corolla 1.3 (E80) EE80	03/85-08/87	FR DS
Toyota	Corolla 1.3 (E80) EE80	03/85-08/87	FR DS
Toyota	Corolla 1.3 (E80) EE80	03/85-08/87	FR DS
Toyota	Corolla 1.4 (E110) ZZE111	02/00-03/02	FR PS
Toyota	Corolla 1.4 (E110) ZZE111	02/00-03/02	FR PS
Toyota	Corolla 1.4 (E120) ZZE121	09/02-07/07	FR PS

Toyota	Corolla 1.4 (E120) ZZE121	12/01-07/07	FR PS
Toyota	Corolla 1.4 (E120) ZZE121	12/01-07/07	FR PS
Toyota	Corolla 1.4 D-4D (E120) NDE120	08/04-07/07	FR PS
Toyota	Corolla 1.4 D-4D (E120) NDE120	08/04-07/07	FR PS
Toyota	Corolla 1.4 D-4D (E120) NDE120	08/04-07/07	FR PS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	RR
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	FR PS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	RR
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	FR PS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	FR PS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	FR PS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	RR
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR PS
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR PS
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR PS
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR PS
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR PS
Toyota	Corolla 1.6 (E110) AE111	10/98-02/00	FR PS
Toyota	Corolla 1.6 (E110) AE111	10/98-02/00	FR PS
Toyota	Corolla 1.6 (E110) ZZE111	02/00-03/02	FR PS
Toyota	Corolla 1.6 (E110) ZZE112	02/00-03/02	FR PS
Toyota	Corolla 1.6 (E110) ZZE112	02/00-03/02	FR PS
Toyota	Corolla 1.6 (E110) ZZE112	02/00-03/02	FR PS
Toyota	Corolla 1.6 (E110) ZZE112	02/00-03/02	FR PS
Toyota	Corolla 1.6 (E110) ZZE112	02/00-03/02	FR PS
Toyota	Corolla 1.6 (E120) ZZE121	09/02-07/07	FR PS
Toyota	Corolla 1.6 (E120) ZZE121	12/01-07/07	FR PS
Toyota	Corolla 1.6 (E120) ZZE121	12/01-07/07	FR PS
Toyota	Corolla 1.6 (E120) ZZE121	12/01-07/07	FR PS
Toyota	Corolla 1.6 (E120) ZZE121	12/01-07/07	FR PS
Toyota	Corolla 1.6 (E90) AE92	08/87-12/92	FR PS
Toyota	Corolla 1.6 (E90) AE92	08/87-12/92	FR PS
Toyota	Corolla 1.6 (E90) AE95	03/88-12/91	FR PS
Toyota	Corolla 1.6 GT (E80) AE82	03/85-08/87	FR DS
Toyota	Corolla 1.6 GT (E80) AE82	03/85-08/87	FR DS
Toyota	Corolla 1.6 GT (E80) AE82	03/85-08/87	FR DS
Toyota	Corolla 1.6 GT (E80) AE86	02/84-08/87	FR DS
Toyota	Corolla 1.6 GTi-16 (E90) AE92	08/87-08/92	FR PS
Toyota	Corolla 1.6 GTi-16 (E90) AE92	08/87-08/92	RR
Toyota	Corolla 1.8 (E100) AE102	03/93-03/95	RR
Toyota	Corolla 1.8 (E100) AE102	03/93-03/95	FR PS
Toyota	Corolla 1.8 (E120) ZZE123	12/01-07/06	FR PS
Toyota	Corolla 1.8 (E120) ZZE123	12/01-07/06	FR PS
Toyota	Corolla 1.8 Compressor (E120) ZZE123	11/05-03/06	FR PS
Toyota	Corolla 1.8 T Sport Compressor (E120) ZZE123	07/06-12/06	FR PS
Toyota	Corolla 1.9 (E110) ZZE110	02/00-10/00	FR PS
Toyota	Corolla 2.0 (E110) CDE110	10/00-03/02	FR PS
Toyota	Corolla 2.0 (E110) CDE110	10/00-03/02	FR PS
Toyota	Corolla 2.0 (E110) CE110	06/97-02/00	FR PS

Toyota	Corolla 2.0 (E120) CDE120	08/04-07/07	FR PS
Toyota	Corolla 2.0 (E120) CDE120	12/01-08/03	FR PS
Toyota	Corolla 2.0 (E120) CDE120	12/01-08/03	FR PS
Toyota	Corolla 2.0 (E120) CDE120	12/01-09/04	FR PS
Toyota	Corolla 2.0 (E120) CDE120	12/01-09/04	FR PS
Toyota	Corolla 2.0 (E120) CDE120	12/01-09/04	FR PS
Toyota	Corolla 2.0 D-4D (E120) CDE120	06/03-07/07	FR PS
Toyota	Corolla 2.0 D-4D (E120) CDE120	06/03-07/07	FR PS
Toyota	Estima 2.4	12/99-12/05	FR PS
Toyota	Estima 2.4	12/99-12/05	FR PS
Toyota	Hi-Ace 2.4 RZH103/113	07/94-01/96	RR
Toyota	Hi-Lux 1.8 YN56	01/85-12/88	RR
Toyota	Hi-Lux 1.8 YN56	01/85-12/88	RR
Toyota	Hi-Lux 2.0 YN65	01/85-12/88	RR
Toyota	Hi-Lux 2.0 YN65	01/85-12/88	RR
Toyota	Hi-Lux 2.2 YN65/67	09/86-07/88	RR
Toyota	Hi-Lux 2.5 LN65/66/67	01/86-12/88	RR
Toyota	iQ 1.0 (2009-2015)	01/09-08/15	FR PS
Toyota	iQ 1.0 (2009-2015)	01/09-08/15	FR PS
Toyota	iQ 1.33 (2009-2015)	06/09-08/15	FR PS
Toyota	iQ 1.33 (2009-2015)	06/09-08/15	FR PS
Toyota	MR2 1.6 AW11	03/85-04/90	FR PS
Toyota	MR2 1.6 AW11	03/85-04/90	FR DS
Toyota	MR2 1.6 T-Bar AW11	05/86-04/90	FR PS
Toyota	MR2 1.6 T-Bar AW11	05/86-04/90	FR DS
Toyota	Paseo 1.5 EL54	03/96-12/99	FR PS
Toyota	Power Van 2.4 RCH13/23	01/96-01/98	RR
Toyota	Previa 2.0 CLR307	05/01-05/07	FR PS
Toyota	Previa 2.4 ACR30	07/00-05/06	FR PS
Toyota	Previa 2.4 ACR30	07/00-05/07	FR PS
Toyota	Previa 2.4 TCR11	09/90-12/00	FR PS
Toyota	Previa 2.4 TCR11	09/90-12/00	FR PS
Toyota	RAV-4 2.0 XA10 (1994-2000)	06/94-10/96	FR PS
Toyota	RAV-4 2.0 XA10 (1994-2000)	06/94-10/96	FR PS
Toyota	RAV-4 2.0 XA10 (1994-2000)	06/94-10/96	FR PS
Toyota	RAV-4 2.0 XA10 (1994-2000)	06/94-10/96	FR PS
Toyota	RAV-4 2.0 XA10 (1994-2000)	10/96-08/00	FR PS
Toyota	RAV-4 2.0 XA10 (1994-2000)	10/96-08/00	FR PS
Toyota	RAV-4 2.0 XA10 (1994-2000)	10/96-08/00	FR PS
Toyota	RAV-4 2.0 XA10 (1994-2000)	10/96-08/00	FR PS
Vauxhall	Agila 1.0 (2000-2008)	06/00-10/03	FR PS
Vauxhall	Agila 1.0 (2000-2008)	10/03-06/08	FR PS
Vauxhall	Agila 1.0 (2008-2014)	03/08-08/12	FR PS
Vauxhall	Agila 1.0 (2008-2014)	07/11-12/14	FR PS
Vauxhall	Agila 1.2 (2000-2008)	06/00-12/04	FR PS
Vauxhall	Agila 1.2 (2008-2014)	03/08-05/11	FR PS
Vauxhall	Agila 1.2 (2008-2014)	03/08-05/11	FR PS
Vauxhall	Agila 1.2 (2008-2014)	09/10-12/14	FR PS
Vauxhall	Agila 1.2 (2008-2014)	09/10-12/14	FR PS
Vauxhall	Agila 1.2 Twinport (2000-2008)	10/04-06/08	FR PS

Vauxhall	Astra F 1.8 MK 3 (1991-1998)	08/94-12/99	FR DS
Vauxhall	Astra F 1.8 MK 3 (1991-1998)	08/94-12/99	FR PS
Vauxhall	Astra F 1.8 MK 3 (1991-1998)	08/94-12/99	FR DS
Vauxhall	Astra F 1.8 MK 3 (1991-1998)	08/94-12/99	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR DS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	04/95-12/98	FR DS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	07/93-12/94	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	07/93-12/94	FR DS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	10/91-04/95	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR DS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR PS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR DS
Vauxhall	Astra F 2.0 MK 3 (1991-1998)	10/91-12/93	FR PS
Vauxhall	Astramax 1.3 (1986-1994)	12/86-12/89	FR PS
Vauxhall	Astramax 1.3 (1986-1994)	12/86-12/89	FR DS
Vauxhall	Astramax 1.4 (1986-1994)	09/89-12/91	FR PS
Vauxhall	Astramax 1.4 (1986-1994)	09/89-12/91	FR DS
Vauxhall	Astramax 1.4 SPi (1986-1994)	10/91-07/94	FR PS
Vauxhall	Astramax 1.4 SPi (1986-1994)	10/91-07/94	FR DS
Vauxhall	Astramax 1.6 (1986-1994)	12/86-01/89	FR DS
Vauxhall	Astramax 1.6 (1986-1994)	12/86-01/89	FR PS
Vauxhall	Astramax 1.6 SPi (1986-1994)	10/91-07/94	FR DS
Vauxhall	Astramax 1.6 SPi (1986-1994)	10/91-07/94	FR DS
Vauxhall	Astramax 1.6 SPi (1986-1994)	10/91-07/94	FR PS
Vauxhall	Astramax 1.6 SPi (1986-1994)	10/91-07/94	FR PS
Vauxhall	Belmont 1.3 (1986-1991)	01/86-12/87	FR DS
Vauxhall	Belmont 1.3 (1986-1991)	01/86-12/87	FR PS
Vauxhall	Belmont 1.3 (1986-1991)	01/86-12/89	FR DS
Vauxhall	Belmont 1.3 (1986-1991)	01/86-12/89	FR PS
Vauxhall	Belmont 1.3 (1986-1991)	01/86-12/89	FR PS
Vauxhall	Belmont 1.3 (1986-1991)	01/86-12/89	FR DS
Vauxhall	Belmont 1.4 SPi Catalyst (1986-1991)	08/90-12/91	FR PS
Vauxhall	Belmont 1.4 SPi Catalyst (1986-1991)	08/90-12/91	FR DS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-01/89	FR DS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-01/89	FR PS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR PS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR PS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR PS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR PS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR PS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR DS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR DS
Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR DS

Vauxhall	Belmont 1.6 (1986-1991)	01/86-08/86	FR DS
Vauxhall	Belmont 1.6 (1986-1991)	08/86-12/91	FR PS
Vauxhall	Belmont 1.6 (1986-1991)	08/86-12/91	FR DS
Vauxhall	Belmont 1.6 (1986-1991)	08/86-12/91	FR PS
Vauxhall	Belmont 1.6 (1986-1991)	08/86-12/91	FR DS
Vauxhall	Belmont 1.7 (1986-1991)	01/89-12/91	FR DS
Vauxhall	Belmont 1.7 (1986-1991)	01/89-12/91	FR PS
Vauxhall	Belmont 1.8 (1986-1991)	01/86-12/91	FR DS
Vauxhall	Belmont 1.8 (1986-1991)	01/86-12/91	FR DS
Vauxhall	Belmont 1.8 (1986-1991)	01/86-12/91	FR PS
Vauxhall	Belmont 1.8 (1986-1991)	01/86-12/91	FR PS
Vauxhall	Belmont 1.8 (1986-1991)	12/88-12/91	FR DS
Vauxhall	Belmont 1.8 (1986-1991)	12/88-12/91	FR PS
Vauxhall	Belmont 1.8 (1986-1991)	12/88-12/91	FR DS
Vauxhall	Belmont 1.8 (1986-1991)	12/88-12/91	FR PS
Vauxhall	Brava 2.5 (1988-1997)	02/90-03/97	FR PS
Vauxhall	Brava 2.5 (1988-1997)	02/90-03/97	FR DS
Vauxhall	Brava 2.5 (1997-2002)	03/97-06/02	FR DS
Vauxhall	Brava 2.5 (1997-2002)	03/97-06/02	FR PS
Vauxhall	Brava 2.5 (1997-2002)	08/01-12/02	FR DS
Vauxhall	Brava 2.5 (1997-2002)	08/01-12/02	FR PS
Vauxhall	Brava 2.5 (1997-2002)	08/01-12/02	FR PS
Vauxhall	Brava 2.5 (1997-2002)	08/01-12/02	FR DS
Vauxhall	Brava 2.5 Dual Cab (1988-1997)	11/94-03/97	FR PS
Vauxhall	Brava 2.5 Dual Cab (1988-1997)	11/94-03/97	FR DS
Vauxhall	Brava 2.5 Dual Cab (1997-2002)	03/97-06/02	FR PS
Vauxhall	Brava 2.5 Dual Cab (1997-2002)	03/97-06/02	FR DS
Vauxhall	Brava 2.5 Dual Cab (1997-2002)	05/97-06/02	FR PS
Vauxhall	Brava 2.5 Dual Cab (1997-2002)	05/97-06/02	FR DS
Vauxhall	Brava 2.5 Dual Cab (1997-2002)	08/01-12/02	FR PS
Vauxhall	Brava 2.5 Dual Cab (1997-2002)	08/01-12/02	FR DS
Vauxhall	Brava 2.5 Dual Cab (1997-2002)	08/01-12/02	FR DS
Vauxhall	Brava 2.5 Dual Cab (1997-2002)	08/01-12/02	FR PS
Vauxhall	Brava 2.5 TD (1988-1997)	02/90-03/97	FR DS
Vauxhall	Brava 2.5 TD (1988-1997)	02/90-03/97	FR PS
Vauxhall	Brava 2.5 TD (1997-2002)	03/97-06/02	FR PS
Vauxhall	Brava 2.5 TD (1997-2002)	03/97-06/02	FR DS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR DS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR DS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR DS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR PS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR PS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR PS
Vauxhall	Carlton 2.0 Injection (1978-1986)	07/83-12/84	FR PS
Vauxhall	Carlton 2.0 Injection (1978-1986)	07/83-12/84	FR DS
Vauxhall	Carlton 2.0 Injection (1978-1986)	07/83-12/84	FR DS
Vauxhall	Carlton 2.0 Injection (1978-1986)	07/83-12/84	FR PS
Vauxhall	Carlton 2.2 (1978-1986)	08/84-12/86	FR DS
Vauxhall	Carlton 2.2 (1978-1986)	08/84-12/86	FR PS
Vauxhall	Carlton 2.2 (1978-1986)	08/84-12/86	FR DS

Vauxhall	Carlton 2.2 (1978-1986)	08/84-12/86	FR PS
Vauxhall	Carlton 2.3 (1978-1986)	10/82-12/86	FR PS
Vauxhall	Carlton 2.3 (1978-1986)	10/82-12/86	FR DS
Vauxhall	Carlton 2.3 (1978-1986)	10/82-12/86	FR PS
Vauxhall	Carlton 2.3 (1978-1986)	10/82-12/86	FR DS
Vauxhall	Cavalier 1.3 (1975-1981)	01/80-12/81	FR DS
Vauxhall	Cavalier 1.3 (1975-1981)	01/80-12/81	FR PS
Vauxhall	Cavalier 1.3 (1981-1988)	08/81-12/88	FR PS
Vauxhall	Cavalier 1.3 (1981-1988)	08/81-12/88	FR PS
Vauxhall	Cavalier 1.3 (1981-1988)	08/81-12/88	FR DS
Vauxhall	Cavalier 1.3 (1981-1988)	08/81-12/88	FR DS
Vauxhall	Cavalier 1.3 (1981-1988)	08/83-12/88	FR PS
Vauxhall	Cavalier 1.3 (1981-1988)	08/83-12/88	FR DS
Vauxhall	Cavalier 1.3 (1981-1988)	08/83-12/88	RR
Vauxhall	Cavalier 1.3 (1981-1988)	08/83-12/88	FR DS
Vauxhall	Cavalier 1.3 (1981-1988)	08/83-12/88	FR PS
Vauxhall	Cavalier 1.3 (1981-1988)	08/83-12/88	RR
Vauxhall	Cavalier 1.6 (1975-1981)	01/80-12/81	FR DS
Vauxhall	Cavalier 1.6 (1975-1981)	01/80-12/81	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	07/82-12/88	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	07/82-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	07/82-12/88	RR
Vauxhall	Cavalier 1.6 (1981-1988)	07/82-12/88	RR
Vauxhall	Cavalier 1.6 (1981-1988)	07/82-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	07/82-12/88	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	07/83-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	07/83-12/88	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	07/83-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	07/83-12/88	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	RR
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	RR
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-07/82	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	RR
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR DS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	FR PS
Vauxhall	Cavalier 1.6 (1981-1988)	08/81-12/88	RR
Vauxhall	Cavalier 1.6 (1981-1988)	10/83-12/88	FR DS

Vauxhall	Corsa C 1.4 Twinport (2003-2007)	10/03-04/07	FR PS
Vauxhall	Corsa C 1.4 Twinport (2003-2007)	10/03-04/07	FR PS
Vauxhall	Corsa C 1.4 Twinport (2003-2007)	10/03-04/07	FR PS
Vauxhall	Corsa C 1.4 Twinport (2003-2007)	10/03-04/07	FR PS
Vauxhall	Corsa C 1.7 CDTi (2003-2007)	10/03-11/05	FR PS
Vauxhall	Corsa C 1.7 CDTi (2003-2007)	10/03-11/05	FR PS
Vauxhall	Corsa C 1.7 Di (2000-2003)	02/01-10/03	FR PS
Vauxhall	Corsa C 1.7 Di (2000-2003)	08/01-10/03	FR PS
Vauxhall	Corsa C 1.7 Di (2000-2003)	08/01-10/03	FR PS
Vauxhall	Corsa C 1.7 Di (2000-2003)	08/01-10/03	FR PS
Vauxhall	Corsa C 1.7 Di (2000-2003)	10/00-08/01	FR PS
Vauxhall	Corsa C 1.7 Di (2000-2003)	10/00-08/01	FR PS
Vauxhall	Corsa C 1.7 DTi (2000-2003)	02/01-10/03	FR PS
Vauxhall	Corsa C 1.7 DTi (2000-2003)	10/00-10/03	FR PS
Vauxhall	Corsa C 1.7 DTi (2000-2003)	10/00-10/03	FR PS
Vauxhall	Corsa C 1.7 DTi (2000-2003)	10/00-10/03	FR PS
Vauxhall	Corsa C 1.8 (2000-2003)	10/00-10/03	FR PS
Vauxhall	Corsa C 1.8 (2000-2003)	10/00-10/03	FR PS
Vauxhall	Corsa C 1.8 (2003-2007)	10/03-11/05	FR PS
Vauxhall	Corsa C 1.8 (2003-2007)	10/03-11/05	FR PS
Vauxhall	Insignia 1.4 (2008-2014)	06/11-12/14	FR PS
Vauxhall	Insignia 1.4 (2008-2014)	06/11-12/14	FR PS
Vauxhall	Insignia 1.4 (2008-2014)	06/11-12/14	FR PS
Vauxhall	Insignia 1.4 (2013-2017)	08/13-12/17	FR PS
Vauxhall	Insignia 1.4 (2013-2017)	08/13-12/17	FR PS
Vauxhall	Insignia 1.4 (2013-2017)	12/14-12/17	FR PS
Vauxhall	Insignia 1.4 (2013-2017)	12/14-12/17	FR PS
Vauxhall	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Vauxhall	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Vauxhall	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Vauxhall	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Vauxhall	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Vauxhall	Insignia 1.6 CDTi (2013-2017)	05/15-12/17	FR PS
Vauxhall	Insignia 1.6 SIDI (2013-2017)	08/13-03/16	FR PS
Vauxhall	Insignia 1.6 SIDI (2013-2017)	08/13-03/16	FR PS
Vauxhall	Insignia 1.6 SIDI (2013-2017)	08/13-03/16	FR PS
Vauxhall	Insignia 1.6 SIDI (2013-2017)	08/13-03/16	FR PS
Vauxhall	Insignia 1.6 T (2008-2014)	02/09-12/14	FR PS
Vauxhall	Insignia 1.6 T (2008-2014)	02/09-12/14	FR PS
Vauxhall	Insignia 1.6 T (2008-2014)	02/09-12/14	FR PS
Vauxhall	Insignia 1.8 (2008-2014)	11/08-12/13	FR PS
Vauxhall	Insignia 1.8 (2008-2014)	11/08-12/14	FR PS
Vauxhall	Insignia 1.8 (2008-2014)	11/08-12/14	FR PS
Vauxhall	Insignia 1.8 (2013-2017)	04/15-12/17	FR PS
Vauxhall	Insignia 1.8 (2013-2017)	08/13-12/17	FR PS
Vauxhall	Insignia 2.0 (2013-2017)	08/13-12/17	FR PS
Vauxhall	Insignia 2.0 (2013-2017)	08/13-12/17	FR PS
Vauxhall	Insignia 2.0 (2013-2017)	08/13-12/17	FR PS
Vauxhall	Insignia 2.0 (2013-2017)	08/13-12/17	FR PS
Vauxhall	Insignia 2.0 CDTi 120 (2013-2017)	08/13-03/16	FR PS
Vauxhall	Insignia 2.0 CDTi 120 (2013-2017)	08/13-03/16	FR PS

Vauxhall	Tigra 1.3 CDTi (2004-2010)	03/05-06/10	FR PS
Vauxhall	Tigra 1.4 (1994-2001)	11/94-04/01	FR DS
Vauxhall	Tigra 1.4 (1994-2001)	11/94-04/01	FR PS
Vauxhall	Tigra 1.4 (1994-2001)	11/94-04/01	FR PS
Vauxhall	Tigra 1.4 (1994-2001)	11/94-04/01	FR DS
Vauxhall	Tigra 1.4 (2004-2010)	10/04-06/10	FR PS
Vauxhall	Tigra 1.6 (1994-2001)	11/94-04/01	FR DS
Vauxhall	Tigra 1.6 (1994-2001)	11/94-04/01	FR PS
Vauxhall	Tigra 1.8 (2004-2010)	10/04-06/10	FR PS
Volkswagen	Caddy 1.4 (1996-2004)	02/01-03/04	FR PS
Volkswagen	Caddy 1.4 (1996-2004)	04/96-07/99	FR PS
Volkswagen	Caddy 1.4 (1996-2004)	04/96-07/99	FR PS
Volkswagen	Caddy 1.4 (1996-2004)	04/96-07/99	FR PS
Volkswagen	Caddy 1.6 (1996-2004)	01/98-04/01	FR PS
Volkswagen	Caddy 1.9 (1996-2004)	04/96-03/04	FR PS
Volkswagen	Caddy 1.9 (1996-2004)	04/96-03/04	FR PS
Volkswagen	Caddy 1.9 (1996-2004)	04/96-03/04	FR PS
Volkswagen	Caddy 1.9 (1996-2004)	04/96-12/00	FR PS
Volkswagen	Caddy 1.9 TDi (1996-2004)	05/00-03/04	FR PS
Volkswagen	Caddy 1.9 TDi (1996-2004)	05/00-03/04	FR PS
Volkswagen	Caddy 1.9 TDi (1996-2004)	05/00-03/04	FR PS
Volkswagen	Caravelle 1.6 T25 (T3) (1979-1991)	01/85-12/90	FR PS
Volkswagen	Caravelle 1.6 T25 (T3) (1979-1991)	01/85-12/90	FR DS
Volkswagen	Caravelle 1.6 T25 (T3) (1979-1991)	01/85-12/90	FR DS
Volkswagen	Caravelle 1.6 T25 (T3) (1979-1991)	01/85-12/90	FR PS
Volkswagen	Caravelle 1.6 Turbo T25 (T3) (1979-1991)	01/85-12/90	FR DS
Volkswagen	Caravelle 1.6 Turbo T25 (T3) (1979-1991)	01/85-12/90	FR PS
Volkswagen	Caravelle 1.9 T25 (T3) (1979-1991)	01/85-11/90	FR PS
Volkswagen	Caravelle 1.9 T25 (T3) (1979-1991)	01/85-11/90	FR DS
Volkswagen	Caravelle 1.9 T25 (T3) (1979-1991)	01/85-11/90	FR DS
Volkswagen	Caravelle 1.9 T25 (T3) (1979-1991)	01/85-11/90	FR PS
Volkswagen	Caravelle 1.9 Turbo T4 (1991-1996)	06/94-07/96	RR
Volkswagen	Caravelle 2.1 T25 (T3) (1979-1991)	12/87-12/90	FR DS
Volkswagen	Caravelle 2.1 T25 (T3) (1979-1991)	12/87-12/90	FR DS
Volkswagen	Caravelle 2.1 T25 (T3) (1979-1991)	12/87-12/90	FR PS
Volkswagen	Caravelle 2.1 T25 (T3) (1979-1991)	12/87-12/90	FR PS
Volkswagen	Caravelle 2.4 T4 (1991-1996)	05/91-07/96	RR
Volkswagen	Caravelle 2.4 T4 (1991-1996)	06/93-07/96	RR
Volkswagen	Caravelle 2.4 T4 (1996-1998)	05/96-04/98	RR
Volkswagen	Caravelle 2.4 T4 (1996-1998)	05/96-12/98	RR
Volkswagen	Caravelle 2.4 T4 (1996-1998)	05/96-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	01/97-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	01/97-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	01/97-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	01/97-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	01/97-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	01/97-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	04/98-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	04/98-12/98	RR
Volkswagen	Caravelle 2.5 Turbo T4 (1996-1998)	09/96-12/98	RR

Volkswagen	Transporter 2.5 Turbo T4 (1996-2003)	04/96-12/03	RR
Volkswagen	Transporter 2.5 Turbo T4 (1996-2003)	04/96-12/03	RR
Volkswagen	Transporter 2.5 Turbo T4 (1996-2003)	07/98-12/01	RR
Volkswagen	Transporter 2.5 Turbo T4 (1996-2003)	07/98-12/01	RR
Volkswagen	Transporter 2.5 Turbo T4 (1996-2003)	07/98-12/03	RR
Volkswagen	Transporter 2.5 Turbo T4 (1996-2003)	07/98-12/03	RR
Volvo	340 1.4	09/82-03/90	FR PS
Volvo	340 1.4	09/82-03/90	FR DS
Volvo	340 1.4	09/82-03/90	RR
Volvo	340 1.4	09/82-07/89	FR DS
Volvo	340 1.4	09/82-07/89	RR
Volvo	340 1.4	09/82-07/89	RR
Volvo	340 1.4	09/82-07/89	FR PS
Volvo	340 1.4	09/82-07/89	FR PS
Volvo	340 1.4	09/82-07/89	FR DS
Volvo	340 1.4	09/82-12/91	FR DS
Volvo	340 1.4	09/82-12/91	FR PS
Volvo	340 1.4	09/82-12/91	RR
Volvo	340 1.7	08/85-07/89	FR DS
Volvo	340 1.7	08/85-07/89	FR PS
Volvo	340 1.7	08/85-12/91	FR DS
Volvo	340 1.7	08/85-12/91	FR PS
Volvo	340 1.7	08/85-12/91	FR DS
Volvo	340 1.7	08/85-12/91	FR DS
Volvo	340 1.7	08/85-12/91	RR
Volvo	340 1.7	08/85-12/91	FR PS
Volvo	340 1.7	08/85-12/91	RR
Volvo	340 1.7	08/85-12/91	FR PS
Volvo	340 1.7	08/85-12/91	RR
Volvo	343 1.4	01/80-09/82	FR PS
Volvo	343 1.4	01/80-09/82	FR DS
Volvo	343 1.4	01/80-09/82	RR
Volvo	343 1.4	01/80-09/82	RR
Volvo	343 1.4	01/80-09/82	FR PS
Volvo	343 1.4	01/80-09/82	FR DS
Volvo	345 1.4	01/80-09/82	RR
Volvo	345 1.4	01/80-09/82	RR
Volvo	345 1.4	01/80-09/82	FR PS
Volvo	345 1.4	01/80-09/82	FR PS
Volvo	345 1.4	01/80-09/82	FR DS
Volvo	345 1.4	01/80-09/82	FR DS
Volvo	360 2.0	05/85-07/89	FR DS
Volvo	360 2.0	05/85-07/89	FR PS
Volvo	360 2.0	05/85-07/89	FR DS
Volvo	360 2.0	05/85-07/89	RR
Volvo	360 2.0	05/85-07/89	FR PS
Volvo	360 2.0	05/85-07/89	FR DS
Volvo	360 2.0	05/85-07/89	RR
Volvo	360 2.0	05/85-07/89	FR DS
Volvo	360 2.0	05/85-07/89	FR PS

Volvo	360 2.0	05/85-07/89	RR
Volvo	360 2.0	05/85-07/89	FR PS
Volvo	360 2.0	05/85-07/89	RR
Volvo	360 2.0	09/82-05/85	FR PS
Volvo	360 2.0	09/82-05/85	FR DS
Volvo	360 2.0	09/82-05/85	RR
Volvo	360 2.0	09/82-05/85	FR DS
Volvo	360 2.0	09/82-05/85	RR
Volvo	360 2.0	09/82-05/85	FR DS
Volvo	360 2.0	09/82-05/85	RR
Volvo	360 2.0	09/82-05/85	FR DS
Volvo	360 2.0	09/82-05/85	FR PS
Volvo	360 2.0	09/82-05/85	FR PS
Volvo	360 2.0	09/82-05/85	RR
Volvo	360 2.0	09/82-05/85	FR PS
Volvo	360 2.0	09/83-08/85	FR DS
Volvo	360 2.0	09/83-08/85	FR PS
Volvo	360 2.0 Injection	09/82-07/89	RR
Volvo	360 2.0 Injection	09/82-07/89	FR PS
Volvo	360 2.0 Injection	09/82-07/89	FR PS
Volvo	360 2.0 Injection	09/82-07/89	FR DS
Volvo	360 2.0 Injection	09/82-07/89	FR DS
Volvo	360 2.0 Injection	09/82-07/89	FR PS
Volvo	360 2.0 Injection	09/82-07/89	FR PS
Volvo	360 2.0 Injection	09/82-07/89	FR PS
Volvo	360 2.0 Injection	09/82-07/89	RR
Volvo	360 2.0 Injection	09/82-07/89	FR DS
Volvo	360 2.0 Injection	09/82-07/89	RR
Volvo	360 2.0 Injection	09/82-07/89	FR DS
Volvo	360 2.0 Injection	09/82-07/89	RR
Volvo	360 2.0 Injection	09/82-07/89	FR DS
Volvo	360 2.0 Injection	09/82-07/89	RR
Volvo	360 2.0 Injection	09/82-07/89	FR PS
Volvo	360 2.0 Injection	09/83-07/89	FR PS
Volvo	360 2.0 Injection	09/83-07/89	FR DS
Volvo	360 2.0 Injection	09/83-07/89	FR PS
Volvo	360 2.0 Injection	09/83-07/89	FR DS
Volvo	360 2.0 Injection	09/83-07/89	FR DS
Volvo	360 2.0 Injection	09/83-07/89	FR PS