

Lucas

Compatibility Chart

MANUFACTURER	CAR MODEL	YEAR RANGE	POSITION
Abarth	124 1.4 Spider MultiAir 170 (2016-2019)	06/16-12/19	FR PS
Abarth	124 1.4 Spider MultiAir 170 (2016-2019)	06/16-12/19	FR PS
Alfa Romeo	145 1.6 930 (1994-2001)	03/97-01/01	FR PS
Alfa Romeo	145 1.6 930 (1994-2001)	10/94-03/97	FR PS
Alfa Romeo	145 1.7 930 (1994-2001)	10/94-03/97	FR PS
Alfa Romeo	145 1.8 930 (1994-2001)	03/97-01/01	FR PS
Alfa Romeo	145 1.8 930 (1994-2001)	03/97-01/01	FR PS
Alfa Romeo	145 1.8 930 (1994-2001)	03/97-01/01	FR PS
Alfa Romeo	145 2.0 930 (1994-2001)	02/96-05/99	FR PS
Alfa Romeo	145 2.0 930 (1994-2001)	02/96-05/99	FR PS
Alfa Romeo	145 2.0 930 (1994-2001)	05/99-01/01	FR PS
Alfa Romeo	146 1.6 930 (1995-2001)	03/97-01/01	FR PS
Alfa Romeo	146 1.6 930 (1995-2001)	03/97-01/01	FR PS
Alfa Romeo	146 1.6 930 (1995-2001)	06/95-03/97	FR PS
Alfa Romeo	146 1.7 930 (1995-2001)	06/95-03/97	FR PS
Alfa Romeo	146 1.8 930 (1995-2001)	03/97-01/01	FR PS
Alfa Romeo	146 1.8 930 (1995-2001)	03/97-01/01	FR PS
Alfa Romeo	146 1.8 930 (1995-2001)	03/97-01/01	FR PS
Alfa Romeo	146 2.0 930 (1995-2001)	02/96-05/99	FR PS
Alfa Romeo	146 2.0 930 (1995-2001)	02/96-05/99	FR PS
Alfa Romeo	146 2.0 930 (1995-2001)	05/99-01/01	FR PS
Alfa Romeo	155 1.8 167 (1992-1998)	06/95-07/96	FR PS
Alfa Romeo	155 1.8 167 (1992-1998)	06/95-07/96	FR PS
Alfa Romeo	155 1.8 167 (1992-1998)	07/92-06/95	FR PS
Alfa Romeo	155 1.8 167 (1992-1998)	07/92-06/95	FR PS
Alfa Romeo	155 1.8 167 (1992-1998)	07/96-04/98	FR PS
Alfa Romeo	155 2.0 167 (1992-1998)	06/95-04/98	FR PS
Alfa Romeo	155 2.0 Cloverleaf 4 167 (1992-1998)	01/94-06/95	FR PS
Alfa Romeo	155 2.5 167 (1992-1998)	06/95-09/96	FR PS
Alfa Romeo	155 2.5 167 (1992-1998)	06/95-09/96	FR PS
Alfa Romeo	155 2.5 167 (1992-1998)	06/95-09/96	FR PS
Alfa Romeo	155 2.5 167 (1992-1998)	07/92-06/95	FR PS
Alfa Romeo	155 2.5 167 (1992-1998)	07/92-06/95	FR PS
Alfa Romeo	155 2.5 167 (1992-1998)	07/92-06/95	FR PS
Alfa Romeo	166 2.0 936 (1999-2003)	01/99-10/03	FR PS
Alfa Romeo	166 2.0 936 (1999-2003)	09/00-10/03	FR PS
Alfa Romeo	166 2.0 936 (2003-2005)	09/03-12/05	FR PS
Alfa Romeo	166 2.0 936 (2003-2005)	09/03-12/05	FR PS
Alfa Romeo	166 2.5 936 (1999-2003)	01/99-10/03	FR PS
Alfa Romeo	166 2.5 936 (1999-2003)	01/99-10/03	FR PS
Alfa Romeo	166 2.5 936 (1999-2003)	01/99-10/03	FR PS
Alfa Romeo	166 2.5 936 (1999-2003)	01/99-10/03	FR PS
Alfa Romeo	166 2.5 936 (2003-2005)	09/03-04/04	FR PS
Alfa Romeo	166 3.0 936 (1999-2003)	01/99-10/03	FR PS
Alfa Romeo	166 3.0 936 (1999-2003)	01/99-10/03	FR PS
Alfa Romeo	166 3.0 936 (1999-2003)	01/99-10/03	FR PS

Audi	A3 1.8 T quattro 8L (1996-2003)	06/99-12/02	FR PS
Audi	A3 1.8 T quattro 8L (1996-2003)	06/99-12/02	FR PS
Audi	A3 1.9 8L (1996-2003)	07/01-06/03	FR PS
Audi	A3 1.9 8L (1996-2003)	07/01-06/03	FR PS
Audi	A3 1.9 8L (1996-2003)	07/01-06/03	FR PS
Audi	A3 1.9 8L (1996-2003)	07/01-06/03	FR PS
Audi	A3 1.9 8L (1996-2003)	07/01-06/03	FR PS
Audi	A3 1.9 8L (1996-2003)	07/01-06/03	FR PS
Audi	A3 1.9 8L (1996-2003)	07/01-08/03	FR PS
Audi	A3 1.9 8L (1996-2003)	07/01-08/03	FR PS
Audi	A3 1.9 8L (1996-2003)	09/99-08/01	FR PS
Audi	A3 1.9 8L (1996-2003)	09/99-08/01	FR PS
Audi	A3 1.9 8L (1996-2003)	09/99-08/01	FR PS
Audi	A3 1.9 8L (1996-2003)	09/99-08/01	FR PS
Audi	A3 1.9 8L (1996-2003)	12/96-07/01	FR PS
Audi	A3 1.9 8L (1996-2003)	12/96-07/01	FR PS
Audi	A3 1.9 8L (1996-2003)	12/96-07/01	FR PS
Audi	A3 1.9 8L (1996-2003)	12/96-07/01	FR PS
Audi	A3 1.9 quattro 8L (1996-2003)	10/01-08/03	FR PS
Audi	A3 1.9 quattro 8L (1996-2003)	10/01-08/03	FR PS
Audi	S3 1.8 quattro 8L (1996-2003)	05/99-10/01	FR PS
Audi	S3 1.8 quattro 8L (1996-2003)	05/99-10/01	FR PS
Audi	S3 1.8 quattro 8L (1996-2003)	05/99-10/01	FR PS
Audi	S3 1.8 quattro 8L (1996-2003)	10/01-08/03	FR PS
Chevrolet	Orlando 1.4 J309 (2010-2015)	12/13-04/15	FR PS
Chevrolet	Orlando 1.4 J309 (2010-2015)	12/13-04/15	FR PS
Chevrolet	Orlando 1.8 J309 (2010-2015)	10/10-04/15	FR PS
Chevrolet	Orlando 1.8 J309 (2010-2015)	10/10-04/15	FR PS
Chevrolet	Orlando 2.0 VCDi 130 J309 (2010-2015)	10/10-04/15	FR PS
Chevrolet	Orlando 2.0 VCDi 163 J309 (2010-2015)	10/10-04/15	FR PS
Chevrolet	Orlando 2.0 VCDi 163 J309 (2010-2015)	10/10-04/15	FR PS
Chevrolet	Tacuma 1.6 (2005-2009)	01/05-12/09	FR PS
Chevrolet	Tacuma 2.0 (2005-2009)	01/05-12/08	FR PS
Chevrolet	Tacuma 2.0 (2005-2009)	01/05-12/08	FR PS
Chrysler	Neon 2.0 (1999-2004)	05/00-04/04	FR PS
Chrysler	Neon 2.0 (1999-2004)	10/99-04/04	FR PS
Chrysler	Neon 2.0 (1999-2004)	10/99-04/04	FR PS
Daewoo	Espero 1.5 (1995-1997)	04/95-09/97	FR DS
Daewoo	Espero 1.5 (1995-1997)	04/95-09/97	FR PS
Daewoo	Espero 1.8 (1995-1997)	04/95-09/97	FR PS
Daewoo	Espero 1.8 (1995-1997)	04/95-09/97	FR DS
Daewoo	Espero 2.0 (1995-1997)	04/95-09/97	FR DS
Daewoo	Espero 2.0 (1995-1997)	04/95-09/97	FR PS
Daewoo	Espero 2.0 (1995-1997)	04/95-09/97	FR DS
Daewoo	Espero 2.0 (1995-1997)	04/95-09/97	FR PS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR DS

Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.4 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	RR
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR DS
Daewoo	Lanos 1.6 (1997-2002)	09/97-12/02	FR DS
Daewoo	Leganza 2.0 (1997-2002)	09/97-12/02	FR PS
Daewoo	Leganza 2.0 (1997-2002)	09/97-12/02	FR PS
Daewoo	Nubira 1.6 (2003-2005)	08/03-01/05	FR PS
Daewoo	Nubira 1.6 (2003-2005)	08/03-01/05	FR PS
Daewoo	Nubira 1.6 (2003-2005)	09/04-01/05	FR PS
Daewoo	Nubira 1.6 (2003-2005)	09/04-01/05	FR PS
Daewoo	Nubira 1.8 (2003-2005)	08/03-01/05	FR PS
Daewoo	Nubira 1.8 (2003-2005)	08/03-01/05	FR PS
Daewoo	Nubira 1.8 (2003-2005)	09/04-01/05	FR PS
Daewoo	Nubira 1.8 (2003-2005)	09/04-01/05	FR PS
Daewoo	Nubira 1.8 (2003-2005)	09/04-01/05	FR PS
Daewoo	Nubira 1.8 (2003-2005)	09/04-01/05	FR PS
Daewoo	Tacuma 1.6 (2000-2005)	10/01-01/05	FR PS
Daewoo	Tacuma 1.8 (2000-2005)	09/00-12/01	FR PS
Daewoo	Tacuma 2.0 (2000-2005)	09/00-01/05	FR PS
Daewoo	Tacuma 2.0 (2000-2005)	09/00-01/05	FR PS
Daihatsu	Charade 1.3 (1993-2000)	06/93-10/00	FR DS
Daihatsu	Charade 1.3 (1993-2000)	06/93-10/00	FR DS
Daihatsu	Charade 1.3 (1993-2000)	06/93-10/00	FR DS
Daihatsu	Charade 1.3 (1993-2000)	06/93-10/00	FR DS
Daihatsu	Charade 1.5 (1993-2000)	10/94-10/00	FR DS
Daihatsu	Charade 1.5 (1993-2000)	10/94-10/00	FR DS

Daihatsu	Charade 1.6 (1993-2000)	07/93-03/96	FR DS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR PS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR PS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR PS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR PS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR PS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR PS
Daihatsu	Grand Move 1.6 (1998-2001)	10/98-12/01	FR PS
Daihatsu	Grand Move 1.6 (1998-2001)	10/98-12/01	FR PS
Daihatsu	Grand Move 1.6 (1998-2001)	10/98-12/01	FR PS
Daihatsu	Grand Move 1.6 (1998-2001)	10/98-12/01	FR PS
Daihatsu	Sirion 1.0 (1998-2005)	06/98-10/00	FR DS
Daihatsu	Sirion 1.0 (1998-2005)	06/98-10/00	FR DS
Daihatsu	Sirion 1.0 (1998-2005)	10/00-03/05	FR DS
Daihatsu	Sirion 1.0 (1998-2005)	10/00-03/05	FR DS
Daihatsu	Sirion 1.3 (1998-2005)	10/00-03/05	FR DS
Daihatsu	Sirion 1.3 (1998-2005)	10/00-03/05	FR DS
Daihatsu	Sirion 1.3 4trak (1998-2005)	06/02-03/05	FR DS
Daihatsu	Sirion 1.3 4trak (1998-2005)	06/02-03/05	FR DS
Fiat	124 1.4 Spider MultiAir 140 (2016-2019)	06/16-12/19	FR PS
Fiat	124 1.4 Spider MultiAir 140 (2016-2019)	12/16-12/19	FR PS
Fiat	Barchetta 1.8 183 (1995-2003)	09/95-07/03	FR PS
Fiat	Barchetta 1.8 183 (1995-2003)	09/95-07/03	FR DS
Fiat	Barchetta 1.8 183 (1995-2003)	09/95-07/03	FR PS
Fiat	Barchetta 1.8 183 (1995-2003)	09/95-07/03	FR DS
Fiat	Barchetta 1.8 183 (2003-2005)	07/03-12/05	FR PS
Fiat	Barchetta 1.8 183 (2003-2005)	07/03-12/05	FR DS
Fiat	Barchetta 1.8 183 (2003-2005)	07/03-12/05	FR PS
Fiat	Barchetta 1.8 183 (2003-2005)	07/03-12/05	FR DS
Fiat	Brava 1.2 80 182 (1995-2002)	12/98-04/02	FR PS
Fiat	Brava 1.2 80 182 (1995-2002)	12/98-04/02	FR PS
Fiat	Brava 1.4 182 (1995-2002)	12/95-02/99	FR PS
Fiat	Brava 1.6 100 182 (1995-2002)	06/00-04/02	FR PS
Fiat	Brava 1.6 100 182 (1995-2002)	12/95-04/02	FR PS
Fiat	Brava 1.6 100 182 (1995-2002)	12/95-04/02	FR PS
Fiat	Brava 1.8 115 182 (1995-2002)	12/95-04/02	FR PS
Fiat	Brava 1.9 100 182 (1995-2002)	10/96-04/02	FR PS
Fiat	Brava 1.9 100 182 (1995-2002)	10/96-04/02	FR PS
Fiat	Brava 1.9 105 182 (1995-2002)	12/98-04/02	FR PS
Fiat	Brava 1.9 75 182 (1995-2002)	10/96-02/99	FR PS
Fiat	Cinquecento 0.9 170 (1993-1998)	05/93-06/98	FR PS
Fiat	Cinquecento 0.9 170 (1993-1998)	05/93-06/98	FR DS
Fiat	Cinquecento 1.1 Sporting 170 (1993-1998)	01/95-06/98	FR PS
Fiat	Cinquecento 1.1 Sporting 170 (1993-1998)	01/95-06/98	FR DS
Fiat	Coupe 2.0 175 (1995-2001)	06/95-11/96	FR PS
Fiat	Coupe 2.0 20v 175 (1995-2001)	11/96-08/01	FR PS
Fiat	Coupe 2.0 20v 175 (1995-2001)	11/96-08/01	FR PS
Fiat	Coupe 2.0 20v Turbo 175 (1995-2001)	07/98-08/01	FR PS
Fiat	Coupe 2.0 20v Turbo 175 (1995-2001)	11/96-08/01	FR PS
Fiat	Marea 1.6 100 185 (1997-2003)	03/97-04/03	FR PS

Fiat	Marea 1.6 100 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.6 100 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.6 100 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.6 100 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.6 100 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.6 100 Weekend 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.6 100 Weekend 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.8 115 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.8 115 Weekend 185 (1997-2003)	03/97-04/03	FR PS
Fiat	Marea 1.9 100 185 (1997-2003)	03/97-03/99	FR PS
Fiat	Marea 1.9 100 Weekend 185 (1997-2003)	03/97-03/99	FR PS
Fiat	Marea 1.9 100 Weekend 185 (1997-2003)	03/97-03/99	FR PS
Fiat	Marea 1.9 105 185 (1997-2003)	03/99-04/01	FR PS
Fiat	Marea 1.9 105 Weekend 185 (1997-2003)	03/99-04/01	FR PS
Fiat	Marea 1.9 110 185 (1997-2003)	12/00-04/03	FR PS
Fiat	Marea 1.9 110 Weekend 185 (1997-2003)	12/00-04/03	FR PS
Fiat	Marea 1.9 75 185 (1997-2003)	03/97-04/01	FR PS
Fiat	Marea 1.9 75 Weekend 185 (1997-2003)	03/97-04/01	FR PS
Fiat	Marea 2.0 150 185 (1997-2003)	12/00-04/03	FR PS
Fiat	Marea 2.0 150 Weekend 185 (1997-2003)	12/00-04/03	FR PS
Fiat	Marea 2.0 155 185 (1997-2003)	03/97-05/99	FR PS
Fiat	Marea 2.0 155 185 (1997-2003)	05/99-12/00	FR PS
Fiat	Marea 2.0 155 Weekend 185 (1997-2003)	03/97-05/99	FR PS
Fiat	Marea 2.0 155 Weekend 185 (1997-2003)	05/99-12/00	FR PS
Fiat	Marea 2.4 125 185 (1997-2003)	03/97-03/99	FR PS
Fiat	Marea 2.4 125 Weekend 185 (1997-2003)	03/97-03/99	FR PS
Fiat	Marea 2.4 130 185 (1997-2003)	03/99-04/01	FR PS
Fiat	Marea 2.4 130 185 (1997-2003)	03/99-04/01	FR PS
Fiat	Marea 2.4 130 Weekend 185 (1997-2003)	03/99-04/01	FR PS
Fiat	Marea 2.4 130 Weekend 185 (1997-2003)	03/99-04/01	FR PS
Fiat	Seicento 0.9 187 (1998-2004)	06/98-03/01	FR DS
Fiat	Seicento 0.9 187 (1998-2004)	06/98-03/01	FR PS
Fiat	Seicento 0.9 187 (1998-2004)	06/98-03/01	FR PS
Fiat	Seicento 0.9 187 (1998-2004)	06/98-03/01	FR DS
Fiat	Seicento 1.1 187 (1998-2004)	06/98-03/04	FR PS
Fiat	Seicento 1.1 187 (1998-2004)	06/98-03/04	FR PS
Fiat	Seicento 1.1 187 (1998-2004)	06/98-03/04	FR DS
Fiat	Seicento 1.1 187 (1998-2004)	06/98-03/04	FR DS
Fiat	Tipo 1.4 160 (1988-1995)	06/88-07/92	FR PS
Fiat	Tipo 1.4 160 (1988-1995)	06/88-07/92	FR DS
Fiat	Tipo 1.4 160 (1988-1995)	06/88-07/92	FR DS
Fiat	Tipo 1.4 160 (1988-1995)	06/88-07/92	FR DS
Fiat	Tipo 1.4 160 (1988-1995)	06/88-07/92	FR DS
Fiat	Tipo 1.4 160 (1988-1995)	06/88-07/92	FR PS
Fiat	Tipo 1.4 160 (1988-1995)	06/88-07/92	FR PS
Fiat	Tipo 1.4 160 (1988-1995)	06/88-07/92	FR PS
Fiat	Tipo 1.4 ie 160 (1988-1995)	07/92-10/95	FR PS
Fiat	Tipo 1.4 ie 160 (1988-1995)	07/92-10/95	FR DS
Fiat	Tipo 1.4 ie 160 (1988-1995)	07/92-10/95	FR PS
Fiat	Tipo 1.4 ie 160 (1988-1995)	07/92-10/95	FR DS

Fiat	Tipo 1.4 ie 160 (1988-1995)	07/92-10/95	FR PS
Fiat	Tipo 1.4 ie 160 (1988-1995)	07/92-10/95	FR DS
Fiat	Tipo 1.6 160 (1988-1995)	06/88-07/92	FR PS
Fiat	Tipo 1.6 160 (1988-1995)	06/88-07/92	FR DS
Fiat	Tipo 1.6 ie 160 (1988-1995)	07/92-10/95	FR PS
Fiat	Tipo 1.6 ie 160 (1988-1995)	07/92-10/95	FR PS
Fiat	Tipo 1.6 ie 160 (1988-1995)	07/92-10/95	FR PS
Fiat	Tipo 1.6 ie 160 (1988-1995)	07/92-10/95	FR DS
Fiat	Tipo 1.6 ie 160 (1988-1995)	07/92-10/95	FR DS
Fiat	Tipo 1.6 ie 160 (1988-1995)	07/92-10/95	FR DS
Fiat	Tipo 1.7 160 (1988-1995)	01/94-10/95	FR DS
Fiat	Tipo 1.7 160 (1988-1995)	01/94-10/95	FR PS
Fiat	Tipo 1.7 160 (1988-1995)	10/88-12/92	FR PS
Fiat	Tipo 1.7 160 (1988-1995)	10/88-12/92	FR DS
Fiat	Tipo 1.8 160 (1988-1995)	09/90-07/93	FR DS
Fiat	Tipo 1.8 160 (1988-1995)	09/90-07/93	FR PS
Fiat	Tipo 1.9 160 (1988-1995)	06/88-10/95	FR DS
Fiat	Tipo 1.9 160 (1988-1995)	06/88-10/95	FR PS
Fiat	Tipo 1.9 160 (1988-1995)	06/88-10/95	FR DS
Fiat	Tipo 1.9 160 (1988-1995)	06/88-10/95	FR PS
Fiat	Tipo 1.9 160 (1988-1995)	06/88-10/95	FR PS
Fiat	Tipo 1.9 160 (1988-1995)	06/88-10/95	FR DS
Fiat	Tipo 2.0 ie 160 (1988-1995)	01/92-10/95	FR DS
Fiat	Tipo 2.0 ie 160 (1988-1995)	01/92-10/95	FR PS
Fiat	Tipo 2.0 ie 160 (1988-1995)	01/92-10/95	FR DS
Fiat	Tipo 2.0 ie 160 (1988-1995)	01/92-10/95	FR PS
Fiat	Tipo 2.0 ie 160 (1988-1995)	02/93-10/95	FR DS
Fiat	Tipo 2.0 ie 160 (1988-1995)	02/93-10/95	FR PS
Ford	Courier 1.8 (1991-1995)	10/91-12/95	FR DS
Ford	Courier 1.8 (1991-1995)	10/91-12/95	FR PS
Ford	Courier 1.8 (1991-1995)	10/91-12/95	FR PS
Ford	Courier 1.8 (1991-1995)	10/91-12/95	FR DS
Ford	Courier 1.8 (1991-1995)	10/91-12/95	FR PS
Ford	Courier 1.8 (1991-1995)	10/91-12/95	FR DS
Ford	Courier 1.8 (1995-2002)	01/96-12/00	FR PS
Ford	Courier 1.8 (1995-2002)	01/96-12/00	FR DS
Ford	Courier 1.8 (1995-2002)	01/96-12/00	FR PS
Ford	Courier 1.8 (1995-2002)	01/96-12/00	FR DS
Ford	Courier 1.8 TDDi (1995-2002)	03/00-12/02	FR PS
Ford	Courier 1.8 TDDi (1995-2002)	03/00-12/02	FR DS
Ford	Courier 1.8 TDDi (1995-2002)	03/00-12/02	FR PS
Ford	Courier 1.8 TDDi (1995-2002)	03/00-12/02	FR DS
Ford	Courier 1.8 TDDi (1995-2002)	03/00-12/02	FR PS
Ford	Courier 1.8 TDDi (1995-2002)	03/00-12/02	FR DS
Ford	Fiesta 1.0 MK 3 (1989-1997)	02/89-12/91	FR DS
Ford	Fiesta 1.0 MK 3 (1989-1997)	02/89-12/91	FR DS
Ford	Fiesta 1.0 MK 3 (1989-1997)	02/89-12/91	FR PS
Ford	Fiesta 1.0 MK 3 (1989-1997)	02/89-12/91	FR PS
Ford	Fiesta 1.0 MK 3 (1989-1997)	04/89-12/91	FR DS
Ford	Fiesta 1.0 MK 3 (1989-1997)	04/89-12/91	FR PS

Ford	Fiesta 1.4 MK 4 (1995-1999)	03/96-07/00	FR PS
Ford	Fiesta 1.4 MK 4 (1995-1999)	03/96-07/00	FR PS
Ford	Fiesta 1.4 MK 4 (1995-1999)	03/96-08/00	FR DS
Ford	Fiesta 1.4 MK 4 (1995-1999)	03/96-08/00	FR PS
Ford	Fiesta 1.4 MK 4 (1995-1999)	03/96-08/00	FR DS
Ford	Fiesta 1.4 MK 4 (1995-1999)	03/96-08/00	FR PS
Ford	Fiesta 1.4 MK 5 (1999-2002)	10/99-12/00	FR DS
Ford	Fiesta 1.4 MK 5 (1999-2002)	10/99-12/00	FR PS
Ford	Fiesta 1.4 MK 5 (1999-2002)	10/99-12/00	FR DS
Ford	Fiesta 1.4 MK 5 (1999-2002)	10/99-12/00	FR PS
Ford	Fiesta 1.4 MK 5 (1999-2002)	10/99-12/00	FR DS
Ford	Fiesta 1.4 MK 5 (1999-2002)	10/99-12/00	FR PS
Ford	Fiesta 1.4 MK 5 (1999-2002)	10/99-12/00	FR PS
Ford	Fiesta 1.4 MK 5 (1999-2002)	10/99-12/00	FR DS
Ford	Fiesta 1.6 MK 2 (1983-1989)	01/85-04/89	FR DS
Ford	Fiesta 1.6 MK 2 (1983-1989)	01/85-04/89	FR PS
Ford	Fiesta 1.6 MK 3 (1989-1997)	01/94-10/95	FR DS
Ford	Fiesta 1.6 MK 3 (1989-1997)	01/94-10/95	FR PS
Ford	Fiesta 1.6 MK 3 (1989-1997)	01/94-10/95	FR DS
Ford	Fiesta 1.6 MK 3 (1989-1997)	01/94-10/95	FR PS
Ford	Fiesta 1.6 MK 3 (1989-1997)	04/89-12/91	FR PS
Ford	Fiesta 1.6 MK 3 (1989-1997)	04/89-12/91	FR DS
Ford	Fiesta 1.6 MK 3 (1989-1997)	04/89-12/91	FR DS
Ford	Fiesta 1.6 MK 3 (1989-1997)	04/89-12/91	FR PS
Ford	Fiesta 1.6 MK 5 (1999-2002)	04/00-04/02	FR PS
Ford	Fiesta 1.6 MK 5 (1999-2002)	04/00-04/02	FR PS
Ford	Fiesta 1.6 MK 5 (1999-2002)	04/00-04/02	FR DS
Ford	Fiesta 1.6 MK 5 (1999-2002)	04/00-04/02	FR DS
Ford	Fiesta 1.6 MK 5 (1999-2002)	04/00-04/02	FR DS
Ford	Fiesta 1.6 MK 5 (1999-2002)	04/00-04/02	FR PS
Ford	Fiesta 1.6 MK 5 (1999-2002)	04/00-04/02	FR PS
Ford	Fiesta 1.6 MK 5 (1999-2002)	04/00-04/02	FR DS
Ford	Fiesta 1.6 RS Turbo MK 3 (1989-1997)	07/90-07/92	FR PS
Ford	Fiesta 1.6 RS Turbo MK 3 (1989-1997)	07/90-07/92	FR DS
Ford	Fiesta 1.6 XR2i MK 3 (1989-1997)	04/89-07/92	FR PS
Ford	Fiesta 1.6 XR2i MK 3 (1989-1997)	04/89-07/92	FR DS
Ford	Fiesta 1.8 Endura D MK 4 (1995-1999)	10/96-08/00	FR DS
Ford	Fiesta 1.8 Endura D MK 4 (1995-1999)	10/96-08/00	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR DS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR DS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR DS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR DS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR DS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-01/97	FR DS

Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-12/96	FR DS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-12/96	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-12/96	FR DS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-12/96	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-12/96	FR PS
Ford	Fiesta 1.8 MK 3 (1989-1997)	04/89-12/96	FR DS
Ford	Fiesta 1.8 MK 4 (1995-1999)	10/95-07/00	FR DS
Ford	Fiesta 1.8 MK 4 (1995-1999)	10/95-07/00	FR PS
Ford	Fiesta 1.8 MK 4 (1995-1999)	10/95-07/00	FR DS
Ford	Fiesta 1.8 MK 4 (1995-1999)	10/95-07/00	FR PS
Ford	Fiesta 1.8 MK 4 (1995-1999)	10/95-08/00	FR DS
Ford	Fiesta 1.8 MK 4 (1995-1999)	10/95-08/00	FR PS
Ford	Fiesta 1.8 MK 4 (1995-1999)	10/95-08/00	FR DS
Ford	Fiesta 1.8 MK 4 (1995-1999)	10/95-08/00	FR PS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-02/00	FR PS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-02/00	FR PS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-02/00	FR DS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-02/00	FR PS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-02/00	FR DS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-02/00	FR PS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-02/00	FR DS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-02/00	FR DS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-12/00	FR PS
Ford	Fiesta 1.8 MK 5 (1999-2002)	10/99-12/00	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR PS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR PS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR PS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR PS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR PS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	02/00-04/02	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	03/00-06/02	FR DS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	03/00-06/02	FR PS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	03/00-06/02	FR PS
Ford	Fiesta 1.8 TDdi MK 5 (1999-2002)	03/00-06/02	FR DS
Ford	Fiesta 1.8 XR2i MK 3 (1989-1997)	05/92-12/94	FR DS
Ford	Fiesta 1.8 XR2i MK 3 (1989-1997)	05/92-12/94	FR PS
Ford	Fiesta 950 MK 2 (1983-1989)	01/85-04/89	FR DS
Ford	Fiesta 950 MK 2 (1983-1989)	01/85-04/89	FR PS
Ford	Fiesta RS 1800 MK 3 (1989-1997)	05/92-10/95	FR PS
Ford	Fiesta RS 1800 MK 3 (1989-1997)	05/92-10/95	FR DS
Ford	Focus 1.4 MK 1 (1998-2005)	10/98-04/05	FR PS
Ford	Focus 1.4 MK 1 (1998-2005)	10/98-04/05	FR PS
Ford	Focus 1.4 MK 1 (1998-2005)	10/98-04/05	FR PS
Ford	Focus 1.4 MK 1 (1998-2005)	10/98-04/05	FR PS

Ford	Ka 1.3 MK 1 (1996-2009)	09/96-06/03	FR DS
Ford	Ka 1.3 MK 1 (1996-2009)	09/96-06/03	FR DS
Ford	Maverick 2.0 (2001-2004)	04/01-03/04	FR PS
Ford	Maverick 2.0 (2001-2004)	04/01-03/04	FR DS
Ford	Maverick 3.0 (2001-2004)	04/01-03/04	FR DS
Ford	Maverick 3.0 (2001-2004)	04/01-03/04	FR PS
Ford	Mondeo 1.8 MK 3 (2000-2007)	10/00-10/06	RR
Ford	Mondeo 1.8 MK 3 (2000-2007)	10/00-10/06	RR
Ford	Mondeo 1.8 MK 3 (2000-2007)	10/00-10/07	RR
Ford	Mondeo 1.8 MK 3 (2000-2007)	10/00-10/07	RR
Ford	Mondeo 1.8 MK 3 (2000-2007)	10/00-10/07	RR
Ford	Mondeo 1.8 SCi MK 3 (2000-2007)	07/03-10/07	RR
Ford	Mondeo 1.8 SCi MK 3 (2000-2007)	07/03-10/07	RR
Ford	Mondeo 1.8 SCi MK 3 (2000-2007)	07/03-10/07	RR
Ford	Mondeo 2.0 Di 115 MK 3 (2000-2007)	10/00-03/02	RR
Ford	Mondeo 2.0 Di 115 MK 3 (2000-2007)	10/00-03/02	RR
Ford	Mondeo 2.0 Di 115 MK 3 (2000-2007)	10/00-03/02	RR
Ford	Mondeo 2.0 Di 115 MK 3 (2000-2007)	10/00-03/02	RR
Ford	Mondeo 2.0 Di 90 MK 3 (2000-2007)	10/00-12/04	RR
Ford	Mondeo 2.0 Di 90 MK 3 (2000-2007)	10/00-12/04	RR
Ford	Mondeo 2.0 MK 3 (2000-2007)	10/00-10/07	RR
Ford	Mondeo 2.0 MK 3 (2000-2007)	10/00-10/07	RR
Ford	Mondeo 2.0 MK 3 (2000-2007)	10/00-10/07	RR
Ford	Mondeo 2.0 MK 3 (2000-2007)	10/00-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 115 MK 3 (2000-2007)	03/02-10/07	RR
Ford	Mondeo 2.0 TDCi 130 MK 3 (2000-2007)	11/01-10/07	RR
Ford	Mondeo 2.0 TDCi 130 MK 3 (2000-2007)	11/01-10/07	RR
Ford	Mondeo 2.0 TDCi 130 MK 3 (2000-2007)	11/01-10/07	RR
Ford	Mondeo 2.0 TDCi 130 MK 3 (2000-2007)	11/01-10/07	RR
Ford	Mondeo 2.0 TDCi 130 MK 3 (2000-2007)	11/02-10/07	RR
Ford	Mondeo 2.0 TDCi 130 MK 3 (2000-2007)	11/02-10/07	RR
Ford	Mondeo 2.0 TDCi 89 MK 3 (2000-2007)	10/05-10/07	RR
Ford	Mondeo 2.0 TDCi 89 MK 3 (2000-2007)	10/05-10/07	RR
Ford	Mondeo 2.2 TDCi MK 3 (2000-2007)	07/04-10/07	RR
Ford	Mondeo 2.2 TDCi MK 3 (2000-2007)	07/04-10/07	RR
Ford	Mondeo 3.0 MK 3 (2000-2007)	01/05-10/07	RR
Ford	Mondeo 3.0 ST220 MK 3 (2000-2007)	03/03-01/05	RR
Ford	Mondeo 3.0 ST220 MK 3 (2000-2007)	05/02-01/05	RR
Ford	Mondeo 3.0 ST220 MK 3 (2000-2007)	11/04-10/07	RR

Ford	Puma 1.4 (1997-2003)	02/98-10/00	FR DS
Ford	Puma 1.4 (1997-2003)	02/98-10/00	FR PS
Ford	Puma 1.4 (1997-2003)	02/98-10/00	FR DS
Ford	Puma 1.4 (1997-2003)	02/98-10/00	FR PS
Ford	Puma 1.6 (1997-2003)	10/00-03/03	FR DS
Ford	Puma 1.6 (1997-2003)	10/00-03/03	FR PS
Ford	Puma 1.7 (1997-2003)	06/97-03/03	FR PS
Ford	Puma 1.7 (1997-2003)	06/97-03/03	FR PS
Ford	Puma 1.7 (1997-2003)	06/97-03/03	FR DS
Ford	Puma 1.7 (1997-2003)	06/97-03/03	FR DS
Ford	Puma 1.7 Racing (1997-2003)	10/99-12/00	FR PS
Ford	Puma 1.7 Racing (1997-2003)	10/99-12/00	FR PS
Ford	Puma 1.7 Racing (1997-2003)	10/99-12/00	FR DS
Ford	Puma 1.7 Racing (1997-2003)	10/99-12/00	FR DS
Ford	StreetKa 1.6 MK 1 (1996-2009)	04/03-12/06	FR DS
Ford	StreetKa 1.6 MK 1 (1996-2009)	04/03-12/06	FR DS
Honda	Accord 1.8 MK 6 (1998-2003)	08/98-06/99	FR PS
Honda	Accord 1.8 MK 6 (1998-2003)	08/98-06/99	FR PS
Honda	Accord 1.8 Vtec MK 6 (1998-2003)	06/99-04/03	FR PS
Honda	Accord 1.8 Vtec MK 6 (1998-2003)	06/99-04/03	FR PS
Honda	Accord 2.0 Carburettor MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.0 Carburettor MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.0 Carburettor MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.0 Carburettor MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.0 Injection MK 4 (1989-1994)	04/92-12/94	FR PS
Honda	Accord 2.0 Injection MK 4 (1989-1994)	04/92-12/94	FR PS
Honda	Accord 2.0 Injection MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.0 Injection MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.0 Injection MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.0 Injection MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.0 MK 6 (1998-2003)	07/98-12/01	FR PS
Honda	Accord 2.0 MK 6 (1998-2003)	07/98-12/01	FR PS
Honda	Accord 2.0 MK 6 (1998-2003)	07/98-12/01	FR PS
Honda	Accord 2.0 MK 6 (1998-2003)	07/98-12/01	FR PS
Honda	Accord 2.0 MK 6 (1998-2003)	08/98-04/03	FR PS
Honda	Accord 2.0 MK 6 (1998-2003)	08/98-04/03	FR PS
Honda	Accord 2.2 Aerodeck MK 4 (1989-1994)	04/91-12/94	FR PS
Honda	Accord 2.2 Aerodeck MK 4 (1989-1994)	04/91-12/94	FR PS
Honda	Accord 2.2 Aerodeck MK 4 (1989-1994)	04/91-12/94	FR PS
Honda	Accord 2.2 Aerodeck MK 4 (1989-1994)	04/91-12/94	FR PS
Honda	Accord 2.2 MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.2 MK 4 (1989-1994)	09/89-07/93	FR PS
Honda	Accord 2.2 MK 6 (1998-2003)	02/99-04/03	FR PS
Honda	Accord 2.3 MK 6 (1998-2003)	11/00-04/03	FR PS
Honda	Accord 2.3 MK 6 (1998-2003)	11/00-04/03	FR PS
Honda	Accord 2.3 MK 6 (1998-2003)	11/00-04/03	FR PS
Honda	Accord 2.3 MK 6 (1998-2003)	11/00-04/03	FR PS
Honda	Accord 3.0 MK 6 (1998-2003)	07/98-12/01	FR PS
Honda	Civic 1.3 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.3 MK 4 (1987-1991)	08/87-12/91	FR DS

Honda	Civic 1.3 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.3 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.4 MK 4 (1987-1991)	08/87-12/91	FR DS
Honda	Civic 1.6 MK 4 (1987-1991)	07/90-12/91	FR DS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR PS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR PS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR PS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR PS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR PS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR PS
Honda	Civic CRX 1.6 (1984-1992)	10/87-07/90	FR PS
Honda	Civic CRX 1.6 (1984-1992)	10/87-07/90	FR DS
Honda	Civic CRX 1.6 (1984-1992)	10/87-07/90	FR PS
Honda	Civic CRX 1.6 (1984-1992)	10/87-07/90	FR DS
Honda	Civic Shuttle 1.4 (1988-1991)	04/88-01/91	FR DS
Honda	Civic Shuttle 1.4 (1988-1991)	04/88-01/91	FR DS
Honda	Civic Shuttle 1.6 (1988-1991)	04/88-01/90	FR DS
Honda	Civic Shuttle 1.6 (1988-1991)	04/88-01/90	FR DS
Honda	CR-V 2.0 MK 1 (1997-2002)	03/99-03/02	FR DS
Honda	CR-V 2.0 MK 1 (1997-2002)	03/99-03/02	FR PS
Honda	CR-V 2.0 MK 1 (1997-2002)	03/99-03/02	FR DS
Honda	CR-V 2.0 MK 1 (1997-2002)	03/99-03/02	FR PS
Honda	CR-V 2.0 MK 1 (1997-2002)	06/97-03/99	FR PS
Honda	CR-V 2.0 MK 1 (1997-2002)	06/97-03/99	FR DS
Honda	CR-V 2.0 MK 1 (1997-2002)	06/97-03/99	FR PS
Honda	CR-V 2.0 MK 1 (1997-2002)	06/97-03/99	FR DS
Honda	FR-V 1.7 VTEC (2004-2010)	11/04-10/07	FR PS
Honda	FR-V 1.8 VTEC (2004-2010)	06/07-06/10	FR PS
Honda	FR-V 1.8 VTEC (2004-2010)	06/07-06/10	FR PS
Honda	FR-V 2.0 VTEC (2004-2010)	11/04-12/06	FR PS
Honda	FR-V 2.2 CDTi (2004-2010)	09/05-06/10	FR PS
Honda	Legend 3.2 (1991-1995)	04/91-05/95	FR PS
Honda	Legend 3.2 (1991-1996)	04/91-06/96	FR PS
Honda	Legend 3.5 (1996-2003)	01/00-03/03	FR PS
Honda	Legend 3.5 (1996-2003)	06/96-01/00	FR PS
Honda	Legend 3.5 (2006-2009)	07/06-12/09	FR PS
Honda	Prelude 2.0 (1983-1992)	10/87-07/92	FR DS
Honda	Prelude 2.0 (1983-1992)	10/87-07/92	FR DS
Honda	Prelude 2.0 (1992-1997)	04/92-09/96	FR PS
Honda	Prelude 2.0 (1992-1997)	04/92-09/96	FR PS
Honda	Prelude 2.0 (1997-2001)	02/97-03/01	FR PS
Honda	Prelude 2.0 (1997-2001)	02/97-03/01	FR PS
Honda	Prelude 2.0 4WS (1983-1992)	10/87-07/92	FR DS

Honda	Prelude 2.0 4WS (1983-1992)	10/87-07/92	FR DS
Honda	Prelude 2.0 Injection (1983-1992)	11/85-07/87	FR DS
Honda	Prelude 2.2 (1992-1997)	02/93-09/96	FR PS
Honda	Prelude 2.2 (1997-2001)	01/99-03/01	FR PS
Honda	Prelude 2.2 (1997-2001)	01/99-03/01	FR PS
Honda	Prelude 2.2 (1997-2001)	02/97-01/99	FR PS
Honda	Prelude 2.2 (1997-2001)	02/97-01/99	FR PS
Honda	Prelude 2.3 (1992-1997)	04/92-09/96	FR PS
Honda	Prelude 2.3 (1992-1997)	04/92-09/96	FR PS
Hyundai	Lantra 1.6 (1991-1995)	06/91-12/95	FR PS
Hyundai	Lantra 1.6 (1991-1995)	06/91-12/95	FR PS
Hyundai	Lantra 1.8 (1991-1995)	10/93-12/95	FR PS
Hyundai	Lantra 1.8 (1991-1995)	10/93-12/95	FR PS
Hyundai	S Coupe 1.5 MVi (1990-1996)	10/92-10/95	FR DS
Hyundai	S Coupe 1.5 MVTi (1990-1996)	10/92-03/95	FR DS
Hyundai	Sonata 2.4 (2005-2011)	09/09-03/11	FR PS
Infiniti	M30 3.0 d (2010-2014)	08/10-05/14	FR PS
Infiniti	M35h 3.5 (2010-2014)	04/11-05/14	FR PS
Infiniti	M37 3.7 (2010-2014)	08/10-05/14	FR PS
Infiniti	Q70 2.2 (2013-2017)	01/15-04/17	FR PS
Infiniti	Q70 3.0 (2013-2017)	10/13-12/15	FR PS
Infiniti	Q70 3.7 (2013-2017)	10/13-04/16	FR PS
Infiniti	QX70 3.0 d (2013-2018)	10/13-04/18	FR PS
Infiniti	QX70 3.7 (2013-2018)	10/13-04/18	FR PS
Infiniti	QX70 5.0 (2013-2018)	10/13-04/18	FR PS
Isuzu	D-MAX 1.9 (2012-2022)	01/17-04/22	FR PS
Isuzu	D-MAX 1.9 (2012-2022)	01/17-04/22	FR PS
Isuzu	D-MAX 1.9 (2012-2022)	01/17-04/22	FR PS
Isuzu	D-MAX 1.9 (2012-2022)	01/17-04/22	FR PS
Isuzu	D-MAX 1.9 (2012-2022)	01/17-04/22	FR PS
Isuzu	D-MAX 2.5 (2012-2022)	03/12-04/18	FR PS
Isuzu	D-MAX 2.5 (2012-2022)	03/12-04/18	FR PS
Isuzu	D-MAX 2.5 (2012-2022)	03/12-04/18	FR PS
Isuzu	D-MAX 2.5 (2012-2022)	03/12-04/18	FR PS
Isuzu	D-MAX 2.5 (2012-2022)	03/12-04/18	FR PS
Isuzu	Rodeo 2.5 (2003-2007)	10/03-04/06	FR PS
Isuzu	Rodeo 2.5 (2003-2007)	10/03-04/06	FR PS
Isuzu	Rodeo 2.5 (2007-2012)	03/07-08/12	FR PS
Isuzu	Rodeo 2.5 (2007-2012)	03/07-08/12	FR PS
Isuzu	Rodeo 2.5 (2007-2012)	06/08-08/12	FR PS
Isuzu	Rodeo 2.5 (2007-2012)	06/08-08/12	FR PS
Isuzu	Rodeo 3.0 (2003-2007)	10/03-06/07	FR PS
Isuzu	Rodeo 3.0 (2003-2007)	10/03-06/07	FR PS
Isuzu	Rodeo 3.0 (2003-2007)	10/03-06/07	FR PS
Isuzu	Rodeo 3.0 (2003-2007)	10/03-06/07	FR PS
Isuzu	Rodeo 3.0 (2003-2007)	10/03-06/07	FR PS
Isuzu	Rodeo 3.0 (2003-2007)	10/03-06/07	FR PS
Isuzu	Rodeo 3.0 (2007-2012)	06/08-08/12	FR PS
Isuzu	Rodeo 3.0 (2007-2012)	06/08-08/12	FR PS
Isuzu	Rodeo 3.0 (2007-2012)	06/08-08/12	FR PS

Jaguar/Daimler	X Type 2.0 D X400	03/04-08/10	FR PS
Jaguar/Daimler	X Type 2.0 X400	10/04-11/05	FR PS
Jaguar/Daimler	X Type 2.0 X400	10/04-11/05	FR PS
Jaguar/Daimler	X Type 2.2 D X400	08/07-08/10	FR PS
Jaguar/Daimler	X Type 2.2 D X400	09/05-08/10	FR PS
Jaguar/Daimler	X Type 2.2 D X400	09/05-08/10	FR PS
Jaguar/Daimler	X Type 2.5 X400	03/04-04/08	FR PS
Jaguar/Daimler	X Type 2.5 X400	03/04-04/08	FR PS
Jaguar/Daimler	X Type 3.0 X400	03/04-06/04	FR PS
Jaguar/Daimler	X Type 3.0 X400	03/04-06/04	FR PS
Jaguar/Daimler	X Type 3.0 X400	06/04-08/10	FR PS
Jaguar/Daimler	X Type 3.0 X400	06/04-08/10	FR PS
Jeep	Cherokee 2.4 (2001-2005)	01/02-02/05	FR PS
Jeep	Cherokee 2.4 (2001-2005)	01/02-02/05	FR DS
Jeep	Cherokee 2.4 (2005-2008)	01/05-08/06	FR PS
Jeep	Cherokee 2.4 (2005-2008)	01/05-08/06	FR DS
Jeep	Cherokee 2.5 (2001-2005)	08/03-02/05	FR DS
Jeep	Cherokee 2.5 (2001-2005)	08/03-02/05	FR PS
Jeep	Cherokee 2.5 (2001-2005)	08/03-02/05	FR PS
Jeep	Cherokee 2.5 (2001-2005)	08/03-02/05	FR DS
Jeep	Cherokee 2.5 (2001-2005)	09/01-05/03	FR DS
Jeep	Cherokee 2.5 (2001-2005)	09/01-05/03	FR PS
Jeep	Cherokee 2.5 (2001-2005)	09/01-05/03	FR DS
Jeep	Cherokee 2.5 (2001-2005)	09/01-05/03	FR PS
Jeep	Cherokee 2.8 (2001-2005)	08/02-02/05	FR PS
Jeep	Cherokee 2.8 (2001-2005)	08/02-02/05	FR PS
Jeep	Cherokee 2.8 (2001-2005)	08/02-02/05	FR DS
Jeep	Cherokee 2.8 (2001-2005)	08/02-02/05	FR DS
Jeep	Cherokee 2.8 CRD (2005-2008)	01/05-08/08	FR PS
Jeep	Cherokee 2.8 CRD (2005-2008)	01/05-08/08	FR DS
Jeep	Cherokee 2.8 CRD (2005-2008)	01/05-08/08	FR PS
Jeep	Cherokee 2.8 CRD (2005-2008)	01/05-08/08	FR DS
Jeep	Cherokee 2.8 CRD (2005-2008)	01/05-08/08	FR DS
Jeep	Cherokee 2.8 CRD (2005-2008)	01/05-08/08	FR PS
Jeep	Cherokee 2.8 CRD (2005-2008)	01/05-08/08	FR PS
Jeep	Cherokee 3.7 (2001-2005)	01/01-02/05	FR PS
Jeep	Cherokee 3.7 (2001-2005)	01/01-02/05	FR DS
Jeep	Cherokee 3.7 (2005-2008)	01/05-10/07	FR DS
Jeep	Cherokee 3.7 (2005-2008)	01/05-10/07	FR PS
Jeep	Cherokee Pioneer 2.5 (2001-2005)	03/04-02/05	FR PS
Jeep	Cherokee Pioneer 2.5 (2001-2005)	03/04-02/05	FR DS
Jeep	Cherokee Pioneer 2.8 (2005-2008)	01/05-12/06	FR PS
Jeep	Cherokee Pioneer 2.8 (2005-2008)	01/05-12/06	FR DS
Kia	Carens 1.8 RS (2000-2007)	07/00-10/02	FR PS
Kia	Carens 1.8 RS (2000-2007)	10/02-04/05	FR PS
Kia	Carens 1.8 RS (2000-2007)	10/02-04/05	FR PS
Kia	Shuma 1.5 (1999-2002)	06/99-02/01	FR PS
Kia	Shuma 1.5 (1999-2002)	06/99-02/01	FR PS
Kia	Shuma 1.8 (1999-2002)	06/99-02/01	FR PS

Kia	Shuma 1.8 (1999-2002)	06/99-02/01	FR PS
Kia	Shuma 1.8 MK 2 (2002-2004)	03/02-01/04	FR PS
Kia	Shuma 1.8 MK 2 (2002-2004)	03/02-01/04	FR PS
Kia	Shuma 1.8 MK 2 (2002-2004)	03/02-01/04	RR
Kia	Shuma 1.8 MK 2 (2002-2004)	03/02-01/04	RR
Kia	Soul 1.6 (2009-2015) AM	02/09-04/12	FR PS
Kia	Soul 1.6 (2009-2015) AM	02/09-04/12	FR PS
Kia	Soul 1.6 CRDi (2009-2015) AM	02/09-04/13	FR PS
Kia	Soul 1.6 CRDi (2009-2015) AM	02/09-04/15	FR PS
Kia	Soul 1.6 CRDi (2009-2015) AM	07/11-04/15	FR PS
Kia	Soul 1.6 CRDi (2009-2015) AM	09/11-04/15	FR PS
Kia	Soul 1.6 GDi 140 (2009-2015) AM	09/11-04/15	FR PS
Lancia	Dedra 1.6	03/90-12/94	FR PS
Lancia	Dedra 1.8	03/90-12/94	FR PS
Lancia	Dedra 2.0	03/90-12/93	FR PS
Lancia	Dedra 2.0 Turbo	03/90-12/93	FR PS
Lexus	GS300 3.0 (1993-1997)	10/93-10/97	FR PS
Lexus	GS300 3.0 (2005-2010)	04/05-04/10	FR PS
Lexus	GS430 4.3 (2005-2008)	04/05-06/08	FR PS
Lexus	GS450h 3.5 (2006-2012)	05/06-04/12	FR PS
Lexus	GS450h 3.5 (2006-2012)	05/06-04/12	FR PS
Lexus	GS460 4.6 (2007-2010)	12/07-04/10	FR PS
Lexus	IS200 2.0 (1999-2006)	03/99-02/06	FR PS
Lexus	IS200 2.0 (1999-2006)	03/99-02/06	FR PS
Lexus	IS200 2.0 Sportcross (1999-2006)	08/02-02/06	FR PS
Lexus	IS300 3.0 (1999-2006)	08/01-02/06	FR PS
Lexus	IS300 3.0 Sportcross (1999-2006)	08/01-02/06	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS
Mazda	121 1.25 (1996-1999)	03/96-12/99	FR PS

Mazda	121 1.25 (1996-1999)	03/96-12/99	FR DS
Mazda	121 1.3 (1996-1999)	03/96-12/00	FR PS
Mazda	121 1.3 (1996-1999)	03/96-12/00	FR PS
Mazda	121 1.3 (1996-1999)	03/96-12/00	FR DS
Mazda	121 1.3 (1996-1999)	03/96-12/00	FR DS
Mazda	121 1.8 (1996-1999)	03/96-09/97	FR DS
Mazda	121 1.8 (1996-1999)	03/96-09/97	FR DS
Mazda	121 1.8 (1996-1999)	03/96-09/97	FR PS
Mazda	121 1.8 (1996-1999)	03/96-09/97	FR PS
Mazda	323 1.3 (1998-2003)	06/01-11/03	FR PS
Mazda	323 1.3 (1998-2003)	10/98-06/01	FR PS
Mazda	323 1.5 (1998-2003)	10/00-12/01	FR PS
Mazda	323 1.5 (1998-2003)	10/98-10/01	FR PS
Mazda	323F 1.3 (1994-1998)	01/97-08/98	FR PS
Mazda	323F 1.3 (1994-1998)	04/95-12/95	FR PS
Mazda	626 1.8 (1987-1992)	01/90-07/92	FR DS
Mazda	626 1.8 (1987-1992)	01/90-07/92	FR PS
Mazda	626 1.8 (1987-1992)	01/90-07/92	FR DS
Mazda	626 1.8 (1987-1992)	01/90-07/92	FR PS
Mazda	626 1.8 (1987-1992)	01/90-07/92	FR PS
Mazda	626 1.8 (1987-1992)	01/90-07/92	FR DS
Mazda	626 1.8 (1987-1992)	10/87-04/90	FR PS
Mazda	626 1.8 (1987-1992)	10/87-04/90	FR DS
Mazda	626 1.8 (1997-1999)	06/97-10/99	FR PS
Mazda	626 1.8 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.0 (1987-1992)	06/88-01/90	FR PS
Mazda	626 2.0 (1987-1992)	06/88-01/90	FR DS
Mazda	626 2.0 (1987-1992)	06/88-01/90	FR DS
Mazda	626 2.0 (1987-1992)	06/88-01/90	FR DS
Mazda	626 2.0 (1987-1992)	06/88-01/90	FR DS
Mazda	626 2.0 (1987-1992)	06/88-01/90	FR PS

Mazda	626 2.0 (1997-1999)	06/98-10/99	FR PS
Mazda	626 2.0 (1997-1999)	06/98-10/99	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR PS
Mazda	626 2.0 4WS (1987-1992)	04/88-04/90	FR PS
Mazda	626 2.0 4WS (1987-1992)	04/88-04/90	FR DS
Mazda	626 2.0 4WS (1987-1992)	04/88-04/90	FR PS
Mazda	626 2.0 4WS (1987-1992)	04/88-04/90	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR DS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR PS
Mazda	626 2.2 (1987-1992)	01/90-07/92	FR PS
Mazda	MX30 EV 35.5kWh (2021-)	02/21-	FR PS
Mazda	Tribute 2.0 (2001-2005)	08/01-03/05	FR PS
Mazda	Tribute 2.0 (2001-2005)	08/01-03/05	FR PS
Mazda	Tribute 3.0 (2001-2005)	08/01-03/05	FR PS
Mazda	Tribute 3.0 (2001-2005)	08/01-03/05	FR PS
Mini	MINI 1.2 One F55 (2014-2025)	09/14-04/19	FR DS
Mini	MINI 1.2 One F55 (2014-2025)	09/14-04/19	FR DS
Mini	MINI 1.4 Clubman One R55 (2006-2015)	03/09-08/10	FR PS
Mini	MINI 1.4 Clubman One R55 (2006-2015)	03/09-08/10	FR PS
Mini	MINI 1.4 First R56 (2006-2014)	07/09-08/10	FR PS
Mini	MINI 1.4 One D R50 (2001-2006)	06/03-03/06	FR PS
Mini	MINI 1.4 One D R50 (2001-2006)	09/05-12/06	FR PS
Mini	MINI 1.4 One R56 (2006-2014)	03/07-08/10	FR PS
Mini	MINI 1.4 One R56 (2006-2014)	03/07-08/10	FR PS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	08/14-04/19	FR DS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	08/14-04/19	FR DS

Mini	MINI 1.5 Cooper D F55 (2014-2025)	10/17-04/19	FR DS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	12/17-04/19	FR DS
Mini	MINI 1.5 Cooper D F55 (2014-2025)	12/17-04/19	FR DS
Mini	MINI 1.5 Cooper D F57 (2016-2025)	01/16-04/19	FR PS
Mini	MINI 1.5 Cooper D F57 (2016-2025)	01/16-04/19	FR PS
Mini	MINI 1.5 Cooper F55 (2014-2025)	08/14-04/19	FR DS
Mini	MINI 1.5 Cooper F55 (2014-2025)	08/14-04/19	FR DS
Mini	MINI 1.5 Cooper F55 (2014-2025)	08/14-04/19	FR DS
Mini	MINI 1.5 Cooper F55 (2014-2025)	08/14-04/19	FR DS
Mini	MINI 1.5 Cooper F55 (2014-2025)	12/17-04/25	FR DS
Mini	MINI 1.5 Cooper F55 (2014-2025)	12/17-12/23	FR DS
Mini	MINI 1.5 Cooper F57 (2016-2025)	01/16-04/19	FR PS
Mini	MINI 1.5 Cooper F57 (2016-2025)	01/16-04/19	FR PS
Mini	MINI 1.5 Cooper F57 (2016-2025)	05/18-04/25	FR PS
Mini	MINI 1.5 Cooper F57 (2016-2025)	05/18-12/23	FR PS
Mini	MINI 1.5 One D F55 (2014-2025)	08/14-04/19	FR DS
Mini	MINI 1.5 One F55 (2014-2025)	09/17-12/22	FR DS
Mini	MINI 1.5 One F55 (2014-2025)	09/17-12/22	FR DS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	08/10-09/15	FR PS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	11/07-12/10	FR PS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	11/07-12/10	FR PS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	11/07-12/10	FR PS
Mini	MINI 1.6 Clubman Cooper D R55 (2006-2015)	11/07-12/10	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR PS
Mini	MINI 1.6 Clubman Cooper R55 (2006-2015)	11/07-08/10	FR PS
Mini	MINI 1.6 Clubman Cooper S R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubman Cooper S R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubman Cooper S R55 (2006-2015)	11/07-08/10	FR PS
Mini	MINI 1.6 Clubman Cooper S R55 (2006-2015)	11/07-08/10	FR PS
Mini	MINI 1.6 Clubman John Cooper Works R55 (2006-2015)	03/12-09/15	FR PS
Mini	MINI 1.6 Clubman John Cooper Works R55 (2006-2015)	06/09-12/13	FR PS
Mini	MINI 1.6 Clubman One D R55 (2006-2015)	08/10-09/15	FR PS
Mini	MINI 1.6 Clubman One R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubman One R55 (2006-2015)	01/10-09/15	FR PS
Mini	MINI 1.6 Clubvan Cooper D R55 (2006-2015)	09/12-09/15	FR PS
Mini	MINI 1.6 Clubvan Cooper R55 (2006-2015)	09/12-09/15	FR PS
Mini	MINI 1.6 Clubvan Cooper R55 (2006-2015)	09/12-09/15	FR PS
Mini	MINI 1.6 Clubvan Cooper R55 (2006-2015)	09/12-09/15	FR PS
Mini	MINI 1.6 Clubvan Cooper R55 (2006-2015)	09/12-09/15	FR PS
Mini	MINI 1.6 Clubvan One R55 (2006-2015)	09/12-09/15	FR PS
Mini	MINI 1.6 Clubvan One R55 (2006-2015)	09/12-09/15	FR PS
Mini	MINI 1.6 Cooper D R56 (2006-2014)	03/07-12/10	FR PS
Mini	MINI 1.6 Cooper D R56 (2006-2014)	03/07-12/10	FR PS
Mini	MINI 1.6 Cooper D R56 (2006-2014)	03/07-12/10	FR PS

Mini	MINI 1.6 Cooper D R56 (2006-2014)	03/07-12/10	FR PS
Mini	MINI 1.6 Cooper D R57 (2009-2016)	08/10-12/16	FR PS
Mini	MINI 1.6 Cooper R50 (2001-2006)	04/01-12/06	FR PS
Mini	MINI 1.6 Cooper R50 (2001-2006)	04/01-12/06	FR PS
Mini	MINI 1.6 Cooper R52 (2004-2009)	01/07-05/09	FR PS
Mini	MINI 1.6 Cooper R52 (2004-2009)	01/07-05/09	FR PS
Mini	MINI 1.6 Cooper R52 (2004-2009)	07/04-12/06	FR PS
Mini	MINI 1.6 Cooper R52 (2004-2009)	07/04-12/06	FR PS
Mini	MINI 1.6 Cooper R56 (2006-2014)	08/06-08/10	FR PS
Mini	MINI 1.6 Cooper R56 (2006-2014)	08/06-08/10	FR PS
Mini	MINI 1.6 Cooper R57 (2009-2016)	01/10-12/16	FR PS
Mini	MINI 1.6 Cooper R57 (2009-2016)	01/10-12/16	FR PS
Mini	MINI 1.6 Cooper R57 (2009-2016)	01/10-12/16	FR PS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR PS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR PS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR PS
Mini	MINI 1.6 Cooper R57 (2009-2016)	03/09-08/10	FR PS
Mini	MINI 1.6 Cooper S R52 (2004-2009)	01/07-05/09	FR PS
Mini	MINI 1.6 Cooper S R52 (2004-2009)	01/07-05/09	FR PS
Mini	MINI 1.6 Cooper S R52 (2004-2009)	12/06-12/06	FR PS
Mini	MINI 1.6 Cooper S R52 (2004-2009)	12/06-12/06	FR PS
Mini	MINI 1.6 Cooper S R53 (2001-2006)	08/06-04/07	FR PS
Mini	MINI 1.6 Cooper S R53 (2001-2006)	08/06-04/07	FR PS
Mini	MINI 1.6 Cooper S R56 (2006-2014)	08/06-08/10	FR PS
Mini	MINI 1.6 Cooper S R56 (2006-2014)	08/06-08/10	FR PS
Mini	MINI 1.6 Cooper S R57 (2009-2016)	01/10-12/16	FR PS
Mini	MINI 1.6 Cooper S R57 (2009-2016)	01/10-12/16	FR PS
Mini	MINI 1.6 Cooper S R57 (2009-2016)	03/09-08/10	FR PS
Mini	MINI 1.6 Cooper S R57 (2009-2016)	03/09-08/10	FR PS
Mini	MINI 1.6 Cooper S Works GP R53 (2001-2006)	07/06-12/06	FR PS
Mini	MINI 1.6 Cooper S Works R52 (2004-2009)	11/04-07/06	FR PS
Mini	MINI 1.6 Cooper S Works R53 (2001-2006)	03/03-09/04	FR PS
Mini	MINI 1.6 Cooper S Works R53 (2001-2006)	09/04-07/06	FR PS
Mini	MINI 1.6 John Cooper Works R57 (2009-2016)	03/09-12/13	FR PS
Mini	MINI 1.6 John Cooper Works R57 (2009-2016)	03/12-12/16	FR PS
Mini	MINI 1.6 One R50 (2001-2006)	04/01-03/06	FR PS
Mini	MINI 1.6 One R50 (2001-2006)	04/01-03/06	FR PS
Mini	MINI 1.6 One R52 (2004-2009)	01/07-05/09	FR PS
Mini	MINI 1.6 One R52 (2004-2009)	06/04-03/06	FR PS
Mini	MINI 1.6 One R57 (2009-2016)	01/10-12/16	FR PS
Mini	MINI 1.6 One R57 (2009-2016)	01/10-12/16	FR PS
Mini	MINI 2.0 Clubman Cooper D Auto R55 (2006-2015)	01/11-09/15	FR PS
Mini	MINI 2.0 Clubman Cooper SD R55 (2006-2015)	01/11-09/15	FR PS
Mini	MINI 2.0 Clubman Cooper SD R55 (2006-2015)	01/11-09/15	FR PS
Mini	MINI 2.0 Clubvan Cooper D Auto R55 (2006-2015)	09/12-09/15	FR PS
Mini	MINI 2.0 Cooper D Auto R57 (2009-2016)	01/11-12/16	FR PS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	01/18-12/21	FR DS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	01/18-12/21	FR DS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	01/21-04/25	FR DS

Mini	MINI 2.0 Cooper S F55 (2014-2025)	01/21-12/23	FR DS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	08/14-12/18	FR DS
Mini	MINI 2.0 Cooper S F55 (2014-2025)	08/14-12/18	FR DS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/16-12/18	FR PS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/16-12/18	FR PS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/18-12/21	FR PS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/18-12/21	FR PS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/21-04/25	FR PS
Mini	MINI 2.0 Cooper S F57 (2016-2025)	01/21-12/23	FR PS
Mini	MINI 2.0 Cooper SD F55 (2014-2025)	08/14-04/18	FR DS
Mini	MINI 2.0 Cooper SD F55 (2014-2025)	08/14-04/18	FR DS
Mini	MINI 2.0 Cooper SD R57 (2009-2016)	01/11-12/16	FR PS
Mini	MINI 2.0 Cooper SD R57 (2009-2016)	01/11-12/16	FR PS
Mini	MINI 2.0 John Cooper Works F57 (2016-2025)	01/16-12/18	FR PS
Mini	MINI 2.0 John Cooper Works F57 (2016-2025)	01/16-12/18	FR PS
Mini	MINI 2.0 John Cooper Works F57 (2016-2025)	01/18-04/25	FR PS
Mini	MINI 2.0 John Cooper Works F57 (2016-2025)	01/18-12/23	FR PS
Mitsubishi	Colt Mirage 1.3 (1996-2004)	03/96-05/03	FR PS
Mitsubishi	Colt Mirage 1.3 (1996-2004)	03/96-05/03	FR PS
Mitsubishi	Colt Mirage 1.6 (1996-2004)	04/03-07/04	FR PS
Mitsubishi	Colt Mirage 1.6 (1996-2004)	04/03-07/04	FR PS
Mitsubishi	Galant 1.8 (1988-1993)	03/88-12/92	FR DS
Mitsubishi	Galant 1.8 (1988-1993)	03/88-12/92	FR DS
Mitsubishi	Galant 1.8 (1993-1997)	03/93-08/96	FR PS
Mitsubishi	Galant 1.8 (1993-1997)	03/93-08/96	FR PS
Mitsubishi	Galant 1.8 (1993-1997)	03/93-08/96	FR PS
Mitsubishi	Galant 1.8 (1993-1997)	03/93-08/96	FR PS
Mitsubishi	Galant 2.0 (1988-1993)	03/88-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	04/90-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	04/90-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	04/90-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	04/90-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	05/89-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	05/89-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	05/89-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	05/89-12/92	FR DS
Mitsubishi	Galant 2.0 (1988-1993)	06/88-12/92	FR DS
Mitsubishi	Galant 2.0 (1993-1997)	03/93-12/96	FR PS
Mitsubishi	Galant 2.0 (1993-1997)	03/93-12/96	FR PS
Mitsubishi	Galant 2.0 (1993-1997)	03/93-12/96	FR PS
Mitsubishi	Galant 2.0 (1993-1997)	03/93-12/96	FR PS
Mitsubishi	L200 2.5 (1986-1996)	02/88-01/93	FR PS
Mitsubishi	L200 2.5 (1986-1996)	02/88-01/93	FR DS
Mitsubishi	L200 2.5 (1986-1996)	10/86-12/96	FR DS
Mitsubishi	L200 2.5 (1986-1996)	10/86-12/96	FR PS
Mitsubishi	L200 2.5 (1996-2006)	12/96-10/01	FR DS
Mitsubishi	L200 2.5 (1996-2006)	12/96-10/01	FR PS
Mitsubishi	L200 2.5 (2006-2016)	03/06-04/16	FR PS
Mitsubishi	L200 2.5 (2006-2016)	03/06-04/16	FR PS
Mitsubishi	L200 2.5 (2006-2016)	03/06-04/16	FR PS

Mitsubishi	L200 2.5 (2006-2016)	03/06-04/16	FR PS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR PS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR PS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR PS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR PS
Mitsubishi	L200 2.5 (2006-2016)	04/08-12/10	FR PS
Mitsubishi	L200 2.5 (2006-2016)	04/08-12/10	FR PS
Mitsubishi	L200 2.5 Dual Cab Turbo (1996-2006)	06/98-10/01	FR DS
Mitsubishi	L200 2.5 Dual Cab Turbo (1996-2006)	06/98-10/01	FR PS
Mitsubishi	L200 2.5 Dual Cab Turbo (1996-2006)	10/01-04/06	FR PS
Mitsubishi	L200 2.5 Dual Cab Turbo (1996-2006)	10/01-04/06	FR DS
Mitsubishi	L200 2.5 Power Upgrade Pack (2006-2016)	03/06-10/08	FR PS
Mitsubishi	L200 2.5 Power Upgrade Pack (2006-2016)	03/06-10/08	FR PS
Mitsubishi	L200 2.5 Turbo (1986-1996)	01/93-12/96	FR DS
Mitsubishi	L200 2.5 Turbo (1986-1996)	01/93-12/96	FR PS
Mitsubishi	L200 2.5 Turbo (1996-2006)	10/01-04/06	FR PS
Mitsubishi	L200 2.5 Turbo (1996-2006)	10/01-04/06	FR DS
Mitsubishi	L200 2.5 Turbo (1996-2006)	10/01-04/06	FR DS
Mitsubishi	L200 2.5 Turbo (1996-2006)	10/01-04/06	FR PS
Mitsubishi	L200 2.5 Turbo (1996-2006)	12/96-10/01	FR PS
Mitsubishi	L200 2.5 Turbo (1996-2006)	12/96-10/01	FR DS
Mitsubishi	Pajero 2.8 TD	01/93-12/00	FR DS
Mitsubishi	Pajero 2.8 TD	01/93-12/00	FR PS
Mitsubishi	Pajero 2.8 TD	01/93-12/00	FR DS
Mitsubishi	Pajero 2.8 TD	01/93-12/00	FR DS
Mitsubishi	Pajero 2.8 TD	01/93-12/00	FR PS
Mitsubishi	Pajero 2.8 TD	01/93-12/00	FR DS
Mitsubishi	Pajero 2.8 TD	01/93-12/00	FR PS
Mitsubishi	Pajero 2.8 TD	01/93-12/00	FR PS
Mitsubishi	Pajero 3.0	04/91-12/94	FR PS
Mitsubishi	Pajero 3.0	04/91-12/94	FR PS
Mitsubishi	Pajero 3.0	04/91-12/94	FR DS
Mitsubishi	Pajero 3.0	04/91-12/94	FR PS
Mitsubishi	Pajero 3.0	04/91-12/94	FR DS
Mitsubishi	Pajero 3.0	04/91-12/94	FR DS
Mitsubishi	Pajero 3.0	04/91-12/94	FR DS
Mitsubishi	Pajero 3.0	04/91-12/94	FR PS
Mitsubishi	Pajero 3.5	01/93-12/97	FR PS
Mitsubishi	Pajero 3.5	01/93-12/97	FR PS
Mitsubishi	Pajero 3.5	01/93-12/97	FR PS
Mitsubishi	Pajero 3.5	01/93-12/97	FR DS
Mitsubishi	Pajero 3.5	01/93-12/97	FR DS
Mitsubishi	Pajero 3.5	01/93-12/97	FR DS
Mitsubishi	Pajero 3.5	01/93-12/97	FR PS
Mitsubishi	Pajero 3.5	01/93-12/97	FR DS
Mitsubishi	Pajero io 1.8	01/99-12/07	FR PS
Mitsubishi	Pajero io 1.8	01/99-12/07	FR PS
Mitsubishi	Pajero io 2.0	01/99-12/07	FR PS
Mitsubishi	Pajero io 2.0	01/99-12/07	FR PS
Mitsubishi	Pajero Pinin 1.8 GDI	01/99-12/06	FR PS

Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/05	FR PS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/06	FR PS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/06	FR PS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/06	FR PS
Mitsubishi	Shogun Pinin 2.0 (1999-2006)	12/00-12/06	FR PS
Nissan	300ZX 3.0 Turbo Targa Z32	03/90-12/94	RR
Nissan	300ZX 3.0 Turbo Targa Z32	03/90-12/94	RR
Nissan	370Z 3.7 Nismo Z34	05/13-12/21	FR PS
Nissan	370Z 3.7 Roadster Z34	09/09-12/14	FR PS
Nissan	370Z 3.7 Roadster Z34	09/09-12/14	FR PS
Nissan	Almera 1.4 N15	05/97-02/00	FR PS
Nissan	Almera 1.4 N15	10/95-02/00	FR PS
Nissan	Almera 1.4 N15	10/95-02/00	FR PS
Nissan	Almera 1.6 N15	05/96-02/00	FR PS
Nissan	Almera 1.6 N15	05/96-02/00	FR PS
Nissan	Almera 1.6 N15	10/95-02/00	FR PS
Nissan	Almera 1.6 N15	10/95-02/00	FR PS
Nissan	Almera 2.0 GTi N15	07/96-02/00	FR PS
Nissan	Almera 2.0 N15	05/96-04/99	FR PS
Nissan	Almera 2.0 N15	10/95-04/99	FR PS
Nissan	Bluebird 1.6 T12	01/88-09/90	FR PS
Nissan	Bluebird 1.6 T12	01/88-09/90	FR PS
Nissan	Bluebird 1.6 T12	01/88-09/90	FR DS
Nissan	Bluebird 1.6 T12	01/88-09/90	FR DS
Nissan	Bluebird 1.6 T12	03/86-01/88	FR DS
Nissan	Bluebird 1.6 T12	03/86-01/88	FR DS
Nissan	Bluebird 1.6 T12	03/86-01/88	FR PS
Nissan	Bluebird 1.6 T12	03/86-01/88	FR PS
Nissan	Bluebird 1.8 Turbo Executive T12	10/87-09/88	FR DS
Nissan	Bluebird 1.8 Turbo Executive T12	10/87-09/88	FR DS
Nissan	Bluebird 1.8 Turbo Executive T12	10/87-09/88	FR PS
Nissan	Bluebird 1.8 Turbo Executive T12	10/87-09/88	FR PS
Nissan	Bluebird 1.8 Turbo ZX U11	05/84-03/86	FR PS
Nissan	Bluebird 1.8 Turbo ZX U11	05/84-03/86	FR DS
Nissan	Bluebird 1.8 Turbo ZX U11	05/84-03/86	FR DS
Nissan	Bluebird 1.8 Turbo ZX U11	05/84-03/86	FR PS
Nissan	Bluebird 1.8 U11	05/84-03/86	FR PS
Nissan	Bluebird 1.8 U11	05/84-03/86	FR DS
Nissan	Bluebird 1.8 U11	05/84-03/86	FR PS
Nissan	Bluebird 1.8 U11	05/84-03/86	FR DS
Nissan	Bluebird 1.8 ZX Turbo T12	02/86-09/90	FR PS
Nissan	Bluebird 1.8 ZX Turbo T12	02/86-09/90	FR DS
Nissan	Bluebird 1.8 ZX Turbo T12	02/87-09/90	FR DS
Nissan	Bluebird 1.8 ZX Turbo T12	02/87-09/90	FR PS
Nissan	Bluebird 2.0 Injected T12	07/88-09/90	FR DS
Nissan	Bluebird 2.0 Injected T12	07/88-09/90	FR DS
Nissan	Bluebird 2.0 Injected T12	07/88-09/90	FR PS
Nissan	Bluebird 2.0 Injected T12	07/88-09/90	FR PS
Nissan	Bluebird 2.0 Injected T12	07/88-09/90	FR PS
Nissan	Bluebird 2.0 Injected T12	07/88-09/90	FR DS

Nissan	Bluebird 2.0 Injected T12	07/88-09/90	FR DS
Nissan	Bluebird 2.0 Injected T12	07/88-09/90	FR PS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR PS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR DS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR DS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR PS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR DS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR DS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR DS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR DS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR PS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR PS
Nissan	Bluebird 2.0 T12	03/86-07/88	FR PS
Nissan	Bluebird 2.0 T72	03/86-09/90	FR DS
Nissan	Bluebird 2.0 T72	03/86-09/90	FR DS
Nissan	Bluebird 2.0 T72	03/86-09/90	FR PS
Nissan	Bluebird 2.0 T72	03/86-09/90	FR PS
Nissan	Bluebird 2.0 U11	03/86-09/90	FR DS
Nissan	Bluebird 2.0 U11	03/86-09/90	FR PS
Nissan	Bluebird 2.0 U11	03/86-09/90	FR DS
Nissan	Bluebird 2.0 U11	03/86-09/90	FR PS
Nissan	Bluebird 2.0 U11	05/84-03/86	FR PS
Nissan	Bluebird 2.0 U11	05/84-03/86	FR DS
Nissan	Bluebird 2.0 U11	05/84-03/86	FR DS
Nissan	Bluebird 2.0 U11	05/84-03/86	FR PS
Nissan	Bluebird 2.0 U11	05/84-03/86	FR PS
Nissan	Bluebird 2.0 U11	05/84-03/86	FR DS
Nissan	Bluebird 2.0 U11	05/84-03/86	FR PS
Nissan	Bluebird 2.0 U11	05/84-03/86	FR DS
Nissan	D21 2.0 1 Ton	08/92-10/93	FR PS
Nissan	D21 2.0 1 Ton	08/92-10/93	FR DS
Nissan	D21 2.0 1.215 Ton	04/86-01/92	FR DS
Nissan	D21 2.0 1.215 Ton	04/86-01/92	FR PS
Nissan	D21 2.4 1.215 Ton	05/86-01/92	FR DS
Nissan	D21 2.4 1.215 Ton	05/86-01/92	FR PS
Nissan	D21 2.5 1 Ton	08/92-08/98	FR PS
Nissan	D21 2.5 1 Ton	08/92-08/98	FR PS
Nissan	D21 2.5 1 Ton	08/92-08/98	FR DS
Nissan	D21 2.5 1 Ton	08/92-08/98	FR DS
Nissan	D21 2.5 1.215 Ton	01/88-01/92	FR PS
Nissan	D21 2.5 1.215 Ton	01/88-01/92	FR PS
Nissan	D21 2.5 1.215 Ton	01/88-01/92	FR DS
Nissan	D21 2.5 1.215 Ton	01/88-01/92	FR DS
Nissan	D21 2.5 1.215 Ton	04/86-01/92	FR PS
Nissan	D21 2.5 1.215 Ton	04/86-01/92	FR DS
Nissan	D21 2.5 1.215 Ton	04/86-01/92	FR PS
Nissan	D21 2.5 1.215 Ton	04/86-01/92	FR DS
Nissan	D21 2.5 1.215 Ton	04/86-01/92	FR DS
Nissan	D21 2.7 TD	08/92-08/98	FR PS
Nissan	D21 2.7 TD	08/92-08/98	FR PS

Nissan	D21 2.7 TD	08/92-08/98	FR DS
Nissan	D21 2.7 TD	08/92-08/98	FR DS
Nissan	D22 2.5	02/02-12/08	FR DS
Nissan	D22 2.5	02/02-12/08	FR PS
Nissan	D22 2.5	02/02-12/08	FR DS
Nissan	D22 2.5	02/02-12/08	FR PS
Nissan	D22 2.5	05/98-07/02	FR PS
Nissan	D22 2.5	05/98-07/02	FR DS
Nissan	D22 2.5 Dual Cab (King cab)	02/02-12/08	FR PS
Nissan	D22 2.5 Dual Cab (King cab)	02/02-12/08	FR DS
Nissan	D22 2.5 Dual Cab (King cab)	07/98-07/02	FR PS
Nissan	D22 2.5 Dual Cab (King cab)	07/98-07/02	FR DS
Nissan	D22 2.5 Dual Cab (King cab)	07/98-08/02	FR DS
Nissan	D22 2.5 Dual Cab (King cab)	07/98-08/02	FR PS
Nissan	D22 2.5 Single cab	02/99-08/02	FR PS
Nissan	D22 2.5 Single cab	02/99-08/02	FR DS
Nissan	GT-R 3.8 Nismo R35	04/14-04/23	FR PS
Nissan	GT-R 3.8 R35	03/09-03/11	FR PS
Nissan	GT-R 3.8 R35	08/16-04/23	FR PS
Nissan	GT-R 3.8 R35	10/10-12/12	FR PS
Nissan	GT-R 3.8 R35	11/11-04/17	FR PS
Nissan	GT-R 3.8 R35	11/11-04/17	FR PS
Nissan	GT-R 3.8 SpecV R35	03/10-03/11	FR PS
Nissan	Murano 3.5 Z50	10/04-12/08	FR PS
Nissan	Navara 2.5 D40	03/10-12/16	FR PS
Nissan	Navara 2.5 D40	03/10-12/16	FR PS
Nissan	Navara 2.5 D40	05/13-12/16	FR PS
Nissan	Navara 2.5 D40	06/05-12/10	FR PS
Nissan	Navara 2.5 D40	06/05-12/10	FR PS
Nissan	Navara 3.0 D40	05/10-12/16	FR PS
Nissan	Pathfinder 2.5 R51	03/05-12/10	FR PS
Nissan	Pathfinder 2.5 R51	03/05-12/10	FR PS
Nissan	Pathfinder 4.0 R51	08/05-05/07	FR PS
Nissan	Patrol 2.8 Y61	03/98-06/00	FR PS
Nissan	Patrol 2.8 Y61	03/98-06/00	FR PS
Nissan	Patrol 3.0 Y61	05/00-12/04	FR PS
Nissan	Patrol 3.0 Y61	05/00-12/04	FR PS
Nissan	Patrol 3.0 Y61	05/00-12/04	FR PS
Nissan	Patrol 3.0 Y61	05/00-12/04	FR PS
Nissan	Patrol 3.0 Y61	10/04-08/10	FR PS
Nissan	Patrol 3.0 Y61	10/04-08/10	FR PS
Nissan	Prairie 2.0 M11	04/89-12/91	FR DS
Nissan	Prairie 2.0 M11	04/89-12/91	FR PS
Nissan	Prairie 2.0 M11	04/89-12/91	FR PS
Nissan	Prairie 2.0 M11	04/89-12/91	FR PS
Nissan	Prairie 2.0 M11	04/89-12/91	FR PS
Nissan	Prairie 2.0 M11	04/89-12/91	FR DS
Nissan	Prairie 2.0 M11	04/89-12/91	FR DS
Nissan	Prairie 2.0 M11	04/89-12/91	FR DS
Nissan	Primera 1.6 Carburettor P10	09/90-12/91	FR PS

Nissan	Primera 1.6 Carburettor P10	09/90-12/91	FR PS
Nissan	Primera 1.6 Carburettor W10	02/91-12/91	FR PS
Nissan	Primera 1.6 MPi P10	06/93-10/96	FR PS
Nissan	Primera 1.6 MPi P10	06/93-10/96	FR PS
Nissan	Primera 1.6 MPi W10	06/93-10/96	FR PS
Nissan	Primera 1.6 P12	03/02-12/07	FR PS
Nissan	Primera 1.6 P12	03/02-12/07	FR PS
Nissan	Primera 1.6 SPi P10	01/92-06/93	FR PS
Nissan	Primera 1.6 SPi P10	01/92-06/93	FR PS
Nissan	Primera 1.6 SPi W10	01/92-06/93	FR PS
Nissan	Primera 1.6 W12	03/02-12/07	FR PS
Nissan	Primera 1.8 P12	03/02-12/04	FR PS
Nissan	Primera 1.8 P12	03/02-12/04	FR PS
Nissan	Primera 1.8 P12	09/02-12/06	FR PS
Nissan	Primera 1.8 P12	09/02-12/06	FR PS
Nissan	Primera 1.8 W12	03/02-12/06	FR PS
Nissan	Primera 1.8 W12	03/02-12/06	FR PS
Nissan	Primera 2.0 eZX P10	09/90-10/96	FR PS
Nissan	Primera 2.0 P10	06/92-11/96	FR PS
Nissan	Primera 2.0 P10	06/92-11/96	FR PS
Nissan	Primera 2.0 P10	06/93-10/96	FR PS
Nissan	Primera 2.0 P10	06/93-10/96	FR PS
Nissan	Primera 2.0 P10	06/93-10/96	FR PS
Nissan	Primera 2.0 P10	06/93-10/96	FR PS
Nissan	Primera 2.0 P12	03/02-12/04	FR PS
Nissan	Primera 2.0 P12	03/02-12/04	FR PS
Nissan	Primera 2.0 P12	09/02-03/06	FR PS
Nissan	Primera 2.0 P12	09/02-03/06	FR PS
Nissan	Primera 2.0 W10	02/91-10/96	FR PS
Nissan	Primera 2.0 W10	02/91-10/96	FR PS
Nissan	Primera 2.0 W10	06/95-11/96	FR PS
Nissan	Primera 2.0 W12	03/02-03/06	FR PS
Nissan	Primera 2.0 W12	03/02-03/06	FR PS
Nissan	Primera 2.2 dCi P12	04/03-03/06	FR PS
Nissan	Primera 2.2 dCi P12	04/03-12/04	FR PS
Nissan	Primera 2.2 dCi W12	04/03-03/06	FR PS
Nissan	Primera 2.2 P12	03/02-04/03	FR PS
Nissan	Primera 2.2 P12	09/02-04/03	FR PS
Nissan	Primera 2.2 W12	03/02-04/03	FR PS
Nissan	Sunny 1.3 N13	09/86-03/89	FR PS
Nissan	Sunny 1.3 N13	09/86-03/89	FR DS
Nissan	Sunny 1.3 N13	09/86-03/89	FR DS
Nissan	Sunny 1.3 N13	09/86-03/89	FR PS
Nissan	Sunny 1.3 N13	09/86-08/88	FR DS
Nissan	Sunny 1.3 N13	09/86-08/88	FR DS
Nissan	Sunny 1.3 N13	09/86-08/88	FR PS
Nissan	Sunny 1.3 N13	09/86-08/88	FR PS
Nissan	Sunny 1.4 MPi N14	02/93-10/95	FR PS
Nissan	Sunny 1.4 MPi N14	02/93-10/95	FR PS
Nissan	Sunny 1.4 MPi N14	02/93-10/95	FR PS

Nissan	Sunny 1.4 N14	12/91-02/93	FR PS
Nissan	Sunny 1.4 N14	12/91-02/93	FR PS
Nissan	Sunny 1.4 N14	12/91-02/93	FR PS
Nissan	Sunny 1.6 B12	02/88-03/89	FR PS
Nissan	Sunny 1.6 B12	02/88-03/89	FR PS
Nissan	Sunny 1.6 B12	02/88-03/89	FR PS
Nissan	Sunny 1.6 B12	02/88-03/89	FR DS
Nissan	Sunny 1.6 B12	02/88-03/89	FR DS
Nissan	Sunny 1.6 B12	02/88-03/89	FR DS
Nissan	Sunny 1.6 B12	09/86-02/88	FR DS
Nissan	Sunny 1.6 B12	09/86-02/88	FR PS
Nissan	Sunny 1.6 B12	09/86-03/89	FR DS
Nissan	Sunny 1.6 B12	09/86-03/89	FR PS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR PS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR PS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR PS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR PS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR PS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR PS
Nissan	Sunny 1.6 N13	09/86-02/88	FR PS
Nissan	Sunny 1.6 N13	09/86-02/88	FR PS
Nissan	Sunny 1.6 N13	09/86-02/88	FR PS
Nissan	Sunny 1.6 N13	09/86-02/88	FR DS
Nissan	Sunny 1.6 N13	09/86-02/88	FR DS
Nissan	Sunny 1.6 N13	09/86-02/88	FR DS
Nissan	Sunny 1.6 N13	09/86-02/88	FR PS
Nissan	Sunny 1.6 N13	09/86-02/88	FR DS
Nissan	Sunny 1.6 N14	02/91-12/91	FR PS
Nissan	Sunny 1.6 N14	02/91-12/91	FR PS
Nissan	Sunny 1.6 N14	02/91-12/91	FR DS
Nissan	Sunny 1.6 N14	02/91-12/91	FR DS
Nissan	Sunny 1.6 N14	02/91-12/91	FR DS
Nissan	Sunny 1.6 N14	02/91-12/91	FR DS
Nissan	Sunny 1.6 N14	02/91-12/91	FR PS
Nissan	Sunny 1.6 N14	02/91-12/91	FR PS
Nissan	Sunny 1.6 SPi N14	12/91-02/93	FR PS
Nissan	Sunny 1.6 SPi N14	12/91-02/93	FR PS
Nissan	Sunny 1.6 SPi N14	12/91-02/93	FR PS
Nissan	Sunny 1.6 SPi N14	12/91-02/93	FR PS
Nissan	Sunny 1.6 Y10	02/91-12/91	FR PS
Nissan	Sunny 1.6 Y10	02/91-12/91	FR DS
Nissan	Sunny 1.7 N13	09/86-12/88	FR PS
Nissan	Sunny 1.7 N13	09/86-12/88	FR DS
Nissan	Sunny 1.7 N13	09/86-12/91	FR PS
Nissan	Sunny 1.7 N13	09/86-12/91	FR DS
Nissan	Sunny 1.8 ZX B12	03/89-12/91	FR PS
Nissan	Sunny 1.8 ZX B12	03/89-12/91	FR DS
Nissan	Sunny 2.0 e GTi N14	01/92-08/94	FR PS
Nissan	Sunny 2.0 GTi-R N14	04/92-12/93	FR PS
Nissan	Sunny 2.0 N14	02/93-10/95	FR PS

Nissan	Sunny 2.0 N14	02/93-10/95	FR PS
Opel	Astra G 1.4 Dual Fuel MK 4 (1998-2006)	09/99-06/03	FR PS
Opel	Astra G 1.4 Dual Fuel MK 4 (1998-2006)	09/99-06/03	FR PS
Opel	Astra G 1.4 MK 4 (1998-2006)	02/98-03/05	FR PS
Opel	Astra G 1.4 MK 4 (1998-2006)	02/98-03/05	FR PS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	02/98-12/00	FR PS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	02/98-12/00	FR PS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/00-12/03	FR PS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/00-12/03	FR PS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/99-08/04	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-09/00	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-09/00	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	09/00-03/05	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	09/00-03/05	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	10/03-08/04	FR PS
Opel	Astra G 1.6 MK 4 (1998-2006)	10/03-08/04	FR PS
Opel	Astra G 1.7 CDTi MK 4 (1998-2006)	06/03-03/05	FR PS
Opel	Astra G 1.7 DTi MK 4 (1998-2006)	01/00-03/05	FR PS
Opel	Astra G 1.7 TD MK 4 (1998-2006)	02/98-01/00	FR PS
Opel	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Opel	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Opel	Astra G 1.8 MK 4 (1998-2006)	09/00-03/05	FR PS
Opel	Astra G 1.8 MK 4 (1998-2006)	09/00-03/05	FR PS
Opel	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-03/05	FR PS
Opel	Astra G 2.2 MK 4 (1998-2006)	06/02-03/05	FR PS
Opel	Astra G 2.2 MK 4 (1998-2006)	06/02-03/05	FR PS
Peugeot	206 1.1 (1998-2009)	10/98-03/06	FR DS
Peugeot	206 1.1 (1998-2009)	10/98-03/06	FR DS
Peugeot	206 1.1 (1998-2009)	10/98-03/06	FR DS
Peugeot	206 1.1 (1998-2009)	10/98-03/06	FR DS
Peugeot	206 1.4 (1998-2009)	10/05-12/09	FR DS
Peugeot	206 1.4 (1998-2009)	10/05-12/09	FR DS
Peugeot	206 1.4 (1998-2009)	10/98-12/03	FR DS
Peugeot	206 1.4 (1998-2009)	10/98-12/03	FR DS
Peugeot	206 1.4 (1998-2009)	10/98-12/03	FR DS
Peugeot	206 1.4 (1998-2009)	10/98-12/03	FR DS
Peugeot	206 1.4 (1998-2009)	10/98-12/09	FR DS
Peugeot	206 1.4 (1998-2009)	10/98-12/09	FR DS
Peugeot	206 1.4 (1998-2009)	10/98-12/09	FR DS
Peugeot	206 1.4 (1998-2009)	10/98-12/09	FR DS
Peugeot	206 1.4 (1998-2009) Tiptronic	08/03-12/06	FR DS
Peugeot	206 1.4 (1998-2009) Tiptronic	08/03-12/06	FR DS
Peugeot	206 1.4 (1998-2009) Tiptronic	08/03-12/06	FR DS
Peugeot	206 1.4 (1998-2009) Tiptronic	08/03-12/06	FR DS
Peugeot	206 1.6 (1998-2009)	10/98-10/00	FR DS
Peugeot	206 1.6 (1998-2009)	10/98-10/00	FR DS

Peugeot	206 1.9 (1998-2009)	10/98-10/02	FR DS
Peugeot	206 1.9 (1998-2009)	10/98-10/02	FR DS
Peugeot	206 1.9 (1998-2009)	10/98-10/02	FR DS
Peugeot	206 1.9 (1998-2009)	10/98-10/02	FR DS
Peugeot	206 2.0 (1998-2009)	01/99-10/00	FR DS
Peugeot	206 2.0 (1998-2009)	10/00-11/05	FR DS
Peugeot	206 2.0 HDi (1998-2009)	11/99-11/05	FR DS
Peugeot	206 2.0 HDi (1998-2009)	11/99-11/05	FR DS
Peugeot	206 2.0 HDi Eco (1998-2009)	10/00-12/03	FR DS
Peugeot	206 2.0 HDi Eco (1998-2009)	10/00-12/03	FR DS
Rover	820 2.0 (1986-1991)	05/88-09/90	FR PS
Rover	820 2.0 (1986-1991)	05/88-09/90	FR PS
Rover	820 2.0 (1986-1991)	05/88-09/90	RR
Rover	820 2.0 (1986-1991)	05/88-09/90	RR
Rover	820 2.0 (1986-1991)	05/88-09/90	FR DS
Rover	820 2.0 (1986-1991)	05/88-09/90	FR DS
Rover	820 2.0 (1986-1991)	05/88-09/90	RR
Rover	820 2.0 (1986-1991)	05/88-09/90	FR DS
Rover	820 2.0 (1986-1991)	05/88-09/90	FR PS
Rover	820 2.0 (1991-1999)	11/91-10/99	FR PS
Rover	820 2.0 (1991-1999)	11/91-10/99	FR DS
Rover	820 2.0 (1991-1999)	11/91-10/99	FR DS
Rover	820 2.0 (1991-1999)	11/91-10/99	FR PS
Rover	820 2.0 (1991-1999)	11/91-10/99	RR
Rover	820 2.0 (1991-1999)	11/91-10/99	FR PS
Rover	820 2.0 (1991-1999)	11/91-10/99	FR PS
Rover	820 2.0 (1991-1999)	11/91-10/99	FR DS
Rover	820 2.0 (1991-1999)	11/91-10/99	FR DS
Rover	820 2.0 (1991-1999)	11/91-10/99	RR
Rover	820 2.0 MPi (1986-1991)	05/88-11/91	RR
Rover	820 2.0 MPi (1986-1991)	05/88-11/91	FR DS
Rover	820 2.0 MPi (1986-1991)	05/88-11/91	RR
Rover	820 2.0 MPi (1986-1991)	05/88-11/91	FR PS
Rover	820 2.0 MPi (1986-1991)	05/88-11/91	FR PS
Rover	820 2.0 MPi (1986-1991)	05/88-11/91	FR DS
Rover	820 2.0 MPi (1986-1991)	07/86-11/91	FR PS
Rover	820 2.0 MPi (1986-1991)	07/86-11/91	FR DS
Rover	820 2.0 MPi (1986-1991)	07/86-11/91	FR PS
Rover	820 2.0 MPi (1986-1991)	07/86-11/91	FR DS
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	RR
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	FR DS
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	RR
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	FR PS
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	FR DS
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	FR PS
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	FR PS
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	FR PS
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	RR
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	FR DS
Rover	820 2.0 SPi (1986-1991)	05/88-09/90	RR

Rover	820 2.0 SPi (1986-1991)	05/88-09/90	FR DS
Rover	820 2.0 SPi (1986-1991)	10/86-09/90	FR DS
Rover	820 2.0 SPi (1986-1991)	10/86-09/90	FR PS
Rover	820 2.0 SPi (1986-1991)	10/86-09/90	FR PS
Rover	820 2.0 SPi (1986-1991)	10/86-09/90	FR DS
Rover	820 2.0 SPi (1986-1991)	10/86-09/90	FR PS
Rover	820 2.0 SPi (1986-1991)	10/86-09/90	FR PS
Rover	820 2.0 SPi (1986-1991)	10/86-09/90	FR DS
Rover	820 2.0 SPi (1986-1991)	10/86-09/90	FR DS
Rover	825 2.5 (1986-1991)	07/86-02/88	FR DS
Rover	825 2.5 (1986-1991)	07/86-02/88	FR PS
Rover	825 2.5 (1986-1991)	07/86-02/88	FR DS
Rover	825 2.5 (1986-1991)	07/86-02/88	FR PS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR PS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR PS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR DS
Rover	825 2.5 (1991-1999)	01/96-10/99	RR
Rover	825 2.5 (1991-1999)	01/96-10/99	FR DS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR DS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR PS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR DS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR PS
Rover	825 2.5 (1991-1999)	01/96-10/99	RR
Rover	825 2.5 Di (1991-1999)	03/96-10/99	FR DS
Rover	825 2.5 Di (1991-1999)	03/96-10/99	FR DS
Rover	825 2.5 Di (1991-1999)	03/96-10/99	FR PS
Rover	825 2.5 Di (1991-1999)	03/96-10/99	FR PS
Rover	825 2.5 Di (1991-1999)	03/96-10/99	FR PS
Rover	825 2.5 Di (1991-1999)	03/96-10/99	FR DS
Rover	825 2.5 Di (1991-1999)	03/96-10/99	FR PS
Rover	825 2.5 Di (1991-1999)	03/96-10/99	FR DS
Rover	825 2.5 Di (1991-1999)	03/96-10/99	RR
Rover	825 2.5 Di (1991-1999)	03/96-10/99	RR
Rover	825 2.5 Di (1991-1999)	12/91-04/97	FR DS
Rover	825 2.5 Di (1991-1999)	12/91-04/97	FR DS
Rover	825 2.5 Di (1991-1999)	12/91-04/97	FR PS
Rover	825 2.5 Di (1991-1999)	12/91-04/97	FR PS
Rover	825 2.5 Di (1991-1999)	12/91-04/97	FR PS
Rover	825 2.5 Di (1991-1999)	12/91-04/97	FR DS
Rover	825 2.5 Di (1991-1999)	12/91-04/97	FR PS
Rover	825 2.5 Di (1991-1999)	12/91-04/97	FR DS
Rover	825 2.5 Di (1991-1999)	12/91-04/97	RR
Rover	825 2.5 Di (1991-1999)	12/91-04/97	RR
Rover	827 2.7 (1986-1991)	02/88-11/91	FR DS
Rover	827 2.7 (1986-1991)	02/88-11/91	FR PS
Rover	827 2.7 (1986-1991)	02/88-11/91	FR DS
Rover	827 2.7 (1986-1991)	02/88-11/91	FR PS
Rover	827 2.7 (1986-1991)	05/88-11/91	FR DS
Rover	827 2.7 (1986-1991)	05/88-11/91	RR
Rover	827 2.7 (1986-1991)	05/88-11/91	FR DS

Rover	827 2.7 (1986-1991)	05/88-11/91	FR PS
Rover	827 2.7 (1986-1991)	05/88-11/91	FR PS
Rover	827 2.7 (1986-1991)	05/88-11/91	RR
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	FR DS
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	FR DS
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	FR PS
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	RR
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	RR
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	FR PS
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	FR PS
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	FR PS
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	FR DS
Rover	827/Sterling 2.7 (1991-1999)	11/91-03/96	FR DS
Seat	Arosa 1.0 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.0 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.0 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.0 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.0 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.0 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.0 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.0 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.0 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.4 (1997-2001)	01/00-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	01/00-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	01/00-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (1997-2001)	09/97-01/01	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-06/04	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-12/01	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-12/01	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.4 (2001-2004)	01/01-12/04	FR DS
Seat	Arosa 1.7 (1997-2001)	01/98-01/01	FR DS
Seat	Cordoba 1.4 (1994-1999)	04/95-04/96	FR PS
Seat	Cordoba 1.4 (1994-1999)	04/96-10/99	FR PS
Seat	Cordoba 1.4 (1994-1999)	04/96-10/99	FR PS
Seat	Cordoba 1.4 (1994-1999)	04/96-10/99	FR PS
Seat	Cordoba 1.4 (1994-1999)	04/96-10/99	FR PS

Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR PS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR PS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR PS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR PS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR PS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR PS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR PS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR PS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.6 6K (1993-1999)	10/93-12/96	FR PS
Seat	Ibiza 1.6 6K (1993-1999)	10/93-12/96	FR PS
Seat	Ibiza 1.6 6K (1993-1999)	10/93-12/96	FR PS
Seat	Ibiza 1.6 6K (1993-1999)	10/93-12/96	FR PS
Seat	Ibiza 1.6 6K (1993-1999)	12/96-12/97	FR PS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.8 6K (1993-1999)	10/93-06/94	FR PS
Seat	Ibiza 1.8 6K (1993-1999)	10/93-06/94	FR PS
Seat	Ibiza 1.8 6K (1993-1999)	10/94-12/96	FR PS
Seat	Ibiza 1.9 6K (1993-1999)	10/93-01/99	FR PS
Seat	Ibiza 1.9 6K (1993-1999)	10/93-01/99	FR PS
Seat	Ibiza 1.9 6K (1993-1999)	10/93-01/99	FR PS
Seat	Ibiza 1.9 6K (1993-1999)	10/93-01/99	FR PS
Seat	Ibiza 1.9 TDi 110 6K (1999-2002)	09/01-05/02	FR PS
Seat	Ibiza 1.9 TDi 90 6K (1993-1999)	07/97-10/99	FR PS
Seat	Ibiza 1.9 TDi 90 6K (1993-1999)	07/97-10/99	FR PS
Seat	Ibiza 1.9 TDi 90 6K (1993-1999)	07/97-10/99	FR PS
Seat	Ibiza 1.9 TDi 90 6K (1993-1999)	07/97-10/99	FR PS
Seat	Ibiza 1.9 TDi 90 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.9 TDi 90 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.9 TDi 90 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 1.9 TDi 90 6K (1999-2002)	10/99-05/02	FR PS
Seat	Ibiza 2.0 6K (1993-1999)	10/93-10/99	FR PS
Seat	Ibiza 2.0 6K (1993-1999)	10/93-10/99	FR PS
Seat	Ibiza 2.0 6K (1993-1999)	12/96-10/99	FR PS
Subaru	Forester 2.0 SF (1997-2000)	09/97-04/00	FR PS
Subaru	Forester 2.0 SF (1997-2000)	09/97-04/00	FR PS
Subaru	Forester 2.0 SF (2000-2002)	04/00-10/02	FR PS
Subaru	Forester 2.0 SF (2000-2002)	04/00-10/02	FR PS
Subaru	Forester 2.0 SG (2005-2008)	09/05-12/08	FR PS
Subaru	Forester 2.0 SG (2005-2008)	09/05-12/08	FR PS
Subaru	Forester 2.0 SG (2005-2008)	09/05-12/08	FR PS
Subaru	Forester 2.0 SG (2005-2008)	09/05-12/08	FR PS

Subaru	Forester 2.0 Turbo SF (1997-2000)	10/98-04/00	FR PS
Subaru	Forester 2.0 Turbo SF (1997-2000)	10/98-04/00	FR PS
Subaru	Forester 2.0 Turbo SF (2000-2002)	02/01-10/02	FR PS
Subaru	Forester 2.0 Turbo SF (2000-2002)	02/01-10/02	FR PS
Subaru	Forester 2.0 Turbo SF (2000-2002)	04/00-02/01	FR PS
Subaru	Forester 2.0 Turbo SF (2000-2002)	04/00-02/01	FR PS
Subaru	Forester 2.0 X SG (2002-2005)	10/02-10/05	FR PS
Subaru	Forester 2.0 X SG (2002-2005)	10/02-10/05	FR PS
Subaru	Forester 2.0 X SG (2002-2005)	10/02-10/05	FR PS
Subaru	Forester 2.0 X SG (2002-2005)	10/02-10/05	FR PS
Subaru	Forester 2.0 XT SG (2002-2005)	10/02-10/05	FR PS
Subaru	Forester 2.0 XT SG (2002-2005)	10/02-10/05	FR PS
Subaru	Forester 2.0 XT SG (2002-2005)	10/02-10/05	FR PS
Subaru	Forester 2.0 XT SG (2002-2005)	10/02-10/05	FR PS
Subaru	Forester 2.5 XT SG (2002-2005)	11/04-10/05	FR PS
Subaru	Legacy 2.0 (1994-1999)	04/94-10/98	FR PS
Subaru	Legacy 2.0 (1994-1999)	04/94-10/99	FR PS
Subaru	Legacy 2.0 (1998-2003)	09/99-10/99	FR PS
Subaru	Legacy 2.0 (1998-2003)	09/99-10/99	FR PS
Subaru	Legacy 2.0 (2003-2010)	05/08-08/10	FR PS
Subaru	Legacy 2.0 (2003-2010)	05/08-08/10	FR PS
Subaru	Legacy 2.0 (2003-2010)	08/08-08/10	FR PS
Subaru	Legacy 2.0 (2003-2010)	09/05-09/08	FR PS
Subaru	Legacy 2.0 (2003-2010)	09/05-09/08	FR PS
Subaru	Legacy 2.0 (2003-2010)	09/07-06/10	FR PS
Subaru	Legacy 2.0 (2003-2010)	11/03-10/05	FR PS
Subaru	Legacy 2.0 (2003-2010)	11/03-10/05	FR PS
Subaru	Legacy 2.0 (2009-2016)	04/11-05/14	FR PS
Subaru	Legacy 2.0 (2009-2016)	04/11-05/14	FR PS
Subaru	Legacy 2.0 (2009-2016)	04/11-05/14	FR PS
Subaru	Legacy 2.0 (2009-2016)	04/11-05/14	FR PS
Subaru	Legacy 2.0 (2009-2016)	10/09-05/14	FR PS
Subaru	Legacy 2.2 (1994-1999)	04/94-01/98	FR PS
Subaru	Legacy 2.2 (1994-1999)	04/94-01/98	FR PS
Subaru	Legacy 2.2 (1994-1999)	04/94-01/98	FR PS
Subaru	Legacy 2.2 (1994-1999)	04/94-01/98	FR PS
Subaru	Legacy 2.5 (1994-1999)	01/98-10/98	FR PS
Subaru	Legacy 2.5 (1994-1999)	01/98-12/98	FR PS
Subaru	Legacy 2.5 (1994-1999)	09/96-10/98	FR PS
Subaru	Legacy 2.5 (1994-1999)	09/96-12/98	FR PS
Subaru	Legacy 2.5 (1998-2003)	12/98-10/99	FR PS
Subaru	Legacy 2.5 (1998-2003)	12/98-10/99	FR PS
Subaru	Legacy 2.5 (2003-2010)	02/08-08/10	FR PS
Subaru	Legacy 2.5 (2003-2010)	02/08-08/10	FR PS
Subaru	Legacy 2.5 (2003-2010)	11/03-10/05	FR PS
Subaru	Legacy 2.5 (2003-2010)	11/03-10/05	FR PS
Subaru	Legacy 2.5 (2009-2016)	10/09-05/14	FR PS
Subaru	Legacy 3.0 (2003-2010)	11/03-08/10	FR PS
Subaru	Legacy 3.0 (2003-2010)	11/03-08/10	FR PS
Subaru	Legacy Outback 2.5 (1994-1999)	01/98-12/98	FR PS

Subaru	Legacy Outback 2.5 (1994-1999)	09/96-12/98	FR PS
Suzuki	Grand Vitara 1.6 (1998-2005)	01/01-11/05	FR PS
Suzuki	Grand Vitara 1.6 (1998-2005)	01/01-11/05	FR DS
Suzuki	Grand Vitara 1.6 (1998-2005)	01/01-11/05	FR PS
Suzuki	Grand Vitara 1.6 (1998-2005)	01/01-11/05	FR DS
Suzuki	Grand Vitara 1.6 (2005-2015)	10/05-04/15	FR PS
Suzuki	Grand Vitara 1.9 DDiS (2005-2015)	12/05-04/15	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	03/02-03/06	FR DS
Suzuki	Grand Vitara 2.0 (1998-2005)	03/02-03/06	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	03/02-03/06	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	03/02-03/06	FR DS
Suzuki	Grand Vitara 2.0 (1998-2005)	03/03-03/05	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	03/03-03/05	FR DS
Suzuki	Grand Vitara 2.0 (1998-2005)	05/99-11/05	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	05/99-11/05	FR DS
Suzuki	Grand Vitara 2.0 (1998-2005)	05/99-11/05	FR DS
Suzuki	Grand Vitara 2.0 (1998-2005)	05/99-11/05	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	05/99-11/05	FR DS
Suzuki	Grand Vitara 2.0 (1998-2005)	05/99-11/05	FR DS
Suzuki	Grand Vitara 2.0 (1998-2005)	05/99-11/05	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	05/99-11/05	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	09/98-03/01	FR DS
Suzuki	Grand Vitara 2.0 (1998-2005)	09/98-03/01	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	09/98-03/01	FR PS
Suzuki	Grand Vitara 2.0 (1998-2005)	09/98-03/01	FR DS
Suzuki	Grand Vitara 2.0 (2005-2015)	10/05-04/10	FR PS
Suzuki	Grand Vitara 2.0 (2005-2015)	10/05-04/10	FR PS
Suzuki	Grand Vitara 2.4 (2005-2015)	10/08-04/15	FR PS
Suzuki	Grand Vitara 2.4 (2005-2015)	10/08-04/15	FR PS
Suzuki	Grand Vitara 2.4 (2005-2015)	10/08-04/15	FR PS
Suzuki	Grand Vitara 2.4 (2005-2015)	10/08-04/15	FR PS
Suzuki	Grand Vitara 2.5 (1998-2005)	04/98-01/02	FR PS
Suzuki	Grand Vitara 2.5 (1998-2005)	04/98-01/02	FR DS
Suzuki	Grand Vitara 2.5 (1998-2005)	04/98-01/02	FR DS
Suzuki	Grand Vitara 2.5 (1998-2005)	04/98-01/02	FR PS
Suzuki	Grand Vitara 2.7 (1998-2005)	01/04-11/05	FR PS
Suzuki	Grand Vitara 2.7 (1998-2005)	01/04-11/05	FR PS
Suzuki	Grand Vitara 2.7 (1998-2005)	09/01-01/04	FR DS
Suzuki	Grand Vitara 2.7 (1998-2005)	09/01-01/04	FR PS
Suzuki	Grand Vitara 2.7 (1998-2005)	09/01-01/04	FR DS
Suzuki	Grand Vitara 2.7 (1998-2005)	09/01-01/04	FR PS
Suzuki	Ignis 1.2 (2016-2025)	08/16-04/21	FR DS
Suzuki	Ignis 1.2 (2016-2025)	08/16-04/21	FR DS
Suzuki	Ignis 1.2 SHVS (2016-2025)	06/16-04/21	FR DS
Suzuki	Ignis 1.2 SHVS Allgrip (2016-2025)	06/16-04/21	FR DS
Suzuki	Ignis 1.3 (2000-2008)	09/03-08/08	FR DS
Suzuki	Ignis 1.3 (2000-2008)	09/03-08/08	FR DS
Suzuki	Ignis 1.3 (2000-2008)	12/00-06/04	FR DS
Suzuki	Ignis 1.3 (2000-2008)	12/00-06/04	FR DS
Suzuki	Ignis 1.3 (2000-2008)	12/00-06/05	FR DS

Suzuki	Ignis 1.3 (2000-2008)	12/00-06/05	FR DS
Suzuki	Ignis 1.5 (2000-2008)	09/03-06/08	FR DS
Suzuki	Ignis 1.5 4GRIP (2000-2008)	09/03-06/08	FR DS
Suzuki	Ignis 1.5 Sport (2000-2008)	09/03-08/06	FR DS
Suzuki	Ignis 1.5 Sport (2000-2008)	09/03-08/06	FR DS
Suzuki	Swift 1.0 A2 (2017-2025)	04/17-12/20	FR PS
Suzuki	Swift 1.0 A2 (2017-2025)	04/17-12/20	FR PS
Suzuki	Swift 1.0 SHVS A2 (2017-2025)	04/17-12/20	FR PS
Suzuki	Swift 1.2 A2 (2017-2025)	04/17-12/20	FR PS
Suzuki	Swift 1.3 DDiS RS (2005-2011)	02/08-03/11	FR PS
Suzuki	Swift 1.3 DDiS RS (2005-2011)	02/08-03/11	FR PS
Suzuki	Swift 1.3 DDiS RS (2005-2011)	02/08-03/11	FR PS
Suzuki	Swift 1.3 DDiS RS (2005-2011)	09/05-03/09	FR PS
Suzuki	Swift 1.3 RS (2005-2011)	04/05-03/11	FR PS
Suzuki	Swift 1.3 RS (2005-2011)	04/05-03/11	FR PS
Suzuki	Swift 1.4 Sport A2 (2017-2025)	04/18-12/20	FR PS
Suzuki	Swift 1.5 RS (2005-2011)	04/05-03/11	FR PS
Suzuki	Swift 1.5 RS (2005-2011)	04/05-03/11	FR PS
Suzuki	Swift 1.5 RS (2005-2011)	04/05-03/11	FR PS
Suzuki	Swift 1.5 RS (2005-2011)	04/05-03/11	FR PS
Suzuki	Swift 1.6 Sport RS (2005-2011)	10/06-12/11	FR PS
Toyota	Camry 1.8 SV10	04/83-08/85	FR PS
Toyota	Camry 1.8 SV10	04/83-08/85	FR PS
Toyota	Camry 2.0 SV11	04/84-01/87	FR PS
Toyota	Camry 2.0 SV11	04/84-01/87	FR PS
Toyota	Camry 2.2 SXV10	09/91-09/95	FR PS
Toyota	Camry 2.2 SXV10	09/91-09/95	FR PS
Toyota	Camry 2.2 SXV10	09/91-12/95	FR PS
Toyota	Camry 2.2 SXV10	09/91-12/95	FR PS
Toyota	Camry 2.2 SXV20	11/96-12/01	FR PS
Toyota	Camry 2.2 SXV20	11/96-12/01	FR PS
Toyota	Camry 3.0 VCV10	10/91-09/95	FR PS
Toyota	Camry 3.0 VCV10	10/91-12/95	FR PS
Toyota	Celica 1.8 AT200	07/95-10/99	FR PS
Toyota	Celica 2.0 GT-Four ST205	05/94-10/96	FR PS
Toyota	Celica 2.0 ST202	03/94-10/99	FR PS
Toyota	Celica 2.0 ST202	03/94-10/99	FR PS
Toyota	Celica 2.0 ST202	03/94-10/99	FR PS
Toyota	Celica 2.0 ST202	03/94-10/99	FR PS
Toyota	MR2 1.8 ZZW30	01/04-12/06	FR PS
Toyota	MR2 1.8 ZZW30	04/00-12/04	FR PS
Toyota	MR2 1.8 ZZW30	04/00-12/04	FR PS
Toyota	MR-S 1.8	01/99-12/05	FR PS
Toyota	MR-S 1.8	01/99-12/05	FR PS
Vauxhall	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR PS
Vauxhall	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR PS
Vauxhall	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR PS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-03/05	FR PS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-03/05	FR PS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-12/05	FR PS

Vauxhall	Astra G 1.7 CDTi MK 4 (1998-2006)	06/03-12/05	FR PS
Vauxhall	Astra G 1.7 CDTi MK 4 (1998-2006)	08/03-12/06	FR PS
Vauxhall	Astra G 1.7 DTi MK 4 (1998-2006)	01/00-03/05	FR PS
Vauxhall	Astra G 1.7 DTi MK 4 (1998-2006)	01/00-03/05	FR PS
Vauxhall	Astra G 1.7 DTi MK 4 (1998-2006)	01/00-03/05	FR PS
Vauxhall	Astra G 1.7 DTi MK 4 (1998-2006)	01/00-08/04	FR PS
Vauxhall	Astra G 1.7 DTi MK 4 (1998-2006)	02/00-06/04	FR PS
Vauxhall	Astra G 1.7 LP Turbo MK 4 (1998-2006)	09/98-04/00	FR PS
Vauxhall	Astra G 1.7 TD MK 4 (1998-2006)	02/98-01/00	FR PS
Vauxhall	Astra G 1.7 TD MK 4 (1998-2006)	02/98-01/00	FR PS
Vauxhall	Astra G 1.7 TD MK 4 (1998-2006)	02/98-01/00	FR PS
Vauxhall	Astra G 1.7 TD MK 4 (1998-2006)	02/98-01/00	FR PS
Vauxhall	Astra G 1.8 Dual Fuel MK 4 (1998-2006)	07/02-08/04	FR PS
Vauxhall	Astra G 1.8 Dual Fuel MK 4 (1998-2006)	07/02-12/03	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	04/01-05/06	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	07/00-03/02	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	07/00-06/04	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-03/05	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-03/05	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	10/98-09/00	FR PS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	10/98-09/00	FR PS
Vauxhall	Astra G 2.0 Di MK 4 (1998-2006)	08/00-08/03	FR PS
Vauxhall	Astra G 2.0 Di MK 4 (1998-2006)	09/98-08/03	FR PS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	07/02-03/05	FR PS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-03/05	FR PS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-08/04	FR PS
Vauxhall	Astra G 2.0 MK 4 (1998-2006)	08/98-12/01	FR PS
Vauxhall	Astra G 2.0 SRi Turbo MK 4 (1998-2006)	04/02-12/02	FR PS
Vauxhall	Astra G 2.0 Turbo MK 4 (1998-2006)	03/02-05/06	FR PS
Vauxhall	Astra G 2.0 Turbo MK 4 (1998-2006)	07/00-06/04	FR PS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	04/01-05/06	FR PS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	04/01-05/06	FR PS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	06/02-03/05	FR PS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	06/02-03/05	FR PS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	07/00-06/04	FR PS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	10/00-08/04	FR PS

Vauxhall	Astra G 2.2 MK 4 (1998-2006)	10/00-08/04	FR PS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	10/00-08/04	FR PS
Vauxhall	Calibra 2.0 (1990-1998)	06/90-02/94	FR PS
Vauxhall	Calibra 2.0 (1990-1998)	06/90-02/94	FR DS
Vauxhall	Calibra 2.0 (1990-1998)	06/90-12/96	FR DS
Vauxhall	Calibra 2.0 (1990-1998)	06/90-12/96	FR PS
Vauxhall	Calibra 2.0 (1990-1998)	09/90-07/92	FR PS
Vauxhall	Calibra 2.0 (1990-1998)	09/90-07/92	FR DS
Vauxhall	Calibra 2.0 Ecotec (1990-1998)	02/94-12/97	FR PS
Vauxhall	Calibra 2.0 Ecotec (1990-1998)	02/94-12/97	FR DS
Vauxhall	Calibra 2.0 Ecotec (1990-1998)	02/94-12/97	FR DS
Vauxhall	Calibra 2.0 Ecotec (1990-1998)	02/94-12/97	FR PS
Vauxhall	Calibra 2.0 Turbo (1990-1998)	04/92-12/98	FR DS
Vauxhall	Calibra 2.0 Turbo (1990-1998)	04/92-12/98	FR PS
Vauxhall	Calibra 2.5 (1990-1998)	08/93-12/98	FR DS
Vauxhall	Calibra 2.5 (1990-1998)	08/93-12/98	FR DS
Vauxhall	Calibra 2.5 (1990-1998)	08/93-12/98	FR DS
Vauxhall	Calibra 2.5 (1990-1998)	08/93-12/98	FR PS
Vauxhall	Calibra 2.5 (1990-1998)	08/93-12/98	FR PS
Vauxhall	Calibra 2.5 (1990-1998)	08/93-12/98	FR PS
Vauxhall	Calibra 2.5 (1990-1998)	08/93-12/98	FR PS
Vauxhall	Calibra 2.5 (1990-1998)	08/93-12/98	FR DS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-04/85	FR DS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-04/85	FR PS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR PS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR DS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR PS
Vauxhall	Carlton 1.8 (1978-1986)	11/82-12/86	FR DS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR DS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR DS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR PS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR DS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR PS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR PS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR PS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR PS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR PS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR DS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR PS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR DS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR DS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR DS
Vauxhall	Carlton 1.8 (1986-1994)	11/86-12/90	FR DS
Vauxhall	Carlton 1.8 Injection (1986-1994)	11/86-12/92	FR PS
Vauxhall	Carlton 1.8 Injection (1986-1994)	11/86-12/92	FR DS
Vauxhall	Carlton 1.8 Injection (1986-1994)	11/86-12/92	FR PS
Vauxhall	Carlton 1.8 Injection (1986-1994)	11/86-12/92	FR DS
Vauxhall	Carlton 1.8 Injection (1986-1994)	11/86-12/92	FR DS
Vauxhall	Carlton 1.8 Injection (1986-1994)	11/86-12/92	FR DS

Vauxhall	Carlton 1.8 Injection (1986-1994)	11/86-12/92	FR PS
Vauxhall	Carlton 1.8 Injection (1986-1994)	11/86-12/92	FR PS
Vauxhall	Carlton 2.0 (1986-1994)	11/86-07/95	FR PS
Vauxhall	Carlton 2.0 (1986-1994)	11/86-07/95	FR DS
Vauxhall	Carlton 2.0 (1986-1994)	11/86-07/95	FR PS
Vauxhall	Carlton 2.0 (1986-1994)	11/86-07/95	FR DS
Vauxhall	Carlton 2.0 (1986-1994)	11/86-07/95	FR DS
Vauxhall	Carlton 2.0 (1986-1994)	11/86-07/95	FR PS
Vauxhall	Carlton 2.0 (1986-1994)	11/86-07/95	FR PS
Vauxhall	Carlton 2.0 (1986-1994)	11/86-07/95	FR DS
Vauxhall	Carlton 2.2 (1978-1986)	08/85-12/86	FR PS
Vauxhall	Carlton 2.2 (1978-1986)	08/85-12/86	FR DS
Vauxhall	Carlton 2.2 (1978-1986)	08/85-12/86	FR PS
Vauxhall	Carlton 2.2 (1978-1986)	08/85-12/86	FR DS
Vauxhall	Carlton 2.3 (1978-1986)	10/82-12/86	FR DS
Vauxhall	Carlton 2.3 (1978-1986)	10/82-12/86	FR PS
Vauxhall	Carlton 2.3 (1978-1986)	10/82-12/86	FR DS
Vauxhall	Carlton 2.3 (1978-1986)	10/82-12/86	FR PS
Vauxhall	Carlton 2.3 (1986-1994)	11/86-12/91	FR PS
Vauxhall	Carlton 2.3 (1986-1994)	11/86-12/91	FR DS
Vauxhall	Carlton 2.3 (1986-1994)	11/86-12/91	FR DS
Vauxhall	Carlton 2.3 (1986-1994)	11/86-12/91	FR PS
Vauxhall	Carlton 2.3 (1986-1994)	11/86-12/92	FR PS
Vauxhall	Carlton 2.3 (1986-1994)	11/86-12/92	FR DS
Vauxhall	Carlton 2.3 (1986-1994)	11/86-12/92	FR PS
Vauxhall	Carlton 2.3 (1986-1994)	11/86-12/92	FR DS
Vauxhall	Carlton 2.3 Turbo (1986-1994)	10/91-07/94	FR DS
Vauxhall	Carlton 2.3 Turbo (1986-1994)	10/91-07/94	FR DS
Vauxhall	Carlton 2.3 Turbo (1986-1994)	10/91-07/94	FR PS
Vauxhall	Carlton 2.3 Turbo (1986-1994)	10/91-07/94	FR DS
Vauxhall	Carlton 2.3 Turbo (1986-1994)	10/91-07/94	FR PS
Vauxhall	Carlton 2.3 Turbo (1986-1994)	10/91-07/94	FR PS
Vauxhall	Carlton 2.3 Turbo (1986-1994)	10/91-07/94	FR DS
Vauxhall	Carlton 2.6 (1986-1994)	09/90-07/94	FR DS
Vauxhall	Carlton 2.6 (1986-1994)	09/90-07/94	FR DS
Vauxhall	Carlton 2.6 (1986-1994)	09/90-07/94	FR PS
Vauxhall	Carlton 2.6 (1986-1994)	09/90-07/94	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	02/93-07/94	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	02/93-07/94	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	02/93-07/94	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	02/93-07/94	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	03/87-10/89	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	03/87-10/89	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	03/87-10/89	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	03/87-10/89	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	08/89-12/90	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	08/89-12/90	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	08/89-12/90	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	08/89-12/90	FR DS

Vauxhall	Carlton 3.0 (1986-1994)	09/88-10/89	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	09/88-10/89	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	09/88-10/89	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	09/88-10/89	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	10/89-12/93	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	10/89-12/93	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	10/89-12/93	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	10/89-12/93	FR DS
Vauxhall	Carlton 3.0 (1986-1994)	10/89-12/93	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	10/89-12/93	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	10/89-12/93	FR PS
Vauxhall	Carlton 3.0 (1986-1994)	10/89-12/93	FR PS
Vauxhall	Carlton 3.6 Lotus (1986-1994)	09/90-07/94	FR PS
Vauxhall	Carlton 3.6 Lotus (1986-1994)	09/90-07/94	FR DS
Vauxhall	Cavalier 1.4 (1988-1995)	11/88-12/92	RR
Vauxhall	Cavalier 1.4 (1988-1995)	11/88-12/92	FR DS
Vauxhall	Cavalier 1.4 (1988-1995)	11/88-12/92	FR DS
Vauxhall	Cavalier 1.4 (1988-1995)	11/88-12/92	FR PS
Vauxhall	Cavalier 1.4 (1988-1995)	11/88-12/92	FR PS
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	RR
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	RR
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 1.6 Carburettor (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 1.6 Catalyst (1988-1995)	03/91-12/95	FR PS
Vauxhall	Cavalier 1.6 Catalyst (1988-1995)	03/91-12/95	FR PS
Vauxhall	Cavalier 1.6 Catalyst (1988-1995)	03/91-12/95	RR
Vauxhall	Cavalier 1.6 Catalyst (1988-1995)	03/91-12/95	FR DS
Vauxhall	Cavalier 1.6 Catalyst (1988-1995)	03/91-12/95	FR DS
Vauxhall	Cavalier 1.6 E-Drive (1988-1995)	08/93-12/95	FR DS
Vauxhall	Cavalier 1.6 E-Drive (1988-1995)	08/93-12/95	FR DS
Vauxhall	Cavalier 1.6 E-Drive (1988-1995)	08/93-12/95	RR
Vauxhall	Cavalier 1.6 E-Drive (1988-1995)	08/93-12/95	FR PS
Vauxhall	Cavalier 1.6 E-Drive (1988-1995)	08/93-12/95	FR PS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR PS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR PS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR DS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR DS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR DS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR PS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR PS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR DS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	RR
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	FR DS
Vauxhall	Cavalier 1.8 Carburettor (1988-1995)	10/89-07/92	RR

Vauxhall	Cavalier 2.0 Ecotec (1988-1995)	03/94-12/95	RR
Vauxhall	Cavalier 2.0 GSi (1988-1995)	10/89-12/92	FR DS
Vauxhall	Cavalier 2.0 GSi (1988-1995)	10/89-12/92	FR PS
Vauxhall	Cavalier 2.0 GSi (1988-1995)	10/89-12/92	FR DS
Vauxhall	Cavalier 2.0 GSi (1988-1995)	10/89-12/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	RR
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	RR
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	RR
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	RR
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR PS
Vauxhall	Cavalier 2.0 Injection (1988-1995)	10/88-07/92	FR DS
Vauxhall	Cavalier 2.0 SRI (1988-1995)	12/88-12/92	RR
Vauxhall	Cavalier 2.0 SRI (1988-1995)	12/88-12/92	FR PS
Vauxhall	Cavalier 2.0 SRI (1988-1995)	12/88-12/92	FR DS
Vauxhall	Cavalier 2.0 SRI (1988-1995)	12/88-12/92	FR DS
Vauxhall	Cavalier 2.0 SRI (1988-1995)	12/88-12/92	FR PS
Vauxhall	Cavalier 2.0 SRI Catalyst (1988-1995)	03/91-03/94	RR
Vauxhall	Cavalier 2.0 SRI Catalyst (1988-1995)	03/91-03/94	FR PS
Vauxhall	Cavalier 2.0 SRI Catalyst (1988-1995)	03/91-03/94	FR PS
Vauxhall	Cavalier 2.0 SRI Catalyst (1988-1995)	03/91-03/94	FR DS
Vauxhall	Cavalier 2.0 SRI Catalyst (1988-1995)	03/91-03/94	FR DS
Vauxhall	Cavalier 2.0 Turbo (1988-1995)	10/92-12/94	FR PS
Vauxhall	Cavalier 2.0 Turbo (1988-1995)	10/92-12/94	FR DS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	FR DS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	FR DS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	FR DS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	FR DS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	FR PS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	RR
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	FR PS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	FR PS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	FR PS
Vauxhall	Cavalier 2.5 (1988-1995)	03/94-12/95	RR
Vauxhall	Frontera 2.0 (1991-1998)	10/91-12/98	FR DS
Vauxhall	Frontera 2.0 (1991-1998)	10/91-12/98	FR PS
Vauxhall	Frontera 2.0 (1991-1998)	10/91-12/98	FR DS

Vauxhall	Senator 3.0 (1987-1994)	09/87-12/92	FR PS
Vauxhall	Senator 3.0 (1987-1994)	10/89-07/94	FR DS
Vauxhall	Senator 3.0 (1987-1994)	10/89-07/94	FR PS
Vauxhall	Signum 1.8 (2003-2008)	01/06-10/08	FR PS
Vauxhall	Signum 1.8 (2003-2008)	12/04-02/06	FR PS
Vauxhall	Signum 1.9 CDTi 120 (2003-2008)	06/04-10/08	FR PS
Vauxhall	Signum 1.9 CDTi 120 (2003-2008)	06/04-10/08	FR PS
Vauxhall	Signum 1.9 CDTi 150 (2003-2008)	06/04-10/08	FR PS
Vauxhall	Signum 1.9 CDTi 150 (2003-2008)	06/04-10/08	FR PS
Vauxhall	Signum 2.0 DTi (2003-2008)	06/03-11/05	FR PS
Vauxhall	Signum 2.0 T (2003-2008)	10/05-10/08	FR PS
Vauxhall	Signum 2.0 Turbo (2003-2008)	06/03-11/05	FR PS
Vauxhall	Signum 2.2 (2003-2008)	06/03-10/08	FR PS
Vauxhall	Signum 2.2 (2003-2008)	06/03-10/08	FR PS
Vauxhall	Signum 2.2 DTi (2003-2008)	06/03-10/04	FR PS
Vauxhall	Signum 2.2 DTi (2003-2008)	06/03-10/04	FR PS
Vauxhall	Signum 2.8 (2003-2008)	10/05-06/07	FR PS
Vauxhall	Signum 2.8 (2003-2008)	10/05-06/07	FR PS
Vauxhall	Signum 2.8 (2003-2008)	10/05-06/07	FR PS
Vauxhall	Signum 2.8 (2003-2008)	10/05-06/07	FR PS
Vauxhall	Signum 3.0 CDTi (2003-2008)	06/03-12/05	FR PS
Vauxhall	Signum 3.0 CDTi (2003-2008)	06/03-12/05	FR PS
Vauxhall	Signum 3.0 CDTi (2003-2008)	10/05-10/08	FR PS
Vauxhall	Signum 3.0 CDTi (2003-2008)	10/05-10/08	FR PS
Vauxhall	Signum 3.2 (2003-2008)	06/03-11/05	FR PS
Vauxhall	Signum 3.2 (2003-2008)	06/03-11/05	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	RR
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR DS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR DS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR DS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR DS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	RR
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR DS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR DS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	RR
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	RR
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR DS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR DS
Vauxhall	Vectra 1.6 B (1995-2002)	10/95-08/02	FR PS

Vauxhall	Vectra 2.2 B (1995-2002)	09/00-08/02	FR DS
Vauxhall	Vectra 2.2 B (1995-2002)	09/00-08/02	FR PS
Vauxhall	Vectra 2.2 B (1995-2002)	09/00-08/02	FR PS
Vauxhall	Vectra 2.2 B (1995-2002)	09/00-08/02	FR PS
Vauxhall	Vectra 2.2 B (1995-2002)	09/00-08/02	RR
Vauxhall	Vectra 2.2 B (1995-2002)	09/00-08/02	FR PS
Vauxhall	Vectra 2.2 B (1995-2002)	09/00-08/02	FR DS
Vauxhall	Vectra 2.2 B (1995-2002)	09/00-08/02	FR DS
Vauxhall	Vectra 2.2 DTi B (1995-2002)	09/00-08/02	FR PS
Vauxhall	Vectra 2.2 DTi B (1995-2002)	09/00-08/02	FR DS
Vauxhall	Vectra 2.2 DTi B (1995-2002)	09/00-08/02	FR DS
Vauxhall	Vectra 2.2 DTi B (1995-2002)	09/00-08/02	FR PS
Vauxhall	Vectra 2.2 DTi B (1995-2002)	09/00-08/02	RR
Vauxhall	Vectra 2.2 DTi B (1995-2002)	09/00-08/02	FR DS
Vauxhall	Vectra 2.2 DTi B (1995-2002)	09/00-08/02	FR PS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	FR PS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	FR PS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	FR DS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	FR DS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	FR DS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	FR DS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	FR PS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	FR PS
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	RR
Vauxhall	Vectra 2.5 B (1995-2002)	10/95-12/00	RR
Vauxhall	Vectra 2.5 B (1995-2002)	10/96-12/00	FR DS
Vauxhall	Vectra 2.5 B (1995-2002)	10/96-12/00	FR DS
Vauxhall	Vectra 2.5 B (1995-2002)	10/96-12/00	FR PS
Vauxhall	Vectra 2.5 B (1995-2002)	10/96-12/00	FR PS
Vauxhall	Vectra 2.5 GSi B (1995-2002)	04/98-09/00	FR DS
Vauxhall	Vectra 2.5 GSi B (1995-2002)	04/98-09/00	FR DS
Vauxhall	Vectra 2.5 GSi B (1995-2002)	04/98-09/00	FR PS
Vauxhall	Vectra 2.5 GSi B (1995-2002)	04/98-09/00	FR PS
Vauxhall	Vectra 2.5 GSi B (1995-2002)	04/98-09/00	FR PS
Vauxhall	Vectra 2.5 GSi B (1995-2002)	04/98-09/00	RR
Vauxhall	Vectra 2.5 GSi B (1995-2002)	04/98-09/00	FR DS
Vauxhall	Vectra 2.8 VXR C (2002-2009)	09/06-12/09	FR PS
Vauxhall	Vectra 2.8 VXR C (2002-2009)	09/06-12/09	FR PS
Volkswagen	Bora 1.6 (1999-2005)	02/99-12/00	FR PS
Volkswagen	Bora 1.6 (1999-2005)	02/99-12/00	FR PS
Volkswagen	Bora 1.6 (1999-2005)	02/99-12/00	FR PS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR PS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR PS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR PS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR PS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR PS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR PS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR PS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR PS
Volkswagen	Bora 1.8 T (1999-2005)	07/01-02/02	FR PS
Volkswagen	Bora 1.8 T (1999-2005)	07/01-02/02	FR PS

Volkswagen	Scirocco 1.8 Injection (1981-1992)	08/88-12/91	FR PS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	08/88-12/91	FR DS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	08/88-12/91	FR DS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	08/88-12/91	FR PS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	10/82-08/88	FR PS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	10/82-08/88	FR DS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	10/82-08/88	FR PS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	10/82-08/88	FR PS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	10/82-08/88	FR PS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	10/82-08/88	FR DS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	10/82-08/88	FR DS
Volkswagen	Scirocco 1.8 Injection (1981-1992)	10/82-08/88	FR DS
Volkswagen	Vento 1.4 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 1.4 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 1.6 (1992-1998)	01/94-04/96	FR PS
Volkswagen	Vento 1.6 (1992-1998)	01/94-04/96	FR PS
Volkswagen	Vento 1.6 (1992-1998)	01/94-04/96	FR PS
Volkswagen	Vento 1.8 (1992-1998)	01/93-04/98	FR PS
Volkswagen	Vento 1.8 (1992-1998)	01/93-04/98	FR PS
Volkswagen	Vento 1.8 (1992-1998)	01/93-04/98	FR PS
Volkswagen	Vento 1.8 (1992-1998)	01/93-04/98	FR PS
Volkswagen	Vento 1.9 (1992-1998)	04/94-04/96	FR PS
Volkswagen	Vento 1.9 TD (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 1.9 TDi (1992-1998)	04/94-04/98	FR PS
Volkswagen	Vento 1.9 TDi (1992-1998)	04/94-04/98	FR PS
Volkswagen	Vento 1.9 TDi (1992-1998)	04/94-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR PS
Volkswagen	Vento 2.8 VR6 (1992-1998)	07/93-04/98	FR PS
Volkswagen	Vento 2.8 VR6 (1992-1998)	10/92-04/98	FR PS