

**Lucas**

## Compatibility Chart

MANUFACTURER	CAR MODEL	YEAR RANGE	POSITION
Alfa Romeo	Arna 1.2	11/84-05/86	FR PS
Alfa Romeo	Arna 1.2	11/84-05/86	FR DS
Alfa Romeo	Arna 1.2	11/84-05/86	FR DS
Alfa Romeo	Arna 1.2	11/84-05/86	FR PS
Alfa Romeo	Arna 1.5 Ti	05/85-05/86	FR DS
Alfa Romeo	Arna 1.5 Ti	05/85-05/86	FR PS
Alfa Romeo	Arna 1.5 Ti	05/85-05/86	FR DS
Alfa Romeo	Arna 1.5 Ti	05/85-05/86	FR PS
BMW	316 1.6 Baur cabriolet E30	09/88-07/91	FR DS
BMW	316 1.6 Baur cabriolet E30	09/88-07/91	FR PS
BMW	316 1.6 Baur cabriolet E30	09/88-07/91	FR DS
BMW	316 1.6 Baur cabriolet E30	09/88-07/91	FR DS
BMW	316 1.6 Baur cabriolet E30	09/88-07/91	FR PS
BMW	316 1.6 Baur cabriolet E30	09/88-07/91	FR PS
BMW	316 1.6 Baur cabriolet E30	09/88-07/91	FR DS
BMW	316 1.6 Baur cabriolet E30	09/88-07/91	FR PS
BMW	316 1.8 Baur cabriolet E30	01/84-09/88	FR PS
BMW	316 1.8 Baur cabriolet E30	01/84-09/88	FR PS
BMW	316 1.8 Baur cabriolet E30	01/84-09/88	FR DS
BMW	316 1.8 Baur cabriolet E30	01/84-09/88	FR DS
BMW	316 1.8 E30	03/83-05/86	FR PS
BMW	316 1.8 E30	03/83-05/86	FR DS
BMW	316 1.8 E30	03/83-05/86	FR PS
BMW	316 1.8 E30	03/83-05/86	FR DS
BMW	316 1.8 E30	03/83-09/88	FR DS
BMW	316 1.8 E30	03/83-09/88	FR DS
BMW	316 1.8 E30	03/83-09/88	FR DS
BMW	316 1.8 E30	03/83-09/88	FR PS
BMW	316 1.8 E30	03/83-09/88	FR PS
BMW	316 1.8 E30	03/83-09/88	FR DS
BMW	316 1.8 E30	03/83-09/88	FR PS
BMW	316 1.8 E30	03/83-09/88	FR PS
BMW	316 1.8 E30	10/84-09/88	FR PS
BMW	316 1.8 E30	10/84-09/88	FR DS
BMW	316 1.8 E30	10/84-09/88	FR DS
BMW	316 1.8 E30	10/84-09/88	FR PS
BMW	316i 1.6 Compact E36	09/94-01/99	FR DS
BMW	316i 1.6 Compact E36	09/94-01/99	FR PS
BMW	316i 1.6 Compact E36	09/94-01/99	FR PS
BMW	316i 1.6 Compact E36	09/94-01/99	FR DS
BMW	316i 1.6 E30	09/88-07/91	FR PS
BMW	316i 1.6 E30	09/88-07/91	FR PS
BMW	316i 1.6 E30	09/88-07/91	FR DS
BMW	316i 1.6 E30	09/88-07/91	FR DS
BMW	316i 1.6 E30	09/88-07/91	FR DS
BMW	316i 1.6 E30	09/88-07/91	FR PS

BMW	316i 1.6 E30	09/88-07/91	FR PS
BMW	316i 1.6 E30	09/88-07/91	FR DS
BMW	316i 1.6 E36	01/94-07/99	FR PS
BMW	316i 1.6 E36	01/94-07/99	FR PS
BMW	316i 1.6 E36	04/91-09/98	FR PS
BMW	316i 1.6 E36	04/91-09/98	FR PS
BMW	316i 1.6 E36	04/91-09/98	FR PS
BMW	316i 1.6 E36	04/91-09/98	FR PS
BMW	316i 1.6 E36	04/91-09/98	FR PS
BMW	316i 1.6 Touring E30	09/91-07/94	FR DS
BMW	316i 1.6 Touring E30	09/91-07/94	FR PS
BMW	316i 1.6 Touring E30	09/91-07/94	FR PS
BMW	316i 1.6 Touring E30	09/91-07/94	FR DS
BMW	316i 1.6 Touring E36	04/97-11/99	FR PS
BMW	316i 1.6 Touring E36	04/97-11/99	FR PS
BMW	316i 1.8 E46	01/02-04/05	FR PS
BMW	316i 1.8 E46	01/02-04/05	FR PS
BMW	316i 1.8 E46	01/02-04/05	FR PS
BMW	316i 1.8 E46	01/02-04/05	FR PS
BMW	316i 1.8 E46	01/02-04/05	FR PS
BMW	316i 1.8 E46	01/02-04/05	FR PS
BMW	316i 1.8 E46	01/02-04/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.8 Touring E46	09/01-12/05	FR PS
BMW	316i 1.9 Compact E36	01/99-12/01	FR PS
BMW	316i 1.9 Compact E36	01/99-12/01	FR DS
BMW	316i 1.9 Compact E36	01/99-12/01	FR PS
BMW	316i 1.9 Compact E36	01/99-12/01	FR DS
BMW	316i 1.9 Compact E36	01/99-12/01	FR PS
BMW	316i 1.9 Compact E36	01/99-12/01	FR DS
BMW	316i 1.9 Compact E36	01/99-12/01	FR DS
BMW	316i 1.9 E46	03/99-01/02	FR PS
BMW	316i 1.9 E46	03/99-01/02	FR PS
BMW	316i 1.9 E46	03/99-01/02	FR PS
BMW	316i 1.9 E46	03/99-01/02	FR PS
BMW	316ti 1.8 Compact E46	09/01-04/05	FR PS
BMW	316ti 1.8 Compact E46	09/01-04/05	FR PS
BMW	316ti 1.8 Compact E46	09/01-04/05	FR PS
BMW	316ti 1.8 Compact E46	09/01-04/05	FR PS
BMW	318Ci 1.9 E46	07/99-09/01	FR PS
BMW	318Ci 1.9 E46	07/99-09/01	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS

BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318Ci 2.0 E46	09/01-04/07	FR PS
BMW	318d 2.0 E46	03/04-04/05	FR PS
BMW	318d 2.0 E46	03/04-04/05	FR PS
BMW	318d 2.0 E46	03/04-04/05	FR PS
BMW	318d 2.0 Touring E46	03/04-12/05	FR PS
BMW	318d 2.0 Touring E46	03/04-12/05	FR PS
BMW	318d 2.0 Touring E46	03/04-12/05	FR PS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR PS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR PS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR DS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR DS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR PS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR PS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR DS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR PS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR DS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR PS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR DS
BMW	318i 1.8 Baur cabriolet E30	09/83-10/87	FR DS
BMW	318i 1.8 Baur cabriolet E30	10/87-07/91	FR PS
BMW	318i 1.8 Baur cabriolet E30	10/87-07/91	FR DS
BMW	318i 1.8 Baur cabriolet E30	10/87-07/91	FR DS
BMW	318i 1.8 Baur cabriolet E30	10/87-07/91	FR PS
BMW	318i 1.8 E30	01/91-07/93	FR PS
BMW	318i 1.8 E30	01/91-07/93	FR DS
BMW	318i 1.8 E30	01/91-07/93	FR DS
BMW	318i 1.8 E30	01/91-07/93	FR PS
BMW	318i 1.8 E30	09/83-10/87	FR PS
BMW	318i 1.8 E30	09/83-10/87	FR PS
BMW	318i 1.8 E30	09/83-10/87	FR DS
BMW	318i 1.8 E30	09/83-10/87	FR DS
BMW	318i 1.8 E30	09/83-10/87	FR PS
BMW	318i 1.8 E30	09/83-10/87	FR DS
BMW	318i 1.8 E30	09/83-10/87	FR DS
BMW	318i 1.8 E30	09/83-10/87	FR PS
BMW	318i 1.8 E30	10/87-07/91	FR PS
BMW	318i 1.8 E30	10/87-07/91	FR DS
BMW	318i 1.8 E30	10/87-07/91	FR DS
BMW	318i 1.8 E30	10/87-07/91	FR DS
BMW	318i 1.8 E30	10/87-07/91	FR DS
BMW	318i 1.8 E30	10/87-07/91	FR DS
BMW	318i 1.8 E30	10/87-07/91	FR PS
BMW	318i 1.8 E30	10/87-07/91	FR PS

BMW	318i 1.8 E30	10/87-07/91	FR PS
BMW	318i 1.8 E36	01/94-09/98	FR PS
BMW	318i 1.8 E36	01/94-09/98	FR PS
BMW	318i 1.8 E36	04/91-01/94	FR PS
BMW	318i 1.8 E36	04/91-01/94	FR PS
BMW	318i 1.8 E36	05/94-05/00	FR PS
BMW	318i 1.8 E36	05/94-05/00	FR PS
BMW	318i 1.8 Touring E30	04/89-07/94	FR DS
BMW	318i 1.8 Touring E30	04/89-07/94	FR PS
BMW	318i 1.8 Touring E30	04/89-07/94	FR PS
BMW	318i 1.8 Touring E30	04/89-07/94	FR DS
BMW	318i 1.8 Touring E36	01/96-11/99	FR PS
BMW	318i 1.8 Touring E36	01/96-11/99	FR PS
BMW	318i 1.9 E46	09/98-09/01	FR PS
BMW	318i 1.9 E46	09/98-09/01	FR PS
BMW	318i 1.9 E46	09/98-09/01	FR PS
BMW	318i 1.9 E46	09/98-09/01	FR PS
BMW	318i 1.9 Touring E46	09/99-09/01	FR PS
BMW	318i 1.9 Touring E46	09/99-09/01	FR PS
BMW	318i 1.9 Touring E46	09/99-09/01	FR PS
BMW	318i 1.9 Touring E46	09/99-09/01	FR PS
BMW	318i 2.0 E46	09/01-04/05	FR PS
BMW	318i 2.0 E46	09/01-04/05	FR PS
BMW	318i 2.0 E46	09/01-04/05	FR PS
BMW	318i 2.0 E46	09/01-04/05	FR PS
BMW	318i 2.0 E46	09/01-04/05	FR PS
BMW	318i 2.0 E46	09/01-04/05	FR PS
BMW	318i 2.0 Touring E46	09/01-12/05	FR PS
BMW	318i 2.0 Touring E46	09/01-12/05	FR PS
BMW	318i 2.0 Touring E46	09/01-12/05	FR PS
BMW	318i 2.0 Touring E46	09/01-12/05	FR PS
BMW	318i 2.0 Touring E46	09/01-12/05	FR PS
BMW	318i 2.0 Touring E46	09/01-12/05	FR PS
BMW	318iS 1.8 E30	06/90-07/91	FR DS
BMW	318iS 1.8 E30	06/90-07/91	FR PS
BMW	318iS 1.8 E36	04/92-04/96	FR PS
BMW	318iS 1.8 E36	04/92-04/96	FR PS
BMW	318iS 1.9 E36	02/98-03/99	FR PS
BMW	318iS 1.9 E36	04/94-07/99	FR PS
BMW	318iS 1.9 E36	04/94-07/99	FR PS
BMW	318tds 1.7 Compact E36	09/95-12/01	FR DS
BMW	318tds 1.7 Compact E36	09/95-12/01	FR PS
BMW	318tds 1.7 E36	08/95-03/98	FR PS
BMW	318tds 1.7 Touring E36	09/95-11/99	FR PS
BMW	318ti 1.8 Compact E36	09/94-04/96	FR PS
BMW	318ti 1.8 Compact E36	09/94-04/96	FR DS
BMW	318ti 1.8 Compact E36	09/94-04/96	FR PS
BMW	318ti 1.8 Compact E36	09/94-04/96	FR DS
BMW	318ti 1.9 Compact E36	04/96-12/01	FR PS
BMW	318ti 1.9 Compact E36	04/96-12/01	FR DS

BMW	318ti 1.9 Compact E36	04/96-12/01	FR DS
BMW	318ti 1.9 Compact E36	04/96-12/01	FR PS
BMW	318ti 2.0 Compact E46	09/01-04/05	FR PS
BMW	318ti 2.0 Compact E46	09/01-04/05	FR PS
BMW	318ti 2.0 Compact E46	09/01-04/05	FR PS
BMW	318ti 2.0 Compact E46	09/01-04/05	FR PS
BMW	320Cd 2.0 E46	02/05-04/07	FR PS
BMW	320Cd 2.0 E46	02/05-04/07	FR PS
BMW	320Cd 2.0 E46	02/05-04/07	FR PS
BMW	320Cd 2.0 E46	02/05-04/07	FR PS
BMW	320Cd 2.0 E46	10/03-04/07	FR PS
BMW	320Cd 2.0 E46	10/03-04/07	FR PS
BMW	320Cd 2.0 E46	10/03-04/07	FR PS
BMW	320Cd 2.0 E46	10/03-04/07	FR PS
BMW	320Cd 2.0 E46	10/03-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320Ci 2.2 E46	09/00-04/07	FR PS
BMW	320d 2.0 E46	01/03-04/05	FR PS
BMW	320d 2.0 E46	01/03-04/05	FR PS
BMW	320d 2.0 E46	06/99-09/01	FR PS
BMW	320d 2.0 E46	06/99-09/01	FR PS
BMW	320d 2.0 E46	09/01-04/05	FR PS
BMW	320d 2.0 E46	09/01-04/05	FR PS
BMW	320d 2.0 E46	09/01-04/05	FR PS
BMW	320d 2.0 Touring E46	06/99-09/01	FR PS
BMW	320d 2.0 Touring E46	06/99-09/01	FR PS
BMW	320d 2.0 Touring E46	09/01-12/05	FR PS
BMW	320d 2.0 Touring E46	09/01-12/05	FR PS
BMW	320d 2.0 Touring E46	09/01-12/05	FR PS
BMW	320d 2.0 Touring E46	09/01-12/05	FR PS
BMW	320i 2.0 Baur cabriolet E30	10/87-07/93	FR PS
BMW	320i 2.0 Baur cabriolet E30	10/87-07/93	FR DS
BMW	320i 2.0 Baur cabriolet E30	10/87-07/93	FR DS
BMW	320i 2.0 Baur cabriolet E30	10/87-07/93	FR PS
BMW	320i 2.0 Baur cabriolet E30	10/87-07/93	FR DS
BMW	320i 2.0 Baur cabriolet E30	10/87-07/93	FR DS
BMW	320i 2.0 Baur cabriolet E30	10/87-07/93	FR PS
BMW	320i 2.0 Baur cabriolet E30	10/87-07/93	FR PS
BMW	320i 2.0 E30	03/83-09/85	FR PS
BMW	320i 2.0 E30	03/83-09/85	FR PS
BMW	320i 2.0 E30	03/83-09/85	FR PS
BMW	320i 2.0 E30	03/83-09/85	FR PS
BMW	320i 2.0 E30	03/83-09/85	FR DS
BMW	320i 2.0 E30	03/83-09/85	FR PS
BMW	320i 2.0 E30	03/83-09/85	FR DS



BMW	320i 2.0 Touring E36	03/95-01/97	FR PS
BMW	320i 2.0 Touring E36	03/95-01/97	FR PS
BMW	320i 2.0 Touring E36	03/95-01/97	FR PS
BMW	320i 2.2 E46	09/00-04/05	FR PS
BMW	320i 2.2 E46	09/00-04/05	FR PS
BMW	320i 2.2 E46	09/00-04/05	FR PS
BMW	320i 2.2 E46	09/00-04/05	FR PS
BMW	320i 2.2 Touring E46	09/00-12/05	FR PS
BMW	320i 2.2 Touring E46	09/00-12/05	FR PS
BMW	320i 2.2 Touring E46	09/00-12/05	FR PS
BMW	320i 2.2 Touring E46	09/00-12/05	FR PS
BMW	320td 2.0 Compact E46	01/03-04/05	FR PS
BMW	320td 2.0 Compact E46	03/03-04/05	FR PS
BMW	320td 2.0 Compact E46	09/01-04/05	FR PS
BMW	320td 2.0 Compact E46	09/01-04/05	FR PS
BMW	320td 2.0 Compact E46	09/01-04/05	FR PS
BMW	320td 2.0 Compact E46	09/01-04/05	FR PS
BMW	323Ci 2.5 E46	03/99-09/00	FR PS
BMW	323Ci 2.5 E46	03/99-09/00	FR PS
BMW	323Ci 2.5 E46	05/00-09/00	FR PS
BMW	323Ci 2.5 E46	05/00-09/00	FR PS
BMW	323i 2.3 E30	03/83-10/83	FR PS
BMW	323i 2.3 E30	03/83-10/83	FR DS
BMW	323i 2.3 E30	03/83-10/83	FR DS
BMW	323i 2.3 E30	03/83-10/83	FR PS
BMW	323i 2.3 E30	10/83-07/85	FR PS
BMW	323i 2.3 E30	10/83-07/85	FR DS
BMW	323i 2.3 E30	10/83-07/85	FR PS
BMW	323i 2.3 E30	10/83-07/85	FR DS
BMW	323i 2.3 E30	10/83-07/85	FR PS
BMW	323i 2.3 E30	10/83-07/85	FR DS
BMW	323i 2.3 E30	10/83-07/85	FR PS
BMW	323i 2.3 E30	10/83-07/85	FR DS
BMW	323i 2.5 E36	01/97-05/00	FR PS
BMW	323i 2.5 E36	01/97-05/00	FR PS
BMW	323i 2.5 E36	03/95-07/99	FR PS
BMW	323i 2.5 E36	03/95-07/99	FR PS
BMW	323i 2.5 E36	09/96-09/98	FR PS
BMW	323i 2.5 E36	09/96-09/98	FR PS
BMW	323i 2.5 E46	09/98-09/00	FR PS
BMW	323i 2.5 E46	09/98-09/00	FR PS
BMW	323i 2.5 E46	09/98-09/00	FR PS
BMW	323i 2.5 E46	09/98-09/00	FR PS
BMW	323i 2.5 Touring E36	01/97-11/99	FR PS
BMW	323i 2.5 Touring E36	01/97-11/99	FR PS
BMW	325Ci 2.5 E46	09/00-04/07	FR PS
BMW	325Ci 2.5 E46	09/00-04/07	FR PS
BMW	325Ci 2.5 E46	09/00-04/07	FR PS
BMW	325Ci 2.5 E46	09/00-04/07	FR PS
BMW	325i 2.5 Baur cabriolet E30	09/86-07/93	FR DS

BMW	325i 2.5 Baur cabriolet E30	09/86-07/93	FR DS
BMW	325i 2.5 Baur cabriolet E30	09/86-07/93	FR PS
BMW	325i 2.5 Baur cabriolet E30	09/86-07/93	FR PS
BMW	325i 2.5 E30	09/86-07/93	FR PS
BMW	325i 2.5 E30	09/86-07/93	FR DS
BMW	325i 2.5 E30	09/86-07/93	FR DS
BMW	325i 2.5 E30	09/86-07/93	FR PS
BMW	325i 2.5 E30	10/85-07/91	FR DS
BMW	325i 2.5 E30	10/85-07/91	FR PS
BMW	325i 2.5 E30	10/85-07/91	FR DS
BMW	325i 2.5 E30	10/85-07/91	FR PS
BMW	325i 2.5 E30	10/85-07/91	FR PS
BMW	325i 2.5 E30	10/85-07/91	FR DS
BMW	325i 2.5 E30	10/85-07/91	FR DS
BMW	325i 2.5 E30	10/85-07/91	FR PS
BMW	325i 2.5 E36	04/91-09/95	FR PS
BMW	325i 2.5 E36	04/91-09/95	FR PS
BMW	325i 2.5 E36	04/91-09/95	FR PS
BMW	325i 2.5 E36	04/91-09/95	FR PS
BMW	325i 2.5 E36	04/92-09/95	FR PS
BMW	325i 2.5 E36	04/92-09/95	FR PS
BMW	325i 2.5 E36	04/92-09/95	FR PS
BMW	325i 2.5 E36	04/92-09/95	FR PS
BMW	325i 2.5 E36	04/92-09/95	FR PS
BMW	325i 2.5 E36	04/92-09/95	FR PS
BMW	325i 2.5 E36	07/93-09/95	FR PS
BMW	325i 2.5 E36	07/93-09/95	FR PS
BMW	325i 2.5 E36	07/93-09/95	FR PS
BMW	325i 2.5 E36	07/93-09/95	FR PS
BMW	325i 2.5 E46	09/00-04/05	FR PS
BMW	325i 2.5 E46	09/00-04/05	FR PS
BMW	325i 2.5 E46	09/00-04/05	FR PS
BMW	325i 2.5 E46	09/00-04/05	FR PS
BMW	325i 2.5 E46	09/00-04/05	FR PS
BMW	325i 2.5 E46	09/00-04/05	FR PS
BMW	325iX 2.5 E30	04/87-05/89	FR DS
BMW	325iX 2.5 E30	04/87-05/89	FR DS
BMW	325iX 2.5 E30	04/87-05/89	FR PS
BMW	325iX 2.5 E30	04/87-05/89	FR PS
BMW	325td 2.5 E36	07/93-04/96	FR PS
BMW	325td 2.5 E36	07/93-04/96	FR PS
BMW	325tds 2.5 E36	04/97-02/98	FR PS
BMW	325tds 2.5 E36	04/97-02/98	FR PS
BMW	325tds 2.5 E36	07/93-04/97	FR PS



BMW	325tds 2.5 E36	07/93-04/97	FR PS
BMW	325tds 2.5 Touring E36	04/97-11/99	FR PS
BMW	325tds 2.5 Touring E36	04/97-11/99	FR PS
BMW	325tds 2.5 Touring E36	05/96-04/97	FR PS
BMW	325tds 2.5 Touring E36	05/96-04/97	FR PS
BMW	325ti 2.5 Compact E46	09/01-04/05	FR PS
BMW	325ti 2.5 Compact E46	09/01-04/05	FR PS
BMW	325ti 2.5 Compact E46	09/01-04/05	FR PS
BMW	325ti 2.5 Compact E46	09/01-04/05	FR PS
BMW	328Ci 2.8 E46	06/99-07/00	FR PS
BMW	328Ci 2.8 E46	06/99-07/00	FR PS
BMW	328i 2.8 E36	03/95-02/98	FR PS
BMW	328i 2.8 E36	03/95-02/98	FR PS
BMW	328i 2.8 E36	03/95-02/98	FR PS
BMW	328i 2.8 E36	03/95-02/98	FR PS
BMW	328i 2.8 E36	03/95-05/00	FR PS
BMW	328i 2.8 E36	03/95-05/00	FR PS
BMW	328i 2.8 E36	03/95-05/00	FR PS
BMW	328i 2.8 E36	03/95-05/00	FR PS
BMW	328i 2.8 E36	03/95-05/00	FR PS
BMW	328i 2.8 E36	03/95-07/99	FR PS
BMW	328i 2.8 E36	03/95-07/99	FR PS
BMW	328i 2.8 E36	03/95-07/99	FR PS
BMW	328i 2.8 E36	03/95-07/99	FR PS
BMW	328i 2.8 E46	09/98-07/00	FR PS
BMW	328i 2.8 E46	09/98-07/00	FR PS
BMW	328i 2.8 Touring E36	03/95-07/00	FR PS
BMW	328i 2.8 Touring E36	03/95-07/00	FR PS
BMW	328i 2.8 Touring E36	03/95-07/00	FR PS
BMW	328i 2.8 Touring E36	03/95-07/00	FR PS
BMW	328i 2.8 Touring E46	09/99-07/00	FR PS
BMW	328i 2.8 Touring E46	09/99-07/00	FR PS
BMW	330Cd 3.0 E46	03/04-04/07	FR PS
BMW	330Cd 3.0 E46	03/04-04/07	FR PS
BMW	330Cd 3.0 E46	03/04-04/07	FR PS
BMW	330Cd 3.0 E46	03/04-04/07	FR PS
BMW	330Cd 3.0 E46	03/05-04/07	FR PS
BMW	330Cd 3.0 E46	03/05-04/07	FR PS
BMW	330Cd 3.0 E46	03/05-04/07	FR PS
BMW	330Ci 3.0 E46	03/03-04/07	FR PS
BMW	330Ci 3.0 E46	03/03-04/07	FR PS
BMW	330Ci 3.0 E46	03/03-04/07	FR PS
BMW	330Ci 3.0 E46	03/03-04/07	FR PS
BMW	330Ci 3.0 E46	06/00-04/07	FR PS
BMW	330Ci 3.0 E46	06/00-04/07	FR PS
BMW	330Ci 3.0 E46	06/00-04/07	FR PS
BMW	330Ci 3.0 E46	06/00-04/07	FR PS
BMW	330Ci 3.0 E46	06/00-12/05	FR PS
BMW	330Ci 3.0 E46	06/00-12/05	FR PS
BMW	330Ci 3.0 E46	06/00-12/05	FR PS
BMW	330Ci 3.0 E46	06/00-12/05	FR PS

BMW	330d 3.0 E46	03/03-04/05	FR PS
BMW	330d 3.0 E46	03/03-04/05	FR PS
BMW	330d 3.0 E46	03/03-04/05	FR PS
BMW	330d 3.0 E46	03/03-04/05	FR PS
BMW	330d 3.0 E46	10/99-08/03	FR PS
BMW	330d 3.0 E46	10/99-08/03	FR PS
BMW	330d 3.0 E46	10/99-08/03	FR PS
BMW	330d 3.0 E46	10/99-08/03	FR PS
BMW	330d 3.0 E46	10/99-08/03	FR PS
BMW	330d 3.0 Touring E46	03/03-12/05	FR PS
BMW	330d 3.0 Touring E46	03/03-12/05	FR PS
BMW	330d 3.0 Touring E46	03/03-12/05	FR PS
BMW	330d 3.0 Touring E46	03/03-12/05	FR PS
BMW	330d 3.0 Touring E46	06/00-08/03	FR PS
BMW	330d 3.0 Touring E46	06/00-08/03	FR PS
BMW	330d 3.0 Touring E46	06/00-08/03	FR PS
BMW	330d 3.0 Touring E46	06/00-08/03	FR PS
BMW	330i 3.0 E46	03/03-04/05	FR PS
BMW	330i 3.0 E46	03/03-04/05	FR PS
BMW	330i 3.0 E46	06/00-04/05	FR PS
BMW	330i 3.0 E46	06/00-04/05	FR PS
BMW	330i 3.0 E46	06/00-04/05	FR PS
BMW	330i 3.0 E46	06/00-04/05	FR PS
BMW	330i 3.0 E46	06/00-04/05	FR PS
BMW	330i 3.0 Touring E46	03/03-12/05	FR PS
BMW	330i 3.0 Touring E46	03/03-12/05	FR PS
BMW	330i 3.0 Touring E46	06/00-12/05	FR PS
BMW	330i 3.0 Touring E46	06/00-12/05	FR PS
BMW	330i 3.0 Touring E46	06/00-12/05	FR PS
BMW	330i 3.0 Touring E46	06/00-12/05	FR PS
BMW	M3 2.3 E30	04/87-09/89	FR PS
BMW	M3 2.3 E30	04/87-09/89	FR DS
BMW	M3 2.3 E30	09/89-12/90	FR DS
BMW	M3 2.3 E30	09/89-12/90	FR PS
BMW	M3 2.5 Sport Evolution E30	02/90-04/90	FR DS
BMW	M3 2.5 Sport Evolution E30	02/90-04/90	FR PS
BMW	M3 2.5 Sport Evolution E30	02/90-04/90	FR DS
BMW	M3 2.5 Sport Evolution E30	02/90-04/90	FR PS
BMW	M3 3.0 E36	05/93-09/95	FR PS
BMW	M3 3.0 E36	07/94-09/95	FR PS
BMW	M3 3.2 CS E46	04/05-09/07	FR PS
BMW	M3 3.2 CS E46	04/05-09/07	FR PS
BMW	M3 3.2 CS E46	04/05-09/07	FR PS
BMW	M3 3.2 CS E46	04/05-09/07	FR PS
BMW	M3 3.2 CSL E46	08/03-05/04	FR PS
BMW	M3 3.2 CSL E46	08/03-05/04	FR PS
BMW	M3 3.2 E46	03/01-09/07	FR PS
BMW	M3 3.2 E46	03/01-09/07	FR PS
BMW	M3 3.2 E46	03/01-09/07	FR PS
BMW	M3 3.2 E46	03/01-09/07	FR PS
BMW	M3 3.2 E46	10/00-09/07	FR PS
BMW	M3 3.2 E46	10/00-09/07	FR PS

BMW	M3 3.2 E46	10/00-09/07	FR PS
BMW	M3 3.2 E46	10/00-09/07	FR PS
BMW	M3 3.2 Evolution E36	03/96-01/98	FR PS
BMW	M3 3.2 Evolution E36	03/96-05/01	FR PS
BMW	M3 3.2 Evolution E36	03/96-07/99	FR PS
BMW	X3 2.0 d E83	09/04-05/08	FR PS
BMW	X3 2.0 d E83	09/07-04/09	FR PS
BMW	X3 2.0 d E83	09/07-04/09	FR PS
BMW	X3 2.0 i E83	09/05-11/06	FR PS
BMW	X3 2.0 i E83	09/05-11/06	FR PS
BMW	X3 2.0 xDrive18d E83	03/09-03/11	FR PS
BMW	X3 2.0 xDrive20d E83	08/08-03/11	FR PS
BMW	X3 2.0 xDrive20d E83	08/08-03/11	FR PS
BMW	X3 2.0 xDrive20d E83	08/08-03/11	FR PS
BMW	X3 2.0 xDrive20d E83	08/08-03/11	FR PS
BMW	X3 2.5 i E83	05/04-11/06	FR PS
BMW	X3 2.5 i E83	05/04-11/06	FR PS
BMW	X3 2.5 i E83	05/04-11/06	FR PS
BMW	X3 2.5 i E83	05/04-11/06	FR PS
BMW	X3 2.5 si E83	08/06-04/09	FR PS
BMW	X3 2.5 si E83	08/06-04/09	FR PS
BMW	X3 2.5 xDrive25i E83	08/08-03/11	FR PS
BMW	X3 2.5 xDrive25i E83	08/08-03/11	FR PS
BMW	X3 3.0 d E83	09/05-04/09	FR PS
BMW	X3 3.0 d E83	09/05-04/09	FR PS
BMW	X3 3.0 d E83	09/05-04/09	FR PS
BMW	X3 3.0 d E83	09/05-04/09	FR PS
BMW	X3 3.0 i E83	05/04-11/06	FR PS
BMW	X3 3.0 i E83	05/04-11/06	FR PS
BMW	X3 3.0 sd E83	09/06-04/09	FR PS
BMW	X3 3.0 sd E83	09/06-04/09	FR PS
BMW	X3 3.0 si E83	08/06-04/09	FR PS
BMW	X3 3.0 xDrive30d E83	08/08-03/11	FR PS
BMW	X3 3.0 xDrive30d E83	08/08-03/11	FR PS
BMW	X3 3.0 xDrive30d E83	08/08-03/11	FR PS
BMW	X3 3.0 xDrive30i E83	08/08-12/09	FR PS
BMW	X3 3.0 xDrive35d E83	08/08-03/11	FR PS
BMW	X3 3.0 xDrive35d E83	08/08-03/11	FR PS
BMW	X5 2.0 sDrive25d F15	06/15-09/19	FR PS
BMW	X5 2.0 sDrive25d F15	08/13-04/16	FR PS
BMW	X5 2.0 xDrive25d F15	06/15-09/19	FR PS
BMW	X5 2.0 xDrive25d F15	08/13-04/16	FR PS
BMW	X5 2.0 xDrive40e F15	04/15-09/19	FR PS
BMW	X5 3.0 M50d F15	07/13-09/19	FR PS
BMW	X5 3.0 xDrive30d F15	07/13-09/19	FR PS
BMW	X5 3.0 xDrive40d F15	08/13-09/19	FR PS
BMW	X5 4.4 M F15	10/14-09/19	FR PS
BMW	X5 4.4 xDrive50i F15	07/13-09/19	FR PS
BMW	Z1 2.5 E30/Z1	10/89-06/91	FR PS
BMW	Z1 2.5 E30/Z1	10/89-06/91	FR DS

BMW	Z3 1.8 E36/7	04/99-06/01	FR PS
BMW	Z3 1.8 E36/7	04/99-06/01	FR PS
BMW	Z3 1.8 E36/7	04/99-06/01	FR PS
BMW	Z3 1.9 E36/7	01/97-07/99	FR PS
BMW	Z3 1.9 E36/7	01/97-07/99	FR PS
BMW	Z3 1.9 E36/7	06/01-04/03	FR PS
BMW	Z3 1.9 E36/7	06/01-04/03	FR PS
BMW	Z3 1.9 E36/7	06/01-04/03	FR PS
BMW	Z3 2.0 E36/7	04/99-09/00	FR PS
BMW	Z3 2.0 E36/7	04/99-09/00	FR PS
BMW	Z3 2.0 E36/7	04/99-09/00	FR PS
BMW	Z3 2.0 E36/7	04/99-09/00	FR PS
BMW	Z3 2.2 E36/7	10/00-04/03	FR PS
BMW	Z3 2.2 E36/7	10/00-04/03	FR PS
BMW	Z3 2.2 E36/7	10/00-04/03	FR PS
BMW	Z3 2.2 E36/7	10/00-04/03	FR PS
BMW	Z3 2.8 E36/7	04/97-09/00	FR PS
BMW	Z3 2.8 E36/7	04/97-09/00	FR PS
BMW	Z3 2.8 E36/7	04/97-09/00	FR PS
BMW	Z3 2.8 E36/7	04/97-09/00	FR PS
BMW	Z3 3.0 E36/7	06/00-04/03	FR PS
BMW	Z3 3.0 E36/7	06/00-04/03	FR PS
BMW	Z3 3.0 E36/7	06/00-04/03	FR PS
BMW	Z3 3.0 E36/7	06/00-04/03	FR PS
BMW	Z3 3.2 M E36/7	01/98-03/01	FR PS
BMW	Z3 3.2 M E36/7	03/01-06/03	FR PS
BMW	Z3 3.2 M E36/8	03/01-06/03	FR PS
BMW	Z3 3.2 M E36/8	03/01-06/03	FR DS
BMW	Z3 3.2 M E36/8	03/01-06/03	FR DS
BMW	Z3 3.2 M E36/8	03/01-06/03	FR PS
BMW	Z3 3.2 M E36/8	09/98-03/01	FR PS
BMW	Z3 3.2 M E36/8	09/98-03/01	FR DS
BMW	Z4 2.0 sDrive18i E89	01/13-04/17	FR PS
BMW	Z4 2.0 sDrive18i E89	01/13-04/17	FR PS
BMW	Z4 2.0 sDrive18i E89	01/13-04/17	FR PS
BMW	Z4 2.0 sDrive18i E89	01/13-04/17	FR PS
BMW	Z4 2.0 sDrive20i E89	05/11-04/17	FR PS
BMW	Z4 2.0 sDrive20i E89	05/11-04/17	FR PS
BMW	Z4 2.0 sDrive20i E89	05/11-04/17	FR PS
BMW	Z4 2.0 sDrive20i E89	05/11-04/17	FR PS
BMW	Z4 2.0 sDrive28i E89	05/11-04/17	FR PS
BMW	Z4 2.0 sDrive28i E89	05/11-04/17	FR PS
BMW	Z4 2.0 sDrive28i E89	05/11-04/17	FR PS
BMW	Z4 2.0 sDrive28i E89	05/11-04/17	FR PS
BMW	Z4 2.5 sDrive23i E89	05/09-07/12	FR PS
BMW	Z4 2.5 sDrive23i E89	05/09-07/12	FR PS
BMW	Z4 3.0 sDrive30i E89	05/09-07/12	FR PS
BMW	Z4 3.0 sDrive30i E89	05/09-07/12	FR PS
BMW	Z4 3.0 sDrive35i E89	05/09-04/17	FR PS
BMW	Z4 3.0 sDrive35i E89	05/09-04/17	FR PS



Citroen	BX 1.6 (1983-1995)	08/85-07/92	FR DS
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/93	FR DS
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/93	FR DS
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/93	RR
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/93	FR DS
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/93	FR DS
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/93	RR
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/93	RR
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/95	FR DS
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/95	FR DS
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/95	FR DS
Citroen	BX 1.6 Injection (1983-1995)	09/92-07/95	FR DS
Citroen	BX 1.6 RE/RE Leader (1983-1995)	03/87-12/89	FR DS
Citroen	BX 1.6 RE/RE Leader (1983-1995)	03/87-12/89	RR
Citroen	BX 1.9 (1983-1995)	02/90-12/92	FR DS
Citroen	BX 1.9 (1983-1995)	03/84-12/93	RR
Citroen	BX 1.9 (1983-1995)	03/84-12/93	RR
Citroen	BX 1.9 (1983-1995)	03/84-12/93	RR
Citroen	BX 1.9 (1983-1995)	03/84-12/93	FR DS
Citroen	BX 1.9 (1983-1995)	03/84-12/93	FR DS
Citroen	BX 1.9 (1983-1995)	03/84-12/93	FR DS
Citroen	BX 1.9 (1983-1995)	08/85-07/95	FR DS
Citroen	BX 1.9 (1983-1995)	08/85-07/95	FR DS
Citroen	BX 1.9 (1983-1995)	08/85-07/95	FR DS
Citroen	BX 1.9 (1983-1995)	10/87-12/92	RR
Citroen	BX 1.9 (1983-1995)	10/87-12/92	FR DS
Citroen	BX 1.9 Carburettor (1983-1995)	09/85-12/92	FR DS
Citroen	BX 1.9 Carburettor (1983-1995)	09/85-12/92	RR
Citroen	BX 1.9 Carburettor (1983-1995)	09/85-12/92	FR DS
Citroen	BX 1.9 Carburettor (1983-1995)	09/85-12/92	RR
Citroen	BX 1.9 Carburettor (1983-1995)	09/85-12/92	FR DS
Citroen	BX 1.9 Carburettor (1983-1995)	09/85-12/92	FR DS
Citroen	BX 1.9 Carburettor (1983-1995)	09/85-12/92	FR DS
Citroen	BX 1.9 GT (1983-1995)	09/84-08/86	FR DS
Citroen	BX 1.9 GT (1983-1995)	09/84-08/86	RR
Citroen	BX 1.9 GT (1983-1995)	09/84-08/86	FR DS
Citroen	BX 1.9 GT (1983-1995)	09/84-08/86	RR
Citroen	BX 1.9 GT (1983-1995)	09/84-08/86	FR DS
Citroen	BX 1.9 GT (1983-1995)	09/84-08/86	RR
Citroen	BX 1.9 GTi (1983-1995)	02/90-12/92	RR
Citroen	BX 1.9 GTi (1983-1995)	02/90-12/92	FR DS
Citroen	BX 1.9 GTi (1983-1995)	02/90-12/92	FR DS
Citroen	BX 1.9 GTi (1983-1995)	02/90-12/92	RR
Citroen	BX 1.9 GTi (1983-1995)	08/86-12/92	RR
Citroen	BX 1.9 GTi (1983-1995)	08/86-12/92	FR DS
Citroen	BX 1.9 GTi (catalyst) (1983-1995)	01/92-12/93	FR DS
Citroen	BX 1.9 GTi (catalyst) (1983-1995)	01/92-12/93	RR
Citroen	BX 1.9 GTi (catalyst) (1983-1995)	01/92-12/93	RR
Citroen	BX 1.9 GTi (catalyst) (1983-1995)	01/92-12/93	FR DS

Citroen	BX 1.9 Injection (1983-1995)	03/90-12/92	RR
Citroen	BX 1.9 Injection (1983-1995)	03/90-12/92	RR
Citroen	BX 1.9 Injection (1983-1995)	03/90-12/92	FR DS
Citroen	BX 1.9 Injection (1983-1995)	03/90-12/92	FR DS
Citroen	BX 1.9 Injection (1983-1995)	04/88-12/92	FR DS
Citroen	BX 1.9 Injection (1983-1995)	04/88-12/92	FR DS
Citroen	BX 1.9 Injection (1983-1995)	04/88-12/92	FR DS
Citroen	BX 1.9 Injection (1983-1995)	04/88-12/92	FR DS
Citroen	BX 1.9 Turbo (1983-1995)	01/92-07/95	FR DS
Citroen	BX 1.9 Turbo (1983-1995)	01/92-07/95	FR DS
Citroen	BX17 1.8 (1983-1995)	09/85-12/93	RR
Citroen	BX17 1.8 (1983-1995)	09/85-12/93	FR DS
Citroen	BX17 1.8 Turbo (1983-1995)	05/88-07/95	FR DS
Citroen	BX17 1.8 Turbo (1983-1995)	05/88-07/95	FR DS
Citroen	BX17 1.8 Turbo (1983-1995)	05/88-12/93	FR DS
Citroen	BX17 1.8 Turbo (1983-1995)	05/88-12/93	FR DS
Citroen	BX17 1.8 Turbo (1983-1995)	05/88-12/93	RR
Citroen	BX17 1.8 Turbo (1983-1995)	05/88-12/93	RR
Citroen	C25 1.8 (1987-1992)	04/87-10/92	FR PS
Citroen	C25 1.8 (1987-1992)	04/87-10/92	FR DS
Citroen	C25 1.9 (1987-1992)	08/87-10/92	FR PS
Citroen	C25 1.9 (1987-1992)	08/87-10/92	FR DS
Citroen	C25 1.9 Relay (1992-1994)	10/92-06/94	FR DS
Citroen	C25 1.9 Relay (1992-1994)	10/92-06/94	FR PS
Citroen	C25 2.0 (1987-1992)	04/87-10/92	FR DS
Citroen	C25 2.0 (1987-1992)	04/87-10/92	FR DS
Citroen	C25 2.0 (1987-1992)	04/87-10/92	FR PS
Citroen	C25 2.0 (1987-1992)	04/87-10/92	FR PS
Citroen	C25 2.0 Relay (1992-1994)	10/92-06/94	FR PS
Citroen	C25 2.0 Relay (1992-1994)	10/92-06/94	FR DS
Citroen	C25 2.0 Relay (1992-1994)	10/92-06/94	FR PS
Citroen	C25 2.0 Relay (1992-1994)	10/92-06/94	FR DS
Citroen	C25 2.5 (1987-1992)	04/87-10/92	FR DS
Citroen	C25 2.5 (1987-1992)	04/87-10/92	FR DS
Citroen	C25 2.5 (1987-1992)	04/87-10/92	FR PS
Citroen	C25 2.5 (1987-1992)	04/87-10/92	FR PS
Citroen	C25 2.5 Relay (1992-1994)	10/92-06/94	FR DS
Citroen	C25 2.5 Relay (1992-1994)	10/92-06/94	FR DS
Citroen	C25 2.5 Relay (1992-1994)	10/92-06/94	FR PS
Citroen	C25 2.5 Relay (1992-1994)	10/92-06/94	FR PS
Citroen	C25 2.5 Relay Turbo (1992-1994)	10/92-06/94	FR PS
Citroen	C25 2.5 Relay Turbo (1992-1994)	10/92-06/94	FR PS
Citroen	C25 2.5 Relay Turbo (1992-1994)	10/92-06/94	FR DS
Citroen	C25 2.5 Relay Turbo (1992-1994)	10/92-06/94	FR DS
Citroen	C25 2.5 Turbo (1987-1992)	08/87-10/92	FR DS
Citroen	C25 2.5 Turbo (1987-1992)	08/87-10/92	FR PS
Citroen	C25 2.5 Turbo (1987-1992)	08/87-10/92	FR DS
Citroen	C25 2.5 Turbo (1987-1992)	08/87-10/92	FR PS
Citroen	C-Crosser 2.2 HDi Enterprise (2007-2012)	08/08-12/10	FR PS
Citroen	Dispatch 1.6 (2007-2017)	01/07-04/12	FR PS

Citroen	Dispatch 1.6 Combi (2007-2017)	03/09-04/12	FR PS
Citroen	Dispatch 1.6 HDi 90 (2007-2017)	06/10-04/17	FR PS
Citroen	Dispatch 2.0 (2007-2017)	01/07-03/11	FR PS
Citroen	Dispatch 2.0 (2007-2017)	01/07-04/12	FR PS
Citroen	Dispatch 2.0 (2007-2017)	03/09-03/11	FR PS
Citroen	Dispatch 2.0 (2007-2017)	03/09-03/11	FR PS
Citroen	Dispatch 2.0 Combi (2004-2007)	01/04-05/07	FR PS
Citroen	Dispatch 2.0 Combi (2004-2007)	01/04-05/07	FR PS
Citroen	Dispatch 2.0 Combi (2004-2007)	01/04-05/07	FR PS
Citroen	Dispatch 2.0 Combi (2004-2007)	01/04-05/07	FR PS
Citroen	Dispatch 2.0 Combi (2007-2017)	03/09-04/12	FR PS
Citroen	Dispatch 2.0 Combi (2007-2017)	03/09-04/12	FR PS
Citroen	Dispatch 2.0 Combi HDi 125 (2007-2017)	09/11-04/17	FR PS
Citroen	Dispatch 2.0 Combi HDi 160 (2007-2017)	09/11-04/17	FR PS
Citroen	Dispatch 2.0 Combi HDi 160 (2007-2017)	09/11-04/17	FR PS
Citroen	Dispatch 2.0 Combi HDi 95 (2007-2017)	09/11-04/17	FR PS
Citroen	Dispatch 2.0 HDi 125 (2007-2017)	09/11-04/17	FR PS
Citroen	Dispatch 2.0 HDi 125 (2007-2017)	09/11-04/17	FR PS
Citroen	Dispatch 2.0 HDi 95 (2007-2017)	09/11-04/17	FR PS
Citroen	Saxo 1.0 (1996-1999)	06/97-10/99	FR DS
Citroen	Saxo 1.0 (1999-2004)	10/99-12/00	FR DS
Citroen	Saxo 1.1 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.1 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.1 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.1 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.1 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	05/96-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR DS
Citroen	Saxo 1.4 (1996-1999)	10/97-10/99	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.4 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.5 (1996-1999)	10/96-10/99	FR DS
Citroen	Saxo 1.5 (1996-1999)	10/96-10/99	FR DS
Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR DS



Citroen	Saxo 1.5 (1999-2004)	10/99-02/04	FR DS
Citroen	Saxo 1.6 (1996-1999)	09/96-10/99	FR DS
Citroen	Saxo 1.6 (1996-1999)	09/96-10/99	FR DS
Citroen	Saxo 1.6 (1996-1999)	09/96-10/99	FR DS
Citroen	Saxo 1.6 (1996-1999)	09/96-10/99	FR DS
Citroen	Saxo 1.6 VTR (1999-2004)	09/00-02/04	FR DS
Citroen	Saxo 1.6 VTR (1999-2004)	10/99-09/00	FR DS
Citroen	Saxo 1.6 VTS (1996-1999)	01/97-10/99	FR DS
Citroen	Saxo 1.6 VTS (1999-2004)	10/99-02/04	FR DS
Citroen	Synergie 1.9 (1995-2002)	10/95-10/99	FR PS
Citroen	Synergie 1.9 (1995-2002)	10/95-10/99	FR PS
Citroen	Synergie 1.9 (1995-2002)	10/99-12/00	FR PS
Citroen	Synergie 1.9 (1995-2002)	10/99-12/00	FR PS
Citroen	Synergie 2.0 (1995-2002)	05/00-07/02	FR PS
Citroen	Synergie 2.0 (1995-2002)	05/00-07/02	FR PS
Citroen	Synergie 2.0 (1995-2002)	10/95-05/00	FR PS
Citroen	Synergie 2.0 HDi (1995-2002)	10/00-06/02	FR PS
Citroen	Synergie 2.0 HDi (1995-2002)	10/99-06/02	FR PS
Citroen	Xantia 1.6 (1993-2001)	04/95-12/97	FR PS
Citroen	Xantia 1.6 (1993-2001)	07/93-12/97	FR PS
Citroen	Xantia 1.8 (1993-2001)	05/95-09/95	FR PS
Citroen	Xantia 1.8 (1993-2001)	05/95-12/01	FR PS
Citroen	Xantia 1.8 (1993-2001)	07/93-09/95	FR PS
Citroen	Xantia 1.8 (1993-2001)	09/95-04/99	FR PS
Citroen	Xantia 1.8 (1993-2001)	09/95-04/99	FR PS
Citroen	Xantia 1.8 (1993-2001)	11/97-12/01	FR PS
Citroen	Xantia 1.8 (1993-2001)	11/97-12/01	FR PS
Citroen	Xantia 1.8 (1993-2001)	12/97-12/01	FR PS
Citroen	Xantia 1.9 (1993-2001)	05/94-10/99	FR PS
Citroen	Xantia 1.9 (1993-2001)	05/94-10/99	FR PS
Citroen	Xantia 1.9 (1993-2001)	05/94-10/99	FR PS
Citroen	Xantia 1.9 (1993-2001)	07/93-10/99	FR PS
Citroen	Xantia 1.9 (1993-2001)	07/93-10/99	FR PS
Citroen	Xantia 1.9 (1993-2001)	07/93-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	07/93-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	07/93-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	07/93-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	07/93-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	07/93-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	10/99-12/00	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	10/99-12/00	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	10/99-12/00	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	10/99-12/00	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	10/99-12/00	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	10/99-12/00	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	10/99-12/00	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	10/99-12/00	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	12/97-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	12/97-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	12/97-10/99	FR PS

Citroen	Xantia 1.9 Turbo (1993-2001)	12/97-10/99	FR PS
Citroen	Xantia 1.9 Turbo (1993-2001)	12/97-10/99	FR PS
Citroen	Xantia 2.0 (1993-2001)	05/93-07/98	FR PS
Citroen	Xantia 2.0 (1993-2001)	05/93-12/95	FR PS
Citroen	Xantia 2.0 (1993-2001)	05/95-12/00	FR PS
Citroen	Xantia 2.0 (1993-2001)	09/95-12/00	FR PS
Citroen	Xantia 2.0 (1993-2001)	12/97-12/00	FR PS
Citroen	Xantia 2.0 (1993-2001)	12/97-12/00	FR PS
Citroen	Xantia 2.0 HDi 110 (1993-2001)	10/98-12/01	FR PS
Citroen	Xantia 2.0 HDi 110 (1993-2001)	10/98-12/01	FR PS
Citroen	Xantia 2.0 HDi 90 (1993-2001)	01/00-12/00	FR PS
Citroen	Xantia 2.0 HDi 90 (1993-2001)	01/00-12/00	FR PS
Citroen	Xantia 2.0 Turbo (1993-2001)	02/96-12/00	FR PS
Citroen	Xantia 2.0 Turbo (1993-2001)	02/96-12/00	FR PS
Citroen	Xantia 2.0 VSX (1993-2001)	05/93-12/95	FR PS
Citroen	Xantia 2.0 VSX (1993-2001)	05/93-12/95	FR PS
Citroen	Xantia 2.1 (1993-2001)	06/97-12/00	FR PS
Citroen	Xantia 2.1 (1993-2001)	06/97-12/00	FR PS
Citroen	Xantia 3.0 (1993-2001)	06/97-12/00	FR PS
Citroen	Xsara 1.4 (1997-2000)	05/98-10/00	FR PS
Citroen	Xsara 1.4 (1997-2000)	05/98-10/00	FR PS
Citroen	Xsara 1.4 (1997-2000)	10/98-10/00	FR PS
Citroen	Xsara 1.4 (1997-2000)	10/98-10/00	FR PS
Citroen	Xsara 1.4 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.4 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.4 (2000-2004)	10/00-12/01	FR PS
Citroen	Xsara 1.4 (2000-2004)	10/00-12/01	FR PS
Citroen	Xsara 1.4 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 1.4 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 1.4 HDi (2000-2004)	04/03-12/04	FR PS
Citroen	Xsara 1.6 (1997-2000)	03/98-10/00	FR PS
Citroen	Xsara 1.6 (1997-2000)	03/98-10/00	FR PS
Citroen	Xsara 1.6 (1997-2000)	05/98-10/00	FR PS
Citroen	Xsara 1.6 (1997-2000)	05/98-10/00	FR PS
Citroen	Xsara 1.6 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.6 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.6 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 1.6 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 1.6 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 1.6 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 1.6 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 1.8 (1997-2000)	03/98-10/00	FR PS
Citroen	Xsara 1.8 (1997-2000)	05/98-10/00	FR PS
Citroen	Xsara 1.8 (1997-2000)	05/98-10/00	FR PS
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.8 (1997-2000)	11/97-10/00	FR PS
Citroen	Xsara 1.9 (1997-2000)	04/98-10/99	FR PS
Citroen	Xsara 1.9 (1997-2000)	10/98-05/01	FR PS

Citroen	Xsara 1.9 (1997-2000)	10/98-05/01	FR PS
Citroen	Xsara 1.9 (1997-2000)	10/98-05/01	FR PS
Citroen	Xsara 1.9 (1997-2000)	10/98-05/01	FR PS
Citroen	Xsara 1.9 (1997-2000)	10/99-10/00	FR PS
Citroen	Xsara 1.9 (1997-2000)	10/99-10/00	FR PS
Citroen	Xsara 1.9 (1997-2000)	10/99-10/00	FR PS
Citroen	Xsara 1.9 (1997-2000)	10/99-10/00	FR PS
Citroen	Xsara 1.9 (1997-2000)	11/97-10/99	FR PS
Citroen	Xsara 1.9 Turbo (1997-2000)	04/98-07/99	FR PS
Citroen	Xsara 1.9 Turbo (1997-2000)	10/98-10/00	FR PS
Citroen	Xsara 1.9 Turbo (1997-2000)	11/97-07/99	FR PS
Citroen	Xsara 2.0 (1997-2000)	03/98-10/00	FR PS
Citroen	Xsara 2.0 (2000-2004)	10/00-04/02	FR PS
Citroen	Xsara 2.0 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 2.0 HDi (1997-2000)	06/99-10/00	FR PS
Citroen	Xsara 2.0 HDi (1997-2000)	06/99-10/00	FR PS
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	FR PS
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	FR PS
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	FR PS
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	FR PS
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	FR PS
Citroen	Xsara 2.0 HDi 110 (2000-2004)	05/01-12/04	FR PS
Citroen	Xsara 2.0 HDi 90 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara 2.0 HDi 90 (2000-2004)	10/00-12/04	FR PS
Citroen	Xsara Enterprise 2.0 HDi 90 (2000-2004)	01/03-12/04	FR PS
Citroen	Xsara Enterprise 2.0 HDi 90 (2000-2004)	01/03-12/04	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/16-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	05/16-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	11/17-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	11/17-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/12-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/12-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/12-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/12-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/12-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/12-04/19	FR PS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/12-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/12-04/19	FR PS

Dacia	Duster 1.5 dCi 110 (2012-2019)	12/15-04/19	FR DS
Dacia	Duster 1.5 dCi 110 (2012-2019)	12/15-04/19	FR PS
Dacia	Duster 1.6 (2012-2019)	05/15-04/19	FR PS
Dacia	Duster 1.6 (2012-2019)	05/15-04/19	FR PS
Dacia	Duster 1.6 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.6 (2012-2019)	05/15-04/19	FR PS
Dacia	Duster 1.6 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.6 (2012-2019)	05/15-04/19	FR DS
Dacia	Duster 1.6 (2012-2019)	12/12-04/16	FR PS
Dacia	Duster 1.6 (2012-2019)	12/12-04/16	FR DS
Dacia	Duster 1.6 (2012-2019)	12/12-04/16	FR DS
Dacia	Duster 1.6 (2012-2019)	12/12-04/16	FR DS
Dacia	Duster 1.6 (2012-2019)	12/12-04/16	FR PS
Dacia	Duster 1.6 (2012-2019)	12/12-04/16	FR PS
Dacia	Logan 0.9 MCV TCe 90 (2013-2021)	04/13-04/16	FR PS
Dacia	Logan 0.9 MCV TCe 90 (2013-2021)	04/15-04/21	FR PS
Dacia	Logan 0.9 Stepway MCV TCe 90 (2013-2021)	04/17-04/21	FR PS
Dacia	Logan 1.5 MCV dCi 90 (2013-2021)	04/13-04/19	FR PS
Dacia	Logan 1.5 MCV dCi 90 (2013-2021)	04/13-04/19	FR PS
Dacia	Logan 1.5 Stepway MCV dCi 90 (2013-2021)	04/17-04/19	FR PS
Dacia	Logan MCV 1.2 75 (2013-2021)	04/13-04/16	FR PS
Dacia	Sandero 0.9 Stepway TCe 90 (2012-2022)	04/13-04/17	FR PS
Dacia	Sandero 0.9 Stepway TCe 90 (2012-2022)	09/16-04/22	FR PS
Dacia	Sandero 0.9 TCe 90 (2012-2022)	09/16-04/22	FR PS
Dacia	Sandero 0.9 TCe 90 (2012-2022)	12/12-04/17	FR PS
Dacia	Sandero 1.2 75 (2012-2022)	12/12-04/16	FR PS
Dacia	Sandero 1.5 dCi 90 (2012-2022)	09/16-04/19	FR PS
Dacia	Sandero 1.5 dCi 90 (2012-2022)	12/12-04/17	FR PS
Dacia	Sandero 1.5 dCi 90 (2012-2022)	12/12-04/17	FR PS
Dacia	Sandero 1.5 dCi 90 (2012-2022)	12/12-04/17	FR PS
Dacia	Sandero 1.5 Stepway dCi 90 (2012-2022)	04/13-04/17	FR PS
Dacia	Sandero 1.5 Stepway dCi 90 (2012-2022)	09/16-04/19	FR PS
Daewoo	Musso 2.3 (1999-2002)	03/99-12/02	FR DS
Daewoo	Musso 2.3 (1999-2002)	03/99-12/02	FR DS
Daewoo	Musso 2.9 (1999-2002)	03/99-12/02	FR DS
Daewoo	Musso 2.9 (1999-2002)	03/99-12/02	FR DS
Daewoo	Nubira 1.6 (1997-2002)	09/97-12/02	FR DS
Daewoo	Nubira 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Nubira 1.6 (1997-2002)	09/97-12/02	FR DS
Daewoo	Nubira 1.6 (1997-2002)	09/97-12/02	FR PS
Daewoo	Nubira 1.6 (2003-2005)	09/04-01/05	FR DS
Daewoo	Nubira 1.6 (2003-2005)	09/04-01/05	FR PS
Daewoo	Nubira 1.6 (2003-2005)	09/04-01/05	FR PS
Daewoo	Nubira 1.6 (2003-2005)	09/04-01/05	FR DS
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	FR DS
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	FR DS
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	FR PS
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	FR PS
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	FR DS
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	FR PS

Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	FR PS
Daewoo	Nubira 2.0 (1997-2002)	07/99-12/02	FR DS
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	FR PS
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	FR PS
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	FR PS
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	FR DS
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	FR PS
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	FR DS
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	FR DS
Daewoo	Nubira 2.0 (1997-2002)	09/97-07/99	FR DS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR DS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR DS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR DS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR DS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR DS
Daihatsu	Grand Move 1.5 (1998-2001)	03/97-10/98	FR DS
Daihatsu	Grand Move 1.6 (1998-2001)	10/98-12/01	FR DS
Daihatsu	Grand Move 1.6 (1998-2001)	10/98-12/01	FR DS
Daihatsu	Grand Move 1.6 (1998-2001)	10/98-12/01	FR DS
Daihatsu	Grand Move 1.6 (1998-2001)	10/98-12/01	FR DS
Daihatsu	Sirion 1.0 (2005-2010)	02/05-12/10	FR DS
Daihatsu	Sirion 1.3 (2005-2010)	02/05-12/10	FR DS
Daihatsu	Sirion 1.3 (2005-2010)	02/05-12/10	FR DS
Daihatsu	Sirion 1.5 (2005-2010)	11/07-12/10	FR DS
Daihatsu	Sirion 1.5 (2005-2010)	11/07-12/10	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/00-10/06	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/00-10/06	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/97-08/00	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/97-08/00	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/97-08/00	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/97-08/00	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/97-08/00	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/97-08/00	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/97-08/00	FR DS
Daihatsu	Terios 1.3 (1997-2006)	08/97-08/00	FR DS
Fiat	Bravo 1.2 80 182 (1995-2002)	12/98-04/02	FR PS
Fiat	Bravo 1.2 80 182 (1995-2002)	12/98-04/02	FR PS
Fiat	Bravo 1.4 182 (1995-2002)	12/95-02/99	FR PS
Fiat	Bravo 1.6 100 182 (1995-2002)	06/00-04/02	FR PS
Fiat	Bravo 1.6 100 182 (1995-2002)	06/96-04/02	FR PS
Fiat	Bravo 1.8 115 182 (1995-2002)	12/95-04/02	FR PS
Fiat	Bravo 1.9 100 182 (1995-2002)	10/96-04/02	FR PS
Fiat	Bravo 1.9 100 182 (1995-2002)	10/96-04/02	FR PS
Fiat	Bravo 1.9 105 182 (1995-2002)	05/99-04/02	FR PS
Fiat	Bravo 1.9 75 182 (1995-2002)	10/96-02/99	FR PS
Fiat	Bravo 2.0 155 182 (1995-2002)	02/99-04/02	FR PS
Fiat	Bravo 2.0 155 182 (1995-2002)	03/97-02/99	FR PS
Fiat	Croma 2.0 Carburettor 154 (1986-1993)	07/89-07/92	FR DS
Fiat	Croma 2.0 Carburettor 154 (1986-1993)	07/89-07/92	FR PS
Fiat	Croma 2.0 Carburettor 154 (1986-1993)	09/86-07/89	FR DS

Fiat	Croma 2.0 Carburettor 154 (1986-1993)	09/86-07/89	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/90	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/90	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/90	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/90	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/92	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/92	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/92	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/86-05/92	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/89-05/92	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/89-05/92	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/89-05/92	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/89-05/92	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	FR DS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	FR PS
Fiat	Croma 2.0 Injection 154 (1986-1993)	05/92-06/93	FR PS
Fiat	Croma 2.0 Turbo 154 (1986-1993)	05/86-07/92	FR PS
Fiat	Croma 2.0 Turbo 154 (1986-1993)	05/86-07/92	FR DS
Fiat	Croma 2.0 Turbo 154 (1986-1993)	05/86-07/92	FR PS
Fiat	Croma 2.0 Turbo 154 (1986-1993)	05/86-07/92	FR DS
Fiat	Ducato 1.9 Turbo (1986-1994)	02/91-06/94	FR DS
Fiat	Ducato 1.9 Turbo (1986-1994)	02/91-06/94	FR PS
Fiat	Ducato 2.0 (1986-1994)	01/86-06/94	FR DS
Fiat	Ducato 2.0 (1986-1994)	01/86-06/94	FR PS
Fiat	Ducato 2.0 (1986-1994)	01/86-06/94	FR PS
Fiat	Ducato 2.0 (1986-1994)	01/86-06/94	FR DS
Fiat	Ducato 2.0 (1986-1994)	01/86-06/94	FR DS
Fiat	Ducato 2.0 (1986-1994)	01/86-06/94	FR PS
Fiat	Ducato 2.0 (1986-1994)	01/86-06/94	FR PS
Fiat	Ducato 2.0 (1986-1994)	01/86-06/94	FR DS
Fiat	Ducato 2.0 (1986-1994)	02/91-06/94	FR PS
Fiat	Ducato 2.0 (1986-1994)	02/91-06/94	FR DS
Fiat	Ducato 2.4 Turbo (1986-1994)	02/87-02/91	FR DS
Fiat	Ducato 2.4 Turbo (1986-1994)	02/87-02/91	FR DS
Fiat	Ducato 2.4 Turbo (1986-1994)	02/87-02/91	FR PS
Fiat	Ducato 2.4 Turbo (1986-1994)	02/87-02/91	FR PS
Fiat	Ducato 2.5 (1986-1994)	01/86-06/94	FR DS
Fiat	Ducato 2.5 (1986-1994)	01/86-06/94	FR PS
Fiat	Ducato 2.5 (1986-1994)	01/86-06/94	FR PS
Fiat	Ducato 2.5 (1986-1994)	01/86-06/94	FR DS
Fiat	Ducato 2.5 Turbo (1986-1994)	02/91-06/94	FR PS
Fiat	Ducato 2.5 Turbo (1986-1994)	02/91-06/94	FR DS
Fiat	Scudo 1.6 90 Multijet 270 (2007-2017)	01/07-04/17	FR PS
Fiat	Scudo 1.6 90 Multijet 270 (2007-2017)	01/07-04/17	FR PS
Fiat	Scudo 1.6 90 Multijet 270 (2007-2017)	01/07-04/17	FR PS

Fiat	Scudo 1.6 90 Multijet 270 (2007-2017)	09/10-12/17	FR PS
Fiat	Scudo 1.6 90 Multijet 270 (2007-2017)	09/10-12/17	FR PS
Fiat	Scudo 1.6 90 Multijet 270 (2007-2017)	09/10-12/17	FR PS
Fiat	Scudo 1.6 90 Multijet 270 (2007-2017)	09/10-12/17	FR PS
Fiat	Scudo 1.9 220 (1996-2004)	09/96-10/98	FR PS
Fiat	Scudo 1.9 220 (1996-2004)	10/98-04/04	FR PS
Fiat	Scudo 1.9 220 (1996-2004)	10/98-04/04	FR PS
Fiat	Scudo 1.9 220 (2004-2007)	03/04-12/06	FR PS
Fiat	Scudo 1.9 220 (2004-2007)	03/04-12/06	FR PS
Fiat	Scudo 1.9 Turbo 220 (1996-2004)	01/99-06/00	FR PS
Fiat	Scudo 1.9 Turbo 220 (1996-2004)	01/99-06/00	FR PS
Fiat	Scudo 1.9 Turbo 220 (1996-2004)	09/96-06/00	FR PS
Fiat	Scudo 1.9 Turbo 220 (1996-2004)	09/96-06/00	FR PS
Fiat	Scudo 2.0 120 Multijet 270 (2007-2017)	01/07-03/11	FR PS
Fiat	Scudo 2.0 120 Multijet 270 (2007-2017)	01/07-03/11	FR PS
Fiat	Scudo 2.0 120 Multijet 270 (2007-2017)	01/07-03/11	FR PS
Fiat	Scudo 2.0 130 Multijet 270 (2007-2017)	01/11-04/17	FR PS
Fiat	Scudo 2.0 130 Multijet 270 (2007-2017)	01/11-04/17	FR PS
Fiat	Scudo 2.0 130 Multijet 270 (2007-2017)	01/11-04/17	FR PS
Fiat	Scudo 2.0 140 Multijet 270 (2007-2017)	01/07-03/11	FR PS
Fiat	Scudo 2.0 140 Multijet 270 (2007-2017)	01/07-03/11	FR PS
Fiat	Scudo 2.0 165 Multijet 270 (2007-2017)	06/10-04/17	FR PS
Fiat	Scudo 2.0 165 Multijet 270 (2007-2017)	06/10-04/17	FR PS
Fiat	Scudo 2.0 JTD 220 (1996-2004)	02/00-04/04	FR PS
Fiat	Scudo 2.0 JTD 220 (1996-2004)	02/00-04/04	FR PS
Fiat	Scudo 2.0 JTD 220 (2004-2007)	03/04-12/06	FR PS
Fiat	Tempra 1.4 159 (1990-1996)	09/90-07/92	FR PS
Fiat	Tempra 1.4 159 (1990-1996)	09/90-07/92	FR DS
Fiat	Tempra 1.6 Carburettor 159 (1990-1996)	06/91-06/92	FR DS
Fiat	Tempra 1.6 Carburettor 159 (1990-1996)	06/91-06/92	FR PS
Fiat	Tempra 1.6 Carburettor 159 (1990-1996)	06/91-06/92	FR DS
Fiat	Tempra 1.6 Carburettor 159 (1990-1996)	06/91-06/92	FR PS
Fiat	Tempra 1.6 Carburettor 159 (1990-1996)	09/90-06/92	FR DS
Fiat	Tempra 1.6 Carburettor 159 (1990-1996)	09/90-06/92	FR DS
Fiat	Tempra 1.6 Carburettor 159 (1990-1996)	09/90-06/92	FR PS
Fiat	Tempra 1.6 Carburettor 159 (1990-1996)	09/90-06/92	FR PS
Fiat	Tempra 1.6 Multi Point Injection 159 (1990-1996)	09/94-12/96	FR DS
Fiat	Tempra 1.6 Multi Point Injection 159 (1990-1996)	09/94-12/96	FR PS
Fiat	Tempra 1.6 Multi Point Injection 159 (1990-1996)	09/94-12/96	FR DS
Fiat	Tempra 1.6 Multi Point Injection 159 (1990-1996)	09/94-12/96	FR PS
Fiat	Tempra 1.6 Multi Point Injection 159 (1990-1996)	09/94-12/96	FR DS
Fiat	Tempra 1.6 Multi Point Injection 159 (1990-1996)	09/94-12/96	FR DS
Fiat	Tempra 1.6 Multi Point Injection 159 (1990-1996)	09/94-12/96	FR PS
Fiat	Tempra 1.6 Multi Point Injection 159 (1990-1996)	09/94-12/96	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS

Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR PS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.6 Single Point Injection 159 (1990-1996)	06/92-09/94	FR DS
Fiat	Tempra 1.8 159 (1990-1996)	06/91-07/92	FR PS
Fiat	Tempra 1.8 159 (1990-1996)	06/91-07/92	FR DS
Fiat	Tempra 1.8 159 (1990-1996)	06/91-07/92	FR DS
Fiat	Tempra 1.8 159 (1990-1996)	06/91-07/92	FR PS
Fiat	Tempra 1.8 159 (1990-1996)	09/90-07/92	FR PS
Fiat	Tempra 1.8 159 (1990-1996)	09/90-07/92	FR DS
Fiat	Tempra 1.8 159 (1990-1996)	09/90-07/92	FR PS
Fiat	Tempra 1.8 159 (1990-1996)	09/90-07/92	FR DS
Fiat	Tempra 1.9 159 (1990-1996)	08/94-10/96	FR DS
Fiat	Tempra 1.9 159 (1990-1996)	08/94-10/96	FR PS
Fiat	Tempra 1.9 159 (1990-1996)	09/90-10/96	FR DS
Fiat	Tempra 1.9 159 (1990-1996)	09/90-10/96	FR PS
Fiat	Tempra 1.9 159 (1990-1996)	09/90-10/96	FR PS
Fiat	Tempra 1.9 159 (1990-1996)	09/90-10/96	FR DS
Fiat	Tempra 1.9 Turbo 159 (1990-1996)	01/92-10/96	FR PS
Fiat	Tempra 1.9 Turbo 159 (1990-1996)	01/92-10/96	FR DS
Fiat	Tempra 1.9 Turbo 159 (1990-1996)	01/92-10/96	FR DS
Fiat	Tempra 1.9 Turbo 159 (1990-1996)	01/92-10/96	FR PS
Fiat	Tempra 1.9 Turbo 159 (1990-1996)	09/90-10/96	FR DS
Fiat	Tempra 1.9 Turbo 159 (1990-1996)	09/90-10/96	FR DS
Fiat	Tempra 1.9 Turbo 159 (1990-1996)	09/90-10/96	FR PS
Fiat	Tempra 1.9 Turbo 159 (1990-1996)	09/90-10/96	FR PS
Fiat	Tempra 2.0 159 (1990-1996)	06/92-10/96	FR DS
Fiat	Tempra 2.0 159 (1990-1996)	06/92-10/96	FR PS
Fiat	Tempra 2.0 159 (1990-1996)	06/92-10/96	FR DS
Fiat	Tempra 2.0 159 (1990-1996)	06/92-10/96	FR PS
Fiat	Tempra 2.0 159 (1990-1996)	06/93-10/96	FR PS
Fiat	Tempra 2.0 159 (1990-1996)	06/93-10/96	FR DS
Fiat	Tempra 2.0 159 (1990-1996)	06/93-10/96	FR PS
Fiat	Tempra 2.0 159 (1990-1996)	06/93-10/96	FR DS
Fiat	Ulysse 1.9 220 (1995-2003)	10/95-01/00	FR PS
Fiat	Ulysse 2.0 220 (1995-2003)	01/00-08/00	FR PS
Fiat	Ulysse 2.0 220 (1995-2003)	06/00-04/03	FR PS
Fiat	Ulysse 2.0 220 (1995-2003)	10/95-06/00	FR PS
Ford	Cougar 2.0 (1998-2002)	10/98-03/02	FR PS
Ford	Cougar 2.0 (1998-2002)	10/98-03/02	FR PS

















Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR PS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR PS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR DS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR DS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR DS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR DS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR PS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	RR
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR PS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR DS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR DS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	RR
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	RR
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	FR PS
Ford	Escort 1.8 Turbo + Intercooler MK 7 (1994-2002)	01/95-07/00	RR
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	RR
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	RR
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	FR PS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	FR DS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	FR DS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	FR PS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	FR DS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	FR DS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	FR PS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	03/96-01/99	FR PS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	08/96-12/02	RR
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	08/96-12/02	FR PS
Ford	Escort 1.8 Turbo MK 7 (1994-2002)	08/96-12/02	FR DS
Ford	Escort RS 2000 MK 5 (1990-1992)	11/91-07/92	FR DS
Ford	Escort RS 2000 MK 5 (1990-1992)	11/91-07/92	RR
Ford	Escort RS 2000 MK 5 (1990-1992)	11/91-07/92	FR PS
Ford	Escort RS 2000 MK 6 (1992-1995)	07/92-01/95	FR DS
Ford	Escort RS 2000 MK 6 (1992-1995)	07/92-01/95	RR
Ford	Escort RS 2000 MK 6 (1992-1995)	07/92-01/95	FR PS
Ford	Escort RS 2000 MK 6 (1992-1995)	09/93-04/95	FR PS
Ford	Escort RS 2000 MK 6 (1992-1995)	09/93-04/95	FR DS
Ford	Escort RS 2000 MK 6 (1992-1995)	09/93-04/95	RR
Ford	Escort RS 2000 MK 7 (1994-2002)	01/95-12/96	FR DS
Ford	Escort RS 2000 MK 7 (1994-2002)	01/95-12/96	RR
Ford	Escort RS 2000 MK 7 (1994-2002)	01/95-12/96	FR PS
Ford	Escort RS 2000 MK 7 (1994-2002)	04/95-12/96	FR PS
Ford	Escort RS 2000 MK 7 (1994-2002)	04/95-12/96	RR
Ford	Escort RS 2000 MK 7 (1994-2002)	04/95-12/96	FR DS
Ford	Escort RS Cosworth MK 6 (1992-1995)	06/92-01/95	FR DS
Ford	Escort RS Cosworth MK 6 (1992-1995)	06/92-01/95	RR
Ford	Escort RS Cosworth MK 6 (1992-1995)	06/92-01/95	FR PS
Ford	Escort RS Cosworth MK 7 (1994-2002)	01/95-12/96	FR DS
Ford	Escort RS Cosworth MK 7 (1994-2002)	01/95-12/96	FR PS
Ford	Escort RS Cosworth MK 7 (1994-2002)	01/95-12/96	RR
Ford	Granada 1.8 MK 3 (1985-1995)	05/85-07/87	FR DS





Ford	Granada 2.4 MK 3 (1985-1995)	01/87-08/89	RR
Ford	Granada 2.4 MK 3 (1985-1995)	01/87-08/89	FR PS
Ford	Granada 2.5 MK 3 (1985-1995)	01/86-11/88	FR PS
Ford	Granada 2.5 MK 3 (1985-1995)	01/86-11/88	RR
Ford	Granada 2.5 MK 3 (1985-1995)	01/86-11/88	FR DS
Ford	Granada 2.5 Turbo + Intercooler MK 3 (1985-1995)	08/93-03/95	FR DS
Ford	Granada 2.5 Turbo + Intercooler MK 3 (1985-1995)	08/93-03/95	FR PS
Ford	Granada 2.5 Turbo + Intercooler MK 3 (1985-1995)	08/93-03/95	FR PS
Ford	Granada 2.5 Turbo + Intercooler MK 3 (1985-1995)	08/93-03/95	FR DS
Ford	Granada 2.5 Turbo + Intercooler MK 3 (1985-1995)	08/93-03/95	RR
Ford	Granada 2.5 Turbo + Intercooler MK 3 (1985-1995)	08/93-03/95	FR DS
Ford	Granada 2.5 Turbo + Intercooler MK 3 (1985-1995)	08/93-03/95	FR PS
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	01/90-08/93	FR DS
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	01/90-08/93	FR DS
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	01/90-08/93	FR PS
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	01/90-08/93	FR PS
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	12/88-08/93	FR PS
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	12/88-08/93	RR
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	12/88-08/93	FR DS
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	12/88-08/93	FR DS
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	12/88-08/93	RR
Ford	Granada 2.5 Turbo MK 3 (1985-1995)	12/88-08/93	FR PS
Ford	Granada 2.8 MK 3 (1985-1995)	05/85-01/87	FR PS
Ford	Granada 2.8 MK 3 (1985-1995)	05/85-01/87	FR DS
Ford	Granada 2.8 MK 3 (1985-1995)	05/85-01/87	RR
Ford	Granada 2.8 MK 3 (1985-1995)	05/85-01/87	FR PS
Ford	Granada 2.8 MK 3 (1985-1995)	05/85-01/87	RR
Ford	Granada 2.8 MK 3 (1985-1995)	05/85-01/87	FR DS
Ford	Granada 2.8 MK 3 (1985-1995)	11/85-01/87	FR DS
Ford	Granada 2.8 MK 3 (1985-1995)	11/85-01/87	RR
Ford	Granada 2.8 MK 3 (1985-1995)	11/85-01/87	FR PS
Ford	Granada 2.8 MK 3 (1985-1995)	11/85-01/87	RR
Ford	Granada 2.8 MK 3 (1985-1995)	11/85-01/87	FR PS
Ford	Granada 2.8 MK 3 (1985-1995)	11/85-01/87	FR DS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR DS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR DS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR PS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR DS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR PS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR DS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR DS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR DS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	RR
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	RR
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR PS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR PS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	RR
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR PS
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	RR
Ford	Granada 2.9 MK 3 (1985-1995)	01/87-03/95	FR DS















Ford	Orion 1.4 CFi MK 3 (1990-1992)	09/90-07/92	FR PS
Ford	Orion 1.4 MK 3 (1990-1992)	09/90-12/92	FR DS
Ford	Orion 1.4 MK 3 (1990-1992)	09/90-12/92	FR PS
Ford	Orion 1.4 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	Orion 1.4 MK 3 Facelift (1992-1993)	07/92-12/93	FR PS
Ford	Orion 1.4 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	Orion 1.4 MK 3 Facelift (1992-1993)	07/92-12/93	FR PS
Ford	Orion 1.6 Carburettor MK 3 (1990-1992)	09/90-12/92	FR DS
Ford	Orion 1.6 Carburettor MK 3 (1990-1992)	09/90-12/92	FR DS
Ford	Orion 1.6 Carburettor MK 3 (1990-1992)	09/90-12/92	FR DS
Ford	Orion 1.6 Carburettor MK 3 (1990-1992)	09/90-12/92	FR PS
Ford	Orion 1.6 Carburettor MK 3 (1990-1992)	09/90-12/92	FR PS
Ford	Orion 1.6 Carburettor MK 3 (1990-1992)	09/90-12/92	FR DS
Ford	Orion 1.6 Carburettor MK 3 (1990-1992)	09/90-12/92	FR PS
Ford	Orion 1.6 Carburettor MK 3 (1990-1992)	09/90-12/92	FR PS
Ford	Orion 1.6 Injection MK 3 (1990-1992)	09/90-09/92	FR PS
Ford	Orion 1.6 Injection MK 3 (1990-1992)	09/90-09/92	FR DS
Ford	Orion 1.6 MK 3 Facelift (1992-1993)	07/92-12/93	FR PS
Ford	Orion 1.6 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	Orion 1.6 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	Orion 1.6 MK 3 Facelift (1992-1993)	07/92-12/93	FR PS
Ford	Orion 1.8 MK 3 (1990-1992)	02/92-07/92	FR DS
Ford	Orion 1.8 MK 3 (1990-1992)	02/92-07/92	FR PS
Ford	Orion 1.8 MK 3 (1990-1992)	02/92-07/92	FR DS
Ford	Orion 1.8 MK 3 (1990-1992)	02/92-07/92	FR PS
Ford	Orion 1.8 MK 3 (1990-1992)	09/90-07/92	FR DS
Ford	Orion 1.8 MK 3 (1990-1992)	09/90-07/92	FR PS
Ford	Orion 1.8 MK 3 (1990-1992)	09/90-07/92	FR PS
Ford	Orion 1.8 MK 3 (1990-1992)	09/90-07/92	FR DS
Ford	Orion 1.8 MK 3 (1990-1992)	09/90-07/92	FR DS
Ford	Orion 1.8 MK 3 (1990-1992)	09/90-07/92	FR PS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR PS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR PS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR PS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR PS
Ford	Orion 1.8 MK 3 Facelift (1992-1993)	07/92-12/93	FR DS
Ford	P100 2.0 (1989-1994)	01/88-12/94	FR DS
Ford	P100 2.0 (1989-1994)	01/88-12/94	FR PS
Ford	Probe 2.0 (1994-1998)	03/94-04/98	RR
Ford	Probe 2.0 (1994-1998)	03/94-04/98	FR DS
Ford	Probe 2.0 (1994-1998)	03/94-04/98	FR PS
Ford	Probe 2.5 (1994-1998)	03/94-04/98	RR
Ford	Probe 2.5 (1994-1998)	03/94-04/98	FR DS
Ford	Probe 2.5 (1994-1998)	03/94-04/98	FR PS
Ford	Scorpio 2.0 (1995-1998)	01/95-08/96	FR PS

Ford	Scorpio 2.0 (1995-1998)	01/95-08/96	FR DS
Ford	Scorpio 2.0 (1995-1998)	01/95-08/96	FR PS
Ford	Scorpio 2.0 (1995-1998)	01/95-08/96	FR PS
Ford	Scorpio 2.0 (1995-1998)	01/95-08/96	FR DS
Ford	Scorpio 2.0 (1995-1998)	01/95-08/96	FR DS
Ford	Scorpio 2.0 (1995-1998)	08/96-10/97	FR DS
Ford	Scorpio 2.0 (1995-1998)	08/96-10/97	FR PS
Ford	Scorpio 2.0 (1995-1998)	08/96-10/97	FR DS
Ford	Scorpio 2.0 (1995-1998)	08/96-10/97	FR PS
Ford	Scorpio 2.3 (1995-1998)	08/96-07/98	FR DS
Ford	Scorpio 2.3 (1995-1998)	08/96-07/98	FR DS
Ford	Scorpio 2.3 (1995-1998)	08/96-07/98	FR PS
Ford	Scorpio 2.3 (1995-1998)	08/96-07/98	FR PS
Ford	Scorpio 2.3 (1995-1998)	08/96-07/98	FR PS
Ford	Scorpio 2.3 (1995-1998)	08/96-07/98	FR DS
Ford	Scorpio 2.3 (1995-1998)	08/96-07/98	FR DS
Ford	Scorpio 2.3 (1995-1998)	08/96-07/98	FR PS
Ford	Scorpio 2.5 (1995-1998)	01/95-08/96	FR DS
Ford	Scorpio 2.5 (1995-1998)	01/95-08/96	FR DS
Ford	Scorpio 2.5 (1995-1998)	01/95-08/96	FR PS
Ford	Scorpio 2.5 (1995-1998)	01/95-08/96	FR PS
Ford	Scorpio 2.5 (1995-1998)	08/96-07/98	FR PS
Ford	Scorpio 2.5 (1995-1998)	08/96-07/98	FR DS
Ford	Scorpio 2.5 (1995-1998)	08/96-07/98	FR DS
Ford	Scorpio 2.5 (1995-1998)	08/96-07/98	FR PS
Ford	Scorpio 2.5 (1995-1998)	08/97-07/98	FR DS
Ford	Scorpio 2.5 (1995-1998)	08/97-07/98	FR PS
Ford	Scorpio 2.5 (1995-1998)	08/97-07/98	FR PS
Ford	Scorpio 2.5 (1995-1998)	08/97-07/98	FR DS
Ford	Scorpio 2.9 (1995-1998)	01/95-07/98	FR PS
Ford	Scorpio 2.9 (1995-1998)	01/95-07/98	FR PS
Ford	Scorpio 2.9 (1995-1998)	01/95-07/98	FR DS
Ford	Scorpio 2.9 (1995-1998)	01/95-07/98	FR DS
Ford	Scorpio 2.9 (1995-1998)	01/95-08/96	FR DS
Ford	Scorpio 2.9 (1995-1998)	01/95-08/96	FR PS
Ford	Scorpio 2.9 (1995-1998)	01/95-08/96	FR PS
Ford	Scorpio 2.9 (1995-1998)	01/95-08/96	FR DS
Ford	Sierra 1.3 MK 1 (1982-1987)	08/83-12/84	FR PS
Ford	Sierra 1.3 MK 1 (1982-1987)	08/83-12/84	RR
Ford	Sierra 1.3 MK 1 (1982-1987)	08/83-12/84	FR DS
Ford	Sierra 1.3 MK 1 (1982-1987)	10/82-10/86	RR
Ford	Sierra 1.3 MK 1 (1982-1987)	10/82-10/86	FR DS
Ford	Sierra 1.3 MK 1 (1982-1987)	10/82-10/86	FR PS
Ford	Sierra 1.6 CFi MK 2 (1987-1993)	10/91-07/93	FR DS
Ford	Sierra 1.6 CFi MK 2 (1987-1993)	10/91-07/93	FR DS
Ford	Sierra 1.6 CFi MK 2 (1987-1993)	10/91-07/93	FR PS
Ford	Sierra 1.6 CFi MK 2 (1987-1993)	10/91-07/93	FR PS
Ford	Sierra 1.6 MK 1 (1982-1987)	08/83-09/84	RR
Ford	Sierra 1.6 MK 1 (1982-1987)	08/83-09/84	RR
Ford	Sierra 1.6 MK 1 (1982-1987)	08/83-09/84	FR PS











Ford	Sierra 2.0 MK 2 (1987-1993)	09/89-12/91	RR
Ford	Sierra 2.3 MK 1 (1982-1987)	01/83-07/84	FR PS
Ford	Sierra 2.3 MK 1 (1982-1987)	01/83-07/84	FR DS
Ford	Sierra 2.3 MK 1 (1982-1987)	10/82-12/83	FR PS
Ford	Sierra 2.3 MK 1 (1982-1987)	10/82-12/83	FR DS
Ford	Sierra 2.3 MK 1 (1982-1987)	10/82-12/83	RR
Ford	Sierra 2.3 MK 1 (1982-1987)	12/82-03/87	FR PS
Ford	Sierra 2.3 MK 1 (1982-1987)	12/82-03/87	FR DS
Ford	Sierra 2.3 MK 2 (1987-1993)	03/87-02/90	FR PS
Ford	Sierra 2.3 MK 2 (1987-1993)	03/87-02/90	FR DS
Ford	Sierra 2.3 MK 2 (1987-1993)	03/87-02/90	FR DS
Ford	Sierra 2.3 MK 2 (1987-1993)	03/87-02/90	FR PS
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	FR DS
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	FR DS
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	FR PS
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	RR
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	FR PS
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	RR
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	FR DS
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	FR PS
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	FR DS
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	RR
Ford	Sierra 2.8 MK 1 (1982-1987)	06/85-03/87	FR PS
Ford	Sierra 2.8 MK 2 (1987-1993)	03/87-01/89	FR PS
Ford	Sierra 2.8 MK 2 (1987-1993)	03/87-01/89	FR DS
Ford	Sierra 2.8 MK 2 (1987-1993)	03/87-01/89	FR PS
Ford	Sierra 2.8 MK 2 (1987-1993)	03/87-01/89	RR
Ford	Sierra 2.8 MK 2 (1987-1993)	03/87-01/89	FR DS
Ford	Sierra 2.8 XR4i MK 1 (1982-1987)	12/82-05/85	FR PS
Ford	Sierra 2.8 XR4i MK 1 (1982-1987)	12/82-05/85	RR
Ford	Sierra 2.8 XR4i MK 1 (1982-1987)	12/82-05/85	FR DS
Ford	Sierra 2.8 XR4i MK 1 (1982-1987)	12/82-05/85	RR
Ford	Sierra 2.8 XR4i MK 1 (1982-1987)	12/82-05/85	FR DS
Ford	Sierra 2.8 XR4i MK 1 (1982-1987)	12/82-05/85	FR PS
Ford	Sierra 2.9 XR4X4 MK 2 (1987-1993)	01/89-12/90	FR PS
Ford	Sierra 2.9 XR4X4 MK 2 (1987-1993)	01/89-12/90	FR DS
Ford	Sierra 2.9 XR4X4 MK 2 (1987-1993)	01/89-12/90	FR PS
Ford	Sierra 2.9 XR4X4 MK 2 (1987-1993)	01/89-12/90	FR DS
Ford	Sierra Sapphire 1.6 CFi MK 2 (1987-1993)	10/91-07/93	FR DS
Ford	Sierra Sapphire 1.6 CFi MK 2 (1987-1993)	10/91-07/93	FR PS
Ford	Sierra Sapphire 1.6 MK 2 (1987-1993)	03/87-12/91	FR DS
Ford	Sierra Sapphire 1.6 MK 2 (1987-1993)	03/87-12/91	FR PS
Ford	Sierra Sapphire 1.8 CFi MK 2 (1987-1993)	01/92-07/93	FR PS
Ford	Sierra Sapphire 1.8 CFi MK 2 (1987-1993)	01/92-07/93	FR PS
Ford	Sierra Sapphire 1.8 CFi MK 2 (1987-1993)	01/92-07/93	FR DS
Ford	Sierra Sapphire 1.8 CFi MK 2 (1987-1993)	01/92-07/93	FR DS
Ford	Sierra Sapphire 1.8 CFi MK 2 (1987-1993)	01/92-07/93	FR DS
Ford	Sierra Sapphire 1.8 CFi MK 2 (1987-1993)	01/92-07/93	FR DS
Ford	Sierra Sapphire 1.8 CFi MK 2 (1987-1993)	01/92-07/93	FR PS
Ford	Sierra Sapphire 1.8 CFi MK 2 (1987-1993)	01/92-07/93	FR PS





Ford	Sierra Sapphire 2.0 RS Cosworth MK 2 (1987-1993)	02/90-07/93	FR PS
Ford	Sierra Sapphire 2.0 RS Cosworth MK 2 (1987-1993)	02/90-07/93	FR PS
Ford	Sierra Sapphire 2.0 RS Cosworth MK 2 (1987-1993)	02/90-07/93	FR PS
Ford	Sierra Sapphire 2.0 RS Cosworth MK 2 (1987-1993)	02/90-07/93	FR DS
Ford	Sierra Sapphire 2.0 RS Cosworth MK 2 (1987-1993)	02/90-07/93	FR DS
Ford	Sierra Sapphire 2.0 RS Cosworth MK 2 (1987-1993)	02/90-07/93	FR PS
Ford	Tourneo Connect 1.8 TDCi 110 (2002-2009)	08/06-12/09	FR PS
Ford	Tourneo Connect 1.8 TDCi 110 (2002-2009)	08/06-12/09	FR PS
Ford	Tourneo Connect 1.8 TDCi 110 (2002-2009)	08/06-12/09	FR PS
Ford	Tourneo Connect 1.8 TDCi 110 (2009-2013)	08/09-12/13	FR PS
Ford	Tourneo Connect 1.8 TDCi 90 (2002-2009)	06/02-12/09	FR PS
Ford	Tourneo Connect 1.8 TDCi 90 (2002-2009)	06/02-12/09	FR PS
Ford	Tourneo Connect 1.8 TDCi 90 (2009-2013)	08/09-12/13	FR PS
Ford	Tourneo Connect 1.8 TDCi 90 (2009-2013)	08/09-12/13	FR PS
Ford	Transit 1.6 MK 2 (1978-1986)	01/85-02/86	FR PS
Ford	Transit 1.6 MK 2 (1978-1986)	01/85-02/86	FR DS
Ford	Transit 2.0 MK 2 (1978-1986)	01/85-02/86	FR PS
Ford	Transit 2.0 MK 2 (1978-1986)	01/85-02/86	FR PS
Ford	Transit 2.0 MK 2 (1978-1986)	01/85-02/86	FR DS
Ford	Transit 2.0 MK 2 (1978-1986)	01/85-02/86	FR DS
Ford	Transit 2.5 MK 2 (1978-1986)	01/85-02/86	FR PS
Ford	Transit 2.5 MK 2 (1978-1986)	01/85-02/86	FR DS
Ford	Transit Connect 1.8 (2002-2009)	08/02-04/07	FR PS
Ford	Transit Connect 1.8 (2002-2009)	08/02-04/07	FR PS
Ford	Transit Connect 1.8 Dual Fuel (2002-2009)	07/03-04/07	FR PS
Ford	Transit Connect 1.8 Dual Fuel (2002-2009)	07/03-04/07	FR PS
Ford	Transit Connect 1.8 TDCi 110 (2002-2009)	08/06-12/09	FR PS
Ford	Transit Connect 1.8 TDCi 110 (2009-2013)	08/09-12/13	FR PS
Ford	Transit Connect 1.8 TDCi 110 (2009-2013)	08/10-12/13	FR PS
Ford	Transit Connect 1.8 TDCi 75 (2002-2009)	08/06-12/09	FR PS
Ford	Transit Connect 1.8 TDCi 75 (2009-2013)	08/09-12/13	FR PS
Ford	Transit Connect 1.8 TDCi 75 (2009-2013)	08/09-12/13	FR PS
Ford	Transit Connect 1.8 TDCi 75 (2009-2013)	08/09-12/13	FR PS
Ford	Transit Connect 1.8 TDCi 90 (2002-2009)	05/06-12/09	FR PS
Ford	Transit Connect 1.8 TDCi 90 (2002-2009)	08/02-12/09	FR PS
Ford	Transit Connect 1.8 TDCi 90 (2002-2009)	08/02-12/09	FR PS
Ford	Transit Connect 1.8 TDCi 90 (2009-2013)	08/09-12/13	FR PS
Ford	Transit Connect 1.8 TDCi 90 (2009-2013)	08/09-12/13	FR PS
Ford	Transit Connect 1.8 TDCi 90 (2009-2013)	08/09-12/13	FR PS
Ford	Transit Connect 1.8 TDdi 75 (2002-2009)	08/02-12/09	FR PS
Honda	Accord 1.8 Vtec MK 6 (1998-2003)	06/99-04/03	FR PS
Honda	Accord 1.8 Vtec MK 6 (1998-2003)	06/99-04/03	FR PS
Honda	Accord 2.0 Aerodeck MK 5 (1993-1998)	06/94-11/97	FR PS
Honda	Accord 2.0 Aerodeck MK 5 (1993-1998)	06/94-11/97	FR PS
Honda	Accord 2.0 MK 5 (1993-1998)	02/94-03/96	FR PS
Honda	Accord 2.0 MK 5 (1993-1998)	02/94-03/96	FR PS
Honda	Accord 2.0 MK 5 (1993-1998)	05/93-08/98	FR PS
Honda	Accord 2.0 MK 5 (1993-1998)	05/93-08/98	FR PS
Honda	Accord 2.0 MK 5 (1993-1998)	06/94-12/97	FR PS
Honda	Accord 2.0 MK 5 (1993-1998)	06/94-12/97	FR PS





Honda	Civic 1.6 MK 6 (1995-2001)	05/97-11/99	FR DS
Honda	Civic 1.6 MK 6 (1995-2001)	05/97-11/99	FR DS
Honda	Civic 1.6 MK 6 (1995-2001)	05/97-11/99	FR DS
Honda	Civic 1.6 MK 6 (1995-2001)	05/97-11/99	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	01/96-01/99	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	01/96-01/99	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	06/95-05/97	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	11/99-03/01	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	11/99-03/01	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	11/99-03/01	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	11/99-03/01	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	11/99-03/01	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	11/99-03/01	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	11/99-03/01	FR DS
Honda	Civic 1.6 Vtec MK 6 (1995-2001)	11/99-03/01	FR DS
Honda	Civic 1.6 VTi MK 6 (1995-2001)	01/96-03/01	FR DS
Honda	Civic 1.6 VTi MK 6 (1995-2001)	01/96-03/01	FR DS
Honda	Civic 1.6 VTi MK 6 (1995-2001)	01/99-03/01	FR DS
Honda	Civic 1.8 Aerodeck VTi MK 6 (1995-2001)	02/98-03/01	FR DS
Honda	Civic 1.8 VTi MK 6 (1995-2001)	05/97-03/01	FR DS
Honda	Civic 2.0 Turbo intercooled MK 6 (1995-2001)	07/98-05/99	FR DS
Honda	Civic 2.0 Turbo intercooled MK 6 (1995-2001)	07/98-05/99	FR DS
Honda	Civic 2.0 Turbo MK 6 (1995-2001)	05/97-07/98	FR DS
Honda	Civic CRX 1.6 ESi (1992-1997)	02/96-02/98	FR DS
Honda	Civic CRX 1.6 ESi (1992-1997)	02/96-02/98	FR DS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR DS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR DS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR DS
Honda	Civic CRX 1.6 ESi (1992-1997)	06/92-02/96	FR DS
Honda	Civic CRX 1.6 VTi (1992-1997)	06/92-02/95	FR DS
Honda	CR-V 2.0 MK 2 (2001-2007)	11/01-06/07	FR PS
Honda	CR-V 2.0 MK 2 (2001-2007)	11/01-06/07	FR PS
Honda	CR-V 2.2 CDTi MK 2 (2001-2007)	03/05-06/07	FR PS
Honda	HR-V 1.6 GH (1999-2006)	02/99-01/05	FR DS
Honda	HR-V 1.6 GH (1999-2006)	02/99-01/05	FR DS
Honda	HR-V 1.6 GH (1999-2006)	02/99-01/05	FR DS
Honda	HR-V 1.6 GH (1999-2006)	02/99-01/05	FR DS
Honda	HR-V 1.6 GH (1999-2006)	02/99-12/01	FR DS
Honda	HR-V 1.6 Vtec GH (1999-2006)	01/00-07/06	FR DS
Honda	Insight 1.0 IMA Hybrid (2000-2005)	03/00-12/05	FR DS
Honda	Jazz 1.2 i-DSi MK2 (GD) (2002-2009)	10/04-04/09	FR DS
Honda	Jazz 1.2 i-DSi MK2 (GD) (2002-2009)	10/04-04/09	FR DS
Honda	Jazz 1.4 i-DSi MK2 (GD) (2002-2009)	02/02-04/09	FR DS
Honda	Jazz 1.4 i-DSi MK2 (GD) (2002-2009)	02/02-04/09	FR DS
Honda	Legend 2.5 (1986-1991)	10/86-10/87	FR DS
Honda	Legend 2.5 (1986-1991)	10/86-10/87	FR PS
Honda	Legend 2.5 (1986-1991)	10/86-10/87	FR DS
Honda	Legend 2.5 (1986-1991)	10/86-10/87	FR PS
Honda	Legend 3.2 (1991-1995)	04/91-05/95	FR DS
Honda	Legend 3.2 (1991-1996)	04/91-06/96	FR DS

Honda	Legend 3.5 (1996-2003)	01/00-03/03	FR DS
Honda	Legend 3.5 (1996-2003)	06/96-01/00	FR DS
Honda	Legend 3.5 (2006-2009)	07/06-12/09	FR DS
Honda	Logo 1.3 (2000-2001)	04/00-07/01	FR DS
Honda	Logo 1.3 (2000-2001)	04/00-07/01	FR DS
Honda	NSX 3.0 (1991-2005)	01/91-02/98	FR PS
Honda	NSX 3.0 (1991-2005)	01/91-02/98	FR DS
Honda	NSX 3.0 (1991-2005)	01/91-02/98	FR DS
Honda	NSX 3.0 (1991-2005)	01/91-02/98	FR PS
Honda	NSX 3.0 (1991-2005)	02/98-08/05	FR DS
Honda	NSX 3.0 (1991-2005)	02/98-08/05	FR PS
Honda	NSX 3.2 (1991-2005)	02/98-08/05	FR DS
Honda	NSX 3.2 (1991-2005)	02/98-08/05	FR PS
Honda	Prelude 2.0 (1992-1997)	04/92-09/96	FR DS
Honda	Prelude 2.0 (1992-1997)	04/92-09/96	FR DS
Honda	Prelude 2.0 (1997-2001)	02/97-03/01	FR DS
Honda	Prelude 2.0 (1997-2001)	02/97-03/01	FR DS
Honda	Prelude 2.2 (1992-1997)	02/93-09/96	FR DS
Honda	Prelude 2.2 (1997-2001)	01/99-03/01	FR DS
Honda	Prelude 2.2 (1997-2001)	01/99-03/01	FR DS
Honda	Prelude 2.2 (1997-2001)	02/97-01/99	FR DS
Honda	Prelude 2.2 (1997-2001)	02/97-01/99	FR DS
Honda	Prelude 2.3 (1992-1997)	04/92-09/96	FR DS
Honda	Prelude 2.3 (1992-1997)	04/92-09/96	FR DS
Honda	S2000 2.0 (1999-2009)	09/99-12/09	FR PS
Honda	S2000 2.2 (1999-2009)	01/05-12/09	FR PS
Hyundai	Accent 1.3 (1994-2000)	01/00-12/00	FR DS
Hyundai	Accent 1.3 (1994-2000)	01/00-12/00	RR
Hyundai	Accent 1.3 (1994-2000)	01/00-12/00	FR DS
Hyundai	Accent 1.3 (1994-2000)	01/00-12/00	RR
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	RR
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	RR
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	RR
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	RR
Hyundai	Accent 1.3 (1994-2000)	04/99-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	10/94-03/97	FR DS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	RR
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	RR
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	RR
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	RR
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR DS
Hyundai	Accent 1.3 (1994-2000)	10/94-12/99	FR DS
Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	FR DS
Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	RR
Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	FR DS

Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	FR DS
Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	RR
Hyundai	Accent 1.3 (2000-2003)	01/00-03/03	RR
Hyundai	Accent 1.3 (2003-2006)	02/03-12/06	RR
Hyundai	Accent 1.3 (2003-2006)	02/03-12/06	FR DS
Hyundai	Accent 1.3 (2003-2006)	02/03-12/06	RR
Hyundai	Accent 1.3 (2003-2006)	02/03-12/06	FR DS
Hyundai	Accent 1.3 (2003-2006)	02/03-12/06	FR DS
Hyundai	Accent 1.4 (2006-2010)	07/06-03/10	RR
Hyundai	Accent 1.4 (2006-2010)	07/06-03/10	FR DS
Hyundai	Accent 1.4 (2006-2010)	07/06-03/10	RR
Hyundai	Accent 1.4 (2006-2010)	07/06-03/10	FR DS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	RR
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	RR
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	RR
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	RR
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	RR
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	07/99-12/99	RR
Hyundai	Accent 1.5 (1994-2000)	10/94-03/97	FR DS
Hyundai	Accent 1.5 (1994-2000)	10/94-03/97	FR DS
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	RR
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	RR
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	RR
Hyundai	Accent 1.5 (1994-2000)	10/94-05/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	10/98-01/99	FR DS
Hyundai	Accent 1.5 (1994-2000)	10/98-01/99	RR
Hyundai	Accent 1.5 (2000-2003)	01/00-03/03	RR
Hyundai	Accent 1.5 (2000-2003)	01/00-03/03	RR
Hyundai	Accent 1.5 (2000-2003)	01/00-03/03	RR
Hyundai	Accent 1.5 (2000-2003)	01/00-03/03	FR DS
Hyundai	Accent 1.5 (2000-2003)	01/00-03/03	FR DS
Hyundai	Accent 1.5 (2000-2003)	07/02-03/03	FR DS
Hyundai	Accent 1.5 (2000-2003)	07/02-03/03	RR
Hyundai	Accent 1.5 (2003-2006)	02/03-11/05	RR
Hyundai	Accent 1.5 (2003-2006)	02/03-11/05	FR DS
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	RR
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	RR
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	RR
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	FR DS
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	FR DS
Hyundai	Accent 1.5 MVi (1994-2000)	01/97-12/99	FR DS

Hyundai	Accent 1.5 MVi (2000-2003)	06/00-03/03	FR DS
Hyundai	Accent 1.5 MVi (2000-2003)	06/00-03/03	RR
Hyundai	Accent 1.6 (2003-2006)	02/03-03/04	FR DS
Hyundai	Accent 1.6 (2003-2006)	02/03-12/06	FR DS
Hyundai	Accent 1.6 (2003-2006)	02/03-12/06	RR
Hyundai	Accent 1.6 (2003-2006)	02/03-12/06	RR
Hyundai	Accent 1.6 (2003-2006)	02/03-12/06	FR DS
Hyundai	Amica 1.0 (2000-2003)	02/00-03/03	FR DS
Hyundai	Amica 1.0 (2000-2003)	02/00-03/03	FR DS
Hyundai	Amica 1.0 (2000-2003)	02/00-03/03	FR DS
Hyundai	Amica 1.0 (2000-2003)	02/00-03/03	FR DS
Hyundai	Amica 1.0 (2000-2003)	02/00-12/01	FR DS
Hyundai	Amica 1.0 (2000-2003)	02/00-12/01	FR DS
Hyundai	Amica 1.0 (2000-2003)	02/00-12/01	FR DS
Hyundai	Amica 1.0 (2000-2003)	02/00-12/01	FR DS
Hyundai	Atoz 1.0 (1998-2001)	05/98-12/01	FR DS
Hyundai	Atoz 1.0 (1998-2001)	05/98-12/01	FR DS
Hyundai	Atoz 1.0 (1998-2001)	05/98-12/01	FR DS
Hyundai	Atoz 1.0 (1998-2001)	05/98-12/01	FR DS
Hyundai	Atoz 1.0 (1998-2001)	05/98-12/01	FR DS
Hyundai	Coupe 1.6 (1996-2002)	01/00-05/01	RR
Hyundai	Coupe 1.6 (1996-2002)	01/00-05/01	RR
Hyundai	Coupe 1.6 (1996-2002)	01/00-12/01	RR
Hyundai	Coupe 1.6 (1996-2002)	01/00-12/01	RR
Hyundai	Coupe 1.6 (1996-2002)	06/97-01/00	RR
Hyundai	Coupe 1.6 (1996-2002)	06/97-01/00	RR
Hyundai	Coupe 1.6 (1996-2002)	06/97-01/00	RR
Hyundai	Coupe 1.6 (1996-2002)	06/97-01/00	RR
Hyundai	Coupe 1.6 (2002-2005)	01/02-02/05	RR
Hyundai	Coupe 1.6 (2005-2007)	01/05-03/07	RR
Hyundai	Coupe 1.6 SIII (2007-2009)	01/07-12/09	RR
Hyundai	Coupe 2.0 (1996-2002)	01/00-12/01	RR
Hyundai	Coupe 2.0 (1996-2002)	01/00-12/01	RR
Hyundai	Coupe 2.0 (1996-2002)	01/00-12/01	RR
Hyundai	Coupe 2.0 (1996-2002)	01/00-12/01	RR
Hyundai	Coupe 2.0 (1996-2002)	09/96-01/00	RR
Hyundai	Coupe 2.0 (1996-2002)	09/96-01/00	RR
Hyundai	Coupe 2.0 (2002-2005)	01/02-02/05	RR
Hyundai	Coupe 2.0 (2002-2005)	01/02-02/05	RR
Hyundai	Coupe 2.0 (2005-2007)	01/05-03/07	RR
Hyundai	Coupe 2.0 (2005-2007)	01/05-03/07	RR
Hyundai	Coupe 2.0 F2 Evolution (1996-2002)	05/99-12/01	RR
Hyundai	Coupe 2.0 F2 Evolution (1996-2002)	05/99-12/01	RR
Hyundai	Coupe 2.7 (2002-2005)	01/02-02/05	RR
Hyundai	Coupe 2.7 (2002-2005)	01/02-02/05	RR
Hyundai	Coupe 2.7 (2005-2007)	01/05-03/07	RR
Hyundai	Coupe 2.7 (2005-2007)	01/05-03/07	RR
Hyundai	Elantra 1.6 (2001-2006)	03/01-05/04	FR DS
Hyundai	Elantra 1.6 (2001-2006)	03/01-05/04	FR DS



Hyundai	Elantra 1.6 (2001-2006)	03/01-06/04	FR DS
Hyundai	Elantra 1.6 (2001-2006)	03/01-06/04	FR DS
Hyundai	Elantra 2.0 (2001-2006)	02/02-12/06	FR DS
Hyundai	Elantra 2.0 (2001-2006)	03/01-05/04	FR DS
Hyundai	Elantra 2.0 (2001-2006)	03/01-05/04	FR DS
Hyundai	Elantra 2.0 (2001-2006)	03/01-05/04	FR DS
Hyundai	Elantra 2.0 (2001-2006)	03/01-05/04	FR DS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR DS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR DS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR DS
Hyundai	Elantra 2.0 (2001-2006)	03/01-06/04	FR DS
Hyundai	Grandeur 3.3 (2006-2009)	06/06-12/09	FR PS
Hyundai	i800 2.5 CRDi (2008-2019)	06/08-05/14	FR PS
Hyundai	i800 2.5 CRDi (2008-2019)	06/08-05/14	FR PS
Hyundai	i800 2.5 CRDi (2008-2019)	06/08-12/19	FR PS
Hyundai	i800 2.5 CRDi (2008-2019)	06/08-12/19	FR PS
Hyundai	iLoad 2.5 (2009-2019)	01/09-05/14	FR PS
Hyundai	iLoad 2.5 (2009-2019)	01/11-04/19	FR PS
Hyundai	Lantra 1.6 (1991-1995)	06/91-12/95	FR DS
Hyundai	Lantra 1.6 (1991-1995)	06/91-12/95	FR DS
Hyundai	Lantra 1.6 (1995-1998)	11/95-06/98	FR DS
Hyundai	Lantra 1.6 (1995-1998)	11/95-06/98	FR DS
Hyundai	Lantra 1.6 (1995-1998)	11/95-06/98	FR DS
Hyundai	Lantra 1.6 (1995-1998)	11/95-06/98	FR DS
Hyundai	Lantra 1.8 (1991-1995)	10/93-12/95	FR DS
Hyundai	Lantra 1.8 (1991-1995)	10/93-12/95	FR DS
Hyundai	Lantra 1.8 (1995-1998)	11/95-02/97	FR DS
Hyundai	Lantra 1.8 (1995-1998)	11/95-02/97	FR DS
Hyundai	Lantra 1.8 (1995-1998)	11/95-02/97	FR DS
Hyundai	Lantra 1.8 (1995-1998)	11/95-02/97	FR DS
Hyundai	Lantra 2.0 (1995-1998)	02/97-06/98	FR DS
Hyundai	Lantra 2.0 (1995-1998)	02/97-06/98	FR DS
Hyundai	Lantra 2.0 (1995-1998)	11/95-06/98	FR DS
Hyundai	Lantra 2.0 (1995-1998)	11/95-06/98	FR DS
Hyundai	Lantra 2.0 (1998-2001)	06/98-03/01	FR DS
Hyundai	Lantra 2.0 (1998-2001)	06/98-03/01	FR DS
Hyundai	Lantra 2.0 (1998-2001)	06/98-03/01	FR DS
Hyundai	Lantra 2.0 (1998-2001)	06/98-03/01	FR DS
Hyundai	Santa Fe 2.0 SM (2001-2006)	03/01-05/06	FR PS
Hyundai	Santa Fe 2.0 SM (2001-2006)	03/01-05/06	FR PS
Hyundai	Santa Fe 2.0 SM (2001-2006)	03/01-05/06	FR PS
Hyundai	Santa Fe 2.0 SM (2001-2006)	03/01-05/06	FR PS
Hyundai	Santa Fe 2.0 SM (2001-2006)	03/01-12/02	FR PS
Hyundai	Santa Fe 2.0 SM (2001-2006)	03/01-12/02	FR PS
Hyundai	Santa Fe 2.4 SM (2001-2006)	03/01-11/06	FR PS
Hyundai	Santa Fe 2.7 SM (2001-2006)	03/01-05/06	FR PS
Hyundai	Sonata 2.0 (1994-1998)	01/94-09/96	FR DS
Hyundai	Sonata 2.0 (1994-1998)	01/94-09/96	FR PS
Hyundai	Sonata 2.0 (1994-1998)	01/94-09/96	FR DS
Hyundai	Sonata 2.0 (1994-1998)	01/94-09/96	FR PS

Hyundai	Sonata 2.0 (1994-1998)	09/96-10/98	FR PS
Hyundai	Sonata 2.0 (1994-1998)	09/96-10/98	FR PS
Hyundai	Sonata 2.0 (1994-1998)	09/96-10/98	FR DS
Hyundai	Sonata 2.0 (1994-1998)	09/96-10/98	FR DS
Hyundai	Sonata 2.0 (1998-2002)	06/98-12/01	FR PS
Hyundai	Sonata 2.0 (1998-2002)	06/98-12/01	FR PS
Hyundai	Sonata 2.0 (2002-2005)	01/02-07/05	FR PS
Hyundai	Sonata 2.0 (2002-2005)	01/02-07/05	FR PS
Hyundai	Sonata 2.0 (2005-2011)	07/06-03/10	FR PS
Hyundai	Sonata 2.0 (2005-2011)	07/06-03/10	FR PS
Hyundai	Sonata 2.0 (2005-2011)	07/06-03/10	FR PS
Hyundai	Sonata 2.0 (2005-2011)	07/06-03/10	FR PS
Hyundai	Sonata 2.0 (2005-2011)	07/06-03/10	FR PS
Hyundai	Sonata 2.0 (2005-2011)	09/09-03/11	FR PS
Hyundai	Sonata 2.0 (2005-2011)	09/09-03/11	FR PS
Hyundai	Sonata 2.4 (2005-2011)	05/05-08/06	FR PS
Hyundai	Sonata 2.4 (2005-2011)	05/05-08/06	FR PS
Hyundai	Sonata 2.5 (1998-2002)	06/98-12/01	FR PS
Hyundai	Sonata 3.0 (1994-1998)	10/94-10/98	FR DS
Hyundai	Sonata 3.0 (1994-1998)	10/94-10/98	FR PS
Hyundai	Sonata 3.3 (2005-2011)	07/06-05/09	FR PS
Isuzu	Big Horn 3.0 TD (1998-2002)	01/98-12/02	FR DS
Isuzu	Big Horn 3.0 TD (1998-2002)	01/98-12/02	FR PS
Isuzu	Big Horn 3.0 TD (1998-2002)	01/98-12/02	FR DS
Isuzu	Big Horn 3.0 TD (1998-2002)	01/98-12/02	FR PS
Isuzu	Big Horn 3.1 TD (1991-1998)	01/91-12/98	FR DS
Isuzu	Big Horn 3.1 TD (1991-1998)	01/91-12/98	FR PS
Isuzu	Big Horn 3.1 TD (1991-1998)	01/91-12/98	FR PS
Isuzu	Big Horn 3.1 TD (1991-1998)	01/91-12/98	FR DS
Isuzu	Big Horn 3.5 (1998-2002)	01/98-12/02	FR DS
Isuzu	Big Horn 3.5 (1998-2002)	01/98-12/02	FR DS
Isuzu	Big Horn 3.5 (1998-2002)	01/98-12/02	FR PS
Isuzu	Big Horn 3.5 (1998-2002)	01/98-12/02	FR PS
Isuzu	Trooper 3.0	05/98-12/05	FR DS
Isuzu	Trooper 3.0	05/98-12/05	FR DS
Isuzu	Trooper 3.0	05/98-12/05	FR DS
Isuzu	Trooper 3.0	05/98-12/05	FR PS
Isuzu	Trooper 3.0	05/98-12/05	FR PS
Isuzu	Trooper 3.0	05/98-12/05	FR PS
Isuzu	Trooper 3.0	05/98-12/05	FR DS
Isuzu	Trooper 3.0	10/99-12/05	FR DS
Isuzu	Trooper 3.0	10/99-12/05	FR PS
Isuzu	Trooper 3.1	03/92-04/98	FR DS
Isuzu	Trooper 3.1	03/92-04/98	FR PS
Isuzu	Trooper 3.1	03/92-04/98	FR PS
Isuzu	Trooper 3.1	03/92-04/98	FR DS
Isuzu	Trooper 3.1	10/92-12/99	FR PS
Isuzu	Trooper 3.1	10/92-12/99	FR DS
Isuzu	Trooper 3.1	10/92-12/99	FR DS
Isuzu	Trooper 3.1	10/92-12/99	FR PS

Isuzu	Trooper 3.2	03/92-04/98	FR PS
Isuzu	Trooper 3.2	03/92-04/98	FR DS
Isuzu	Trooper 3.2	03/92-04/98	FR DS
Isuzu	Trooper 3.2	03/92-04/98	FR PS
Isuzu	Trooper 3.5	05/98-07/04	FR DS
Isuzu	Trooper 3.5	05/98-07/04	FR PS
Isuzu	Trooper 3.5	05/98-07/04	FR PS
Isuzu	Trooper 3.5	05/98-07/04	FR DS
Jaguar/Daimler	Daimler Century 4.0 X300	10/95-12/96	FR PS
Jaguar/Daimler	Daimler Century 4.0 X300	10/95-12/96	FR DS
Jaguar/Daimler	Daimler Six 4.0 X300	09/94-12/97	FR PS
Jaguar/Daimler	Daimler Six 4.0 X300	09/94-12/97	FR DS
Jaguar/Daimler	Daimler V8 4.0 X308	09/97-04/03	FR PS
Jaguar/Daimler	Daimler V8 4.0 X308	09/97-04/03	FR DS
Jaguar/Daimler	Sovereign 4.0 LWB X308	09/97-12/02	FR DS
Jaguar/Daimler	Sovereign 4.0 LWB X308	09/97-12/02	FR PS
Jeep	Cherokee 4.0 (1993-2001)	01/93-11/95	FR DS
Jeep	Cherokee 4.0 (1993-2001)	01/93-11/95	FR PS
Jeep	Cherokee 4.0 (1993-2001)	11/95-04/97	FR PS
Jeep	Cherokee 4.0 (1993-2001)	11/95-04/97	FR DS
Jeep	Compass 2.0 (2011-2015)	07/11-12/15	FR PS
Jeep	Compass 2.0 CRD (2007-2010)	04/07-12/10	FR PS
Jeep	Compass 2.2 CRD (2011-2015)	07/11-12/15	FR PS
Jeep	Compass 2.2 CRD (2011-2015)	07/11-12/15	FR PS
Jeep	Compass 2.4 (2007-2010)	04/07-12/10	FR PS
Jeep	Compass 2.4 (2007-2010)	04/07-12/10	FR PS
Jeep	Compass 2.4 (2011-2015)	07/11-12/15	FR PS
Jeep	Grand Cherokee 2.5 (1994-1999)	02/97-07/99	FR DS
Jeep	Grand Cherokee 2.5 (1994-1999)	02/97-07/99	FR PS
Jeep	Grand Cherokee 2.5 (1994-1999)	02/97-07/99	FR DS
Jeep	Grand Cherokee 2.5 (1994-1999)	02/97-07/99	FR DS
Jeep	Grand Cherokee 2.5 (1994-1999)	02/97-07/99	FR PS
Jeep	Grand Cherokee 2.5 (1994-1999)	02/97-07/99	FR PS
Jeep	Grand Cherokee 4.0 (1994-1999)	01/96-03/99	FR PS
Jeep	Grand Cherokee 4.0 (1994-1999)	01/96-03/99	FR DS
Jeep	Grand Cherokee 4.0 (1994-1999)	01/96-03/99	FR DS
Jeep	Grand Cherokee 4.0 (1994-1999)	01/96-03/99	FR PS
Jeep	Grand Cherokee 5.2 (1994-1999)	03/94-07/99	FR DS
Jeep	Grand Cherokee 5.2 (1994-1999)	03/94-07/99	FR PS
Kia	Magentis 2.0 CRDi MG (2006-2012)	04/09-12/12	FR PS
Kia	Magentis 2.0 CRDi MG (2006-2012)	04/09-12/12	FR PS
Kia	Magentis 2.0 MG (2006-2012)	06/06-09/09	FR PS
Kia	Magentis 2.0 MG (2006-2012)	06/06-09/09	FR PS
Kia	Magentis 2.0 MS (2001-2006)	01/03-07/06	FR PS
Kia	Magentis 2.0 MS (2001-2006)	01/03-07/06	FR PS
Kia	Magentis 2.0 MS (2001-2006)	01/03-07/06	FR PS
Kia	Magentis 2.0 MS (2001-2006)	01/03-07/06	FR PS
Kia	Magentis 2.5 MS (2001-2006)	06/01-03/04	FR PS
Kia	Magentis 2.5 MS (2001-2006)	06/01-03/04	FR PS
Kia	Magentis 2.5 MS (2001-2006)	06/01-03/04	FR PS

Kia	Magentis 2.5 MS (2001-2006)	06/01-03/04	FR PS
Kia	Magentis 2.7 MG (2006-2012)	06/06-06/09	FR PS
Kia	Sorento 2.0 CRDi (2010-2015)	09/10-12/15	FR PS
Kia	Sorento 2.2 CRDi (2010-2015)	01/10-12/15	FR PS
Kia	Sorento 2.2 CRDi (2010-2015)	01/10-12/15	FR PS
Kia	Sorento 2.2 CRDi (2010-2015)	01/10-12/15	FR PS
Kia	Sorento 2.2 CRDi (2010-2015)	01/10-12/15	FR PS
Kia	Sorento 2.4 (2010-2015)	01/10-03/11	FR PS
Kia	Soul 1.6 CRDi 126 (2014-2020) PS	04/14-04/16	FR PS
Kia	Soul 1.6 CRDi 126 (2014-2020) PS	04/14-04/16	FR PS
Kia	Soul 1.6 CRDi 134 (2014-2020) PS	07/15-04/20	FR PS
Kia	Soul 1.6 CRDi 134 (2014-2020) PS	07/15-04/20	FR PS
Kia	Soul 1.6 GDi 130 (2014-2020) PS	04/14-04/20	FR PS
Kia	Soul 1.6 GDi 200 (2014-2020) PS	10/16-04/20	FR PS
Kia	Soul EV (2014-2020) PS	09/14-04/19	FR PS
Kia	Sportage 2.0 JA (1995-1999)	07/95-06/99	FR DS
Kia	Sportage 2.0 JA (1995-1999)	07/95-06/99	FR PS
Kia	Sportage 2.0 JA (1999-2004)	02/03-03/04	FR DS
Kia	Sportage 2.0 JA (1999-2004)	02/03-03/04	FR PS
Kia	Sportage 2.0 JA (1999-2004)	06/99-02/03	FR DS
Kia	Sportage 2.0 JA (1999-2004)	06/99-02/03	FR DS
Kia	Sportage 2.0 JA (1999-2004)	06/99-02/03	FR PS
Kia	Sportage 2.0 JA (1999-2004)	06/99-02/03	FR PS
Lancia	Thema 2.0 ie	06/89-12/92	FR DS
Lancia	Thema 2.0 ie	06/89-12/92	FR PS
Lancia	Thema 2.0 ie	06/89-12/92	FR DS
Lancia	Thema 2.0 ie	06/89-12/92	FR PS
Lancia	Thema 2.0 ie	10/85-06/89	FR PS
Lancia	Thema 2.0 ie	10/85-06/89	FR DS
Lancia	Thema 2.0 ie	10/85-06/89	FR PS
Lancia	Thema 2.0 ie	10/85-06/89	FR DS
Lancia	Thema 2.0 ie Turbo	06/89-10/92	FR PS
Lancia	Thema 2.0 ie Turbo	06/89-10/92	FR DS
Lancia	Thema 2.0 ie Turbo	10/85-06/89	FR DS
Lancia	Thema 2.0 ie Turbo	10/85-06/89	FR PS
Lancia	Thema 2.0 ie Turbo	10/92-07/94	FR DS
Lancia	Thema 2.0 ie Turbo	10/92-07/94	FR PS
Lancia	Thema 2.8	10/85-03/88	FR DS
Lancia	Thema 2.8	10/85-03/88	FR PS
Lancia	Thema 2.9 8.32	03/88-12/92	FR DS
Lancia	Thema 2.9 8.32	03/88-12/92	FR PS
Land Rover	Discovery Sport 1.5 P300e (2019-)	06/20-	FR PS
Land Rover	Discovery Sport 2.0 D150 (2019-)	05/19-12/21	FR PS
Land Rover	Discovery Sport 2.0 D150 MHEV (2019-)	05/19-12/21	FR PS
Land Rover	Discovery Sport 2.0 D165 (2019-)	01/24-	FR PS
Land Rover	Discovery Sport 2.0 D165 (2019-)	10/20-04/22	FR PS
Land Rover	Discovery Sport 2.0 D165 (2019-)	10/20-12/22	FR PS
Land Rover	Discovery Sport 2.0 D180 MHEV (2019-)	05/19-12/21	FR PS
Land Rover	Discovery Sport 2.0 D200 (2019-)	10/20-	FR PS
Land Rover	Discovery Sport 2.0 D240 MHEV (2019-)	05/19-12/21	FR PS

Land Rover	Discovery Sport 2.0 eD4 150 L550 (2014-2020)	08/18-04/20	FR PS
Land Rover	Discovery Sport 2.0 P200 MHEV (2019-)	05/19-	FR PS
Land Rover	Discovery Sport 2.0 P250 MHEV (2019-)	05/19-	FR PS
Land Rover	Discovery Sport 2.0 P290 (2019-)	10/20-	FR PS
Land Rover	Discovery Sport 2.0 SD4 240 L550 (2014-2020)	06/17-04/20	FR PS
Land Rover	Discovery Sport 2.0 Si4 L550 (2014-2020)	08/17-04/19	FR PS
Land Rover	Discovery Sport 2.0 Si4 L550 (2014-2020)	12/14-04/20	FR PS
Land Rover	Discovery Sport 2.0 TD4 150 L550 (2014-2020)	05/15-04/18	FR PS
Land Rover	Discovery Sport 2.0 TD4 180 L550 (2014-2020)	05/15-04/20	FR PS
Land Rover	Discovery Sport 2.0 TD4 180 L550 (2014-2020)	05/15-04/20	FR PS
Land Rover	Discovery Sport 2.2 SD4 L550 (2014-2020)	12/14-04/16	FR PS
Land Rover	Discovery Sport 2.2 SD4 L550 (2014-2020)	12/14-04/16	FR PS
Land Rover	Discovery Sport 2.2 TD4 L550 (2014-2020)	12/14-04/18	FR PS
Land Rover	Discovery Sport 2.2 TD4 L550 (2014-2020)	12/14-04/18	FR PS
LDV	Convoy 2.4 Turbo	04/02-04/06	FR DS
LDV	Convoy 2.4 Turbo	04/02-04/06	FR PS
LDV	Convoy 2.4 Turbo Intercooled	04/02-04/06	FR DS
LDV	Convoy 2.4 Turbo Intercooled	04/02-04/06	FR PS
LDV	Convoy 2.5	04/96-06/05	FR DS
LDV	Convoy 2.5	04/96-06/05	FR PS
LDV	Convoy 2.5 Turbo	04/96-06/05	FR PS
LDV	Convoy 2.5 Turbo	04/96-06/05	FR DS
LDV	Convoy 2.5 Turbo	04/96-06/05	FR PS
LDV	Convoy 2.5 Turbo	04/96-06/05	FR DS
Lexus	GS300 3.0 (1997-2000)	10/97-10/00	FR PS
Lexus	GS300 3.0 (2000-2005)	10/00-05/05	FR PS
Lexus	GS430 4.3 (2000-2005)	10/00-05/05	FR PS
Lexus	IS200d 2.2 (2005-2013)	08/10-12/13	FR PS
Lexus	IS220 2.2 d (2005-2011)	11/05-03/11	FR PS
Lexus	IS250 2.5 (2005-2013)	11/05-12/13	FR PS
Lexus	IS250 2.5 (2005-2013)	11/05-12/13	FR PS
Lexus	IS250C 2.5 (2009-2013)	06/09-12/13	FR PS
Lexus	IS-F 5.0 (2008-2013)	02/08-12/13	FR PS
Lexus	SC430 4.3 (2001-2010)	03/01-05/06	FR PS
Lexus	SC430 4.3 (2001-2010)	03/05-04/10	FR PS
LTI	TX4 2.5	10/06-04/16	FR DS
LTI	TX4 2.5	10/06-04/16	FR DS
LTI	TX4 2.5	10/06-04/16	FR PS
LTI	TX4 2.5	10/06-04/16	FR PS
LTI	TX4 2.5	10/06-04/16	FR PS
LTI	TX4 2.5	10/06-04/16	FR DS
LTI	TX4 2.5	10/06-04/16	FR DS
LTI	TX4 2.5	10/06-04/16	FR PS
LTI	TX4 2.5	10/11-04/16	FR PS
LTI	TX4 2.5	10/11-04/16	FR PS
LTI	TX4 2.5	10/11-04/16	FR DS
LTI	TX4 2.5	10/11-04/16	FR DS
LTI	TX4 2.5	10/11-04/16	FR PS
LTI	TX4 2.5	10/11-04/16	FR DS
LTI	TX4 2.8	10/15-04/18	FR PS

LTI	TX4 2.8	10/15-04/18	FR DS
LTI	TX4 2.8	10/15-04/18	FR PS
LTI	TX4 2.8	10/15-04/18	FR DS
LTI	TXI 2.7 Nissan Engine TXI	09/97-12/02	FR DS
LTI	TXI 2.7 Nissan Engine TXI	09/97-12/02	FR PS
LTI	TXI 2.7 Nissan Engine TXI	09/97-12/02	FR DS
LTI	TXI 2.7 Nissan Engine TXI	09/97-12/02	FR PS
LTI	TXII 2.4 Ford Engine TXII	01/02-12/06	FR DS
LTI	TXII 2.4 Ford Engine TXII	01/02-12/06	FR PS
LTI	TXII 2.4 Ford Engine TXII	01/02-12/06	FR DS
LTI	TXII 2.4 Ford Engine TXII	01/02-12/06	FR PS
Mazda	121 1.3 Injection (1991-1995)	02/91-12/95	FR DS
Mazda	121 1.3 Injection (1991-1995)	02/91-12/95	FR DS
Mazda	323 1.5 (1985-1989)	05/86-07/87	RR
Mazda	323 1.5 (1985-1989)	05/86-07/87	RR
Mazda	323 1.5 (1985-1989)	05/86-07/87	RR
Mazda	323 1.5 (1985-1989)	07/87-12/89	RR
Mazda	323 1.5 (1985-1989)	07/87-12/89	RR
Mazda	323 1.5 (1985-1989)	07/87-12/89	RR
Mazda	323 1.5 (1989-1994)	01/90-12/91	RR
Mazda	323 1.5 (1989-1994)	01/90-12/91	RR
Mazda	323 1.5 (1989-1994)	01/90-12/91	RR
Mazda	323 1.5 (1994-1998)	01/97-08/98	FR PS
Mazda	323 1.5 (1994-1998)	08/94-12/95	FR PS
Mazda	323 1.6 (1989-1994)	06/91-08/94	RR
Mazda	323 1.6 (1989-1994)	06/91-08/94	RR
Mazda	323F 1.3 (1994-1998)	01/97-08/98	RR
Mazda	323F 1.3 (1994-1998)	04/95-12/95	RR
Mazda	6 1.8 GG (2002-2008)	03/02-06/08	RR
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	RR
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	RR
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	RR
Mazda	6 2.0 GG (2002-2008)	03/02-08/05	RR
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	RR
Mazda	6 2.0 GG (2002-2008)	04/05-06/08	RR
Mazda	6 2.0 GG (2002-2008)	06/02-04/06	RR
Mazda	6 2.0 GG (2002-2008)	06/02-08/05	RR
Mazda	6 2.0 GG (2002-2008)	08/05-06/08	RR
Mazda	6 2.0 GG (2002-2008)	08/05-06/08	RR
Mazda	6 2.3 GG (2002-2008)	03/02-04/06	RR
Mazda	6 2.3 GG (2002-2008)	04/05-06/08	RR
Mazda	626 1.8 (1992-1997)	02/92-02/97	FR PS
Mazda	626 1.8 (1992-1997)	02/92-12/97	FR PS
Mazda	626 2.0 (1992-1997)	02/92-12/94	FR PS
Mazda	626 2.0 (1992-1997)	02/92-12/94	FR PS
Mazda	626 2.0 (1992-1997)	02/92-12/97	FR PS
Mazda	626 2.0 (1992-1997)	02/92-12/97	FR PS
Mazda	626 2.0 (1992-1997)	05/94-12/95	FR PS
Mazda	626 2.5 (1992-1997)	02/92-12/94	FR PS
Mazda	Atenza 1.8 (2002-2008)	06/02-08/08	RR

Mazda	Atenza 2.0 (2002-2008)	04/05-08/08	RR
Mazda	Atenza 2.0 (2002-2008)	06/02-04/06	RR
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	RR
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	RR
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	RR
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	RR
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	RR
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	RR
Mazda	Atenza 2.0 (2002-2008)	06/02-08/08	RR
Mazda	Atenza 2.3 (2002-2008)	04/05-08/08	RR
Mazda	Atenza 2.3 (2002-2008)	06/02-04/06	RR
Mazda	Autozam Revue 1.3	01/90-12/99	FR DS
Mazda	Autozam Revue 1.3	01/90-12/99	FR DS
Mazda	Demio 1.3 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.3 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.3 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.3 (1998-2003)	06/98-04/00	FR DS
Mazda	Demio 1.3 (1998-2003)	06/98-04/00	FR DS
Mazda	Demio 1.3 (1998-2003)	06/98-04/00	FR DS
Mazda	Demio 1.3 (1998-2003)	06/98-04/00	FR DS
Mazda	Demio 1.5 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.5 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.5 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.5 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.5 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.5 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.5 (1998-2003)	04/00-06/03	FR DS
Mazda	Demio 1.5 (1998-2003)	04/00-06/03	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/08	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR DS
Mazda	RX8 Renesis (2.6. 2616cc) SE17 (2003-2010)	07/03-12/10	FR DS
Mazda	Tribute 2.0 (2001-2005)	08/01-03/05	FR DS
Mazda	Tribute 2.0 (2001-2005)	08/01-03/05	FR DS
Mazda	Tribute 3.0 (2001-2005)	08/01-03/05	FR DS
Mazda	Tribute 3.0 (2001-2005)	08/01-03/05	FR DS
Mazda	Xedos 6 1.6	08/94-12/97	FR PS
Mazda	Xedos 6 1.6	10/93-08/94	FR PS
Mazda	Xedos 6 2.0	06/92-08/94	FR PS
Mazda	Xedos 6 2.0	06/92-08/94	FR PS
Mazda	Xedos 6 2.0	08/94-03/00	FR PS
Mazda	Xedos 6 2.0	08/94-03/00	FR PS
Mazda	Xedos 9 2.3 Miller Supercharged	10/98-12/00	FR PS
Mazda	Xedos 9 2.5	01/94-12/98	FR PS
Mercedes Benz	200 2.0 W123	01/80-10/81	FR DS
Mercedes Benz	200 2.0 W123	01/80-10/81	FR PS
Mercedes Benz	200 2.0 W123	01/80-10/81	FR PS

Mercedes Benz	200 2.0 W123	01/80-10/81	FR DS
Mercedes Benz	200 2.0 W123	01/80-10/81	FR PS
Mercedes Benz	200 2.0 W123	01/80-10/81	FR PS
Mercedes Benz	200 2.0 W123	01/80-10/81	FR DS
Mercedes Benz	200 2.0 W123	01/80-10/81	FR DS
Mercedes Benz	200T 2.0 S123	04/81-08/82	FR DS
Mercedes Benz	200T 2.0 S123	04/81-08/82	FR PS
Mercedes Benz	200T 2.0 S123	04/81-11/85	FR DS
Mercedes Benz	200T 2.0 S123	04/81-11/85	FR DS
Mercedes Benz	200T 2.0 S123	04/81-11/85	FR PS
Mercedes Benz	200T 2.0 S123	04/81-11/85	FR PS
Mercedes Benz	230 2.3 W123	01/80-12/80	FR PS
Mercedes Benz	230 2.3 W123	01/80-12/80	FR PS
Mercedes Benz	230 2.3 W123	01/80-12/80	FR DS
Mercedes Benz	230 2.3 W123	01/80-12/80	FR DS
Mercedes Benz	230C 2.3 C123	01/80-12/80	FR PS
Mercedes Benz	230C 2.3 C123	01/80-12/80	FR DS
Mercedes Benz	230C 2.3 C123	01/80-12/80	FR DS
Mercedes Benz	230C 2.3 C123	01/80-12/80	FR PS
Mercedes Benz	230CE 2.3 C123	08/82-09/85	FR PS
Mercedes Benz	230CE 2.3 C123	08/82-09/85	FR DS
Mercedes Benz	230CE 2.3 C123	10/80-08/82	FR DS
Mercedes Benz	230CE 2.3 C123	10/80-08/82	FR PS
Mercedes Benz	230CE 2.3 C123	10/80-09/85	FR DS
Mercedes Benz	230CE 2.3 C123	10/80-09/85	FR PS
Mercedes Benz	230E 2.3 W123	10/80-08/82	FR PS
Mercedes Benz	230E 2.3 W123	10/80-08/82	FR DS
Mercedes Benz	230E 2.3 W123	10/80-09/85	FR PS
Mercedes Benz	230E 2.3 W123	10/80-09/85	FR DS
Mercedes Benz	230E 2.3 W123	10/80-09/85	FR DS
Mercedes Benz	230E 2.3 W123	10/80-09/85	FR PS
Mercedes Benz	230TE 2.3 S123	10/80-04/86	FR DS
Mercedes Benz	230TE 2.3 S123	10/80-04/86	FR PS
Mercedes Benz	230TE 2.3 S123	10/80-04/86	FR DS
Mercedes Benz	230TE 2.3 S123	10/80-04/86	FR PS
Mercedes Benz	230TE 2.3 S123	10/80-08/82	FR PS
Mercedes Benz	230TE 2.3 S123	10/80-08/82	FR DS
Mercedes Benz	250 2.5 W123	01/80-08/82	FR DS
Mercedes Benz	250 2.5 W123	01/80-08/82	FR PS
Mercedes Benz	250 2.5 W123	01/80-12/85	FR DS
Mercedes Benz	250 2.5 W123	01/80-12/85	FR PS
Mercedes Benz	250 2.5 W123	01/80-12/85	FR PS
Mercedes Benz	250 2.5 W123	01/80-12/85	FR DS
Mercedes Benz	Citan 108 1.5 CDI W415	12/12-04/16	FR PS
Mercedes Benz	Citan 108 1.5 CDI W415	12/12-04/16	FR PS
Mercedes Benz	Citan 108 1.5 CDI W415	12/12-04/16	FR PS
Mercedes Benz	Citan 109 1.5 CDI W415	07/19-09/21	FR PS
Mercedes Benz	Citan 109 1.5 CDI W415	12/12-04/20	FR PS
Mercedes Benz	Citan 109 1.5 CDI W415	12/12-04/20	FR PS
Mercedes Benz	Citan 109 1.5 CDI W415	12/12-04/20	FR PS



Mercedes Benz	Citan 111 1.5 CDI W415	06/13-04/20	FR PS
Mercedes Benz	Citan 111 1.5 CDI W415	06/13-04/20	FR PS
Mercedes Benz	Citan 111 1.5 CDI W415	06/13-04/20	FR PS
Mercedes Benz	Citan 111 1.5 CDI W415	07/19-09/21	FR PS
Mercedes Benz	Citan 112 1.2 W415	06/13-04/16	FR PS
Mitsubishi	3000 GT 3.0 (1992-1999)	07/96-10/99	FR PS
Mitsubishi	3000 GT 3.0 (1992-1999)	08/92-10/99	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	08/96-10/97	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	08/96-10/97	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	10/95-10/97	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	10/95-10/97	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.6 (1999-2005)	08/99-04/05	FR PS
Mitsubishi	Carisma 1.6 (1999-2005)	08/99-04/05	FR PS
Mitsubishi	Carisma 1.6 (1999-2005)	08/99-12/01	FR PS
Mitsubishi	Carisma 1.6 (1999-2005)	08/99-12/01	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	08/96-10/97	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	08/96-10/97	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	10/95-10/97	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	10/95-10/97	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR PS
Mitsubishi	Carisma 1.8 (1999-2005)	08/99-05/03	FR PS
Mitsubishi	Carisma 1.8 (1999-2005)	08/99-05/03	FR PS
Mitsubishi	Carisma 1.8 (1999-2005)	08/99-08/01	FR PS
Mitsubishi	Carisma 1.8 (1999-2005)	08/99-08/01	FR PS
Mitsubishi	Carisma 1.9 (1995-1999)	04/97-07/99	FR PS
Mitsubishi	Carisma 1.9 (1995-1999)	04/97-07/99	FR PS
Mitsubishi	Carisma 1.9 (1999-2005)	07/99-05/02	FR PS
Mitsubishi	Carisma 1.9 DI-D (1999-2005)	05/02-04/05	FR PS
Mitsubishi	Carisma 2.0 Evolution VI (1999-2005)	06/99-12/01	FR PS
Mitsubishi	Challenger 2.8	03/00-12/05	FR DS
Mitsubishi	Challenger 2.8	03/00-12/05	FR PS
Mitsubishi	Challenger 2.8 TD	07/96-03/00	FR DS
Mitsubishi	Challenger 2.8 TD	07/96-03/00	FR PS
Mitsubishi	Challenger 3.0 (1998-2000)	11/98-03/00	FR PS
Mitsubishi	Challenger 3.0 (1998-2000)	11/98-03/00	FR DS
Mitsubishi	Colt Mirage 1.3 (1992-1995)	04/92-03/96	FR DS
Mitsubishi	Colt Mirage 1.6 (1992-1995)	04/92-04/96	FR DS
Mitsubishi	Colt Mirage 1.6 (1992-1995)	04/92-04/96	FR DS
Mitsubishi	Colt Mirage 1.8 (1992-1995)	04/92-12/95	FR DS
Mitsubishi	Eclipse Cross 1.5 (2017-2021)	12/17-12/21	FR PS
Mitsubishi	Eclipse Cross 1.5 (2017-2021)	12/17-12/21	FR PS
Mitsubishi	Eclipse Cross 1.5 (2017-2021)	12/17-12/21	FR PS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/94-12/02	FR DS

Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/94-12/97	FR DS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/97-12/02	FR DS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/99-05/02	FR DS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/99-05/02	FR DS
Mitsubishi	Galant 1.8 (1993-1997)	03/93-08/96	RR
Mitsubishi	Galant 1.8 (1993-1997)	03/93-08/96	RR
Mitsubishi	Galant 2.0 (1993-1997)	03/93-12/96	RR
Mitsubishi	Galant 2.0 (1993-1997)	03/93-12/96	RR
Mitsubishi	Lancer 1.3	01/03-12/07	FR DS
Mitsubishi	Lancer 1.6 (1992-1995)	10/92-01/96	FR DS
Mitsubishi	Lancer 1.6 (1992-1995)	10/92-01/96	FR DS
Mitsubishi	Lancer 1.6 (1999-2001)	12/99-12/01	FR DS
Mitsubishi	Lancer 1.6 (2004-2008)	12/04-12/08	FR DS
Mitsubishi	Lancer 1.6 (2004-2008)	12/04-12/08	FR DS
Mitsubishi	Lancer 1.6 (2004-2008)	12/04-12/08	FR DS
Mitsubishi	Lancer 1.6 (2004-2008)	12/04-12/08	FR DS
Mitsubishi	Lancer 1.8 GTi (1992-1995)	10/92-09/95	FR DS
Mitsubishi	Lancer 2.0 260 Evolution VIII	02/04-07/05	FR DS
Mitsubishi	Lancer 2.0 Evolution II	01/94-02/95	FR DS
Mitsubishi	Lancer 2.0 Evolution III	02/95-08/96	FR DS
Mitsubishi	Lancer 2.0 Evolution V	01/98-01/00	FR DS
Mitsubishi	Lancer 2.0 Sport (2004-2008)	07/06-12/08	FR DS
Mitsubishi	Lancer 2.0 Sport (2004-2008)	07/06-12/08	FR DS
Mitsubishi	Lancer 2.0 Sport (2004-2008)	12/04-12/08	FR DS
Mitsubishi	Lancer 2.0 Sport (2004-2008)	12/04-12/08	FR DS
Mitsubishi	Pajero 2.5	01/00-12/07	FR PS
Mitsubishi	Pajero 2.5	01/00-12/07	FR DS
Mitsubishi	Pajero 2.5	01/00-12/07	FR PS
Mitsubishi	Pajero 2.5	01/00-12/07	FR DS
Mitsubishi	Pajero 3.2 (2007-2010)	03/07-12/10	FR DS
Mitsubishi	Pajero 3.2 (2007-2010)	03/07-12/10	FR DS
Mitsubishi	Pajero 3.2 (2007-2010)	03/07-12/10	FR DS
Mitsubishi	Pajero 3.2 (2007-2010)	03/07-12/10	FR DS
Mitsubishi	Pajero 3.2 (2007-2010)	03/07-12/10	FR PS
Mitsubishi	Pajero 3.2 (2007-2010)	03/07-12/10	FR PS
Mitsubishi	Pajero 3.2 (2007-2010)	03/07-12/10	FR PS
Mitsubishi	Pajero 3.2 (2007-2010)	03/07-12/10	FR PS
Mitsubishi	Pajero 3.2 TD	01/99-12/01	FR DS
Mitsubishi	Pajero 3.2 TD	01/99-12/01	FR PS
Mitsubishi	Pajero 3.2 TD	01/99-12/01	FR DS
Mitsubishi	Pajero 3.2 TD	01/99-12/01	FR PS
Mitsubishi	Pajero 3.2 TD	01/99-12/01	FR PS
Mitsubishi	Pajero 3.2 TD	01/99-12/01	FR DS
Mitsubishi	Pajero 3.2 TD	01/99-12/01	FR DS
Mitsubishi	Pajero 3.2 TD	01/99-12/01	FR PS
Mitsubishi	Pajero 3.2 TD	06/01-12/07	FR DS
Mitsubishi	Pajero 3.2 TD	06/01-12/07	FR PS
Mitsubishi	Pajero 3.2 TD	06/01-12/07	FR DS
Mitsubishi	Pajero 3.2 TD	06/01-12/07	FR PS
Mitsubishi	Pajero 3.2 TD	06/01-12/07	FR PS



Mitsubishi	Shogun 3.2 4Work (2006-2019)	11/06-12/10	FR PS
Mitsubishi	Shogun 3.2 4Work (2006-2019)	11/06-12/10	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	04/00-05/07	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	04/00-05/07	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	04/00-05/07	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	04/00-05/07	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	04/00-05/07	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	04/00-05/07	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	04/00-05/07	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	04/00-05/07	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	10/01-03/04	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	10/01-03/04	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	10/01-03/04	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	10/01-03/04	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	12/01-05/07	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	12/01-05/07	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	12/01-05/07	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	12/01-05/07	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	12/01-05/07	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	12/01-05/07	FR PS
Mitsubishi	Shogun 3.5 (2000-2007)	12/01-05/07	FR DS
Mitsubishi	Shogun 3.5 (2000-2007)	12/01-05/07	FR DS
Mitsubishi	Shogun Sport 2.4 (2018-2021)	01/18-12/21	FR PS
Mitsubishi	Shogun Sport 2.5 (1999-2008)	03/99-10/01	FR PS
Mitsubishi	Shogun Sport 2.5 (1999-2008)	03/99-10/01	FR DS
Mitsubishi	Shogun Sport 2.5 (1999-2008)	10/01-05/08	FR PS
Mitsubishi	Shogun Sport 2.5 (1999-2008)	10/01-05/08	FR DS
Mitsubishi	Shogun Sport 3.0 (1999-2008)	03/00-10/01	FR PS
Mitsubishi	Shogun Sport 3.0 (1999-2008)	03/00-10/01	FR DS
Mitsubishi	Shogun Sport 3.0 (1999-2008)	03/00-10/01	FR DS
Mitsubishi	Shogun Sport 3.0 (1999-2008)	03/00-10/01	FR PS
Mitsubishi	Shogun Sport 3.0 (1999-2008)	10/01-03/08	FR DS
Mitsubishi	Shogun Sport 3.0 (1999-2008)	10/01-03/08	FR DS
Mitsubishi	Shogun Sport 3.0 (1999-2008)	10/01-03/08	FR PS
Mitsubishi	Shogun Sport 3.0 (1999-2008)	10/01-03/08	FR PS
Mitsubishi	Shogun Sport Commercial 2.4 (2018-2021)	11/18-12/21	FR PS
Nissan	200SX 1.8 Catalyst S13	01/92-09/94	FR DS
Nissan	200SX 1.8 Catalyst S13	01/92-09/94	FR PS
Nissan	200SX 1.8 Catalyst S13	01/92-09/94	FR PS
Nissan	200SX 1.8 Catalyst S13	01/92-09/94	FR DS
Nissan	200SX 1.8 Non Catalyst S13	04/89-01/92	FR DS
Nissan	200SX 1.8 Non Catalyst S13	04/89-01/92	FR PS
Nissan	200SX 1.8 Non Catalyst S13	04/89-01/92	FR PS
Nissan	200SX 1.8 Non Catalyst S13	04/89-01/92	FR DS
Nissan	200SX 2.0 S14	09/94-07/01	FR PS
Nissan	200SX 2.0 S14	09/94-07/01	FR PS
Nissan	350Z 3.5 Gran Turismo 4 Z33	02/05-12/05	FR DS
Nissan	350Z 3.5 Roadster Z33	01/05-12/05	FR DS
Nissan	350Z 3.5 Roadster Z33	05/07-12/09	FR DS
Nissan	350Z 3.5 Roadster Z33	05/07-12/09	FR DS

Nissan	350Z 3.5 Roadster Z33	12/05-09/07	FR DS
Nissan	350Z 3.5 Z33	05/07-12/09	FR DS
Nissan	350Z 3.5 Z33	05/07-12/09	FR DS
Nissan	350Z 3.5 Z33	09/03-12/05	FR DS
Nissan	350Z 3.5 Z33	12/05-09/07	FR DS
Nissan	Bluebird 2.0 U11	03/86-09/90	RR
Nissan	Bluebird 2.0 U11	03/86-09/90	RR
Nissan	Bluebird 2.0 U11	05/84-03/86	RR
Nissan	Bluebird 2.0 U11	05/84-03/86	RR
Nissan	Cabstar 2.5 (2007-2014)	01/07-04/12	FR DS
Nissan	Cabstar 2.5 (2007-2014)	01/07-04/12	FR DS
Nissan	Cabstar 2.5 (2007-2014)	01/07-04/12	FR PS
Nissan	Cabstar 2.5 (2007-2014)	01/07-04/12	FR PS
Nissan	Cabstar 2.5 dCi (2007-2014)	12/11-12/14	FR PS
Nissan	Cabstar 2.5 dCi (2007-2014)	12/11-12/14	FR PS
Nissan	Cabstar 2.5 dCi (2007-2014)	12/11-12/14	FR DS
Nissan	Cabstar 2.5 dCi (2007-2014)	12/11-12/14	FR DS
Nissan	Cabstar 3.0 (2007-2014)	01/07-04/12	FR PS
Nissan	Cabstar 3.0 (2007-2014)	01/07-04/12	FR DS
Nissan	Cabstar 3.0 dCi (2007-2014)	12/11-12/14	FR PS
Nissan	Cabstar 3.0 dCi (2007-2014)	12/11-12/14	FR DS
Nissan	Cube 1.5 Z12	10/09-04/15	FR DS
Nissan	Cube 1.5 Z12	10/09-04/15	FR PS
Nissan	Cube 1.5 Z12	10/09-04/15	FR PS
Nissan	Cube 1.5 Z12	10/09-04/15	FR DS
Nissan	Cube 1.6 Z12	10/09-06/11	FR DS
Nissan	Cube 1.6 Z12	10/09-06/11	FR PS
Nissan	Cube 1.6 Z12	10/09-06/11	FR PS
Nissan	Cube 1.6 Z12	10/09-06/11	FR DS
Nissan	Kubistar 1.2 X76	10/03-12/05	FR DS
Nissan	Kubistar 1.2 X76	10/03-12/05	FR PS
Nissan	Kubistar 1.2 X76	10/03-12/05	FR DS
Nissan	Kubistar 1.2 X76	10/03-12/05	FR DS
Nissan	Kubistar 1.2 X76	10/03-12/05	FR PS
Nissan	Kubistar 1.2 X76	10/03-12/05	FR PS
Nissan	Kubistar 1.5 dCi 60 X76	04/06-03/10	FR PS
Nissan	Kubistar 1.5 dCi 60 X76	04/06-03/10	FR DS
Nissan	Kubistar 1.5 dCi 60 X76	04/06-03/10	FR DS
Nissan	Kubistar 1.5 dCi 60 X76	04/06-03/10	FR PS
Nissan	Kubistar 1.5 dCi 60 X76	10/03-08/06	FR PS
Nissan	Kubistar 1.5 dCi 60 X76	10/03-08/06	FR PS
Nissan	Kubistar 1.5 dCi 60 X76	10/03-08/06	FR DS
Nissan	Kubistar 1.5 dCi 60 X76	10/03-08/06	FR PS
Nissan	Kubistar 1.5 dCi 60 X76	10/03-08/06	FR DS
Nissan	Kubistar 1.5 dCi 60 X76	10/03-08/06	FR DS
Nissan	Kubistar 1.5 dCi 65 X76	10/03-12/07	FR DS
Nissan	Kubistar 1.5 dCi 65 X76	10/03-12/07	FR PS
Nissan	Kubistar 1.5 dCi 65 X76	10/03-12/07	FR PS
Nissan	Kubistar 1.5 dCi 65 X76	10/03-12/07	FR PS
Nissan	Kubistar 1.5 dCi 65 X76	10/03-12/07	FR DS

Nissan	Kubistar 1.5 dCi 65 X76	10/03-12/07	FR DS
Nissan	Kubistar 1.5 dCi 70 X76	04/06-03/10	FR PS
Nissan	Kubistar 1.5 dCi 70 X76	04/06-03/10	FR PS
Nissan	Kubistar 1.5 dCi 70 X76	04/06-03/10	FR DS
Nissan	Kubistar 1.5 dCi 70 X76	04/06-03/10	FR DS
Nissan	Kubistar 1.5 dCi 70 X76	04/06-03/10	FR PS
Nissan	Kubistar 1.5 dCi 70 X76	04/06-03/10	FR DS
Nissan	Kubistar 1.5 dCi 80 X76	04/06-03/10	FR PS
Nissan	Kubistar 1.5 dCi 80 X76	04/06-03/10	FR DS
Nissan	Kubistar 1.5 dCi 80 X76	04/06-03/10	FR PS
Nissan	Kubistar 1.5 dCi 80 X76	04/06-03/10	FR DS
Nissan	Kubistar 1.5 dCi 80 X76	10/03-08/06	FR DS
Nissan	Kubistar 1.5 dCi 80 X76	10/03-08/06	FR PS
Nissan	Kubistar 1.5 dCi 80 X76	10/03-08/06	FR PS
Nissan	Kubistar 1.5 dCi 80 X76	10/03-08/06	FR DS
Nissan	Maxima 3.0 A31	06/89-07/94	FR PS
Nissan	Micra 1.0 K11	07/00-12/03	FR DS
Nissan	Micra 1.0 K11	07/00-12/03	FR DS
Nissan	Micra 1.0 K11	07/00-12/03	FR DS
Nissan	Micra 1.0 K11	07/00-12/03	FR DS
Nissan	Micra 1.4 K11	07/00-12/03	FR DS
Nissan	Micra 1.4 K11	07/00-12/03	FR DS
Nissan	Micra 1.4 K11	07/00-12/03	FR DS
Nissan	Micra 1.4 K11	07/00-12/03	FR DS
Nissan	NT400 Cabstar 2.5 (2014-2020)	01/14-09/17	FR DS
Nissan	NT400 Cabstar 2.5 (2014-2020)	01/14-09/17	FR PS
Nissan	NT400 Cabstar 2.5 (2014-2020)	01/14-09/17	FR DS
Nissan	NT400 Cabstar 2.5 (2014-2020)	01/14-09/17	FR PS
Nissan	NT400 Cabstar 2.5 (2014-2020)	01/14-09/17	FR PS
Nissan	NT400 Cabstar 2.5 (2014-2020)	01/14-09/17	FR DS
Nissan	NT400 Cabstar 3.0 (2014-2020)	09/16-12/20	FR PS
Nissan	NT400 Cabstar 3.0 (2014-2020)	09/16-12/20	FR DS
Nissan	Patrol 2.8 Y61	03/98-06/00	FR DS
Nissan	Patrol 2.8 Y61	03/98-06/00	FR DS
Nissan	Patrol 3.0 Y61	05/00-12/04	FR DS
Nissan	Patrol 3.0 Y61	05/00-12/04	FR DS
Nissan	Patrol 3.0 Y61	05/00-12/04	FR DS
Nissan	Patrol 3.0 Y61	05/00-12/04	FR DS
Nissan	Patrol 3.0 Y61	10/04-08/10	FR DS
Nissan	Patrol 3.0 Y61	10/04-08/10	FR DS
Nissan	Primera 1.6 P11	10/96-09/99	FR PS
Nissan	Primera 1.6 P11	10/96-09/99	FR PS
Nissan	Primera 1.6 P11-144	09/99-05/02	FR PS
Nissan	Primera 1.6 P11-144	09/99-05/02	FR PS
Nissan	Primera 1.6 W11	04/98-09/99	FR PS
Nissan	Primera 1.6 W11	09/99-05/02	FR PS
Nissan	Primera 1.8 Dual Fuel P11-144	10/00-05/02	FR PS
Nissan	Primera 1.8 P11-144	09/99-05/02	FR PS
Nissan	Primera 1.8 P11-144	09/99-05/02	FR PS
Nissan	Primera 1.8 W11	09/99-05/02	FR PS

Nissan	Primera 2.0 Dual Fuel P11	03/99-09/99	FR PS
Nissan	Primera 2.0 Dual Fuel P11	03/99-09/99	FR PS
Nissan	Primera 2.0 Dual Fuel P11	03/99-09/99	FR PS
Nissan	Primera 2.0 GT P11	05/97-09/99	FR PS
Nissan	Primera 2.0 GT P11	05/97-09/99	FR PS
Nissan	Primera 2.0 P11	10/96-09/99	FR PS
Nissan	Primera 2.0 P11	10/96-09/99	FR PS
Nissan	Primera 2.0 P11	10/96-09/99	FR PS
Nissan	Primera 2.0 P11	10/96-09/99	FR PS
Nissan	Primera 2.0 P11	10/96-09/99	FR PS
Nissan	Primera 2.0 P11	10/96-09/99	FR PS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR PS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR PS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR PS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR PS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR PS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR PS
Nissan	Primera 2.0 W11	04/98-09/99	FR PS
Nissan	Primera 2.0 W11	04/98-09/99	FR PS
Nissan	Primera 2.0 W11	04/98-09/99	FR PS
Nissan	Primera 2.0 W11	09/99-05/02	FR PS
Nissan	Primera 2.0 W11	09/99-05/02	FR PS
Nissan	Primera 2.0 W11	09/99-05/02	FR PS
Nissan	Sunny 1.4 MPi N14	02/93-10/95	RR
Nissan	Sunny 1.4 MPi N14	02/93-10/95	RR
Nissan	Sunny 1.4 N14	12/91-02/93	RR
Nissan	Sunny 1.4 N14	12/91-02/93	RR
Nissan	Sunny 1.6 MPi N14	02/93-10/95	RR
Nissan	Sunny 1.6 MPi N14	02/93-10/95	RR
Nissan	Sunny 1.6 MPi N14	02/93-10/95	RR
Nissan	Sunny 1.6 MPi N14	02/93-10/95	RR
Nissan	Sunny 1.6 SPi N14	12/91-02/93	RR
Nissan	Sunny 1.6 SPi N14	12/91-02/93	RR
Nissan	Sunny 2.0 e GTi N14	01/92-08/94	RR
Nissan	Sunny 2.0 GTi-R N14	04/92-12/93	RR
Nissan	Sunny 2.0 N14	02/93-10/95	RR
Nissan	Terrano 2.7 R50	09/95-02/99	FR PS
Nissan	Terrano 2.7 R50	09/95-02/99	FR PS
Nissan	Terrano 2.7 R50	09/95-02/99	FR PS
Nissan	Terrano 2.7 R50	09/95-02/99	FR PS
Nissan	Terrano 3.0 R50	02/99-12/04	FR PS
Nissan	Terrano 3.0 R50	02/99-12/04	FR PS
Nissan	Terrano 3.0 R50	02/99-12/04	FR PS
Nissan	Terrano 3.0 R50	02/99-12/04	FR PS
Nissan	Terrano 3.3 R50	02/99-12/04	FR PS
Nissan	Terrano 3.3 R50	02/99-12/04	FR PS
Nissan	Terrano 3.3 R50	02/99-12/04	FR PS
Nissan	Terrano 3.3 R50	02/99-12/04	FR PS
Nissan	Terrano 3.3 R50	02/99-12/04	FR PS
Nissan	Terrano II 2.4 R20	07/93-10/96	FR PS
Nissan	Terrano II 2.4 R20	07/96-12/99	FR PS

Nissan	Terrano II 2.4 R20	07/96-12/99	FR PS
Nissan	Terrano II 2.4 R20	12/99-12/01	FR PS
Nissan	Terrano II 2.4 R20	12/99-12/01	FR PS
Nissan	Terrano II 2.7 R20	01/00-12/02	FR PS
Nissan	Terrano II 2.7 R20	01/00-12/06	FR PS
Nissan	Terrano II 2.7 R20	01/00-12/06	FR PS
Nissan	Terrano II 2.7 R20	06/96-01/00	FR PS
Nissan	Terrano II 2.7 R20	07/93-10/96	FR PS
Nissan	Terrano II 2.7 R20	07/93-10/96	FR PS
Nissan	Terrano II 2.7 R20	07/96-01/00	FR PS
Nissan	Terrano II 2.7 R20	07/96-01/00	FR PS
Nissan	Terrano II 2.7 R20	09/98-12/06	FR PS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR PS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR PS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR PS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR PS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR PS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR PS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR PS
Nissan	Terrano Regulus 3.0 R50	01/99-12/01	FR PS
Nissan	Terrano Regulus 3.0 R50	01/99-12/01	FR PS
Nissan	Terrano Regulus 3.0 R50	01/99-12/01	FR PS
Nissan	Terrano Regulus 3.0 R50	01/99-12/01	FR PS
Nissan	Tino 1.8 V10	03/03-03/06	RR
Nissan	Tino 1.8 V10	07/00-03/06	RR
Nissan	Tino 2.0 V10	07/00-05/03	RR
Nissan	Tino 2.2 dCi V10	05/03-03/06	RR
Nissan	Tino 2.2 dCi V10	05/03-03/06	RR
Nissan	Tino 2.2 V10	07/00-05/03	RR
Opel	Astra G 1.4 Dual Fuel MK 4 (1998-2006)	09/99-06/03	FR DS
Opel	Astra G 1.4 Dual Fuel MK 4 (1998-2006)	09/99-06/03	FR DS
Opel	Astra G 1.4 MK 4 (1998-2006)	02/98-03/05	FR DS
Opel	Astra G 1.4 MK 4 (1998-2006)	02/98-03/05	FR DS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	02/98-12/00	FR DS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	02/98-12/00	FR DS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/00-12/03	FR DS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/00-12/03	FR DS
Opel	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/99-08/04	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-09/00	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	02/98-09/00	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	09/00-03/05	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	09/00-03/05	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	10/03-08/04	FR DS
Opel	Astra G 1.6 MK 4 (1998-2006)	10/03-08/04	FR DS
Opel	Astra G 1.7 CDTi MK 4 (1998-2006)	06/03-03/05	FR DS
Opel	Astra G 1.7 DTi MK 4 (1998-2006)	01/00-03/05	FR DS



Opel	Astra G 1.7 TD MK 4 (1998-2006)	02/98-01/00	FR DS
Opel	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR DS
Opel	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR DS
Opel	Astra G 1.8 MK 4 (1998-2006)	09/00-03/05	FR DS
Opel	Astra G 1.8 MK 4 (1998-2006)	09/00-03/05	FR DS
Opel	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-03/05	FR DS
Opel	Astra G 2.2 MK 4 (1998-2006)	06/02-03/05	FR DS
Opel	Astra G 2.2 MK 4 (1998-2006)	06/02-03/05	FR DS
Opel	Insignia Grand Sport 1.5 122 (2017-2022)	10/20-12/22	FR PS
Opel	Insignia Grand Sport 1.5 122 (2017-2022)	10/20-12/22	FR PS
Opel	Insignia Grand Sport 1.5 140 (2017-2022)	02/17-12/18	FR PS
Opel	Insignia Grand Sport 1.5 140 (2017-2022)	02/17-12/18	FR PS
Opel	Insignia Grand Sport 1.5 140 (2017-2022)	06/18-04/19	FR PS
Opel	Insignia Grand Sport 1.5 165 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Grand Sport 1.5 165 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Grand Sport 1.5 165 (2017-2022)	06/18-09/21	FR PS
Opel	Insignia Grand Sport 1.5 165 (2017-2022)	06/18-09/21	FR PS
Opel	Insignia Grand Sport 1.5 165 (2017-2022)	06/18-09/21	FR PS
Opel	Insignia Grand Sport 1.6 200 (2017-2022)	08/18-04/20	FR PS
Opel	Insignia Grand Sport 1.6 Turbo D 110 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Grand Sport 1.6 Turbo D 110 (2017-2022)	06/18-09/21	FR PS
Opel	Insignia Grand Sport 1.6 Turbo D 110 (2017-2022)	06/18-09/21	FR PS
Opel	Insignia Grand Sport 1.6 Turbo D 136 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Grand Sport 1.6 Turbo D 136 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Grand Sport 1.6 Turbo D 136 (2017-2022)	04/18-09/21	FR PS
Opel	Insignia Grand Sport 1.6 Turbo D 136 (2017-2022)	04/18-09/21	FR PS
Opel	Insignia Grand Sport 2.0 200 (2017-2022)	10/20-12/22	FR PS
Opel	Insignia Grand Sport 2.0 230 (2017-2022)	10/20-12/22	FR PS
Opel	Insignia Grand Sport 2.0 260 (2017-2022)	02/17-12/18	FR PS
Opel	Insignia Grand Sport 2.0 Turbo D 170 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Grand Sport 2.0 Turbo D 170 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Grand Sport 2.0 Turbo D 170 (2017-2022)	06/18-09/21	FR PS
Opel	Insignia Grand Sport 2.0 Turbo D 170 (2017-2022)	06/18-09/21	FR PS
Opel	Insignia Grand Sport 2.0 Turbo D 174 (2017-2022)	10/20-12/22	FR PS
Opel	Insignia Grand Sport 2.0 Turbo D 174 (2017-2022)	10/20-12/22	FR PS
Opel	Insignia Grand Sport 2.0 Turbo D 210 (2017-2022)	09/17-04/21	FR PS
Opel	Insignia Sports Tourer 1.5 140 (2017-2022)	02/17-04/20	FR PS
Opel	Insignia Sports Tourer 1.5 165 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Sports Tourer 1.5 165 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Sports Tourer 1.5 165 (2017-2022)	06/18-04/20	FR PS
Opel	Insignia Sports Tourer 1.5 165 (2017-2022)	06/18-04/20	FR PS
Opel	Insignia Sports Tourer 1.5 165 (2017-2022)	06/18-04/20	FR PS
Opel	Insignia Sports Tourer 1.5 165 (2017-2022)	06/18-04/20	FR PS
Opel	Insignia Sports Tourer 1.6 Turbo D 110 (2017-2022)	02/17-04/20	FR PS
Opel	Insignia Sports Tourer 1.6 Turbo D 110 (2017-2022)	08/18-04/20	FR PS
Opel	Insignia Sports Tourer 1.6 Turbo D 110 (2017-2022)	10/18-04/20	FR PS
Opel	Insignia Sports Tourer 1.6 Turbo D 136 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Sports Tourer 1.6 Turbo D 136 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Sports Tourer 1.6 Turbo D 136 (2017-2022)	04/18-04/20	FR PS
Opel	Insignia Sports Tourer 1.6 Turbo D 136 (2017-2022)	04/18-04/20	FR PS

Opel	Insignia Sports Tourer 2.0 260 (2017-2022)	02/17-04/19	FR PS
Opel	Insignia Sports Tourer 2.0 Turbo D 170 (2017-2022)	02/17-04/20	FR PS
Opel	Insignia Sports Tourer 2.0 Turbo D 170 (2017-2022)	02/17-04/20	FR PS
Opel	Insignia Sports Tourer 2.0 Turbo D 170 (2017-2022)	06/18-04/20	FR PS
Opel	Insignia Sports Tourer 2.0 Turbo D 170 (2017-2022)	06/18-04/20	FR PS
Opel	Insignia Sports Tourer 2.0 Turbo D 210 (2017-2022)	09/17-04/20	FR PS
Opel	Monterey 3.1	05/94-03/99	FR DS
Opel	Monterey 3.1	05/94-03/99	FR DS
Opel	Monterey 3.1	05/94-03/99	FR PS
Opel	Monterey 3.1	05/94-03/99	FR PS
Peugeot	106 1.0 (1991-1996)	09/91-12/92	FR DS
Peugeot	106 1.0 (1991-1996)	12/92-06/96	FR DS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.1 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.1 Carburettor (1991-1996)	09/91-08/92	FR DS
Peugeot	106 1.1 Carburettor (1991-1996)	09/91-08/92	FR DS
Peugeot	106 1.1 Carburettor (1991-1996)	09/91-08/92	FR DS
Peugeot	106 1.1 Carburettor (1991-1996)	09/91-08/92	FR DS
Peugeot	106 1.1 Injection (1991-1996)	09/91-06/96	FR DS
Peugeot	106 1.1 Injection (1991-1996)	09/91-06/96	FR DS
Peugeot	106 1.1 Injection (1991-1996)	09/91-06/96	FR DS
Peugeot	106 1.1 Injection (1991-1996)	09/91-06/96	FR DS
Peugeot	106 1.3 (1991-1996)	01/94-06/96	FR DS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.4 (1996-2003)	06/96-03/03	FR DS
Peugeot	106 1.4 Carburettor (1991-1996)	09/91-08/92	FR DS
Peugeot	106 1.4 Carburettor (1991-1996)	09/91-08/92	FR DS
Peugeot	106 1.4 Carburettor (1991-1996)	09/91-08/92	FR DS
Peugeot	106 1.4 Carburettor (1991-1996)	09/91-08/92	FR DS
Peugeot	106 1.4 Injection (1991-1996)	09/91-06/96	FR DS
Peugeot	106 1.4 Injection (1991-1996)	09/91-06/96	FR DS
Peugeot	106 1.4 Injection (1991-1996)	09/91-06/96	FR DS
Peugeot	106 1.4 Injection (1991-1996)	09/91-06/96	FR DS
Peugeot	106 1.4 XSi (1991-1996)	09/91-07/94	FR DS
Peugeot	106 1.5 (1991-1996)	06/94-06/96	FR DS
Peugeot	106 1.5 (1991-1996)	06/94-06/96	FR DS
Peugeot	106 1.5 (1991-1996)	06/94-06/96	FR DS
Peugeot	106 1.5 (1991-1996)	06/94-06/96	FR DS
Peugeot	106 1.5 (1996-2003)	06/96-05/99	FR DS
Peugeot	106 1.5 (1996-2003)	06/96-05/99	FR DS
Peugeot	106 1.5 (1996-2003)	06/96-05/99	FR DS
Peugeot	106 1.5 (1996-2003)	06/96-10/00	FR DS

Peugeot	106 1.5 (1996-2003)	06/96-10/00	FR DS
Peugeot	106 1.5 (1996-2003)	06/96-10/00	FR DS
Peugeot	106 1.5 (1996-2003)	06/96-10/00	FR DS
Peugeot	106 1.5 (1996-2003)	10/00-03/03	FR DS
Peugeot	106 1.5 (1996-2003)	10/00-03/03	FR DS
Peugeot	106 1.5 (1996-2003)	10/00-03/03	FR DS
Peugeot	106 1.5 (1996-2003)	10/00-03/03	FR DS
Peugeot	106 1.6 (1991-1996)	08/94-06/96	FR DS
Peugeot	106 1.6 (1991-1996)	08/94-06/96	FR DS
Peugeot	106 1.6 (1996-2003)	06/96-05/99	FR DS
Peugeot	106 1.6 (1996-2003)	06/96-05/99	FR DS
Peugeot	106 1.6 (1996-2003)	06/96-05/99	FR DS
Peugeot	106 1.6 (1996-2003)	06/96-05/99	FR DS
Peugeot	106 1.6 GTi (1996-2003)	01/97-03/03	FR DS
Peugeot	106 1.6 GTi (1996-2003)	01/97-03/03	FR DS
Peugeot	306 1.4 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.4 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.4 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.4 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.4 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.4 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.4 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.4 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.4 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.4 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.4 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.4 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.4 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.4 (1993-2003)	06/95-12/96	FR PS
Peugeot	306 1.4 (1993-2003)	06/95-12/96	FR PS
Peugeot	306 1.4 (1993-2003)	06/95-12/96	RR
Peugeot	306 1.4 (1993-2003)	06/95-12/96	RR
Peugeot	306 1.4 (1993-2003)	06/95-12/96	FR PS
Peugeot	306 1.4 (1993-2003)	06/95-12/96	RR
Peugeot	306 1.4 (1993-2003)	10/97-12/01	FR PS
Peugeot	306 1.4 (1993-2003)	10/97-12/01	FR PS
Peugeot	306 1.6 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.6 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.6 (1993-2003)	04/93-06/97	FR PS
Peugeot	306 1.6 (1993-2003)	04/97-06/99	FR PS
Peugeot	306 1.6 (1993-2003)	04/97-06/99	RR
Peugeot	306 1.6 (1993-2003)	04/97-10/00	FR PS
Peugeot	306 1.6 (1993-2003)	04/97-10/00	FR PS
Peugeot	306 1.6 (1993-2003)	04/97-10/00	FR PS
Peugeot	306 1.6 (1993-2003)	10/00-12/01	FR PS
Peugeot	306 1.6 (1993-2003)	10/00-12/01	FR PS
Peugeot	306 1.6 (1993-2003)	10/00-12/01	FR PS
Peugeot	306 1.6 (1993-2003)	10/00-12/01	FR PS
Peugeot	306 1.6 (1993-2003)	10/00-12/01	FR PS
Peugeot	306 1.6 (1993-2003)	10/94-06/97	RR
Peugeot	306 1.6 (1993-2003)	10/94-06/97	FR PS
Peugeot	306 1.6 (1993-2003)	10/97-10/00	FR PS

Peugeot	306 1.6 (1993-2003)	10/97-10/00	FR PS
Peugeot	306 1.6 (1993-2003)	12/00-03/03	FR PS
Peugeot	306 1.6 (1993-2003)	12/00-03/03	FR PS
Peugeot	306 1.8 (1993-2003)	02/98-12/01	FR PS
Peugeot	306 1.8 (1993-2003)	04/93-12/98	FR PS
Peugeot	306 1.8 (1993-2003)	04/93-12/98	FR PS
Peugeot	306 1.8 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.8 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.8 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.8 (1993-2003)	04/97-12/01	FR PS
Peugeot	306 1.8 (1993-2003)	04/99-03/03	FR PS
Peugeot	306 1.8 (1993-2003)	07/97-07/99	FR PS
Peugeot	306 1.8 (1993-2003)	07/97-07/99	FR PS
Peugeot	306 1.8 (1993-2003)	10/94-06/97	FR PS
Peugeot	306 1.8 (1993-2003)	10/94-06/97	RR
Peugeot	306 1.9 (1993-2003)	04/97-07/99	FR PS
Peugeot	306 1.9 (1993-2003)	04/97-07/99	FR PS
Peugeot	306 1.9 (1993-2003)	04/97-07/99	FR PS
Peugeot	306 1.9 (1993-2003)	04/97-07/99	FR PS
Peugeot	306 1.9 (1993-2003)	06/93-10/97	FR PS
Peugeot	306 1.9 (1993-2003)	06/93-10/97	FR PS
Peugeot	306 1.9 (1993-2003)	06/93-10/97	FR PS
Peugeot	306 1.9 (1993-2003)	06/93-10/97	FR PS
Peugeot	306 1.9 (1993-2003)	06/93-10/97	FR PS
Peugeot	306 1.9 (1993-2003)	07/99-07/02	FR PS
Peugeot	306 1.9 (1993-2003)	07/99-07/02	FR PS
Peugeot	306 1.9 (1993-2003)	07/99-12/01	FR PS
Peugeot	306 1.9 (1993-2003)	07/99-12/01	FR PS
Peugeot	306 1.9 (1993-2003)	07/99-12/01	FR PS
Peugeot	306 1.9 (1993-2003)	07/99-12/01	FR PS
Peugeot	306 1.9 (1993-2003)	10/97-07/99	FR PS
Peugeot	306 1.9 (1993-2003)	10/97-07/99	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	04/97-05/99	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	04/97-05/99	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	04/97-05/99	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	04/97-05/99	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	06/97-05/99	RR
Peugeot	306 1.9 Turbo (1993-2003)	06/97-05/99	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	06/97-05/99	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	06/97-05/99	RR
Peugeot	306 1.9 Turbo (1993-2003)	07/93-06/97	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	07/93-06/97	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	07/93-06/97	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	07/93-06/97	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	10/94-06/97	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	10/94-06/97	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	10/94-06/97	RR
Peugeot	306 1.9 Turbo (1993-2003)	10/94-06/97	RR
Peugeot	306 1.9 Turbo (1993-2003)	10/97-05/99	FR PS
Peugeot	306 1.9 Turbo (1993-2003)	10/97-05/99	FR PS
Peugeot	306 2.0 (1993-2003)	01/00-06/01	FR PS

Peugeot	306 2.0 (1993-2003)	01/00-06/01	FR PS
Peugeot	306 2.0 (1993-2003)	01/00-06/01	FR PS
Peugeot	306 2.0 (1993-2003)	01/00-06/01	FR PS
Peugeot	306 2.0 (1993-2003)	04/97-05/00	FR PS
Peugeot	306 2.0 (1993-2003)	04/97-05/00	FR PS
Peugeot	306 2.0 (1993-2003)	05/94-06/97	FR PS
Peugeot	306 2.0 (1993-2003)	05/94-06/97	FR PS
Peugeot	306 2.0 (1993-2003)	10/94-12/96	FR PS
Peugeot	306 2.0 (1993-2003)	10/94-12/96	RR
Peugeot	306 2.0 (1993-2003)	10/94-12/96	RR
Peugeot	306 2.0 (1993-2003)	10/94-12/96	FR PS
Peugeot	306 2.0 GTi-6 (1993-2003)	07/96-06/97	FR PS
Peugeot	306 2.0 HDi (1993-2003)	05/99-03/02	FR PS
Peugeot	306 2.0 HDi (1993-2003)	05/99-03/02	FR PS
Peugeot	306 2.0 HDi (1993-2003)	05/99-03/02	FR PS
Peugeot	306 2.0 Roadster (1993-2003)	04/97-12/99	FR PS
Peugeot	306 2.0 Roadster (1993-2003)	04/97-12/99	FR PS
Peugeot	306 2.0 Roadster (1993-2003)	07/96-06/97	FR PS
Peugeot	306 2.0 Roadster (1993-2003)	07/96-06/97	FR PS
Peugeot	306 2.0 S16 (1993-2003)	01/94-09/97	FR PS
Peugeot	306 2.0 XSi (1993-2003)	04/97-06/01	FR PS
Peugeot	306 2.0 XSi (1993-2003)	04/97-06/01	FR PS
Peugeot	406 2.0 (1996-1999)	07/97-12/99	FR PS
Peugeot	406 2.0 (1996-1999)	07/97-12/99	FR PS
Peugeot	406 2.2 (1999-2004)	03/02-09/03	FR PS
Peugeot	406 2.2 HDi (1999-2004)	06/01-09/03	FR PS
Peugeot	806 1.9 (1995-2002)	08/95-12/98	FR PS
Peugeot	806 1.9 (1995-2002)	08/95-12/98	FR PS
Peugeot	806 1.9 (1995-2002)	12/98-12/99	FR PS
Peugeot	806 1.9 (1995-2002)	12/98-12/99	FR PS
Peugeot	806 2.0 (1995-2002)	05/00-12/02	FR PS
Peugeot	806 2.0 (1995-2002)	05/00-12/02	FR PS
Peugeot	806 2.0 (1995-2002)	10/95-05/00	FR PS
Peugeot	806 2.0 HDi (1995-2002)	08/99-12/02	FR PS
Peugeot	806 2.0 HDi (1995-2002)	08/99-12/02	FR PS
Peugeot	Expert 1.6 HDi (2007-2017)	01/07-04/15	FR PS
Peugeot	Expert 1.6 HDi (2007-2017)	01/07-04/15	FR PS
Peugeot	Expert 1.6 HDi (2007-2017)	07/11-04/17	FR PS
Peugeot	Expert 1.9 (1996-2004)	05/99-10/00	FR PS
Peugeot	Expert 1.9 (1996-2004)	05/99-10/00	FR PS
Peugeot	Expert 1.9 (1996-2004)	09/96-05/99	FR PS
Peugeot	Expert 1.9 (1996-2004)	10/00-05/04	FR PS
Peugeot	Expert 1.9 (1996-2004)	10/00-05/04	FR PS
Peugeot	Expert 1.9 (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 1.9 (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 1.9 Turbo (1996-2004)	09/96-02/00	FR PS
Peugeot	Expert 1.9 Turbo (1996-2004)	09/96-02/00	FR PS
Peugeot	Expert 2.0 HDi (1996-2004)	02/00-05/04	FR PS
Peugeot	Expert 2.0 HDi (1996-2004)	02/00-05/04	FR PS
Peugeot	Expert 2.0 HDi (1996-2004)	02/00-05/04	FR PS

Peugeot	Expert 2.0 HDi (1996-2004)	02/00-05/04	FR PS
Peugeot	Expert 2.0 HDi (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 2.0 HDi (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 2.0 HDi (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 2.0 HDi (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 2.0 HDi (2007-2017)	01/07-07/12	FR PS
Peugeot	Expert 2.0 HDi (2007-2017)	01/07-07/12	FR PS
Peugeot	Expert 2.0 HDi 130 (2007-2017)	08/11-04/17	FR PS
Peugeot	Expert 2.0 HDi 130 (2007-2017)	08/11-04/17	FR PS
Peugeot	Expert 2.0 HDi 163 (2007-2017)	01/12-04/17	FR PS
Peugeot	Expert 2.0 HDi Combi (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 2.0 HDi Combi (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 2.0 HDi Combi (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert 2.0 HDi Combi (2004-2007)	04/04-05/07	FR PS
Peugeot	Expert Taxi 2.0 (1996-2004)	01/03-05/04	FR PS
Peugeot	Expert Taxi 2.0 (2004-2007)	04/04-05/07	FR PS
Porsche	924 2.0 Turbo 932	08/79-08/82	RR
Porsche	924 2.5 S	09/85-06/88	RR
Porsche	924 2.5 S	09/85-06/88	RR
Porsche	924 2.5 S	09/85-06/88	RR
Porsche	924 2.5 S	09/85-06/88	RR
Porsche	924 2.5 S	09/85-06/88	RR
Porsche	924 2.5 S	09/85-06/88	RR
Porsche	924 2.5 S	09/85-06/88	RR
Porsche	924 2.5 S	09/85-06/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5	04/82-09/88	RR
Porsche	944 2.5 S	09/86-06/88	RR
Proton	Wira 1.3 (2000-2004)	03/00-12/04	FR DS
Proton	Wira 1.3 (2000-2004)	03/00-12/04	FR DS
Proton	Wira 1.5 (2000-2004)	03/00-12/04	FR DS
Proton	Wira 1.5 (2000-2004)	03/00-12/04	FR DS
Proton	Wira 1.6 (2000-2004)	03/00-12/01	FR DS
Proton	Wira 1.6 (2000-2004)	03/00-12/04	FR DS
Reliant	Scimitar SS1 1.3	02/85-10/87	FR PS
Reliant	Scimitar SS1 1.3	02/85-10/87	FR DS
Reliant	Scimitar SS1 1.6	02/85-01/90	FR PS
Reliant	Scimitar SS1 1.6	02/85-01/90	FR DS
Renault	Clio 1.1 MK 1 (1991-1998)	06/92-12/92	FR DS
Renault	Clio 1.1 MK 1 (1991-1998)	06/92-12/92	FR PS

































Renault	R19 1.4 Carburettor	02/89-07/92	RR
Renault	R19 1.4 Carburettor	02/89-07/92	FR DS
Renault	R19 1.4 Carburettor	02/89-07/92	FR PS
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-07/96	FR DS
Renault	R19 1.4 Injection	10/90-07/96	FR PS
Renault	R19 1.4 Injection	10/90-07/96	RR
Renault	R19 1.4 Injection	10/90-09/94	FR PS
Renault	R19 1.4 Injection	10/90-09/94	FR PS
Renault	R19 1.4 Injection	10/90-09/94	FR DS
Renault	R19 1.4 Injection	10/90-09/94	FR DS
Renault	R19 1.7	12/89-12/91	FR DS
Renault	R19 1.7	12/89-12/91	FR PS
Renault	R19 1.7	12/89-12/91	FR PS
Renault	R19 1.7	12/89-12/91	FR PS
Renault	R19 1.7	12/89-12/91	FR PS
Renault	R19 1.7	12/89-12/91	FR DS
Renault	R19 1.7	12/89-12/91	FR DS

Renault	R19 1.7	12/89-12/91	FR DS
Renault	R19 1.8	03/91-09/94	FR PS
Renault	R19 1.8	03/91-09/94	FR DS
Renault	R19 1.8	03/91-09/95	RR
Renault	R19 1.8	03/91-09/95	FR DS
Renault	R19 1.8	03/91-09/95	FR PS
Renault	R19 1.8	03/91-09/95	RR
Renault	R19 1.8	03/91-09/95	FR PS
Renault	R19 1.8	03/91-09/95	FR DS
Renault	R19 1.8	05/92-09/94	RR
Renault	R19 1.8	05/92-09/94	FR DS
Renault	R19 1.8	05/92-09/94	FR PS
Renault	R19 1.8	05/92-09/94	RR
Renault	R19 1.8	05/92-09/94	FR DS
Renault	R19 1.8	05/92-09/94	FR DS
Renault	R19 1.8	05/92-09/94	FR DS
Renault	R19 1.8	05/92-09/94	FR PS
Renault	R19 1.8	05/92-09/94	FR PS
Renault	R19 1.8	05/92-09/94	FR PS
Renault	R19 1.9	02/89-10/95	FR DS
Renault	R19 1.9	02/89-10/95	FR PS
Renault	R19 1.9	02/89-10/95	RR
Renault	R19 1.9	02/89-10/95	RR
Renault	R19 1.9	02/89-10/95	FR DS
Renault	R19 1.9	02/89-10/95	FR PS
Renault	R19 1.9	02/89-10/95	RR
Renault	R19 1.9	02/89-10/95	FR DS
Renault	R19 1.9	02/89-10/95	RR
Renault	R19 1.9	02/89-10/95	FR PS
Renault	R19 1.9	02/89-10/95	FR DS
Renault	R19 1.9	02/89-10/95	FR PS
Renault	R19 1.9	10/89-09/94	FR DS
Renault	R19 1.9	10/89-09/94	FR PS
Renault	R19 1.9	10/89-09/94	FR PS
Renault	R19 1.9	10/89-09/94	FR DS
Renault	R19 1.9 Turbo	03/92-09/94	FR DS
Renault	R19 1.9 Turbo	03/92-09/94	FR PS
Renault	R21 1.7	06/86-12/92	FR PS
Renault	R21 1.7	06/86-12/92	FR PS
Renault	R21 1.7	06/86-12/92	FR DS
Renault	R21 1.7	06/86-12/92	FR DS
Renault	R21 1.7	06/86-12/92	FR DS
Renault	R21 1.7	06/86-12/92	FR PS
Renault	R21 1.7	06/86-12/92	FR PS
Renault	R21 1.7	06/86-12/92	FR DS
Renault	R21 1.7	09/89-12/92	FR PS
Renault	R21 1.7	09/89-12/92	FR PS
Renault	R21 1.7	09/89-12/92	FR DS
Renault	R21 1.7	09/89-12/92	FR DS
Renault	R21 1.7 Catalyst	01/92-11/93	FR DS

Renault	R21 1.7 Catalyst	01/92-11/93	FR PS
Renault	R21 1.7 Catalyst	01/92-11/93	FR DS
Renault	R21 1.7 Catalyst	01/92-11/93	FR PS
Renault	R21 1.7 Catalyst Savanna	01/92-10/95	FR DS
Renault	R21 1.7 Catalyst Savanna	01/92-10/95	FR PS
Renault	R21 1.7 Catalyst Savanna	01/92-10/95	FR DS
Renault	R21 1.7 Catalyst Savanna	01/92-10/95	FR PS
Renault	R21 1.7 Savanna	10/86-12/92	FR PS
Renault	R21 1.7 Savanna	10/86-12/92	FR DS
Renault	R21 1.7 Savanna	10/86-12/92	FR PS
Renault	R21 1.7 Savanna	10/86-12/92	FR PS
Renault	R21 1.7 Savanna	10/86-12/92	FR DS
Renault	R21 1.7 Savanna	10/86-12/92	FR DS
Renault	R21 1.7 Savanna	10/86-12/92	FR DS
Renault	R21 1.7 Savanna	10/86-12/92	FR PS
Renault	R21 1.7 TL	06/86-10/90	FR PS
Renault	R21 1.7 TL	06/86-10/90	FR DS
Renault	R21 1.7 TL	06/86-10/90	FR PS
Renault	R21 1.7 TL	06/86-10/90	FR DS
Renault	R21 1.7 TL	06/86-10/90	FR DS
Renault	R21 1.7 TL	06/86-10/90	FR PS
Renault	R21 1.7 TL Savanna	10/86-08/88	FR PS
Renault	R21 1.7 TL Savanna	10/86-08/88	FR DS
Renault	R21 1.9	09/89-10/94	FR PS
Renault	R21 1.9	09/89-10/94	FR DS
Renault	R21 1.9	09/89-12/92	FR PS
Renault	R21 1.9	09/89-12/92	FR DS
Renault	R21 1.9 Savanna	09/89-10/95	FR DS
Renault	R21 1.9 Savanna	09/89-10/95	FR PS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR PS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	07/87-12/92	FR DS
Renault	R21 2.0	09/88-12/92	FR PS
Renault	R21 2.0	09/88-12/92	FR PS
Renault	R21 2.0	09/88-12/92	FR DS
Renault	R21 2.0	09/88-12/92	FR PS
Renault	R21 2.0	09/88-12/92	FR PS

Renault	R21 2.0	09/88-12/92	FR DS
Renault	R21 2.0	09/88-12/92	FR DS
Renault	R21 2.0	09/88-12/92	FR DS
Renault	R21 2.0	09/89-12/93	FR PS
Renault	R21 2.0	09/89-12/93	FR DS
Renault	R21 2.0	09/89-12/93	FR PS
Renault	R21 2.0	09/89-12/93	FR PS
Renault	R21 2.0	09/89-12/93	FR DS
Renault	R21 2.0	09/89-12/93	FR DS
Renault	R21 2.0	09/89-12/93	FR PS
Renault	R21 2.0	09/89-12/93	FR DS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR PS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR DS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR DS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR DS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR PS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR PS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR PS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR DS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR DS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR PS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR DS
Renault	R21 2.0 Quadra Savanna	05/90-12/91	FR PS
Renault	R21 2.0 Savanna	07/87-12/89	FR PS
Renault	R21 2.0 Savanna	07/87-12/89	FR DS
Renault	R21 2.0 Savanna	07/87-12/89	FR DS
Renault	R21 2.0 Savanna	07/87-12/89	FR PS
Renault	R21 2.0 Savanna	07/87-12/89	FR DS
Renault	R21 2.0 Savanna	07/87-12/89	FR PS
Renault	R21 2.0 Savanna	07/87-12/89	FR PS
Renault	R21 2.0 Savanna	07/87-12/89	FR DS
Renault	R21 2.0 Savanna	09/88-10/95	FR DS
Renault	R21 2.0 Savanna	09/88-10/95	FR PS
Renault	R21 2.0 Savanna	09/88-10/95	FR PS
Renault	R21 2.0 Savanna	09/88-10/95	FR DS
Renault	R21 2.0 Savanna	09/88-10/95	FR DS
Renault	R21 2.0 Savanna	09/88-10/95	FR PS
Renault	R21 2.0 Savanna	09/88-10/95	FR PS
Renault	R21 2.0 Savanna	10/86-10/95	FR PS
Renault	R21 2.0 Savanna	10/86-10/95	FR DS
Renault	R21 2.0 Savanna	10/86-10/95	FR DS
Renault	R21 2.0 Savanna	10/86-10/95	FR PS
Renault	R21 2.0 Savanna	10/86-10/95	FR DS
Renault	R21 2.0 Savanna	10/86-10/95	FR PS
Renault	R21 2.0 Savanna	10/86-10/95	FR DS
Renault	R21 2.0 Savanna	10/86-10/95	FR PS
Renault	R21 2.0 Turbo	05/88-12/92	FR PS
Renault	R21 2.0 Turbo	05/88-12/92	FR DS
Renault	R21 2.0 Turbo Quadra	07/90-12/92	FR PS



Renault	R21 2.0 Turbo Quadra	07/90-12/92	FR DS
Renault	R21 2.0 TXi	09/89-01/91	FR PS
Renault	R21 2.0 TXi	09/89-01/91	FR DS
Renault	R21 2.0 TXi	09/89-01/91	FR DS
Renault	R21 2.0 TXi	09/89-01/91	FR PS
Renault	R21 2.1	06/86-09/89	FR DS
Renault	R21 2.1	06/86-09/89	FR PS
Renault	R21 2.1 Savanna	06/86-09/89	FR DS
Renault	R21 2.1 Savanna	06/86-09/89	FR PS
Renault	R21 2.1 Turbo	06/86-10/90	FR PS
Renault	R21 2.1 Turbo	06/86-10/90	FR PS
Renault	R21 2.1 Turbo	06/86-10/90	FR PS
Renault	R21 2.1 Turbo	06/86-10/90	FR DS
Renault	R21 2.1 Turbo	06/86-10/90	FR DS
Renault	R21 2.1 Turbo	06/86-10/90	FR DS
Renault	R21 2.1 Turbo Savanna	11/93-10/95	FR DS
Renault	R21 2.1 Turbo Savanna	11/93-10/95	FR DS
Renault	R21 2.1 Turbo Savanna	11/93-10/95	FR PS
Renault	R21 2.1 Turbo Savanna	11/93-10/95	FR PS
Renault	R21 2.1 Turbo Savanna	11/93-10/95	FR DS
Renault	R21 2.1 Turbo Savanna	11/93-10/95	FR PS
Renault	Trafic 1.4 MK 1 (1981-2000)	01/85-12/91	FR PS
Renault	Trafic 1.4 MK 1 (1981-2000)	01/85-12/91	FR DS
Renault	Trafic 1.6 MK 1 (1981-2000)	01/85-06/86	FR DS
Renault	Trafic 1.6 MK 1 (1981-2000)	01/85-06/86	FR DS
Renault	Trafic 1.6 MK 1 (1981-2000)	01/85-06/86	FR PS
Renault	Trafic 1.6 MK 1 (1981-2000)	01/85-06/86	FR PS
Renault	Trafic 1.6 MK 1 (1981-2000)	01/85-06/86	FR DS
Renault	Trafic 1.6 MK 1 (1981-2000)	01/85-06/86	FR PS
Renault	Trafic 1.7 MK 1 (1981-2000)	06/86-12/94	FR DS
Renault	Trafic 1.7 MK 1 (1981-2000)	06/86-12/94	FR PS
Renault	Trafic 1.7 MK 1 (1981-2000)	06/86-12/94	FR PS
Renault	Trafic 1.7 MK 1 (1981-2000)	06/86-12/94	FR PS
Renault	Trafic 1.7 MK 1 (1981-2000)	06/86-12/94	FR DS
Renault	Trafic 1.7 MK 1 (1981-2000)	06/86-12/94	FR DS
Renault	Trafic 1.9 MK 1 (1981-2000)	01/97-12/00	FR PS
Renault	Trafic 1.9 MK 1 (1981-2000)	01/97-12/00	FR DS
Renault	Trafic 2.0 MK 1 (1981-2000)	06/86-12/94	FR DS
Renault	Trafic 2.0 MK 1 (1981-2000)	06/86-12/94	FR DS
Renault	Trafic 2.0 MK 1 (1981-2000)	06/86-12/94	FR DS
Renault	Trafic 2.0 MK 1 (1981-2000)	06/86-12/94	FR PS
Renault	Trafic 2.0 MK 1 (1981-2000)	06/86-12/94	FR PS
Renault	Trafic 2.0 MK 1 (1981-2000)	06/86-12/94	FR PS
Renault	Trafic 2.0 MK 1 (1981-2000)	09/86-05/93	FR DS
Renault	Trafic 2.0 MK 1 (1981-2000)	09/86-05/93	FR PS
Renault	Trafic 2.0 MK 1 (1981-2000)	09/86-05/93	FR DS
Renault	Trafic 2.0 MK 1 (1981-2000)	09/86-05/93	FR PS
Renault	Trafic 2.0 MK 1 (1981-2000)	09/86-05/93	FR DS
Renault	Trafic 2.0 MK 1 (1981-2000)	09/86-05/93	FR PS
Renault	Trafic 2.0 MK 1 (1981-2000)	12/86-12/94	FR PS

Renault	Trafic 2.0 MK 1 (1981-2000)	12/86-12/94	FR DS
Renault	Trafic 2.1 MK 1 (1981-2000)	01/85-10/98	FR PS
Renault	Trafic 2.1 MK 1 (1981-2000)	01/85-10/98	FR DS
Renault	Trafic 2.1 MK 1 (1981-2000)	01/85-10/98	FR DS
Renault	Trafic 2.1 MK 1 (1981-2000)	01/85-10/98	FR PS
Renault	Trafic 2.1 MK 1 (1981-2000)	09/86-12/93	FR DS
Renault	Trafic 2.1 MK 1 (1981-2000)	09/86-12/93	FR PS
Renault	Trafic 2.2 MK 1 (1981-2000)	09/94-10/98	FR DS
Renault	Trafic 2.2 MK 1 (1981-2000)	09/94-10/98	FR PS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR DS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR DS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR PS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR DS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR PS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR PS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR PS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR DS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR PS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR DS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR DS
Renault	Trafic 2.5 MK 1 (1981-2000)	04/89-12/98	FR PS
Rover	414 1.4 (1995-2000)	05/95-07/00	FR DS
Rover	416 1.6 (1995-2000)	05/95-07/00	FR DS
Rover	416 1.6 (1995-2000)	05/95-07/00	FR DS
Rover	416 1.6 (1995-2000)	05/95-07/00	FR DS
Rover	416 1.6 (1995-2000)	05/95-07/00	FR DS
Rover	416 1.6 (1995-2000)	05/95-12/99	FR DS
Rover	416 1.6 (1995-2000)	05/95-12/99	FR DS
Rover	420 2.0 (1995-2000)	03/96-07/00	FR DS
Rover	420 2.0 (1995-2000)	03/96-07/00	FR DS
Rover	420 2.0 (1995-2000)	11/95-07/00	FR DS
Rover	420 2.0 (1995-2000)	11/95-07/00	FR DS
Rover	420 2.0 Di (1995-2000)	06/97-07/00	FR DS
Rover	420 2.0 Di (1995-2000)	06/97-07/00	FR DS
Rover	45 1.4 (1999-2004)	11/99-05/04	FR DS
Rover	45 1.4 (2004-2005)	05/04-12/07	FR DS
Rover	45 1.6 (1999-2004)	11/99-05/04	FR DS
Rover	45 1.6 (1999-2004)	11/99-05/04	FR DS
Rover	45 1.6 (2004-2005)	05/04-12/07	FR DS
Rover	45 1.6 (2004-2005)	05/04-12/07	FR DS
Rover	45 1.8 (1999-2004)	11/99-05/04	FR DS
Rover	45 1.8 (1999-2004)	11/99-05/04	FR DS
Rover	45 1.8 (1999-2004)	11/99-05/04	FR DS
Rover	45 1.8 (1999-2004)	11/99-05/04	FR DS
Rover	45 1.8 (2004-2005)	05/04-12/07	FR DS
Rover	45 1.8 (2004-2005)	05/04-12/07	FR DS
Rover	45 1.8 (2004-2005)	05/04-12/07	FR DS
Rover	45 1.8 (2004-2005)	05/04-12/07	FR DS
Rover	45 1.8 (2004-2005)	05/04-12/07	FR DS
Rover	45 2.0 (1999-2004)	11/99-05/04	FR DS
Rover	45 2.0 (1999-2004)	11/99-05/04	FR DS

Rover	45 2.0 (2004-2005)	05/04-12/07	FR DS
Rover	45 2.0 (2004-2005)	05/04-12/07	FR DS
Rover	618 1.8 (1993-2000)	02/96-10/00	FR PS
Rover	618 1.8 (1993-2000)	02/96-10/00	FR PS
Rover	620 2.0 Di (1993-2000)	12/94-10/99	FR PS
Rover	620 2.0 i (1993-2000)	08/93-03/96	FR PS
Rover	620 2.0 Si/SLi/GSi (1993-2000)	04/93-10/99	FR PS
Rover	620 2.0 Si/SLi/GSi (1993-2000)	04/93-10/99	FR PS
Rover	620 2.0 ti (1993-2000)	07/94-10/99	FR PS
Rover	623 2.3 (1993-2000)	10/93-10/99	FR PS
Rover	623 2.3 (1993-2000)	10/93-10/99	FR PS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR DS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR PS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR DS
Rover	825 2.5 (1991-1999)	01/96-10/99	FR PS
Rover	827 2.7 (1991-1999)	06/92-03/96	FR DS
Rover	827 2.7 (1991-1999)	06/92-03/96	FR PS
Rover	827 2.7 (1991-1999)	06/92-03/96	FR PS
Rover	827 2.7 (1991-1999)	06/92-03/96	FR DS
Rover	Cityrover 1.4 (2003-2005)	11/03-12/07	FR PS
Rover	Cityrover 1.4 (2003-2005)	11/03-12/07	FR DS
Rover	Cityrover 1.4 (2003-2005)	11/03-12/07	FR DS
Rover	Cityrover 1.4 (2003-2005)	11/03-12/07	FR PS
Rover	Maestro 1.3 (1983-1994)	03/83-03/90	FR PS
Rover	Maestro 1.3 (1983-1994)	03/83-03/90	FR PS
Rover	Maestro 1.3 (1983-1994)	03/83-03/90	FR DS
Rover	Maestro 1.3 (1983-1994)	03/83-12/92	FR DS
Rover	Maestro 1.3 (1983-1994)	03/83-12/92	RR
Rover	Maestro 1.3 (1983-1994)	03/83-12/92	RR
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR PS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR PS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR DS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR PS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR DS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR PS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR DS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR DS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR PS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR PS
Rover	Maestro 1.3 HLE/LE (Economy tuned) (1983-1994)	03/83-04/87	FR DS
Rover	Maestro 1.3 With Catalyst (1983-1994)	09/92-12/94	FR DS
Rover	Maestro 1.3 With Catalyst (1983-1994)	09/92-12/94	RR
Rover	Maestro 1.3 With Catalyst (1983-1994)	09/92-12/94	FR PS
Rover	Maestro 1.3 With Catalyst (1983-1994)	09/92-12/94	RR
Rover	Maestro 1.3 With Catalyst (1983-1994)	09/92-12/94	FR DS
Rover	Maestro 1.3 With Catalyst (1983-1994)	09/92-12/94	FR PS
Rover	Maestro 1.6 (1983-1994)	03/83-07/84	FR PS
Rover	Maestro 1.6 (1983-1994)	03/83-07/84	FR PS
Rover	Maestro 1.6 (1983-1994)	03/83-07/84	FR DS

Rover	Maestro 1.6 (1983-1994)	03/83-07/84	FR DS
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	FR PS
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	RR
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	FR PS
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	FR DS
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	RR
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	FR DS
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	RR
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	FR PS
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	RR
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	FR DS
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	FR PS
Rover	Maestro 1.6 (1983-1994)	07/84-07/92	FR DS
Rover	MG Maestro 1.6 (1983-1994)	03/83-10/84	FR DS
Rover	MG Maestro 1.6 (1983-1994)	03/83-10/84	RR
Rover	MG Maestro 1.6 (1983-1994)	03/83-10/84	FR PS
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	FR DS
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	FR PS
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	FR PS
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	RR
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	FR PS
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	RR
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	RR
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	FR DS
Rover	MG Maestro 2.0 (1983-1994)	10/84-12/91	FR DS
Rover	MG Maestro 2.0 Turbo (1983-1994)	01/89-12/91	RR
Rover	MG Maestro 2.0 Turbo (1983-1994)	01/89-12/91	FR PS
Rover	MG Maestro 2.0 Turbo (1983-1994)	01/89-12/91	FR DS
Rover	MG Montego 2.0 Turbo (1984-1994)	04/85-12/91	FR DS
Rover	MG Montego 2.0 Turbo (1984-1994)	04/85-12/91	FR DS
Rover	MG Montego 2.0 Turbo (1984-1994)	04/85-12/91	FR PS
Rover	MG Montego 2.0 Turbo (1984-1994)	04/85-12/91	FR PS
Rover	MGF 1.6	02/00-08/02	FR PS
Rover	MGF 1.6	02/00-08/02	FR DS
Rover	MGF 1.8	06/99-08/02	FR DS
Rover	MGF 1.8	06/99-08/02	FR PS
Rover	MGF 1.8	09/95-08/02	FR PS
Rover	MGF 1.8	09/95-08/02	FR DS
Rover	MGF 1.8 Trophy 160	02/01-08/02	FR PS
Rover	MGF 1.8 Trophy 160	02/01-08/02	FR DS
Rover	MGF 1.8 VVC	11/95-08/02	FR DS
Rover	MGF 1.8 VVC	11/95-08/02	FR PS
Rover	MGTF 1.6 115	02/02-12/07	FR DS
Rover	MGTF 1.6 115	02/02-12/07	FR PS
Rover	MGTF 1.8 120 Stepspeed	02/02-12/07	FR DS
Rover	MGTF 1.8 120 Stepspeed	02/02-12/07	FR PS
Rover	MGTF 1.8 135	02/02-12/09	FR DS
Rover	MGTF 1.8 135	02/02-12/09	FR PS
Rover	MGTF 1.8 135	09/07-12/11	FR PS
Rover	MGTF 1.8 135	09/07-12/11	FR DS



Rover	Montego 2.0 Injection (1984-1994)	02/85-10/88	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/85-10/88	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/85-10/88	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/85-10/88	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/85-10/88	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/85-10/88	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/85-10/88	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/85-10/88	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR PS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR DS
Rover	Montego 2.0 Injection (1984-1994)	02/87-07/92	FR PS
Rover	Montego 2.0 Injection (with catalyst) (1984-1994)	01/91-12/93	FR DS
Rover	Montego 2.0 Injection (with catalyst) (1984-1994)	01/91-12/93	FR PS
Rover	Montego 2.0 Injection (with catalyst) (1984-1994)	01/91-12/93	FR PS
Rover	Montego 2.0 Injection (with catalyst) (1984-1994)	01/91-12/93	FR DS
Saab	900 2.0 (1993-1998)	06/94-06/98	RR
Saab	900 2.0 (1993-1998)	06/94-06/98	RR
Saab	900 2.0 Turbo (1993-1998)	01/95-06/98	RR
Saab	900 2.0 Turbo (1993-1998)	03/94-06/98	RR
Saab	900 2.0 Turbo (1993-1998)	03/94-06/98	RR
Saab	900 2.3 (1993-1998)	10/93-06/98	RR
Saab	900 2.3 (1993-1998)	10/93-06/98	RR
Saab	900 2.5 (1993-1998)	10/93-06/98	RR
Saab	900 2.5 (1993-1998)	10/93-06/98	RR
Saab	9000 2.0	04/86-10/88	FR PS
Saab	9000 2.0	04/86-10/88	FR DS
Saab	9000 2.0	04/86-10/88	RR
Saab	9000 2.0	04/86-10/88	FR PS
Saab	9000 2.0	04/86-10/88	FR DS
Saab	9000 2.0	04/86-10/88	RR
Saab	9000 2.0	05/88-09/90	FR DS
Saab	9000 2.0	05/88-09/90	FR DS
Saab	9000 2.0	05/88-09/90	FR DS
Saab	9000 2.0	05/88-09/90	FR PS
Saab	9000 2.0	05/88-09/90	FR PS
Saab	9000 2.0	05/88-09/90	FR PS
Saab	9000 2.0	05/88-09/90	FR PS

Saab	9000 2.0	05/88-09/90	FR DS
Saab	9000 2.0	09/90-09/97	FR DS
Saab	9000 2.0	09/90-09/97	FR DS
Saab	9000 2.0	09/90-09/97	FR DS
Saab	9000 2.0	09/90-09/97	FR PS
Saab	9000 2.0	09/90-09/97	FR DS
Saab	9000 2.0	09/90-09/97	FR PS
Saab	9000 2.0	09/90-09/97	FR PS
Saab	9000 2.0	09/90-09/97	FR PS
Saab	9000 2.0	10/88-10/91	RR
Saab	9000 2.0	10/88-10/91	RR
Saab	9000 2.0	10/88-10/91	FR DS
Saab	9000 2.0	10/88-10/91	FR PS
Saab	9000 2.0	10/88-10/91	FR PS
Saab	9000 2.0	10/88-10/91	FR DS
Saab	9000 2.0	10/88-10/91	RR
Saab	9000 2.0	10/88-10/91	FR PS
Saab	9000 2.0	10/88-10/91	FR DS
Saab	9000 2.0	10/88-10/91	FR PS
Saab	9000 2.0	10/88-10/91	RR
Saab	9000 2.0	10/88-10/91	FR DS
Saab	9000 2.0	10/91-10/98	FR PS
Saab	9000 2.0	10/91-10/98	RR
Saab	9000 2.0	10/91-10/98	RR
Saab	9000 2.0	10/91-10/98	RR
Saab	9000 2.0	10/91-10/98	FR DS
Saab	9000 2.0	10/91-10/98	FR PS
Saab	9000 2.0	10/91-10/98	FR DS
Saab	9000 2.0	10/91-10/98	FR PS
Saab	9000 2.0	10/91-10/98	RR
Saab	9000 2.0	10/91-10/98	FR DS
Saab	9000 2.0 Carlsson	10/88-09/90	FR PS
Saab	9000 2.0 Carlsson	10/88-09/90	FR PS
Saab	9000 2.0 Carlsson	10/88-09/90	RR
Saab	9000 2.0 Carlsson	10/88-09/90	FR PS
Saab	9000 2.0 Carlsson	10/88-09/90	FR DS
Saab	9000 2.0 Carlsson	10/88-09/90	RR
Saab	9000 2.0 Carlsson	10/88-09/90	FR DS
Saab	9000 2.0 Carlsson	10/88-09/90	FR DS
Saab	9000 2.0 Carlsson	10/88-09/90	RR
Saab	9000 2.0 Carlsson	10/89-09/90	FR PS
Saab	9000 2.0 Carlsson	10/89-09/90	FR PS
Saab	9000 2.0 Carlsson	10/89-09/90	FR DS
Saab	9000 2.0 Carlsson	10/89-09/90	FR DS
Saab	9000 2.0 Carlsson	10/89-09/90	FR DS
Saab	9000 2.0 Carlsson	10/89-09/90	FR PS
Saab	9000 2.0 Eco Power	09/92-09/97	FR PS
Saab	9000 2.0 Eco Power	09/92-09/97	FR PS





Saab	9000 2.0 Turbo	10/90-09/92	FR DS
Saab	9000 2.0 Turbo	10/90-09/92	FR DS
Saab	9000 2.0 Turbo	10/90-09/92	FR DS
Saab	9000 2.0 Turbo	10/90-09/92	FR PS
Saab	9000 2.0 Turbo	10/90-09/92	FR DS
Saab	9000 2.0 Turbo	10/90-09/92	RR
Saab	9000 2.0 Turbo	10/90-09/92	RR
Saab	9000 2.0 Turbo	10/90-09/92	FR PS
Saab	9000 2.3	10/89-09/93	FR PS
Saab	9000 2.3	10/89-09/93	RR
Saab	9000 2.3	10/89-09/93	FR DS
Saab	9000 2.3	10/89-09/93	FR PS
Saab	9000 2.3	10/89-09/93	FR PS
Saab	9000 2.3	10/89-09/93	FR DS
Saab	9000 2.3	10/89-09/93	FR DS
Saab	9000 2.3	10/89-09/93	FR DS
Saab	9000 2.3	10/89-09/93	RR
Saab	9000 2.3	10/89-09/93	FR PS
Saab	9000 2.3 Aero	01/93-09/97	FR PS
Saab	9000 2.3 Aero	01/93-09/97	FR DS
Saab	9000 2.3 Aero	01/93-09/97	RR
Saab	9000 2.3 Aero	01/93-09/97	FR PS
Saab	9000 2.3 Aero	01/93-09/97	FR DS
Saab	9000 2.3 Aero	01/93-09/97	RR
Saab	9000 2.3 Carlsson	09/90-12/92	FR DS
Saab	9000 2.3 Carlsson	09/90-12/92	FR PS
Saab	9000 2.3 Carlsson	09/90-12/92	FR DS
Saab	9000 2.3 Carlsson	09/90-12/92	FR PS
Saab	9000 2.3 Eco Power	09/93-09/97	FR DS
Saab	9000 2.3 Eco Power	09/93-09/97	RR
Saab	9000 2.3 Eco Power	09/93-09/97	FR DS
Saab	9000 2.3 Eco Power	09/93-09/97	FR PS
Saab	9000 2.3 Eco Power	09/93-09/97	FR PS
Saab	9000 2.3 Eco Power	09/93-09/97	FR PS
Saab	9000 2.3 Eco Power	09/93-09/97	RR
Saab	9000 2.3 Eco Power	09/93-09/97	FR DS
Saab	9000 2.3 Eco Power	09/93-09/97	FR DS
Saab	9000 2.3 Eco Power	09/93-09/97	FR PS
Saab	9000 2.3 Eco Power	09/97-10/98	FR DS
Saab	9000 2.3 Eco Power	09/97-10/98	RR
Saab	9000 2.3 Eco Power	09/97-10/98	FR PS
Saab	9000 2.3 Eco Power	09/97-10/98	FR PS
Saab	9000 2.3 Eco Power	09/97-10/98	FR DS
Saab	9000 2.3 Eco Power	09/97-10/98	RR
Saab	9000 2.3 Griffin	01/96-10/98	RR
Saab	9000 2.3 Griffin	01/96-10/98	FR DS
Saab	9000 2.3 Griffin	01/96-10/98	FR PS
Saab	9000 2.3 Griffin	01/96-10/98	FR PS
Saab	9000 2.3 Griffin	01/96-10/98	RR
Saab	9000 2.3 Griffin	01/96-10/98	FR DS



Saab	9-3 2.0 t (1998-2002)	09/00-05/02	RR
Saab	9-3 2.0 t (1998-2002)	09/98-09/00	RR
Saab	9-3 2.0 t (1998-2002)	09/98-09/00	RR
Saab	9-3 2.0 t (1998-2002)	09/98-09/00	RR
Saab	9-3 2.0 t (1998-2002)	09/98-09/00	RR
Saab	9-3 2.0 t (1998-2002)	09/98-09/00	RR
Saab	9-3 2.0 t (1998-2002)	09/98-09/00	RR
Saab	9-3 2.0 t (1998-2002)	09/98-09/00	RR
Saab	9-3 2.0 t (1998-2002)	09/98-09/00	RR
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	RR
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	RR
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	RR
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	RR
Saab	9-3 2.2 TiD (1998-2002)	09/00-05/02	RR
Saab	9-3 2.2 TiD (1998-2002)	09/00-05/02	RR
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	RR
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	RR
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	RR
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	RR
Saab	9-3 2.3 (1998-2002)	03/98-08/98	RR
Saab	9-3 2.3 (1998-2002)	03/98-08/98	RR
Saab	9-3 2.3 (1998-2002)	03/98-08/98	RR
Saab	9-3 2.3 (1998-2002)	03/98-08/98	RR
Saab	9-3 2.3 HOT Viggen (1998-2002)	09/99-07/00	RR
Saab	9-3 2.3 HOT Viggen (1998-2002)	09/99-07/00	RR
Saab	9-3 2.3 T Viggen (1998-2002)	03/99-09/99	RR
Saab	9-3 2.3 T Viggen (1998-2002)	03/99-09/99	RR
Seat	Toledo 1.6 (1991-1998)	04/95-12/96	FR DS
Seat	Toledo 1.6 (1991-1998)	04/95-12/96	FR PS
Seat	Toledo 1.6 (1991-1998)	04/95-12/96	FR PS
Seat	Toledo 1.6 (1991-1998)	04/95-12/96	FR DS
Seat	Toledo 1.6 (1991-1998)	04/95-12/96	FR DS
Seat	Toledo 1.6 (1991-1998)	04/95-12/96	FR PS
Seat	Toledo 1.6 (1991-1998)	06/92-04/95	FR PS
Seat	Toledo 1.6 (1991-1998)	06/92-04/95	FR PS
Seat	Toledo 1.6 (1991-1998)	06/92-04/95	FR PS
Seat	Toledo 1.6 (1991-1998)	06/92-04/95	FR DS
Seat	Toledo 1.6 (1991-1998)	06/92-04/95	FR DS
Seat	Toledo 1.6 (1991-1998)	06/92-04/95	FR DS
Seat	Toledo 1.6 (1991-1998)	10/91-06/92	FR DS
Seat	Toledo 1.6 (1991-1998)	10/91-06/92	FR DS
Seat	Toledo 1.6 (1991-1998)	10/91-06/92	FR PS
Seat	Toledo 1.6 (1991-1998)	10/91-06/92	FR PS
Seat	Toledo 1.6 (1991-1998)	10/91-06/92	FR DS
Seat	Toledo 1.6 (1991-1998)	10/91-06/92	FR PS
Seat	Toledo 1.6 (1991-1998)	12/96-03/99	FR DS
Seat	Toledo 1.6 (1991-1998)	12/96-03/99	FR PS
Seat	Toledo 1.8 (1991-1998)	04/95-12/96	FR PS
Seat	Toledo 1.8 (1991-1998)	04/95-12/96	FR PS
Seat	Toledo 1.8 (1991-1998)	04/95-12/96	FR DS

Seat	Toledo 1.8 (1991-1998)	04/95-12/96	FR PS
Seat	Toledo 1.8 (1991-1998)	04/95-12/96	FR DS
Seat	Toledo 1.8 (1991-1998)	04/95-12/96	FR DS
Seat	Toledo 1.8 (1991-1998)	06/92-04/95	FR DS
Seat	Toledo 1.8 (1991-1998)	06/92-04/95	FR PS
Seat	Toledo 1.8 (1991-1998)	06/92-04/95	FR PS
Seat	Toledo 1.8 (1991-1998)	06/92-04/95	FR PS
Seat	Toledo 1.8 (1991-1998)	06/92-04/95	FR DS
Seat	Toledo 1.8 (1991-1998)	06/92-04/95	FR DS
Seat	Toledo 1.8 (1991-1998)	10/91-01/95	FR PS
Seat	Toledo 1.8 (1991-1998)	10/91-01/95	FR DS
Seat	Toledo 1.8 (1991-1998)	10/91-01/95	FR DS
Seat	Toledo 1.8 (1991-1998)	10/91-01/95	FR PS
Seat	Toledo 1.8 (1991-1998)	10/91-06/92	FR PS
Seat	Toledo 1.8 (1991-1998)	10/91-06/92	FR DS
Seat	Toledo 1.9 (1991-1998)	10/91-03/99	FR DS
Seat	Toledo 1.9 (1991-1998)	10/91-03/99	FR PS
Seat	Toledo 1.9 TD (1991-1998)	06/92-12/96	FR PS
Seat	Toledo 1.9 TD (1991-1998)	06/92-12/96	FR DS
Seat	Toledo 1.9 TDi (1991-1998)	10/95-03/99	FR PS
Seat	Toledo 1.9 TDi (1991-1998)	10/95-03/99	FR DS
Seat	Toledo 1.9 TDi (1991-1998)	10/95-03/99	FR DS
Seat	Toledo 1.9 TDi (1991-1998)	10/95-03/99	FR PS
Seat	Toledo 2.0 (1991-1998)	10/91-03/99	FR DS
Seat	Toledo 2.0 (1991-1998)	10/91-03/99	FR DS
Seat	Toledo 2.0 (1991-1998)	10/91-03/99	FR PS
Seat	Toledo 2.0 (1991-1998)	10/91-03/99	FR DS
Seat	Toledo 2.0 (1991-1998)	10/91-03/99	FR PS
Seat	Toledo 2.0 (1991-1998)	10/91-03/99	FR PS
Seat	Toledo 2.0 (1991-1998)	10/91-03/99	FR PS
Seat	Toledo 2.0 (1991-1998)	10/91-03/99	FR DS
Seat	Toledo 2.0 (1991-1998)	10/94-03/99	FR DS
Seat	Toledo 2.0 (1991-1998)	10/94-03/99	FR PS
Skoda	Felicia 1.3 (1995-2001)	04/96-05/98	FR PS
Skoda	Felicia 1.3 (1995-2001)	04/96-05/98	FR PS
Skoda	Felicia 1.3 (1995-2001)	04/96-05/98	FR DS
Skoda	Felicia 1.3 (1995-2001)	04/96-05/98	FR DS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR DS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR DS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR PS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR PS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR PS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR DS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR PS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR PS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR DS
Skoda	Felicia 1.3 (1995-2001)	04/98-12/01	FR DS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR PS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR DS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR PS

Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR PS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR DS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR PS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR DS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR DS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR DS
Skoda	Felicia 1.3 (1995-2001)	05/95-04/98	FR PS
Skoda	Felicia 1.3 (1995-2001)	05/98-12/01	FR DS
Skoda	Felicia 1.3 (1995-2001)	05/98-12/01	FR DS
Skoda	Felicia 1.3 (1995-2001)	05/98-12/01	FR PS
Skoda	Felicia 1.3 (1995-2001)	05/98-12/01	FR PS
Skoda	Felicia 1.6 (1995-2001)	04/98-12/00	FR PS
Skoda	Felicia 1.6 (1995-2001)	04/98-12/00	FR DS
Skoda	Felicia 1.6 (1995-2001)	05/98-12/00	FR DS
Skoda	Felicia 1.6 (1995-2001)	05/98-12/00	FR PS
Skoda	Felicia 1.6 (1995-2001)	06/96-04/98	FR DS
Skoda	Felicia 1.6 (1995-2001)	06/96-04/98	FR PS
Skoda	Felicia 1.6 (1995-2001)	06/96-04/98	FR PS
Skoda	Felicia 1.6 (1995-2001)	06/96-04/98	FR DS
Skoda	Felicia 1.6 (1995-2001)	06/96-05/98	FR PS
Skoda	Felicia 1.6 (1995-2001)	06/96-05/98	FR DS
Skoda	Felicia 1.9 (1995-2001)	04/97-04/98	FR DS
Skoda	Felicia 1.9 (1995-2001)	04/97-04/98	FR PS
Skoda	Felicia 1.9 (1995-2001)	04/97-05/98	FR DS
Skoda	Felicia 1.9 (1995-2001)	04/97-05/98	FR PS
Skoda	Felicia 1.9 (1995-2001)	04/98-12/01	FR DS
Skoda	Felicia 1.9 (1995-2001)	04/98-12/01	FR PS
Skoda	Felicia 1.9 (1995-2001)	05/98-12/01	FR PS
Skoda	Felicia 1.9 (1995-2001)	05/98-12/01	FR DS
Skoda	Pick Up 1.3 (1996-2001)	05/96-06/98	FR DS
Skoda	Pick Up 1.3 (1996-2001)	05/96-06/98	FR DS
Skoda	Pick Up 1.3 (1996-2001)	05/96-06/98	FR PS
Skoda	Pick Up 1.3 (1996-2001)	05/96-06/98	FR PS
Skoda	Pick Up 1.6 (1996-2001)	06/98-12/01	FR PS
Skoda	Pick Up 1.6 (1996-2001)	06/98-12/01	FR DS
Skoda	Pick Up 1.9 (1996-2001)	10/96-12/01	FR DS
Skoda	Pick Up 1.9 (1996-2001)	10/96-12/01	FR PS
Smart	Roadster 0.7 (2003-2006)	06/03-04/07	FR DS
Smart	Roadster 0.7 (2003-2006)	06/03-04/07	FR DS
Smart	Roadster 0.7 (2003-2006)	06/03-04/07	FR DS
Smart	Roadster 0.7 (2003-2006)	06/03-04/07	FR DS
Smart	Roadster 0.7 (2003-2006)	06/03-08/03	FR DS
Smart	Roadster 0.7 (2003-2006)	06/03-08/03	FR DS
Smart	Roadster 0.7 Brabus (2003-2006)	04/04-04/07	FR DS
Smart	Roadster 0.7 Brabus (2003-2006)	04/04-04/07	FR DS
Smart	Roadster 0.7 Brabus (2003-2006)	04/04-04/07	FR DS
Smart	Roadster 0.7 Brabus (2003-2006)	04/04-04/07	FR DS
Ssangyong	Musso 2.3 (1995-1998)	08/97-12/98	FR DS
Ssangyong	Musso 2.9 (1995-1998)	05/95-12/98	FR DS
Ssangyong	Musso 2.9 Turbo (1995-1998)	01/98-12/98	FR DS



Ssangyong	Rexton 2.7 RX270 MK 2	01/07-12/11	FR DS
Ssangyong	Rexton 2.7 RX270 MK 2	01/07-12/11	FR DS
Ssangyong	Rexton 2.7 RX270 MK 2	01/07-12/11	FR PS
Ssangyong	Rexton 2.7 RX270 MK 2	01/07-12/11	FR PS
Ssangyong	Rexton 2.7 RX270 MK 2	01/07-12/11	FR DS
Ssangyong	Rexton 2.7 RX270 MK 2	01/07-12/11	FR DS
Ssangyong	Rexton 2.7 RX270 MK 2	01/07-12/11	FR PS
Ssangyong	Rexton 2.7 RX270 MK 2	01/07-12/11	FR PS
Ssangyong	Rexton 2.9 RX290 MK 1	08/03-12/05	FR DS
Ssangyong	Rexton 2.9 RX290 MK 1	08/03-12/05	FR DS
Ssangyong	Rexton 2.9 RX290 MK 1	08/03-12/05	FR PS
Ssangyong	Rexton 2.9 RX290 MK 1	08/03-12/05	FR PS
Ssangyong	Rexton 3.2 RX320 MK 1	08/03-12/05	FR DS
Ssangyong	Rexton 3.2 RX320 MK 1	08/03-12/05	FR PS
Subaru	Justy 1.0 (2007-2010)	11/07-08/10	FR DS
Subaru	Justy 1.3 (1996-2001)	03/96-12/01	FR DS
Subaru	Justy 1.3 (1996-2001)	03/96-12/01	FR DS
Subaru	SVX 3.3	05/92-09/96	FR PS
Suzuki	Baleno 1.3 (1995-2002)	05/95-01/02	FR DS
Suzuki	Baleno 1.6 (1995-2002)	05/95-08/99	FR DS
Suzuki	Baleno 1.6 (1995-2002)	05/95-08/99	FR DS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR DS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR DS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR DS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR DS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR DS
Suzuki	Baleno 1.6 (1995-2002)	05/95-12/00	FR DS
Suzuki	Baleno 1.8 (1995-2002)	06/99-01/02	FR DS
Suzuki	Baleno 1.8 (1995-2002)	06/99-01/02	FR DS
Suzuki	Baleno 1.8 (1995-2002)	08/00-01/02	FR DS
Suzuki	Baleno 1.8 (1995-2002)	08/96-12/97	FR DS
Suzuki	Swift 1.0 A2 (2017-2025)	04/17-12/20	FR DS
Suzuki	Swift 1.0 A2 (2017-2025)	04/17-12/20	FR DS
Suzuki	Swift 1.0 SHVS A2 (2017-2025)	04/17-12/20	FR DS
Suzuki	Swift 1.2 A2 (2017-2025)	04/17-12/20	FR DS
Suzuki	Swift 1.4 Sport A2 (2017-2025)	04/18-12/20	FR DS
Suzuki	Wagon R+ 1.0 (1997-2000)	10/97-12/00	FR DS
Suzuki	Wagon R+ 1.2 (1997-2000)	08/98-12/00	FR DS
Suzuki	Wagon R+ 1.2 (1997-2000)	08/98-12/00	FR DS
Suzuki	Wagon R+ 1.3 (2000-2008)	05/00-12/03	FR DS
Suzuki	Wagon R+ 1.3 (2000-2008)	05/00-12/03	FR DS
Suzuki	Wagon R+ 1.3 (2000-2008)	10/03-08/06	FR DS
Suzuki	Wagon R+ 1.3 (2000-2008)	10/03-08/06	FR DS
Toyota	Avensis 1.6 T220 (1997-2003)	08/00-05/03	RR
Toyota	Avensis 1.6 T220 (1997-2003)	11/97-04/01	RR
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	RR
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	RR
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	RR
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	RR

Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	RR
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	RR
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	RR
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	RR
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	RR
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	RR
Toyota	Camry 2.0 SV21	01/87-12/91	FR DS
Toyota	Camry 2.0 SV21	01/87-12/91	FR DS
Toyota	Camry 2.0 SV21	01/87-12/91	FR DS
Toyota	Camry 2.0 SV21	01/87-12/91	FR DS
Toyota	Camry 2.0 SV25	03/88-03/89	FR DS
Toyota	Camry 2.5 XV70	03/19-04/22	FR PS
Toyota	Carina E 1.6 AT190	05/92-03/96	RR
Toyota	Carina E 1.6 AT190	05/92-04/97	RR
Toyota	Carina E 1.8 AT191	03/95-03/96	RR
Toyota	Carina E 1.8 AT191	03/95-03/96	RR
Toyota	Carina E 1.8 AT191	03/96-03/98	RR
Toyota	Carina E 1.8 AT191	03/96-03/98	RR
Toyota	Carina E 2.0 GTi ST191	05/92-05/94	RR
Toyota	Carina E 2.0 ST191	05/92-03/98	RR
Toyota	Carina E 2.0 ST191	05/92-03/98	RR
Toyota	Celica 2.0 RA61	02/82-11/85	FR DS
Toyota	Celica 2.0 RA61	02/82-11/85	FR DS
Toyota	Celica 2.0 ST162	03/87-03/88	FR DS
Toyota	Celica 2.0 ST162	03/87-03/88	FR DS
Toyota	Celica 2.0 ST162	11/85-02/90	FR DS
Toyota	Celica 2.0 ST162	11/85-02/90	FR DS
Toyota	Celica 2.8 Supra MA61	08/82-07/86	FR DS
Toyota	Corolla 1.3 (E100) EE101	01/95-07/95	FR DS
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	FR DS
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	FR DS
Toyota	Corolla 1.3 (E100) EE101	07/95-07/97	FR DS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR DS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR DS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR DS
Toyota	Corolla 1.3 (E100) EE101	08/92-07/95	FR DS
Toyota	Corolla 1.3 (E110) EE111	06/97-02/00	FR DS
Toyota	Corolla 1.3 (E110) EE111	06/97-02/00	FR DS
Toyota	Corolla 1.3 (E110) EE111	06/97-02/00	FR DS
Toyota	Corolla 1.3 (E110) EE111	06/97-02/00	FR DS
Toyota	Corolla 1.3 (E110) EE111 G6	06/97-02/00	FR DS
Toyota	Corolla 1.4 (E110) ZZE111	02/00-03/02	FR DS
Toyota	Corolla 1.4 (E110) ZZE111	02/00-03/02	FR DS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	FR DS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	FR DS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	FR DS
Toyota	Corolla 1.6 (E100) AE101	08/92-07/97	FR DS
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR DS
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR DS
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR DS



Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR DS
Toyota	Corolla 1.6 (E110) AE111	06/97-02/00	FR DS
Toyota	Corolla 1.6 (E110) AE111	10/98-02/00	FR DS
Toyota	Corolla 1.6 (E110) AE111	10/98-02/00	FR DS
Toyota	Corolla 1.6 (E110) ZZE111	02/00-03/02	FR DS
Toyota	Corolla 1.6 (E90) AE92	08/87-12/92	FR DS
Toyota	Corolla 1.6 (E90) AE92	08/87-12/92	FR DS
Toyota	Corolla 1.6 (E90) AE95	03/88-12/91	FR DS
Toyota	Corolla 1.6 GTi-16 (E90) AE92	08/87-08/92	FR DS
Toyota	Corolla 1.8 (E100) AE102	03/93-03/95	FR DS
Toyota	Corolla 1.9 (E110) ZZE110	02/00-10/00	FR DS
Toyota	Corolla 2.0 (E110) CDE110	10/00-03/02	FR DS
Toyota	Corolla 2.0 (E110) CDE110	10/00-03/02	FR DS
Toyota	Corolla 2.0 (E110) CE110	06/97-02/00	FR DS
Toyota	GT 86 2.0 (2012-2021)	04/12-04/21	FR PS
Toyota	GT 86 2.0 (2012-2021)	04/12-04/21	FR PS
Toyota	Landcruiser 2.8 D-4D J15	07/15-08/21	FR PS
Toyota	Landcruiser 2.8 D-4D J15	07/15-08/21	FR PS
Toyota	Landcruiser 2.8 D-4D J15	07/15-08/21	FR PS
Toyota	Landcruiser 2.8 D-4D J15	10/20-09/23	FR PS
Toyota	Landcruiser 2.8 D-4D J15	10/20-09/24	FR PS
Toyota	Landcruiser 3.0 D-4D J15	01/11-06/16	FR PS
Toyota	Landcruiser 3.0 D-4D J15	01/11-06/16	FR PS
Toyota	Landcruiser 3.0 D-4D J15	01/11-06/16	FR PS
Toyota	Landcruiser 3.0 D-4D J15	12/09-12/11	FR PS
Toyota	Landcruiser V8 4.5 D-4D J20 (VDJ200)	02/08-08/12	FR PS
Toyota	Landcruiser V8 4.5 D-4D J20 (VDJ200)	12/11-04/16	FR PS
Toyota	MR2 1.8 ZZW30	01/04-12/06	FR DS
Toyota	MR2 1.8 ZZW30	04/00-12/04	FR DS
Toyota	MR2 1.8 ZZW30	04/00-12/04	FR DS
Toyota	MR-S 1.8	01/99-12/05	FR DS
Toyota	MR-S 1.8	01/99-12/05	FR DS
Toyota	Paseo 1.5 EL54	03/96-12/99	FR DS
Toyota	RAV-4 2.0 XA10 (1994-2000)	06/94-10/96	FR DS
Toyota	RAV-4 2.0 XA10 (1994-2000)	06/94-10/96	FR DS
Toyota	RAV-4 2.0 XA10 (1994-2000)	06/94-10/96	FR DS
Toyota	RAV-4 2.0 XA10 (1994-2000)	06/94-10/96	FR DS
Toyota	RAV-4 2.0 XA10 (1994-2000)	10/96-08/00	FR DS
Toyota	RAV-4 2.0 XA10 (1994-2000)	10/96-08/00	FR DS
Toyota	RAV-4 2.0 XA10 (1994-2000)	10/96-08/00	FR DS
Toyota	RAV-4 2.0 XA10 (1994-2000)	10/96-08/00	FR DS
Toyota	Starlet 1.3 90 Series (1996-1999)	03/96-12/99	FR DS
Toyota	Starlet 1.3 90 Series (1996-1999)	03/96-12/99	FR DS
Toyota	Starlet 1.3 90 Series (1996-1999)	03/96-12/99	FR DS
Toyota	Starlet 1.3 90 Series (1996-1999)	03/96-12/99	FR DS
Toyota	Starlet 1.3 90 Series (1996-1999)	03/96-12/99	FR DS
Toyota	Starlet 1.3 90 Series (1996-1999)	12/97-12/99	FR DS
Vauxhall	Agila 1.0 (2000-2008)	06/00-10/03	FR DS
Vauxhall	Agila 1.0 (2000-2008)	10/03-06/08	FR DS
Vauxhall	Agila 1.0 (2008-2014)	03/08-08/12	FR DS

Vauxhall	Agila 1.0 (2008-2014)	07/11-12/14	FR DS
Vauxhall	Agila 1.2 (2000-2008)	06/00-12/04	FR DS
Vauxhall	Agila 1.2 (2008-2014)	03/08-05/11	FR DS
Vauxhall	Agila 1.2 (2008-2014)	03/08-05/11	FR DS
Vauxhall	Agila 1.2 (2008-2014)	09/10-12/14	FR DS
Vauxhall	Agila 1.2 (2008-2014)	09/10-12/14	FR DS
Vauxhall	Agila 1.2 Twinport (2000-2008)	10/04-06/08	FR DS
Vauxhall	Agila 1.3 CDTi 75 (2008-2014)	03/08-03/11	FR DS
Vauxhall	Agila 1.3 CDTi 75 (2008-2014)	03/08-03/11	FR DS
Vauxhall	Arena 1.9 (1997-2000)	01/98-04/00	FR DS
Vauxhall	Arena 1.9 (1997-2000)	01/98-04/00	FR PS
Vauxhall	Arena 1.9 (1997-2000)	01/98-04/00	FR PS
Vauxhall	Arena 1.9 (1997-2000)	01/98-04/00	FR DS
Vauxhall	Arena 2.5 (1997-2000)	03/97-04/00	FR PS
Vauxhall	Arena 2.5 (1997-2000)	03/97-04/00	FR DS
Vauxhall	Arena 2.5 (1997-2000)	03/97-04/00	FR DS
Vauxhall	Arena 2.5 (1997-2000)	03/97-04/00	FR DS
Vauxhall	Arena 2.5 (1997-2000)	03/97-04/00	FR PS
Vauxhall	Arena 2.5 (1997-2000)	03/97-04/00	FR PS
Vauxhall	Astra D 1.2 MK 1 (1980-1984)	01/82-12/84	RR
Vauxhall	Astra D 1.2 MK 1 (1980-1984)	01/82-12/84	RR
Vauxhall	Astra D 1.3 MK 1 (1980-1984)	02/80-12/84	RR
Vauxhall	Astra D 1.3 MK 1 (1980-1984)	02/80-12/84	RR
Vauxhall	Astra D 1.3 MK 1 (1980-1984)	02/80-12/84	RR
Vauxhall	Astra D 1.3 MK 1 (1980-1984)	02/80-12/84	RR
Vauxhall	Astra D 1.6 MK 1 (1980-1984)	12/81-10/84	RR
Vauxhall	Astra D 1.6 MK 1 (1980-1984)	12/81-10/84	RR
Vauxhall	Astra D 1.6 MK 1 (1980-1984)	12/81-10/84	RR
Vauxhall	Astra D 1.6 MK 1 (1980-1984)	12/81-10/84	RR
Vauxhall	Astra D 1.6 MK 1 (1980-1984)	12/82-10/84	RR
Vauxhall	Astra D 1.6 MK 1 (1980-1984)	12/82-10/84	RR
Vauxhall	Astra D 1.8 MK 1 (1980-1984)	04/83-10/84	RR
Vauxhall	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR DS
Vauxhall	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR DS
Vauxhall	Astra F 1.7 LP Turbo MK 3 (1991-1998)	08/94-12/98	FR DS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-03/05	FR DS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-03/05	FR DS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-12/05	FR DS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-12/05	FR DS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-12/05	FR DS
Vauxhall	Astra G 1.4 MK 4 (1998-2006)	02/98-12/05	FR DS
Vauxhall	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	02/98-12/00	FR DS
Vauxhall	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	02/98-12/00	FR DS
Vauxhall	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/00-12/03	FR DS
Vauxhall	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/00-12/03	FR DS
Vauxhall	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/00-12/03	FR DS
Vauxhall	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/00-12/03	FR DS
Vauxhall	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/99-08/04	FR DS
Vauxhall	Astra G 1.6 Dual Fuel MK 4 (1998-2006)	09/99-08/04	FR DS
Vauxhall	Astra G 1.6 MK 4 (1998-2006)	02/98-04/04	FR DS



Vauxhall	Astra G 1.8 Dual Fuel MK 4 (1998-2006)	07/02-08/04	FR DS
Vauxhall	Astra G 1.8 Dual Fuel MK 4 (1998-2006)	07/02-12/03	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	02/98-09/00	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	04/01-05/06	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	07/00-03/02	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	07/00-06/04	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-03/05	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-03/05	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	10/98-09/00	FR DS
Vauxhall	Astra G 1.8 MK 4 (1998-2006)	10/98-09/00	FR DS
Vauxhall	Astra G 2.0 Di MK 4 (1998-2006)	08/00-08/03	FR DS
Vauxhall	Astra G 2.0 Di MK 4 (1998-2006)	09/98-08/03	FR DS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	07/02-03/05	FR DS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-03/05	FR DS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 2.0 DTi MK 4 (1998-2006)	09/00-08/04	FR DS
Vauxhall	Astra G 2.0 MK 4 (1998-2006)	08/98-12/01	FR DS
Vauxhall	Astra G 2.0 SRi Turbo MK 4 (1998-2006)	04/02-12/02	FR DS
Vauxhall	Astra G 2.0 Turbo MK 4 (1998-2006)	03/02-05/06	FR DS
Vauxhall	Astra G 2.0 Turbo MK 4 (1998-2006)	07/00-06/04	FR DS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	04/01-05/06	FR DS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	04/01-05/06	FR DS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	06/02-03/05	FR DS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	06/02-03/05	FR DS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	07/00-06/04	FR DS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	10/00-08/04	FR DS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	10/00-08/04	FR DS
Vauxhall	Astra G 2.2 MK 4 (1998-2006)	10/00-08/04	FR DS
Vauxhall	Combo 1.3 CDTi 70 (2001-2012)	09/04-12/09	FR DS
Vauxhall	Combo 1.3 CDTi 75 (2001-2012)	07/06-12/12	FR DS
Vauxhall	Combo 1.3 CDTi 75 (2001-2012)	07/06-12/12	FR DS
Vauxhall	Combo 1.4 Twinport (2001-2012)	09/04-12/10	FR DS
Vauxhall	Combo 1.6 (2001-2012)	10/01-10/04	FR DS
Vauxhall	Combo 1.7 CDTi 100 (2001-2012)	09/04-06/12	FR DS
Vauxhall	Combo 1.7 Di (2001-2012)	10/01-03/05	FR DS
Vauxhall	Combo 1.7 DTi (2001-2012)	10/01-03/05	FR DS
Vauxhall	Corsa C 1.0 (2000-2003)	04/02-10/03	FR DS
Vauxhall	Corsa C 1.0 (2000-2003)	04/02-10/03	FR DS



Vauxhall	Corsa C 1.7 DTi (2000-2003)	10/00-10/03	FR DS
Vauxhall	Corsa C 1.8 (2000-2003)	10/00-10/03	FR DS
Vauxhall	Corsa C 1.8 (2000-2003)	10/00-10/03	FR DS
Vauxhall	Corsa C 1.8 (2003-2007)	10/03-11/05	FR DS
Vauxhall	Corsa C 1.8 (2003-2007)	10/03-11/05	FR DS
Vauxhall	Insignia Grand Sport 1.5 122 (2017-2022)	10/20-12/22	FR PS
Vauxhall	Insignia Grand Sport 1.5 122 (2017-2022)	10/20-12/22	FR PS
Vauxhall	Insignia Grand Sport 1.5 140 (2017-2022)	02/17-12/18	FR PS
Vauxhall	Insignia Grand Sport 1.5 140 (2017-2022)	02/17-12/18	FR PS
Vauxhall	Insignia Grand Sport 1.5 140 (2017-2022)	06/18-04/19	FR PS
Vauxhall	Insignia Grand Sport 2.0 200 (2017-2022)	10/20-12/22	FR PS
Vauxhall	Insignia Grand Sport 2.0 230 (2017-2022)	10/20-12/22	FR PS
Vauxhall	Insignia Grand Sport 2.0 Turbo D 174 (2017-2022)	10/20-12/22	FR PS
Vauxhall	Insignia Grand Sport 2.0 Turbo D 174 (2017-2022)	10/20-12/22	FR PS
Vauxhall	Monterey 3.1	05/94-03/99	FR PS
Vauxhall	Monterey 3.1	05/94-03/99	FR PS
Vauxhall	Monterey 3.1	05/94-03/99	FR DS
Vauxhall	Monterey 3.1	05/94-03/99	FR DS
Vauxhall	Monterey 3.2	05/94-03/99	FR PS
Vauxhall	Monterey 3.2	05/94-03/99	FR DS
Vauxhall	Monterey 3.2	05/94-03/99	FR PS
Vauxhall	Monterey 3.2	05/94-03/99	FR DS
Vauxhall	Monterey 3.2	05/94-03/99	FR DS
Vauxhall	Monterey 3.2	05/94-03/99	FR PS
Vauxhall	Monterey 3.2	05/94-03/99	FR DS
Vauxhall	Monterey 3.2	05/94-03/99	FR PS
Vauxhall	Monterey 3.2	05/94-03/99	FR PS
Vauxhall	Tigra 1.3 CDTi (2004-2010)	03/05-06/10	FR DS
Vauxhall	Tigra 1.4 (1994-2001)	11/94-04/01	RR
Vauxhall	Tigra 1.4 (1994-2001)	11/94-04/01	RR
Vauxhall	Tigra 1.4 (2004-2010)	10/04-06/10	FR DS
Vauxhall	Tigra 1.6 (1994-2001)	11/94-04/01	RR
Vauxhall	Tigra 1.8 (2004-2010)	10/04-06/10	FR DS
Volkswagen	Caddy 1.4 (1996-2004)	02/01-03/04	FR DS
Volkswagen	Caddy 1.4 (1996-2004)	04/96-07/99	FR DS
Volkswagen	Caddy 1.4 (1996-2004)	04/96-07/99	FR DS
Volkswagen	Caddy 1.4 (1996-2004)	04/96-07/99	FR DS
Volkswagen	Caddy 1.6 (1996-2004)	10/98-04/01	FR DS
Volkswagen	Caddy 1.9 (1996-2004)	04/96-03/04	FR DS
Volkswagen	Caddy 1.9 (1996-2004)	04/96-03/04	FR DS
Volkswagen	Caddy 1.9 (1996-2004)	04/96-03/04	FR DS
Volkswagen	Caddy 1.9 (1996-2004)	04/96-12/00	FR DS
Volkswagen	Caddy 1.9 TDi (1996-2004)	05/00-03/04	FR DS
Volkswagen	Caddy 1.9 TDi (1996-2004)	05/00-03/04	FR DS
Volkswagen	Caddy 1.9 TDi (1996-2004)	05/00-03/04	FR DS
Volvo	440 1.6	11/91-07/97	RR
Volvo	440 1.7 Carburettor	08/89-10/90	RR
Volvo	440 1.7 Carburettor Catalyst	08/89-12/91	RR
Volvo	440 1.7 Injection Catalyst	08/89-12/92	RR
Volvo	440 1.7 Turbo	12/88-10/90	RR
Volvo	440 1.7 Turbo	12/88-10/90	RR



Volvo	740 2.3 Turbo	08/89-12/90	FR PS
Volvo	740 2.3 Turbo	08/89-12/90	FR PS
Volvo	740 2.3 Turbo	08/89-12/90	FR DS
Volvo	740 2.3 Turbo	08/89-12/90	FR DS
Volvo	740 2.3 Turbo	08/89-12/90	FR DS
Volvo	740 2.3 Turbo	08/89-12/90	FR PS
Volvo	740 2.3 Turbo Catalyst	08/89-12/90	FR DS
Volvo	740 2.3 Turbo Catalyst	08/89-12/90	FR PS
Volvo	740 2.3 Turbo Catalyst	08/89-12/90	FR DS
Volvo	740 2.3 Turbo Catalyst	08/89-12/90	FR PS
Volvo	740 2.3 Turbo Catalyst	08/89-12/90	FR PS
Volvo	740 2.3 Turbo Catalyst	08/89-12/90	FR DS
Volvo	740 2.3 Turbo Catalyst	08/89-12/90	FR PS
Volvo	740 2.3 Turbo Catalyst	08/89-12/90	FR DS
Volvo	740 2.4 Turbo	08/86-12/90	FR PS
Volvo	740 2.4 Turbo	08/86-12/90	FR PS
Volvo	740 2.4 Turbo	08/86-12/90	FR DS
Volvo	740 2.4 Turbo	08/86-12/90	FR DS
Volvo	760 2.3 Turbo	05/83-08/87	FR DS
Volvo	760 2.3 Turbo	05/83-08/87	FR PS
Volvo	760 2.3 Turbo	05/83-08/87	FR DS
Volvo	760 2.3 Turbo	05/83-08/87	FR PS
Volvo	760 2.3 Turbo	08/87-12/90	FR DS
Volvo	760 2.3 Turbo	08/87-12/90	FR DS
Volvo	760 2.3 Turbo	08/87-12/90	FR PS
Volvo	760 2.3 Turbo	08/87-12/90	FR PS
Volvo	760 2.3 Turbo	08/87-12/90	FR DS
Volvo	760 2.3 Turbo	08/87-12/90	FR DS
Volvo	760 2.3 Turbo	08/87-12/90	FR PS
Volvo	760 2.3 Turbo	08/87-12/90	FR PS
Volvo	760 2.3 Turbo	10/85-08/87	FR PS
Volvo	760 2.3 Turbo	10/85-08/87	FR DS
Volvo	760 2.3 Turbo	10/85-08/87	FR DS
Volvo	760 2.3 Turbo	10/85-08/87	FR PS
Volvo	760 2.8 Injection	07/82-08/87	FR PS
Volvo	760 2.8 Injection	07/82-08/87	FR PS
Volvo	760 2.8 Injection	07/82-08/87	FR DS
Volvo	760 2.8 Injection	07/82-08/87	FR PS
Volvo	760 2.8 Injection	07/82-08/87	FR DS
Volvo	760 2.8 Injection	07/82-08/87	FR DS
Volvo	760 2.8 Injection	07/82-08/87	FR PS
Volvo	760 2.8 Injection	08/87-12/90	FR DS
Volvo	760 2.8 Injection	08/87-12/90	FR PS
Volvo	760 2.8 Injection	08/87-12/90	FR DS
Volvo	760 2.8 Injection	08/87-12/90	FR PS
Volvo	760 2.8 Injection	10/85-08/87	FR DS
Volvo	760 2.8 Injection	10/85-08/87	FR PS
Volvo	760 2.8 Injection	10/85-08/87	FR PS
Volvo	760 2.8 Injection	10/85-08/87	FR PS



Volvo	760 2.8 Injection	10/85-08/87	FR DS
Volvo	760 2.8 Injection	10/85-08/87	FR DS
Volvo	760 2.8 Injection	10/85-08/87	FR DS
Volvo	760 2.8 Injection	10/85-08/87	FR PS
Volvo	940 2.0	09/90-12/94	FR DS
Volvo	940 2.0	09/90-12/94	FR PS
Volvo	940 2.0	09/90-12/94	FR PS
Volvo	940 2.0	09/90-12/94	FR PS
Volvo	940 2.0	09/90-12/94	FR PS
Volvo	940 2.0	09/90-12/94	FR DS
Volvo	940 2.0	09/90-12/94	FR DS
Volvo	940 2.0	09/90-12/94	FR DS
Volvo	940 2.0 Turbo	04/91-12/94	FR PS
Volvo	940 2.0 Turbo	04/91-12/94	FR PS
Volvo	940 2.0 Turbo	04/91-12/94	FR DS
Volvo	940 2.0 Turbo	04/91-12/94	FR DS
Volvo	940 2.0 Turbo	04/91-12/94	FR DS
Volvo	940 2.0 Turbo	04/91-12/94	FR PS
Volvo	940 2.0 Turbo	04/91-12/94	FR DS
Volvo	940 2.0 Turbo	04/91-12/94	FR PS
Volvo	940 2.3	09/90-07/95	FR PS
Volvo	940 2.3	09/90-07/95	FR DS
Volvo	940 2.3	09/90-07/95	FR DS
Volvo	940 2.3	09/90-07/95	FR PS
Volvo	940 2.3	09/90-12/92	FR PS
Volvo	940 2.3	09/90-12/92	FR PS
Volvo	940 2.3	09/90-12/92	FR DS
Volvo	940 2.3	09/90-12/92	FR DS
Volvo	940 2.3	09/90-12/92	FR DS
Volvo	940 2.3	09/90-12/92	FR DS
Volvo	940 2.3	09/90-12/92	FR DS
Volvo	940 2.3	09/90-12/92	FR PS
Volvo	940 2.3	09/90-12/92	FR DS
Volvo	940 2.3	09/90-12/92	FR PS
Volvo	940 2.3	09/90-12/92	FR PS
Volvo	940 2.3	09/90-12/92	FR PS
Volvo	940 2.3	09/90-12/94	FR PS
Volvo	940 2.3	09/90-12/94	FR PS
Volvo	940 2.3	09/90-12/94	FR DS
Volvo	940 2.3	09/90-12/94	FR DS
Volvo	940 2.3	09/90-12/94	FR PS
Volvo	940 2.3	09/90-12/94	FR PS
Volvo	940 2.3	09/90-12/94	FR DS
Volvo	940 2.3	09/90-12/94	FR DS
Volvo	940 2.3 H P Turbo	03/96-10/97	FR DS
Volvo	940 2.3 H P Turbo	03/96-10/97	FR PS
Volvo	940 2.3 H P Turbo	03/96-10/97	FR DS
Volvo	940 2.3 H P Turbo	03/96-10/97	FR PS
Volvo	940 2.3 L P Turbo	02/95-11/97	FR DS
Volvo	940 2.3 L P Turbo	02/95-11/97	FR PS

Volvo	940 2.3 L P Turbo	02/95-11/97	FR DS
Volvo	940 2.3 L P Turbo	02/95-11/97	FR PS
Volvo	940 2.3 L P Turbo	10/95-10/97	FR DS
Volvo	940 2.3 L P Turbo	10/95-10/97	FR PS
Volvo	940 2.3 L P Turbo	10/95-10/97	FR DS
Volvo	940 2.3 L P Turbo	10/95-10/97	FR PS
Volvo	940 2.3 L P Turbo	10/95-10/97	FR DS
Volvo	940 2.3 L P Turbo	10/95-10/97	FR PS
Volvo	940 2.3 L P Turbo	10/95-10/97	FR DS
Volvo	940 2.3 L P Turbo	10/95-10/97	FR PS
Volvo	940 2.3 Turbo	08/94-03/96	FR PS
Volvo	940 2.3 Turbo	08/94-03/96	FR DS
Volvo	940 2.3 Turbo	08/94-03/96	FR PS
Volvo	940 2.3 Turbo	08/94-03/96	FR DS
Volvo	940 2.3 Turbo	09/90-12/93	FR PS
Volvo	940 2.3 Turbo	09/90-12/93	FR DS
Volvo	940 2.3 Turbo	09/90-12/93	FR DS
Volvo	940 2.3 Turbo	09/90-12/93	FR PS
Volvo	940 2.3 Turbo	09/90-12/93	FR PS
Volvo	940 2.3 Turbo	09/90-12/93	FR PS
Volvo	940 2.3 Turbo	09/90-12/93	FR DS
Volvo	940 2.3 Turbo	09/90-12/93	FR DS
Volvo	940 2.4	09/90-10/91	FR PS
Volvo	940 2.4	09/90-10/91	FR DS
Volvo	940 2.4	09/90-10/91	FR DS
Volvo	940 2.4	09/90-10/91	FR DS
Volvo	940 2.4	09/90-10/91	FR PS
Volvo	940 2.4	09/90-10/91	FR PS
Volvo	940 2.4	09/90-10/91	FR DS
Volvo	940 2.4	09/90-10/91	FR PS
Volvo	940 2.4	10/91-07/96	FR DS
Volvo	940 2.4	10/91-07/96	FR PS
Volvo	940 2.4	10/91-07/96	FR DS
Volvo	940 2.4	10/91-07/96	FR PS
Volvo	940 2.4	10/91-07/96	FR DS
Volvo	940 2.4	10/91-07/96	FR PS
Volvo	940 2.4	10/91-07/96	FR PS
Volvo	940 2.4	10/91-07/96	FR DS
Volvo	S40 1.6 (1996-2000)	04/99-05/00	FR PS
Volvo	S40 1.6 (2000-2004)	05/00-08/04	FR PS
Volvo	S40 1.8 (1996-2000)	03/96-04/99	FR PS
Volvo	S40 1.8 (1996-2000)	03/96-04/99	FR PS
Volvo	S40 1.8 (1996-2000)	03/96-04/99	FR PS
Volvo	S40 1.8 (1996-2000)	03/96-04/99	FR PS
Volvo	S40 1.8 (1996-2000)	04/98-05/00	FR PS
Volvo	S40 1.8 (1996-2000)	04/99-05/00	FR PS
Volvo	S40 1.8 (1996-2000)	04/99-05/00	FR PS
Volvo	S40 1.8 (1996-2000)	04/99-05/00	FR PS
Volvo	S40 1.8 (2000-2004)	05/00-08/04	FR PS
Volvo	S40 1.8 (2000-2004)	05/00-08/04	FR PS
Volvo	S40 1.8 (2000-2004)	05/00-09/00	FR PS

Volvo	S40 1.8 i (2000-2004)	09/00-08/04	FR PS
Volvo	S40 1.8 i (2000-2004)	09/00-08/04	FR PS
Volvo	S40 1.9 (1996-2000)	01/99-05/00	FR PS
Volvo	S40 1.9 (1996-2000)	12/96-02/99	FR PS
Volvo	S40 1.9 (2000-2004)	05/00-05/03	FR PS
Volvo	S40 1.9 (2000-2004)	05/00-06/04	FR PS
Volvo	S40 1.9 T4 (1996-2000)	06/97-05/00	FR PS
Volvo	S40 1.9 T4 (1996-2000)	06/97-05/00	FR PS
Volvo	S40 1.9 T4 (1996-2000)	06/97-05/00	FR PS
Volvo	S40 1.9 T4 (1996-2000)	06/97-05/00	FR PS
Volvo	S40 1.9 T4 (2000-2004)	05/00-05/03	FR PS
Volvo	S40 1.9 T4 (2000-2004)	05/00-05/03	FR PS
Volvo	S40 2.0 (1996-2000)	03/96-05/00	FR PS
Volvo	S40 2.0 (1996-2000)	03/96-05/00	FR PS
Volvo	S40 2.0 (1996-2000)	03/96-05/00	FR PS
Volvo	S40 2.0 (1996-2000)	03/96-05/00	FR PS
Volvo	S40 2.0 (2000-2004)	05/00-08/04	FR PS
Volvo	S40 2.0 (2000-2004)	05/00-08/04	FR PS
Volvo	S40 2.0 (2000-2004)	05/00-08/04	FR PS
Volvo	S40 2.0 (2000-2004)	05/00-08/04	FR PS
Volvo	S40 2.0 Turbo (1996-2000)	10/97-05/00	FR PS
Volvo	S40 2.0 Turbo (1996-2000)	10/97-05/00	FR PS
Volvo	S40 2.0 Turbo (2000-2004)	05/00-08/04	FR PS
Volvo	S40 2.0 Turbo (2000-2004)	05/00-08/04	FR PS
Volvo	V40 1.6 (1996-2000)	04/99-05/00	FR PS
Volvo	V40 1.6 (1996-2000)	04/99-05/00	FR PS
Volvo	V40 1.6 (2000-2004)	05/00-08/04	FR PS
Volvo	V40 1.6 (2000-2004)	05/00-08/04	FR PS
Volvo	V40 1.8 (1996-2000)	03/96-04/99	FR PS
Volvo	V40 1.8 (1996-2000)	03/96-04/99	FR PS
Volvo	V40 1.8 (1996-2000)	03/96-04/99	FR PS
Volvo	V40 1.8 (1996-2000)	03/96-04/99	FR PS
Volvo	V40 1.8 (1996-2000)	04/98-05/00	FR PS
Volvo	V40 1.8 (1996-2000)	04/98-05/00	FR PS
Volvo	V40 1.8 (1996-2000)	04/99-05/00	FR PS
Volvo	V40 1.8 (1996-2000)	04/99-05/00	FR PS
Volvo	V40 1.8 (2000-2004)	05/00-08/04	FR PS
Volvo	V40 1.8 (2000-2004)	05/00-08/04	FR PS
Volvo	V40 1.8 (2000-2004)	05/00-09/00	FR PS
Volvo	V40 1.8 (2000-2004)	05/00-09/00	FR PS
Volvo	V40 1.8 (2000-2004)	05/00-09/00	FR PS
Volvo	V40 1.8 (2000-2004)	05/00-09/00	FR PS
Volvo	V40 1.8 (2000-2004)	09/00-08/04	FR PS
Volvo	V40 1.8 (2000-2004)	09/00-08/04	FR PS
Volvo	V40 1.8 Dual Fuel (2000-2004)	05/00-08/04	FR PS
Volvo	V40 1.8 Dual Fuel (2000-2004)	05/00-08/04	FR PS
Volvo	V40 1.9 (1996-2000)	01/99-05/00	FR PS
Volvo	V40 1.9 (1996-2000)	12/96-02/99	FR PS
Volvo	V40 1.9 (2000-2004)	05/00-05/03	FR PS
Volvo	V40 1.9 (2000-2004)	05/00-06/04	FR PS

Volvo	V40 1.9 T4 (1996-2000)	06/97-05/00	FR PS
Volvo	V40 1.9 T4 (1996-2000)	06/97-05/00	FR PS
Volvo	V40 1.9 T4 (2000-2004)	05/00-05/03	FR PS
Volvo	V40 1.9 T4 (2000-2004)	05/00-05/03	FR PS
Volvo	V40 2.0 (1996-2000)	03/96-05/00	FR PS
Volvo	V40 2.0 (1996-2000)	03/96-05/00	FR PS
Volvo	V40 2.0 (1996-2000)	03/96-05/00	FR PS
Volvo	V40 2.0 (1996-2000)	03/96-05/00	FR PS
Volvo	V40 2.0 (2000-2004)	05/00-08/04	FR PS
Volvo	V40 2.0 (2000-2004)	05/00-08/04	FR PS
Volvo	V40 2.0 (2000-2004)	05/00-08/04	FR PS
Volvo	V40 2.0 (2000-2004)	05/00-08/04	FR PS
Volvo	V40 2.0 Turbo (1996-2000)	10/97-05/00	FR PS
Volvo	V40 2.0 Turbo (1996-2000)	10/97-05/00	FR PS
Volvo	V40 2.0 Turbo (1996-2000)	10/97-05/00	FR PS
Volvo	V40 2.0 Turbo (1996-2000)	10/97-05/00	FR PS
Volvo	V40 2.0 Turbo (2000-2004)	05/00-08/04	FR PS
Volvo	V40 2.0 Turbo (2000-2004)	05/00-08/04	FR PS
Volvo	V40 2.0 Turbo (2000-2004)	05/00-08/04	FR PS
Volvo	V40 2.0 Turbo (2000-2004)	05/00-08/04	FR PS