

**Lucas**

## Compatibility Chart

MANUFACTURER	CAR MODEL	YEAR RANGE	POSITION
Alfa Romeo	155 1.8 167 (1992-1998)	06/95-07/96	FR DS
Alfa Romeo	155 1.8 167 (1992-1998)	06/95-07/96	FR DS
Alfa Romeo	155 1.8 167 (1992-1998)	07/92-06/95	FR DS
Alfa Romeo	155 1.8 167 (1992-1998)	07/92-06/95	FR DS
Alfa Romeo	155 1.8 167 (1992-1998)	07/96-04/98	FR DS
Alfa Romeo	155 2.0 167 (1992-1998)	06/95-04/98	FR DS
Alfa Romeo	155 2.0 Cloverleaf 4 167 (1992-1998)	01/94-06/95	FR DS
Alfa Romeo	155 2.5 167 (1992-1998)	06/95-09/96	FR DS
Alfa Romeo	155 2.5 167 (1992-1998)	06/95-09/96	FR DS
Alfa Romeo	155 2.5 167 (1992-1998)	06/95-09/96	FR DS
Alfa Romeo	155 2.5 167 (1992-1998)	07/92-06/95	FR DS
Alfa Romeo	155 2.5 167 (1992-1998)	07/92-06/95	FR DS
Alfa Romeo	155 2.5 167 (1992-1998)	07/92-06/95	FR DS
Alfa Romeo	156 1.6 932 (1998-2006)	04/00-03/06	FR PS
Alfa Romeo	156 1.6 932 (1998-2006)	04/00-03/06	FR PS
Alfa Romeo	156 1.6 932 (1998-2006)	04/00-03/06	FR PS
Alfa Romeo	156 1.6 932 (1998-2006)	04/00-03/06	FR PS
Alfa Romeo	156 1.6 932 (1998-2006)	06/00-12/03	FR PS
Alfa Romeo	156 1.6 932 (1998-2006)	06/00-12/03	FR PS
Alfa Romeo	156 1.6 932 (1998-2006)	06/00-12/03	FR PS
Alfa Romeo	156 1.6 932 (1998-2006)	06/00-12/03	FR PS
Alfa Romeo	156 1.8 932 (1998-2006)	01/98-06/02	FR PS
Alfa Romeo	156 1.8 932 (1998-2006)	01/98-06/02	FR PS
Alfa Romeo	156 1.8 932 (1998-2006)	05/02-03/06	FR PS
Alfa Romeo	156 1.8 932 (1998-2006)	05/02-03/06	FR PS
Alfa Romeo	156 1.8 932 (1998-2006)	06/00-06/02	FR PS
Alfa Romeo	156 1.8 932 (1998-2006)	06/00-06/02	FR PS
Alfa Romeo	156 1.9 JTD 115 932 (1998-2006)	04/03-03/06	FR PS
Alfa Romeo	156 1.9 JTD 115 932 (1998-2006)	04/03-03/06	FR PS
Alfa Romeo	156 1.9 JTD 140 932 (1998-2006)	09/03-04/05	FR PS
Alfa Romeo	156 1.9 JTD 140 932 (1998-2006)	09/03-04/05	FR PS
Alfa Romeo	156 1.9 JTD 150 932 (1998-2006)	03/05-03/06	FR PS
Alfa Romeo	156 1.9 JTD 150 932 (1998-2006)	03/05-03/06	FR PS
Alfa Romeo	156 2.0 932 (1998-2006)	01/98-06/02	FR PS
Alfa Romeo	156 2.0 932 (1998-2006)	01/98-06/02	FR PS
Alfa Romeo	156 2.0 932 (1998-2006)	01/98-06/02	FR PS
Alfa Romeo	156 2.0 932 (1998-2006)	05/02-03/06	FR PS
Alfa Romeo	156 2.0 932 (1998-2006)	05/02-03/06	FR PS
Alfa Romeo	156 2.0 932 (1998-2006)	05/02-03/06	FR PS
Alfa Romeo	156 2.0 932 (1998-2006)	06/00-06/02	FR PS
Alfa Romeo	156 2.0 932 (1998-2006)	06/00-06/02	FR PS
Alfa Romeo	156 2.0 932 (1998-2006) Selespeed	05/02-03/06	FR PS
Alfa Romeo	156 2.0 932 (1998-2006) Selespeed	05/02-03/06	FR PS
Alfa Romeo	156 2.0 932 (1998-2006) Selespeed	05/02-03/06	FR PS
Alfa Romeo	156 2.0 932 (1998-2006) Selespeed	06/00-06/02	FR PS
Alfa Romeo	156 2.0 932 (1998-2006) Selespeed	06/00-06/02	FR PS

Alfa Romeo	156 2.4 932 (1998-2006)	06/00-10/02	FR PS
Alfa Romeo	156 2.4 932 (1998-2006)	06/00-10/02	FR PS
Alfa Romeo	156 2.4 932 (1998-2006)	06/99-10/02	FR PS
Alfa Romeo	156 2.4 932 (1998-2006)	06/99-10/02	FR PS
Alfa Romeo	156 2.4 JTD 20V 932 (1998-2006)	09/03-03/06	FR PS
Alfa Romeo	156 2.4 JTD 20V 932 (1998-2006)	09/03-03/06	FR PS
Alfa Romeo	156 2.4 JTD 932 (1998-2006)	10/02-09/03	FR PS
Alfa Romeo	156 2.4 JTD 932 (1998-2006)	10/02-09/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	01/98-10/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	01/98-10/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	01/98-10/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	01/98-10/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	06/00-10/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	06/00-10/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	06/00-10/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	06/00-10/03	FR PS
Alfa Romeo	156 2.5 932 (1998-2006)	06/00-10/03	FR PS
Alfa Romeo	156 3.2 GTA 932 (1998-2006)	05/02-12/05	FR PS
Alfa Romeo	156 3.2 GTA 932 (1998-2006)	05/02-12/05	FR PS
Alfa Romeo	164 2.0 164 (1988-1998)	05/93-04/98	FR
Alfa Romeo	164 2.0 164 (1988-1998)	07/90-11/92	FR
Alfa Romeo	164 2.0 164 (1988-1998)	07/90-11/92	FR
Alfa Romeo	164 2.0 164 (1988-1998)	11/92-09/93	FR
Alfa Romeo	164 3.0 164 (1988-1998)	05/93-04/98	FR
Alfa Romeo	164 3.0 164 (1988-1998)	05/93-04/98	FR
Alfa Romeo	164 3.0 164 (1988-1998)	10/88-05/93	FR
Alfa Romeo	164 3.0 Cloverleaf 164 (1988-1998)	05/93-04/98	FR
Alfa Romeo	164 3.0 Cloverleaf 164 (1988-1998)	10/90-05/93	FR
Alfa Romeo	164 3.0 Cloverleaf 164 (1988-1998)	10/90-05/93	FR
Alfa Romeo	166 2.0 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 2.0 936 (1999-2003)	09/00-10/03	FR DS
Alfa Romeo	166 2.0 936 (2003-2005)	09/03-12/05	FR DS
Alfa Romeo	166 2.0 936 (2003-2005)	09/03-12/05	FR DS
Alfa Romeo	166 2.5 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 2.5 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 2.5 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 2.5 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 2.5 936 (2003-2005)	09/03-04/04	FR DS
Alfa Romeo	166 3.0 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 3.0 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 3.0 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 3.0 936 (1999-2003)	01/99-10/03	FR DS
Alfa Romeo	166 3.0 936 (2003-2005)	09/03-12/05	FR DS
Alfa Romeo	166 3.0 936 (2003-2005)	09/03-12/05	FR DS
Alfa Romeo	166 3.2 936 (2003-2005)	04/04-12/05	FR DS
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	FR DS
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	RR
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	RR
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	FR PS
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	RR
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	FR DS

Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	FR PS
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	RR
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	FR PS
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	FR DS
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	FR DS
Audi	100 1.8 Avant C3 (1983-1991)	08/83-10/86	FR PS
Audi	100 1.8 C3 (1983-1991)	08/83-08/86	FR PS
Audi	100 1.8 C3 (1983-1991)	08/83-08/86	FR DS
Audi	100 1.8 C3 (1983-1991)	08/83-08/86	FR PS
Audi	100 1.8 C3 (1983-1991)	08/83-08/86	FR DS
Audi	100 1.8 C3 (1983-1991)	08/83-08/86	FR DS
Audi	100 1.8 C3 (1983-1991)	08/83-08/86	FR PS
Audi	100 1.8 C3 (1983-1991)	08/83-08/86	FR DS
Audi	100 1.8 C3 (1983-1991)	08/83-08/86	FR PS
Audi	100 1.9 C3 (1983-1991)	01/83-07/83	FR DS
Audi	100 1.9 C3 (1983-1991)	01/83-07/83	FR DS
Audi	100 1.9 C3 (1983-1991)	01/83-07/83	FR PS
Audi	100 1.9 C3 (1983-1991)	01/83-07/83	FR PS
Audi	100 2.0 Avant C3 (1983-1991)	08/88-05/91	FR DS
Audi	100 2.0 Avant C3 (1983-1991)	08/88-05/91	RR
Audi	100 2.0 Avant C3 (1983-1991)	08/88-05/91	FR PS
Audi	100 2.0 Avant C3 (1983-1991)	10/83-08/88	RR
Audi	100 2.0 Avant C3 (1983-1991)	10/83-08/88	FR PS
Audi	100 2.0 Avant C3 (1983-1991)	10/83-08/88	FR PS
Audi	100 2.0 Avant C3 (1983-1991)	10/83-08/88	RR
Audi	100 2.0 Avant C3 (1983-1991)	10/83-08/88	FR DS
Audi	100 2.0 Avant C3 (1983-1991)	10/83-08/88	FR DS
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	FR PS
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	RR
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	RR
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	FR PS
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	RR
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	FR DS
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	FR PS
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	RR
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	RR
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	FR PS
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	FR DS
Audi	100 2.0 Avant C3 (1983-1991)	10/86-05/91	RR
Audi	100 2.0 C3 (1983-1991)	02/83-07/88	FR DS
Audi	100 2.0 C3 (1983-1991)	02/83-07/88	FR PS
Audi	100 2.0 C3 (1983-1991)	02/83-07/88	FR PS
Audi	100 2.0 C3 (1983-1991)	02/83-07/88	FR DS
Audi	100 2.0 C3 (1983-1991)	03/85-05/91	FR PS
Audi	100 2.0 C3 (1983-1991)	03/85-05/91	FR DS
Audi	100 2.0 C3 (1983-1991)	03/85-05/91	FR PS
Audi	100 2.0 C3 (1983-1991)	03/85-05/91	FR PS
Audi	100 2.0 C3 (1983-1991)	03/85-05/91	FR PS
Audi	100 2.0 C3 (1983-1991)	03/85-05/91	FR DS
Audi	100 2.0 C3 (1983-1991)	03/85-05/91	FR DS

Audi	100 2.0 C3 (1983-1991)	03/85-05/91	FR DS
Audi	100 2.0 C3 (1983-1991)	07/88-05/91	FR PS
Audi	100 2.0 C3 (1983-1991)	07/88-05/91	FR DS
Audi	100 2.1 Avant C3 (1983-1991)	08/83-01/85	FR PS
Audi	100 2.1 Avant C3 (1983-1991)	08/83-01/85	FR PS
Audi	100 2.1 Avant C3 (1983-1991)	08/83-01/85	RR
Audi	100 2.1 Avant C3 (1983-1991)	08/83-01/85	RR
Audi	100 2.1 Avant C3 (1983-1991)	08/83-01/85	FR DS
Audi	100 2.1 Avant C3 (1983-1991)	08/83-01/85	FR DS
Audi	100 2.2 Avant C3 (1983-1991)	01/85-09/89	FR DS
Audi	100 2.2 Avant C3 (1983-1991)	01/85-09/89	FR DS
Audi	100 2.2 Avant C3 (1983-1991)	01/85-09/89	FR PS
Audi	100 2.2 Avant C3 (1983-1991)	01/85-09/89	FR PS
Audi	100 2.2 Avant C3 (1983-1991)	01/85-09/89	RR
Audi	100 2.2 Avant C3 (1983-1991)	01/85-09/89	RR
Audi	100 2.2 Avant quattro C3 (1983-1991)	08/88-09/89	RR
Audi	100 2.2 Avant quattro C3 (1983-1991)	08/88-09/89	FR DS
Audi	100 2.2 Avant quattro C3 (1983-1991)	08/88-09/89	FR PS
Audi	100 2.2 Avant quattro C3 (1983-1991)	08/88-09/89	RR
Audi	100 2.2 Avant quattro C3 (1983-1991)	08/88-09/89	FR PS
Audi	100 2.2 Avant quattro C3 (1983-1991)	08/88-09/89	FR DS
Audi	100 2.2 Avant Turbo C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.2 Avant Turbo C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.2 Avant Turbo C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.2 Avant Turbo C3 (1983-1991)	09/89-05/91	RR
Audi	100 2.2 Avant Turbo C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.2 Avant Turbo C3 (1983-1991)	09/89-05/91	RR
Audi	100 2.2 Avant Turbo quattro C3 (1983-1991)	09/89-05/91	RR
Audi	100 2.2 Avant Turbo quattro C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.2 Avant Turbo quattro C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.2 C3 (1983-1991)	01/85-09/89	FR PS
Audi	100 2.2 C3 (1983-1991)	01/85-09/89	FR DS
Audi	100 2.2 C3 (1983-1991)	01/85-09/89	FR DS
Audi	100 2.2 C3 (1983-1991)	01/85-09/89	FR PS
Audi	100 2.2 quattro C3 (1983-1991)	07/84-09/89	FR PS
Audi	100 2.2 quattro C3 (1983-1991)	07/84-09/89	FR DS
Audi	100 2.2 Turbo C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.2 Turbo C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.2 Turbo C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.2 Turbo C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.2 Turbo quattro C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.2 Turbo quattro C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.3 Avant C3 (1983-1991)	09/89-05/91	RR
Audi	100 2.3 Avant C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.3 Avant C3 (1983-1991)	09/89-05/91	RR
Audi	100 2.3 Avant C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.3 Avant C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.3 Avant C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.3 Avant quattro C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.3 Avant quattro C3 (1983-1991)	09/89-05/91	RR

Audi	100 2.3 Avant quattro C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.3 C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.3 C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.3 C3 (1983-1991)	09/89-05/91	FR DS
Audi	100 2.3 C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.3 quattro C3 (1983-1991)	09/89-05/91	FR PS
Audi	100 2.3 quattro C3 (1983-1991)	09/89-05/91	FR DS
Audi	200 2.1 Avant Turbo quattro C3 (1984-1989)	05/85-12/87	RR
Audi	200 2.1 Avant Turbo quattro C3 (1984-1989)	05/85-12/87	FR PS
Audi	200 2.1 Avant Turbo quattro C3 (1984-1989)	05/85-12/87	FR DS
Audi	200 2.1 Turbo C2 (1980-1984)	03/83-03/84	FR DS
Audi	200 2.1 Turbo C2 (1980-1984)	03/83-03/84	FR PS
Audi	200 2.1 Turbo C2 (1980-1984)	03/83-03/84	FR DS
Audi	200 2.1 Turbo C2 (1980-1984)	03/83-03/84	FR PS
Audi	200 2.1 Turbo C3 (1984-1989)	03/84-12/87	FR PS
Audi	200 2.1 Turbo C3 (1984-1989)	03/84-12/87	FR DS
Audi	200 2.1 Turbo C3 (1984-1989)	03/84-12/87	FR DS
Audi	200 2.1 Turbo C3 (1984-1989)	03/84-12/87	FR PS
Audi	200 2.1 Turbo quattro C3 (1984-1989)	01/85-12/87	FR DS
Audi	200 2.1 Turbo quattro C3 (1984-1989)	01/85-12/87	FR PS
Audi	200 2.2 Avant Turbo quattro C3 (1984-1989)	09/88-08/89	FR PS
Audi	200 2.2 Avant Turbo quattro C3 (1984-1989)	09/88-08/89	FR DS
Audi	200 2.2 Avant Turbo quattro C3 (1984-1989)	09/88-08/89	RR
Audi	200 2.2 Turbo C3 (1984-1989)	11/84-08/89	FR DS
Audi	200 2.2 Turbo C3 (1984-1989)	11/84-08/89	FR DS
Audi	200 2.2 Turbo C3 (1984-1989)	11/84-08/89	FR PS
Audi	200 2.2 Turbo C3 (1984-1989)	11/84-08/89	FR PS
Audi	200 2.2 Turbo quattro C3 (1984-1989)	09/88-08/89	FR PS
Audi	200 2.2 Turbo quattro C3 (1984-1989)	09/88-08/89	FR DS
Audi	80 1.6 Avant B4 (1991-1995)	03/94-03/95	FR DS
Audi	80 1.6 Avant B4 (1991-1995)	03/94-03/95	FR PS
Audi	80 1.6 B3 (1986-1991)	12/88-10/91	FR DS
Audi	80 1.6 B3 (1986-1991)	12/88-10/91	FR PS
Audi	80 1.6 B3 (1986-1991)	12/88-10/91	FR DS
Audi	80 1.6 B3 (1986-1991)	12/88-10/91	FR PS
Audi	80 1.6 B4 (1991-1995)	09/93-03/95	FR DS
Audi	80 1.6 B4 (1991-1995)	09/93-03/95	FR PS
Audi	80 1.8 B3 (1986-1991)	01/88-09/89	FR DS
Audi	80 1.8 B3 (1986-1991)	01/88-09/89	FR PS
Audi	80 1.8 B3 (1986-1991)	01/88-09/89	FR PS
Audi	80 1.8 B3 (1986-1991)	01/88-09/89	FR DS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR PS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR PS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR PS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR PS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR PS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR DS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR DS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR PS
Audi	80 1.8 Carbuettor B3 (1986-1991)	10/86-09/89	FR DS

Audi	80 1.8 Carburettor B3 (1986-1991)	10/86-09/89	FR DS
Audi	80 1.8 Carburettor B3 (1986-1991)	10/86-09/89	FR DS
Audi	80 1.8 Carburettor B3 (1986-1991)	10/86-09/89	FR DS
Audi	80 1.8 Carburettor B3 (1986-1991)	10/86-09/89	FR PS
Audi	80 1.8 Carburettor B3 (1986-1991)	10/86-09/89	FR DS
Audi	80 1.8 Carburettor B3 (1986-1991)	10/86-09/89	FR DS
Audi	80 1.8 Carburettor B3 (1986-1991)	10/86-09/89	FR PS
Audi	80 1.8 Injection B3 (1986-1991)	10/86-10/91	FR DS
Audi	80 1.8 Injection B3 (1986-1991)	10/86-10/91	FR PS
Audi	80 1.8 quattro B3 (1986-1991)	10/86-10/91	FR DS
Audi	80 1.8 quattro B3 (1986-1991)	10/86-10/91	FR PS
Audi	80 1.9 TD B4 (1991-1995)	11/92-03/95	FR PS
Audi	80 1.9 TD B4 (1991-1995)	11/92-03/95	FR DS
Audi	80 1.9 TDi Avant B4 (1991-1995)	01/92-03/95	FR PS
Audi	80 1.9 TDi Avant B4 (1991-1995)	01/92-03/95	FR DS
Audi	80 1.9 TDi Avant B4 (1991-1995)	01/92-03/95	FR DS
Audi	80 1.9 TDi Avant B4 (1991-1995)	01/92-03/95	FR PS
Audi	80 1.9 TDi B4 (1991-1995)	01/92-03/95	FR DS
Audi	80 1.9 TDi B4 (1991-1995)	01/92-03/95	FR PS
Audi	80 1.9 TDi B4 (1991-1995)	01/92-03/95	FR DS
Audi	80 1.9 TDi B4 (1991-1995)	01/92-03/95	FR PS
Audi	80 2.0 Avant B4 (1991-1995)	01/93-03/95	FR PS
Audi	80 2.0 Avant B4 (1991-1995)	01/93-03/95	FR DS
Audi	80 2.0 Avant B4 (1991-1995)	01/93-03/95	FR DS
Audi	80 2.0 Avant B4 (1991-1995)	01/93-03/95	FR PS
Audi	80 2.0 Avant B4 (1991-1995)	01/93-03/95	FR PS
Audi	80 2.0 Avant B4 (1991-1995)	01/93-03/95	FR DS
Audi	80 2.0 B3 (1986-1991)	09/89-10/91	FR DS
Audi	80 2.0 B3 (1986-1991)	09/89-10/91	FR PS
Audi	80 2.0 B3 (1986-1991)	09/89-10/91	FR PS
Audi	80 2.0 B3 (1986-1991)	09/89-10/91	FR DS
Audi	80 2.0 B3 (1986-1991)	09/89-10/91	FR PS
Audi	80 2.0 B3 (1986-1991)	09/89-10/91	FR DS
Audi	80 2.0 B3 (1986-1991)	09/89-10/91	FR DS
Audi	80 2.0 B3 (1986-1991)	09/89-10/91	FR PS
Audi	80 2.0 B3 (1986-1991)	10/90-10/91	FR PS
Audi	80 2.0 B3 (1986-1991)	10/90-10/91	FR DS
Audi	80 2.0 B4 (1991-1995)	10/91-03/95	FR DS
Audi	80 2.0 B4 (1991-1995)	10/91-03/95	FR DS
Audi	80 2.0 B4 (1991-1995)	10/91-03/95	FR PS
Audi	80 2.0 B4 (1991-1995)	10/91-03/95	FR PS
Audi	80 2.0 B4 (1991-1995)	10/91-03/95	FR PS
Audi	80 2.0 B4 (1991-1995)	10/91-03/95	FR DS
Audi	80 2.0 B4 (1991-1995)	10/91-12/93	FR DS
Audi	80 2.0 B4 (1991-1995)	10/91-12/93	FR PS
Audi	80 2.0 quattro B3 (1986-1991)	09/89-10/91	FR PS
Audi	80 2.0 quattro B3 (1986-1991)	09/89-10/91	FR DS
Audi	80 2.0 quattro B3 (1986-1991)	09/89-10/91	FR DS
Audi	80 2.0 quattro B3 (1986-1991)	09/89-10/91	FR PS
Audi	80 2.0 quattro B3 (1986-1991)	10/90-10/91	FR DS

Audi	80 2.0 quattro B3 (1986-1991)	10/90-10/91	FR PS
Audi	80 2.0 quattro B4 (1991-1995)	10/91-07/92	FR PS
Audi	80 2.0 quattro B4 (1991-1995)	10/91-07/92	FR DS
Audi	80 2.0 quattro B4 (1991-1995)	10/91-07/92	FR PS
Audi	80 2.0 quattro B4 (1991-1995)	10/91-07/92	FR DS
Audi	80 2.3 B4 (1991-1995)	10/91-07/92	FR PS
Audi	80 2.3 B4 (1991-1995)	10/91-07/92	FR DS
Audi	80 2.3 B4 (1991-1995)	10/91-07/92	FR PS
Audi	80 2.3 B4 (1991-1995)	10/91-07/92	FR DS
Audi	80 2.6 Avant B4 (1991-1995)	09/92-03/95	FR DS
Audi	80 2.6 Avant B4 (1991-1995)	09/92-03/95	FR PS
Audi	80 2.6 Avant B4 (1991-1995)	09/92-03/95	FR DS
Audi	80 2.6 Avant B4 (1991-1995)	09/92-03/95	FR PS
Audi	80 2.6 B4 (1991-1995)	09/92-03/95	FR PS
Audi	80 2.6 B4 (1991-1995)	09/92-03/95	FR PS
Audi	80 2.6 B4 (1991-1995)	09/92-03/95	FR DS
Audi	80 2.6 B4 (1991-1995)	09/92-03/95	FR DS
Audi	80 2.6 quattro Avant B4 (1991-1995)	09/93-03/95	FR DS
Audi	80 2.6 quattro Avant B4 (1991-1995)	09/93-03/95	FR PS
Audi	80 2.6 quattro B4 (1991-1995)	09/93-03/95	FR DS
Audi	80 2.6 quattro B4 (1991-1995)	09/93-03/95	FR PS
Audi	80 2.8 B4 (1991-1995)	10/91-12/92	FR PS
Audi	80 2.8 B4 (1991-1995)	10/91-12/92	FR PS
Audi	80 2.8 B4 (1991-1995)	10/91-12/92	FR DS
Audi	80 2.8 B4 (1991-1995)	10/91-12/92	FR DS
Audi	80 2.8 quattro B4 (1991-1995)	10/91-12/93	FR PS
Audi	80 2.8 quattro B4 (1991-1995)	10/91-12/93	FR DS
Audi	80 2.8 quattro B4 (1991-1995)	10/91-12/93	FR PS
Audi	80 2.8 quattro B4 (1991-1995)	10/91-12/93	FR DS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR DS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR DS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR PS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR PS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR DS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR PS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR DS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR PS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR PS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR DS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR DS
Audi	90 2.0 B2 (1984-1986)	10/84-08/86	FR PS
Audi	90 2.0 B3 (1987-1991)	07/87-08/89	FR PS
Audi	90 2.0 B3 (1987-1991)	07/87-08/89	FR DS
Audi	90 2.2 B3 (1987-1991)	07/87-09/89	FR DS
Audi	90 2.2 B3 (1987-1991)	07/87-09/89	FR PS
Audi	90 2.2 quattro B2 (1984-1986)	07/84-08/86	FR PS
Audi	90 2.2 quattro B2 (1984-1986)	07/84-08/86	FR DS
Audi	90 2.2 quattro B3 (1987-1991)	07/87-09/89	FR PS
Audi	90 2.2 quattro B3 (1987-1991)	07/87-09/89	FR DS
Audi	90 2.3 B3 (1987-1991)	09/89-12/91	FR DS















Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR PS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR DS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR PS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR PS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR DS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR DS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR PS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR DS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR DS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR PS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR DS
Audi	A4 2.8 Avant quattro B5 (8D) (1995-2001)	04/96-06/01	FR PS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 B5 (8D) (1995-2001)	03/96-11/99	FR DS
Audi	A4 2.8 quattro B5 (8D) (1995-2001)	04/96-01/01	FR DS
Audi	A4 2.8 quattro B5 (8D) (1995-2001)	04/96-01/01	FR DS
Audi	A4 2.8 quattro B5 (8D) (1995-2001)	04/96-01/01	FR DS
Audi	A4 2.8 quattro B5 (8D) (1995-2001)	04/96-01/01	FR DS
Audi	A4 2.8 quattro B5 (8D) (1995-2001)	04/96-01/01	FR DS
Audi	A4 2.8 quattro B5 (8D) (1995-2001)	04/96-01/01	FR DS
Audi	A4 2.8 quattro B5 (8D) (1995-2001)	04/96-01/01	FR DS
Audi	Cabriolet 1.8 B4 (1992-2000)	12/96-12/00	FR PS
Audi	Cabriolet 1.8 B4 (1992-2000)	12/96-12/00	FR PS
Audi	Cabriolet 2.0 B4 (1992-2000)	07/93-12/96	FR PS
Audi	Cabriolet 2.3 B4 (1992-2000)	07/92-05/94	FR PS
Audi	Cabriolet 2.3 B4 (1992-2000)	07/92-05/94	FR PS
Audi	Cabriolet 2.6 B4 (1992-2000)	05/94-09/99	FR PS
Audi	Cabriolet 2.6 B4 (1992-2000)	05/94-09/99	FR PS
Audi	Cabriolet 2.8 B4 (1992-2000)	05/96-12/00	FR PS
Audi	Cabriolet 2.8 B4 (1992-2000)	05/96-12/00	FR PS
Audi	Coupe 2.0 B3 (1988-1992)	09/89-10/92	FR PS
Audi	Coupe 2.0 B3 (1988-1992)	09/89-10/92	FR DS
Audi	Coupe 2.0 B3 (1988-1992)	09/89-10/92	FR DS
Audi	Coupe 2.0 B3 (1988-1992)	09/89-10/92	FR PS
Audi	Coupe 2.0 B3 (1988-1992)	09/89-10/92	FR DS
Audi	Coupe 2.0 B3 (1988-1992)	09/89-10/92	FR PS
Audi	Coupe 2.0 B4 (1991-1996)	10/92-12/95	FR DS
Audi	Coupe 2.0 B4 (1991-1996)	10/92-12/95	FR PS
Audi	Coupe 2.0 B4 (1991-1996)	11/94-12/95	FR PS
Audi	Coupe 2.0 B4 (1991-1996)	11/94-12/95	FR DS
Audi	Coupe 2.0 B4 (1991-1996)	11/94-12/95	FR PS

Audi	Coupe 2.0 B4 (1991-1996)	11/94-12/95	FR DS
Audi	Coupe 2.2 quattro B3 (1988-1992)	10/88-09/89	FR DS
Audi	Coupe 2.2 quattro B3 (1988-1992)	10/88-09/89	FR PS
Audi	Coupe 2.2 S2 quattro B4 (1991-1996)	01/91-10/92	FR PS
Audi	Coupe 2.2 S2 quattro B4 (1991-1996)	01/91-10/92	FR DS
Audi	Coupe 2.2 S2 quattro B4 (1991-1996)	10/92-09/96	FR DS
Audi	Coupe 2.2 S2 quattro B4 (1991-1996)	10/92-09/96	FR PS
Audi	Coupe 2.3 B3 (1988-1992)	09/89-12/91	FR PS
Audi	Coupe 2.3 B3 (1988-1992)	09/89-12/91	FR DS
Audi	Coupe 2.3 B3 (1988-1992)	09/89-12/91	FR DS
Audi	Coupe 2.3 B3 (1988-1992)	09/89-12/91	FR PS
Audi	Coupe 2.3 B3 (1988-1992)	09/89-12/92	FR DS
Audi	Coupe 2.3 B3 (1988-1992)	09/89-12/92	FR DS
Audi	Coupe 2.3 B3 (1988-1992)	09/89-12/92	FR PS
Audi	Coupe 2.3 B3 (1988-1992)	09/89-12/92	FR PS
Audi	Coupe 2.3 quattro B3 (1988-1992)	09/89-12/91	FR PS
Audi	Coupe 2.3 quattro B3 (1988-1992)	09/89-12/91	FR DS
Audi	Coupe 2.3 quattro B3 (1988-1992)	09/89-12/91	FR PS
Audi	Coupe 2.3 quattro B3 (1988-1992)	09/89-12/91	FR DS
Audi	Coupe 2.6 B4 (1991-1996)	09/92-09/96	FR DS
Audi	Coupe 2.6 B4 (1991-1996)	09/92-09/96	FR PS
Audi	Coupe 2.6 B4 (1991-1996)	09/92-09/96	FR PS
Audi	Coupe 2.6 B4 (1991-1996)	09/92-09/96	FR DS
Audi	Coupe 2.8 B4 (1991-1996)	10/91-12/92	FR DS
Audi	Coupe 2.8 B4 (1991-1996)	10/91-12/92	FR PS
Audi	Coupe 2.8 B4 (1991-1996)	10/91-12/92	FR DS
Audi	Coupe 2.8 B4 (1991-1996)	10/91-12/92	FR PS
Audi	Coupe 2.8 quattro B4 (1991-1996)	10/91-12/95	FR PS
Audi	Coupe 2.8 quattro B4 (1991-1996)	10/91-12/95	FR DS
Audi	RS2 2.2 Avant quattro B4 (1991-1995)	10/94-12/95	FR DS
Audi	RS2 2.2 Avant quattro B4 (1991-1995)	10/94-12/95	FR PS
Audi	RS4 2.7 Avant quattro B5 (8D) (1995-2001)	04/00-12/01	FR PS
Audi	RS4 2.7 Avant quattro B5 (8D) (1995-2001)	04/00-12/01	FR PS
Audi	RS4 2.7 Avant quattro B5 (8D) (1995-2001)	04/00-12/01	FR DS
Audi	RS4 2.7 Avant quattro B5 (8D) (1995-2001)	04/00-12/01	FR DS
Audi	S2 2.2 B4 (1991-1995)	01/93-03/95	FR DS
Audi	S2 2.2 B4 (1991-1995)	01/93-03/95	FR PS
Audi	S3 1.8 quattro 8L (1996-2003)	05/99-10/01	FR DS
Audi	S3 1.8 quattro 8L (1996-2003)	05/99-10/01	FR DS
Audi	S3 1.8 quattro 8L (1996-2003)	05/99-10/01	FR DS
Audi	S3 1.8 quattro 8L (1996-2003)	10/01-08/03	FR DS
Audi	S4 2.7 Avant quattro B5 (8D) (1995-2001)	08/98-06/01	FR PS
Audi	S4 2.7 Avant quattro B5 (8D) (1995-2001)	08/98-06/01	FR PS
Audi	S4 2.7 Avant quattro B5 (8D) (1995-2001)	08/98-06/01	FR DS
Audi	S4 2.7 Avant quattro B5 (8D) (1995-2001)	08/98-06/01	FR DS
Audi	S4 2.7 quattro B5 (8D) (1995-2001)	08/98-06/01	FR DS
Audi	S4 2.7 quattro B5 (8D) (1995-2001)	08/98-06/01	FR DS
Audi	TT 1.8 8N (1999-2006)	02/99-12/02	FR PS
Audi	TT 1.8 8N (1999-2006)	02/99-12/02	FR PS
Audi	TT 1.8 8N (1999-2006)	02/99-12/02	FR PS





BMW	320i 2.0 E36	04/91-09/96	FR DS
BMW	320i 2.0 E36	04/91-09/96	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	04/92-09/95	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 E36	05/94-01/97	FR DS
BMW	320i 2.0 Touring E36	03/95-01/97	FR DS
BMW	320i 2.0 Touring E36	03/95-01/97	FR DS
BMW	320i 2.0 Touring E36	03/95-01/97	FR DS
BMW	320i 2.0 Touring E36	03/95-01/97	FR DS
BMW	323i 2.5 E36	01/97-05/00	FR DS
BMW	323i 2.5 E36	01/97-05/00	FR DS
BMW	323i 2.5 E36	03/95-07/99	FR DS
BMW	323i 2.5 E36	03/95-07/99	FR DS
BMW	323i 2.5 E36	09/96-09/98	FR DS
BMW	323i 2.5 E36	09/96-09/98	FR DS
BMW	323i 2.5 Touring E36	01/97-11/99	FR DS
BMW	323i 2.5 Touring E36	01/97-11/99	FR DS
BMW	325i 2.5 E36	04/91-09/95	FR DS
BMW	325i 2.5 E36	04/91-09/95	FR DS
BMW	325i 2.5 E36	04/91-09/95	FR DS
BMW	325i 2.5 E36	04/91-09/95	FR DS
BMW	325i 2.5 E36	04/92-09/95	FR DS
BMW	325i 2.5 E36	04/92-09/95	FR DS
BMW	325i 2.5 E36	04/92-09/95	FR DS
BMW	325i 2.5 E36	04/92-09/95	FR DS
BMW	325i 2.5 E36	07/93-09/95	FR DS
BMW	325i 2.5 E36	07/93-09/95	FR DS
BMW	325i 2.5 E36	07/93-09/95	FR DS
BMW	325i 2.5 E36	07/93-09/95	FR DS
BMW	325td 2.5 E36	07/93-04/96	FR DS
BMW	325td 2.5 E36	07/93-04/96	FR DS
BMW	325tds 2.5 E36	04/97-02/98	FR DS
BMW	325tds 2.5 E36	04/97-02/98	FR DS
BMW	325tds 2.5 E36	07/93-04/97	FR DS
BMW	325tds 2.5 E36	07/93-04/97	FR DS



BMW	Z4 2.5 i E85	06/03-04/06	FR DS
BMW	Z4 2.5 sDrive23i E89	05/09-07/12	FR DS
BMW	Z4 2.5 sDrive23i E89	05/09-07/12	FR DS
BMW	Z4 2.5 si E85	02/06-12/09	FR DS
BMW	Z4 2.5 si E85	02/06-12/09	FR DS
BMW	Z4 3.0 i E85	06/03-06/06	FR DS
BMW	Z4 3.0 i E85	06/03-06/06	FR DS
BMW	Z4 3.0 i E85	06/03-06/06	FR DS
BMW	Z4 3.0 i E85	06/03-06/06	FR DS
BMW	Z4 3.0 i E85	06/03-12/04	FR DS
BMW	Z4 3.0 i E85	06/03-12/04	FR DS
BMW	Z4 3.0 sDrive30i E89	05/09-07/12	FR DS
BMW	Z4 3.0 sDrive30i E89	05/09-07/12	FR DS
BMW	Z4 3.0 sDrive35i E89	05/09-04/17	FR DS
BMW	Z4 3.0 sDrive35i E89	05/09-04/17	FR DS
BMW	Z4 3.0 sDrive35i E89	05/09-04/17	FR DS
BMW	Z4 3.0 sDrive35is E89	03/10-04/17	FR DS
BMW	Z4 3.0 si E85	02/06-12/09	FR DS
BMW	Z4 3.0 si E85	02/06-12/09	FR DS
BMW	Z4 3.0 si E85	02/06-12/09	FR DS
BMW	Z4 3.0 si E85	02/06-12/09	FR DS
BMW	Z4 3.0 si E86	07/06-12/09	FR DS
BMW	Z4 3.0 si E86	07/06-12/09	FR DS
BMW	Z4 3.0 si E86	07/06-12/09	FR DS
BMW	Z4 3.0 si E86	07/06-12/09	FR DS
BMW	Z4 3.2 M E85	07/06-12/09	FR DS
BMW	Z4 3.2 M E85	07/06-12/09	FR DS
BMW	Z4 3.2 M E86	07/06-12/09	FR DS
BMW	Z4 3.2 M E86	07/06-12/09	FR DS
Chrysler	Neon 1.8 (1996-1999)	03/98-10/99	FR DS
Chrysler	Neon 2.0 (1996-1999)	06/96-10/99	FR DS
Chrysler	Neon 2.0 (1996-1999)	06/96-10/99	FR DS
Chrysler	PT Cruiser 2.0 (2000-2008)	07/00-05/05	FR DS
Chrysler	PT Cruiser 2.0 (2000-2008)	07/00-05/05	FR DS
Chrysler	PT Cruiser 2.2 CRD (2000-2008)	04/02-11/05	FR DS
Chrysler	PT Cruiser 2.2 CRD (2000-2008)	11/05-12/08	FR DS
Chrysler	PT Cruiser 2.4 (2000-2008)	11/04-12/08	FR DS
Chrysler	PT Cruiser 2.4 (2000-2008)	11/04-12/08	FR DS
Chrysler	PT Cruiser 2.4 (2000-2008)	11/04-12/08	FR DS
Chrysler	PT Cruiser 2.4 (2000-2008)	11/04-12/08	FR DS
Daewoo	Matiz 0.8 (1998-2005)	08/98-01/05	FR DS
Daewoo	Matiz 1.0 (1998-2005)	01/03-01/05	FR DS
Daewoo	Matiz 1.0 (1998-2005)	01/03-01/05	FR DS
Daewoo	Matiz 1.0 (1998-2005)	01/03-01/05	FR DS
Daihatsu	Terios 1.5 (2006-2010)	05/06-12/10	FR DS
Daihatsu	Terios 1.5 (2006-2010)	05/06-12/10	FR DS
Fiat	Coupe 2.0 175 (1995-2001)	06/95-11/96	FR DS
Fiat	Coupe 2.0 20v 175 (1995-2001)	11/96-08/01	FR DS
Fiat	Coupe 2.0 20v 175 (1995-2001)	11/96-08/01	FR DS
Fiat	Coupe 2.0 20v Turbo 175 (1995-2001)	07/98-08/01	FR DS

Fiat	Coupe 2.0 20v Turbo 175 (1995-2001)	11/96-08/01	FR DS
Fiat	Stilo 1.2 192 (2001-2007)	11/01-03/04	FR DS
Fiat	Stilo 1.2 192 (2001-2007)	11/01-03/04	FR DS
Fiat	Stilo 1.2 192 (2001-2007)	11/01-03/04	FR DS
Fiat	Stilo 1.2 192 (2001-2007)	11/01-03/04	FR DS
Fiat	Stilo 1.4 192 (2001-2007)	02/04-12/07	FR DS
Fiat	Stilo 1.4 192 (2001-2007)	02/04-12/07	FR DS
Fiat	Stilo 1.4 192 (2001-2007)	02/04-12/07	FR DS
Fiat	Stilo 1.4 192 (2001-2007)	02/04-12/07	FR DS
Fiat	Stilo 1.6 192 (2001-2007)	11/01-10/05	FR DS
Fiat	Stilo 1.6 192 (2001-2007)	11/01-10/05	FR DS
Fiat	Stilo 1.6 Multiwagon 192 (2001-2007)	03/03-12/06	FR DS
Fiat	Stilo 1.8 192 (2001-2007)	11/01-12/06	FR DS
Fiat	Stilo 1.8 192 (2001-2007)	11/01-12/06	FR DS
Fiat	Stilo 1.9 JTD 115 192 (2001-2007)	11/01-12/06	FR DS
Fiat	Stilo 1.9 JTD 115 192 (2001-2007)	11/01-12/06	FR DS
Fiat	Stilo 1.9 JTD 115 Multiwagon 192 (2001-2007)	03/03-12/06	FR DS
Fiat	Stilo 1.9 JTD 120 192 (2001-2007)	10/06-03/07	FR DS
Fiat	Stilo 1.9 JTD 120 192 (2001-2007)	10/06-03/07	FR DS
Fiat	Stilo 1.9 JTD 120 Multiwagon 192 (2001-2007)	10/06-12/07	FR DS
Fiat	Stilo 1.9 JTD 150 192 (2001-2007)	06/06-03/07	FR DS
Fiat	Stilo 1.9 JTD 150 192 (2001-2007)	06/06-03/07	FR DS
Fiat	Stilo 1.9 JTD 80 192 (2001-2007)	09/03-03/04	FR DS
Fiat	Stilo 1.9 JTD 80 Multiwagon 192 (2001-2007)	03/03-03/04	FR DS
Fiat	Stilo 2.4 192 (2001-2007)	11/01-12/06	FR DS
Fiat	Stilo 2.4 192 (2001-2007)	11/01-12/06	FR DS
Fiat	Stilo 2.4 192 (2001-2007)	11/01-12/06	FR DS
Fiat	Stilo Multiwagon 1.8 192 (2001-2007)	03/03-04/04	FR DS
Ford	Maverick 2.4 (1993-1999)	07/93-07/96	FR DS
Ford	Maverick 2.4 (1993-1999)	07/93-07/96	FR DS
Ford	Maverick 2.4 (1993-1999)	07/96-03/99	FR DS
Ford	Maverick 2.4 (1993-1999)	07/96-03/99	FR DS
Ford	Maverick 2.7 (1993-1999)	03/96-12/98	FR DS
Ford	Maverick 2.7 (1993-1999)	03/96-12/98	FR DS
Ford	Maverick 2.7 (1993-1999)	07/93-07/96	FR DS
Ford	Maverick 2.7 (1993-1999)	07/93-07/96	FR DS
Ford	Maverick 2.7 (1993-1999)	07/96-03/99	FR DS
Ford	Maverick 2.7 (1993-1999)	07/96-03/99	FR DS
Ford	Maverick 2.7 (1993-1999)	07/96-12/98	FR DS
Ford	Maverick 2.7 (1993-1999)	07/96-12/98	FR DS
Ford	Mondeo 1.6 MK 1 (1993-1996)	02/93-08/96	FR DS
Ford	Mondeo 1.6 MK 1 (1993-1996)	02/93-08/96	FR DS
Ford	Mondeo 1.6 MK 1 (1993-1996)	02/93-08/96	FR DS
Ford	Mondeo 1.6 MK 1 (1993-1996)	02/93-08/96	FR DS
Ford	Mondeo 1.6 MK 1 (1993-1996)	06/93-08/96	FR DS
Ford	Mondeo 1.6 MK 1 (1993-1996)	06/93-08/96	FR DS
Ford	Mondeo 1.6 MK 2 (1996-2000)	08/96-07/99	FR DS
Ford	Mondeo 1.6 MK 2 (1996-2000)	08/96-07/99	FR DS
Ford	Mondeo 1.6 MK 2 (1996-2000)	08/96-07/99	FR DS
Ford	Mondeo 1.6 MK 2 (1996-2000)	08/96-07/99	FR DS



Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.0 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 1 (1993-1996)	02/95-08/96	FR DS
Ford	Mondeo 2.5 MK 1 (1993-1996)	02/95-08/96	FR DS
Ford	Mondeo 2.5 MK 1 (1993-1996)	10/94-08/96	FR DS
Ford	Mondeo 2.5 MK 1 (1993-1996)	10/94-08/96	FR DS
Ford	Mondeo 2.5 MK 1 (1993-1996)	10/94-08/96	FR DS
Ford	Mondeo 2.5 MK 1 (1993-1996)	10/94-08/96	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Ford	Mondeo 2.5 MK 2 (1996-2000)	08/96-10/00	FR DS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR DS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR DS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR DS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR DS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR DS
Honda	Civic 1.7 Vtec MK 7 (2000-2006)	04/01-09/03	FR DS
Honda	CR-V 2.0 MK 2 (2001-2007)	11/01-06/07	FR DS
Honda	CR-V 2.0 MK 2 (2001-2007)	11/01-06/07	FR DS
Honda	CR-V 2.2 CDTi MK 2 (2001-2007)	03/05-06/07	FR DS
Jaguar/Daimler	Daimler 4.0 XJ40	09/89-12/94	FR PS
Jaguar/Daimler	Daimler 4.0 XJ40	09/89-12/94	FR DS
Jaguar/Daimler	Daimler Century 6.0 X300	10/95-12/96	FR DS
Jaguar/Daimler	Daimler Century 6.0 X300	10/95-12/96	FR PS
Jaguar/Daimler	Daimler Double Six 6.0 X300	09/94-12/97	FR DS
Jaguar/Daimler	Daimler Double Six 6.0 X300	09/94-12/97	FR PS

Jaguar/Daimler	F Type 2.0 P300 X152	01/20-04/24	FR PS
Jaguar/Daimler	F Type 2.0 P300 X152	01/20-04/24	FR PS
Jaguar/Daimler	F Type 2.0 P300 X152	01/20-04/24	FR DS
Jaguar/Daimler	F Type 2.0 P300 X152	01/20-04/24	FR DS
Jaguar/Daimler	F Type 2.0 X152	02/17-12/20	FR PS
Jaguar/Daimler	F Type 2.0 X152	02/17-12/20	FR DS
Jaguar/Daimler	F Type 2.0 X152	02/17-12/20	FR PS
Jaguar/Daimler	F Type 2.0 X152	02/17-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6 Sport 400 X152	03/17-04/18	FR DS
Jaguar/Daimler	F Type 3.0 V6 Sport 400 X152	03/17-04/18	FR PS
Jaguar/Daimler	F Type 3.0 V6 Sport 400 X152	03/17-04/18	FR PS
Jaguar/Daimler	F Type 3.0 V6 Sport 400 X152	03/17-04/18	FR DS
Jaguar/Daimler	F Type 3.0 V6 X152	01/15-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6 X152	01/15-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6 X152	01/15-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6 X152	01/15-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6 X152	04/13-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6 X152	04/13-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6 X152	12/13-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6 X152	12/13-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6S X152	01/15-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6S X152	01/15-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6S X152	01/15-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6S X152	01/15-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6S X152	02/15-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6S X152	02/15-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6S X152	02/15-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6S X152	02/15-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6S X152	04/13-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6S X152	04/13-12/20	FR PS
Jaguar/Daimler	F Type 3.0 V6S X152	12/13-12/20	FR DS
Jaguar/Daimler	F Type 3.0 V6S X152	12/13-12/20	FR PS
Jaguar/Daimler	F Type 5.0 P450 X152	01/20-04/24	FR PS
Jaguar/Daimler	F Type 5.0 P450 X152	01/20-04/24	FR DS
Jaguar/Daimler	F Type 5.0 P450 X152	01/20-04/24	FR DS
Jaguar/Daimler	F Type 5.0 P450 X152	01/20-04/24	FR PS
Jaguar/Daimler	F Type 5.0 P450 X152	01/20-04/24	FR PS
Jaguar/Daimler	F Type 5.0 P450 X152	01/20-04/24	FR DS
Jaguar/Daimler	F Type 5.0 P450 X152	01/20-04/24	FR DS
Jaguar/Daimler	F Type 5.0 P450 X152	01/20-04/24	FR PS
Jaguar/Daimler	F Type 5.0 P575 X152	01/20-04/24	FR PS
Jaguar/Daimler	F Type 5.0 P575 X152	01/20-04/24	FR DS
Jaguar/Daimler	F Type 5.0 P575 X152	01/20-04/24	FR DS
Jaguar/Daimler	F Type 5.0 P575 X152	01/20-04/24	FR PS
Jaguar/Daimler	F Type 5.0 Project 7 X152	07/15-12/16	FR DS
Jaguar/Daimler	F Type 5.0 Project 7 X152	07/15-12/16	FR PS
Jaguar/Daimler	F Type 5.0 SVR X152	02/16-12/20	FR DS
Jaguar/Daimler	F Type 5.0 SVR X152	02/16-12/20	FR PS
Jaguar/Daimler	F Type 5.0 SVR X152	02/16-12/20	FR DS
Jaguar/Daimler	F Type 5.0 SVR X152	02/16-12/20	FR PS

Jaguar/Daimler	F Type 5.0 V8R X152	02/15-04/18	FR PS
Jaguar/Daimler	F Type 5.0 V8R X152	02/15-04/18	FR DS
Jaguar/Daimler	F Type 5.0 V8R X152	02/15-04/20	FR PS
Jaguar/Daimler	F Type 5.0 V8R X152	02/15-04/20	FR DS
Jaguar/Daimler	F Type 5.0 V8R X152	02/15-04/20	FR DS
Jaguar/Daimler	F Type 5.0 V8R X152	02/15-04/20	FR PS
Jaguar/Daimler	F Type 5.0 V8R X152	12/13-04/18	FR DS
Jaguar/Daimler	F Type 5.0 V8R X152	12/13-04/18	FR PS
Jaguar/Daimler	F Type 5.0 V8S X152	04/13-09/15	FR DS
Jaguar/Daimler	F Type 5.0 V8S X152	04/13-09/15	FR PS
Jaguar/Daimler	Sovereign 2.9 XJ40	10/86-12/90	FR PS
Jaguar/Daimler	Sovereign 2.9 XJ40	10/86-12/90	FR DS
Jaguar/Daimler	Sovereign 2.9 XJ40	10/86-12/90	FR DS
Jaguar/Daimler	Sovereign 2.9 XJ40	10/86-12/90	FR PS
Jaguar/Daimler	Sovereign 3.2 X300	09/94-12/97	FR PS
Jaguar/Daimler	Sovereign 3.2 X300	09/94-12/97	FR DS
Jaguar/Daimler	Sovereign 3.2 XJ40	09/90-12/93	FR DS
Jaguar/Daimler	Sovereign 3.2 XJ40	09/90-12/93	FR PS
Jaguar/Daimler	Sovereign 4.0 LWB X300	07/95-12/97	FR DS
Jaguar/Daimler	Sovereign 4.0 LWB X300	07/95-12/97	FR PS
Jaguar/Daimler	Sovereign 4.0 LWB X300	07/95-12/97	FR PS
Jaguar/Daimler	Sovereign 4.0 LWB X300	07/95-12/97	FR DS
Jaguar/Daimler	Sovereign 4.0 X300	09/94-12/97	FR PS
Jaguar/Daimler	Sovereign 4.0 X300	09/94-12/97	FR DS
Jaguar/Daimler	Sovereign 4.0 X300	09/94-12/97	FR PS
Jaguar/Daimler	Sovereign 4.0 X300	09/94-12/97	FR PS
Jaguar/Daimler	Sovereign 4.0 X300	09/94-12/97	FR DS
Jaguar/Daimler	Sovereign 4.0 X300	09/94-12/97	FR PS
Jaguar/Daimler	Sovereign 4.0 X300	09/94-12/97	FR DS
Jaguar/Daimler	Sovereign 4.0 X300	09/94-12/97	FR DS
Jaguar/Daimler	XJ12 6.0 LWB X300	07/95-12/96	FR DS
Jaguar/Daimler	XJ12 6.0 LWB X300	07/95-12/96	FR PS
Jaguar/Daimler	XJ12 6.0 X300	09/94-12/96	FR DS
Jaguar/Daimler	XJ12 6.0 X300	09/94-12/96	FR PS
Jaguar/Daimler	XJ6 2.9 XJ40	10/86-12/90	FR DS
Jaguar/Daimler	XJ6 2.9 XJ40	10/86-12/90	FR PS
Jaguar/Daimler	XJ6 3.2 LWB X300	07/95-12/97	FR PS
Jaguar/Daimler	XJ6 3.2 LWB X300	07/95-12/97	FR DS
Jaguar/Daimler	XJ6 3.2 X300	09/94-12/97	FR PS
Jaguar/Daimler	XJ6 3.2 X300	09/94-12/97	FR DS
Jaguar/Daimler	XJ6 3.2 X300	09/94-12/97	FR DS
Jaguar/Daimler	XJ6 3.2 X300	09/94-12/97	FR PS
Jaguar/Daimler	XJ6 3.2 XJ40	09/90-12/94	FR PS
Jaguar/Daimler	XJ6 3.2 XJ40	09/90-12/94	FR DS
Jaguar/Daimler	XJ6 4.0 X300	09/94-12/97	FR PS
Jaguar/Daimler	XJ6 4.0 X300	09/94-12/97	FR DS
Jaguar/Daimler	XJ6 4.0 X300	09/94-12/97	FR PS
Jaguar/Daimler	XJ6 4.0 X300	09/94-12/97	FR DS
Jaguar/Daimler	XJ8 3.2 X308	09/97-12/02	FR DS
Jaguar/Daimler	XJ8 3.2 X308	09/97-12/02	FR PS



Jaguar/Daimler	XJR 4.0 Supercharged X300	09/94-12/97	FR PS
Jaguar/Daimler	XJR 4.0 Supercharged X300	09/94-12/97	FR PS
Jaguar/Daimler	XJR 4.0 Supercharged X300	09/94-12/97	FR DS
Jaguar/Daimler	XJR 4.0 Supercharged X300	09/94-12/97	FR DS
Jaguar/Daimler	XJR 4.0 XJ40	09/89-12/94	FR PS
Jaguar/Daimler	XJR 4.0 XJ40	09/89-12/94	FR PS
Jaguar/Daimler	XJR 4.0 XJ40	09/89-12/94	FR DS
Jaguar/Daimler	XJR 4.0 XJ40	09/89-12/94	FR DS
Jaguar/Daimler	XK60 4.2 X150	07/08-06/09	FR DS
Jaguar/Daimler	XK60 4.2 X150	07/08-06/09	FR PS
Jaguar/Daimler	XK60 4.2 X150	07/08-06/09	FR DS
Jaguar/Daimler	XK60 4.2 X150	07/08-06/09	FR PS
Jaguar/Daimler	XK8 4.0 X100	10/96-09/02	FR DS
Jaguar/Daimler	XK8 4.0 X100	10/96-09/02	FR PS
Jaguar/Daimler	XK8 4.0 X100	10/96-09/02	FR PS
Jaguar/Daimler	XK8 4.0 X100	10/96-09/02	FR DS
Jaguar/Daimler	XK8 4.0 X100	10/96-09/02	FR PS
Jaguar/Daimler	XK8 4.0 X100	10/96-09/02	FR DS
Jaguar/Daimler	XK8 4.0 X100	10/96-09/02	FR DS
Jaguar/Daimler	XK8 4.0 X100	10/96-09/02	FR PS
Jaguar/Daimler	XK8 4.2 X100	09/02-08/05	FR DS
Jaguar/Daimler	XK8 4.2 X100	09/02-08/05	FR DS
Jaguar/Daimler	XK8 4.2 X100	09/02-08/05	FR PS
Jaguar/Daimler	XK8 4.2 X100	09/02-08/05	FR DS
Jaguar/Daimler	XK8 4.2 X100	09/02-08/05	FR PS
Jaguar/Daimler	XK8 4.2 X100	09/02-08/05	FR DS
Jaguar/Daimler	XK8 4.2 X100	09/02-08/05	FR PS
Jaguar/Daimler	XK8 4.2 X150	03/06-06/09	FR DS
Jaguar/Daimler	XK8 4.2 X150	03/06-06/09	FR PS
Jaguar/Daimler	XK8 4.2 X150	03/06-06/09	FR PS
Jaguar/Daimler	XK8 4.2 X150	03/06-06/09	FR DS
Jaguar/Daimler	XK8 4.2 X150	03/06-06/09	FR PS
Jaguar/Daimler	XK8 4.2 X150	03/06-06/09	FR DS
Jaguar/Daimler	XK8 4.2 X150	03/06-06/09	FR DS
Jaguar/Daimler	XK8 4.2 X150	03/06-06/09	FR PS
Jaguar/Daimler	XK8 5.0 X150	03/09-03/15	FR DS
Jaguar/Daimler	XK8 5.0 X150	03/09-03/15	FR PS
Jaguar/Daimler	XK8 5.0 X150	03/09-03/15	FR PS
Jaguar/Daimler	XK8 5.0 X150	03/09-03/15	FR DS
Jaguar/Daimler	XK8 5.0 X150	03/09-03/15	FR DS
Jaguar/Daimler	XK8 5.0 X150	03/09-03/15	FR DS
Jaguar/Daimler	XK8 5.0 X150	03/09-03/15	FR PS
Jaguar/Daimler	XK8 5.0 X150	03/09-03/15	FR PS
Jaguar/Daimler	XKR 4.0 Supercharged X100	05/98-09/02	FR PS
Jaguar/Daimler	XKR 4.0 Supercharged X100	05/98-09/02	FR PS
Jaguar/Daimler	XKR 4.0 Supercharged X100	05/98-09/02	FR PS
Jaguar/Daimler	XKR 4.0 Supercharged X100	05/98-09/02	FR DS
Jaguar/Daimler	XKR 4.0 Supercharged X100	05/98-09/02	FR DS
Jaguar/Daimler	XKR 4.0 Supercharged X100	05/98-09/02	FR DS

Jaguar/Daimler	XKR 4.0 Supercharged X100	05/98-09/02	FR DS
Jaguar/Daimler	XKR 4.0 Supercharged X100	05/98-09/02	FR PS
Jaguar/Daimler	XKR 4.2 S X150	02/08-06/09	FR DS
Jaguar/Daimler	XKR 4.2 S X150	02/08-06/09	FR PS
Jaguar/Daimler	XKR 4.2 Supercharged X100	09/02-08/05	FR DS
Jaguar/Daimler	XKR 4.2 Supercharged X100	09/02-08/05	FR DS
Jaguar/Daimler	XKR 4.2 Supercharged X100	09/02-08/05	FR PS
Jaguar/Daimler	XKR 4.2 Supercharged X100	09/02-08/05	FR PS
Jaguar/Daimler	XKR 4.2 Supercharged X100	09/02-08/05	FR DS
Jaguar/Daimler	XKR 4.2 Supercharged X100	09/02-08/05	FR PS
Jaguar/Daimler	XKR 4.2 Supercharged X100	09/02-08/05	FR DS
Jaguar/Daimler	XKR 4.2 Supercharged X100	09/02-08/05	FR PS
Jaguar/Daimler	XKR 4.2 Supercharged X150	06/06-06/09	FR PS
Jaguar/Daimler	XKR 4.2 Supercharged X150	06/06-06/09	FR DS
Jaguar/Daimler	XKR 4.2 Supercharged X150	08/07-06/09	FR PS
Jaguar/Daimler	XKR 4.2 Supercharged X150	08/07-06/09	FR DS
Jaguar/Daimler	XKR 5.0 75 X150	08/10-08/11	FR PS
Jaguar/Daimler	XKR 5.0 75 X150	08/10-08/11	FR DS
Jaguar/Daimler	XKR 5.0 75 X150	08/10-08/11	FR DS
Jaguar/Daimler	XKR 5.0 75 X150	08/10-08/11	FR PS
Jaguar/Daimler	XKR 5.0 S GT X150	08/13-03/15	FR PS
Jaguar/Daimler	XKR 5.0 S GT X150	08/13-03/15	FR DS
Jaguar/Daimler	XKR 5.0 S GT X150	08/13-03/15	FR PS
Jaguar/Daimler	XKR 5.0 S GT X150	08/13-03/15	FR DS
Jaguar/Daimler	XKR 5.0 S X150	02/12-03/15	FR DS
Jaguar/Daimler	XKR 5.0 S X150	02/12-03/15	FR PS
Jaguar/Daimler	XKR 5.0 S X150	02/12-03/15	FR PS
Jaguar/Daimler	XKR 5.0 S X150	02/12-03/15	FR DS
Jaguar/Daimler	XKR 5.0 S X150	03/11-03/15	FR DS
Jaguar/Daimler	XKR 5.0 S X150	03/11-03/15	FR DS
Jaguar/Daimler	XKR 5.0 S X150	03/11-03/15	FR PS
Jaguar/Daimler	XKR 5.0 S X150	03/11-03/15	FR PS
Jaguar/Daimler	XKR 5.0 X150	03/09-03/15	FR DS
Jaguar/Daimler	XKR 5.0 X150	03/09-03/15	FR DS
Jaguar/Daimler	XKR 5.0 X150	03/09-03/15	FR PS
Jaguar/Daimler	XKR 5.0 X150	03/09-03/15	FR PS
Jaguar/Daimler	XKR 5.0 X150	03/09-03/15	FR DS
Jaguar/Daimler	XKR 5.0 X150	03/09-03/15	FR DS
Jaguar/Daimler	XKR 5.0 X150	03/09-03/15	FR PS
Jaguar/Daimler	XKR 5.0 X150	03/09-03/15	FR PS
Jeep	Grand Cherokee 3.0 CRD (2005-2011)	01/10-04/11	FR PS
Jeep	Grand Cherokee 3.0 CRD (2005-2011)	01/10-04/11	FR DS
Jeep	Grand Cherokee 3.0 CRD (2005-2011)	06/05-04/11	FR DS
Jeep	Grand Cherokee 3.0 CRD (2005-2011)	06/05-04/11	FR PS
Jeep	Grand Cherokee 4.7 (2005-2011)	06/05-08/06	FR DS
Jeep	Grand Cherokee 4.7 (2005-2011)	06/05-08/06	FR PS
Jeep	Grand Cherokee 5.7 Hemi (2005-2011)	06/05-07/07	FR DS
Jeep	Grand Cherokee 5.7 Hemi (2005-2011)	06/05-07/07	FR PS
Jeep	Grand Cherokee 6.1 SRT-8 (2005-2011)	07/06-04/11	FR DS
Jeep	Grand Cherokee 6.1 SRT-8 (2005-2011)	07/06-04/11	FR PS

Jeep	Patriot 2.0 CRD	07/07-12/10	FR PS
Jeep	Patriot 2.0 CRD	07/07-12/10	FR DS
Jeep	Patriot 2.0 CRD	07/07-12/10	FR DS
Jeep	Patriot 2.0 CRD	07/07-12/10	FR PS
Jeep	Patriot 2.2 CRD	07/10-03/12	FR DS
Jeep	Patriot 2.2 CRD	07/10-03/12	FR PS
Jeep	Patriot 2.4	07/07-03/12	FR DS
Jeep	Patriot 2.4	07/07-03/12	FR PS
Jeep	Patriot 2.4	07/07-03/12	FR DS
Jeep	Patriot 2.4	07/07-03/12	FR PS
Kia	Rio 1.3 DC (2001-2005)	07/01-07/05	FR DS
Kia	Rio 1.3 DC (2001-2005)	07/01-07/05	FR DS
Kia	Rio 1.5 DC (2001-2005)	07/01-03/04	FR DS
Kia	Rio 1.5 DC (2001-2005)	07/01-03/04	FR DS
Kia	Shuma 1.5 (1999-2002)	06/99-02/01	FR DS
Kia	Shuma 1.5 (1999-2002)	06/99-02/01	FR DS
Kia	Shuma 1.8 (1999-2002)	06/99-02/01	FR DS
Kia	Shuma 1.8 (1999-2002)	06/99-02/01	FR DS
Kia	Shuma 1.8 MK 2 (2002-2004)	03/02-01/04	FR DS
Kia	Shuma 1.8 MK 2 (2002-2004)	03/02-01/04	FR DS
Lancia	Dedra 1.6	03/90-12/94	FR DS
Lancia	Dedra 1.8	03/90-12/94	FR DS
Lancia	Dedra 2.0	03/90-12/93	FR DS
Lancia	Dedra 2.0 Turbo	03/90-12/93	FR DS
Land Rover	Freelander 1.8 MK 1 (L314) (1997-2007)	08/00-02/07	FR PS
Land Rover	Freelander 1.8 MK 1 (L314) (1997-2007)	08/00-02/07	FR PS
Land Rover	Freelander 1.8 MK 1 (L314) (1997-2007)	10/97-08/00	FR PS
Land Rover	Freelander 1.8 MK 1 (L314) (1997-2007)	10/97-08/00	FR PS
Land Rover	Freelander 2.0 di MK 1 (L314) (1997-2007)	07/99-08/00	FR PS
Land Rover	Freelander 2.0 di MK 1 (L314) (1997-2007)	07/99-08/00	FR PS
Land Rover	Freelander 2.0 di MK 1 (L314) (1997-2007)	07/99-08/00	FR PS
Land Rover	Freelander 2.0 di MK 1 (L314) (1997-2007)	07/99-08/00	FR PS
Land Rover	Freelander 2.0 Td4 MK 1 (L314) (1997-2007)	08/00-02/07	FR PS
Land Rover	Freelander 2.0 Td4 MK 1 (L314) (1997-2007)	08/00-02/07	FR PS
Land Rover	Freelander 2.0 Td4 MK 1 (L314) (1997-2007)	08/00-02/07	FR PS
Land Rover	Freelander 2.0 Td4 MK 1 (L314) (1997-2007)	08/00-02/07	FR PS
Land Rover	Freelander 2.5 MK 1 (L314) (1997-2007)	09/00-02/07	FR PS
Land Rover	Freelander 2.5 MK 1 (L314) (1997-2007)	09/00-02/07	FR PS
LDV	Maxus 2.5	01/05-12/09	FR PS
LDV	Maxus 2.5	01/05-12/09	FR PS
LDV	Maxus 2.5	04/07-12/09	FR PS
LDV	Maxus 2.5	04/07-12/09	FR PS
Lexus	GS300 3.0 (1993-1997)	10/93-10/97	FR DS
Lexus	RX300 3.0 XU30 (2003-2006)	03/03-09/06	FR PS
Lotus	Elan 1.6 S2 Type M100	06/94-07/95	FR PS
Lotus	Elan 1.6 SE (Turbo) Type M100	01/90-12/92	FR PS
Lotus	Elan 1.6 Type M100	01/90-12/92	FR PS
Mazda	323 1.3 (1985-1989)	07/87-04/90	FR DS
Mazda	323 1.3 (1985-1989)	07/87-04/90	FR DS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR DS

Mazda	323 1.3 (1989-1994)	05/91-07/95	FR DS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR DS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR DS
Mazda	323 1.3 (1989-1994)	05/91-07/95	FR DS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR DS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR DS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR DS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR DS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR DS
Mazda	323 1.3 (1989-1994)	10/89-05/91	FR DS
Mazda	323 1.3 (1998-2003)	06/01-11/03	FR DS
Mazda	323 1.3 (1998-2003)	06/01-11/03	FR DS
Mazda	323 1.3 (1998-2003)	10/98-06/01	FR DS
Mazda	323 1.3 (1998-2003)	10/98-06/01	FR DS
Mazda	323 1.5 (1985-1989)	05/86-07/87	FR DS
Mazda	323 1.5 (1985-1989)	05/86-07/87	FR DS
Mazda	323 1.5 (1985-1989)	05/86-07/87	FR DS
Mazda	323 1.5 (1985-1989)	07/87-12/89	FR DS
Mazda	323 1.5 (1985-1989)	07/87-12/89	FR DS
Mazda	323 1.5 (1985-1989)	07/87-12/89	FR DS
Mazda	323 1.5 (1989-1994)	01/90-12/91	FR DS
Mazda	323 1.5 (1989-1994)	01/90-12/91	FR DS
Mazda	323 1.5 (1989-1994)	01/90-12/91	FR DS
Mazda	323 1.5 (1994-1998)	01/97-08/98	FR DS
Mazda	323 1.5 (1994-1998)	08/94-12/95	FR DS
Mazda	323 1.5 (1998-2003)	10/00-12/01	FR DS
Mazda	323 1.5 (1998-2003)	10/98-10/01	FR DS
Mazda	323 1.5 (1998-2003)	10/98-10/01	FR DS
Mazda	323 1.5 (1998-2003)	10/98-10/01	FR DS
Mazda	323 1.5 (1998-2003)	10/98-10/01	FR DS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR DS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR DS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR DS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR DS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR DS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR DS
Mazda	323 1.6 (1989-1994)	06/91-08/94	FR DS
Mazda	323 1.6 (1998-2003)	06/01-11/03	FR DS
Mazda	323 1.6 (1998-2003)	06/01-11/03	FR DS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR DS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR DS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR DS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR DS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR DS
Mazda	323 1.8 (1998-2003)	10/98-12/01	FR DS
Mazda	323 1.8 GTi (1989-1994)	10/89-06/91	FR DS
Mazda	323 1.8 GTi (1989-1994)	10/89-06/91	FR DS
Mazda	323 1.8 GTi (1989-1994)	10/89-06/91	FR DS
Mazda	323 1.8 GTi (1989-1994)	10/89-06/91	FR DS
Mazda	323 2.0 (1998-2003)	08/01-11/03	FR DS
Mazda	323 2.0 (1998-2003)	08/01-11/03	FR DS
Mazda	323 2.0 Di (1998-2003)	06/01-12/01	FR DS
Mazda	323 2.0 Di (1998-2003)	06/01-12/01	FR DS

Mazda	323 2.0 Di (1998-2003)	07/00-06/01	FR DS
Mazda	323 2.0 Di (1998-2003)	12/01-11/03	FR DS
Mazda	323 2.0 Di (1998-2003)	12/01-11/03	FR DS
Mazda	323F 1.3 (1994-1998)	01/97-08/98	FR DS
Mazda	323F 1.3 (1994-1998)	04/95-12/95	FR DS
Mazda	626 1.8 (1992-1997)	02/92-02/97	FR DS
Mazda	626 1.8 (1992-1997)	02/92-12/97	FR DS
Mazda	626 1.8 (1997-1999)	06/97-10/99	FR DS
Mazda	626 1.8 (1997-1999)	06/97-10/99	RR
Mazda	626 1.8 (1999-2002)	10/99-10/02	FR DS
Mazda	626 1.8 (1999-2002)	10/99-10/02	RR
Mazda	626 2.0 (1992-1997)	02/92-12/94	FR DS
Mazda	626 2.0 (1992-1997)	02/92-12/94	FR DS
Mazda	626 2.0 (1992-1997)	02/92-12/97	FR DS
Mazda	626 2.0 (1992-1997)	02/92-12/97	FR DS
Mazda	626 2.0 (1992-1997)	05/94-12/95	FR DS
Mazda	626 2.0 (1997-1999)	03/98-10/99	FR DS
Mazda	626 2.0 (1997-1999)	03/98-10/99	FR DS
Mazda	626 2.0 (1997-1999)	03/98-12/99	FR DS
Mazda	626 2.0 (1997-1999)	06/97-10/99	RR
Mazda	626 2.0 (1997-1999)	06/97-10/99	RR
Mazda	626 2.0 (1997-1999)	06/97-10/99	FR DS
Mazda	626 2.0 (1997-1999)	06/97-10/99	FR DS
Mazda	626 2.0 (1997-1999)	06/97-12/99	FR DS
Mazda	626 2.0 (1997-1999)	06/97-12/99	RR
Mazda	626 2.0 (1997-1999)	06/97-12/99	FR DS
Mazda	626 2.0 (1997-1999)	06/97-12/99	FR DS
Mazda	626 2.0 (1997-1999)	06/97-12/99	FR DS
Mazda	626 2.0 (1997-1999)	06/97-12/99	RR
Mazda	626 2.0 (1997-1999)	06/98-10/99	FR DS
Mazda	626 2.0 (1997-1999)	06/98-10/99	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	RR
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	RR
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	RR
Mazda	626 2.0 (1999-2002)	10/99-10/02	RR
Mazda	626 2.0 (1999-2002)	10/99-10/02	RR
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	RR
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.0 (1999-2002)	10/99-10/02	FR DS
Mazda	626 2.5 (1992-1997)	02/92-12/94	FR DS

Mazda	MX3 1.6 (1991-1998)	09/91-04/94	FR DS
Mazda	MX3 1.6 (1991-1998)	09/91-04/94	FR DS
Mazda	MX3 1.6 (1991-1998)	09/91-04/94	FR DS
Mazda	MX3 1.6 (1991-1998)	09/91-04/94	FR DS
Mazda	MX3 1.8 (1991-1998)	08/94-12/98	FR DS
Mazda	MX3 1.8 (1991-1998)	08/94-12/98	FR DS
Mazda	MX3 1.8 (1991-1998)	08/94-12/98	FR DS
Mazda	MX3 1.8 (1991-1998)	09/91-08/94	FR DS
Mazda	Xedos 6 1.6	08/94-12/97	FR DS
Mazda	Xedos 6 1.6	10/93-08/94	FR DS
Mazda	Xedos 6 2.0	06/92-08/94	FR DS
Mazda	Xedos 6 2.0	06/92-08/94	FR DS
Mazda	Xedos 6 2.0	08/94-03/00	FR DS
Mazda	Xedos 6 2.0	08/94-03/00	FR DS
Mazda	Xedos 9 2.3 Miller Supercharged	10/98-12/00	FR DS
Mazda	Xedos 9 2.5	01/94-12/98	FR DS
Mercedes Benz	380SEC 3.8 C126	10/81-10/85	FR PS
Mercedes Benz	380SEC 3.8 C126	10/81-10/85	FR DS
Mercedes Benz	420SEC 4.2 C126	02/86-12/91	FR PS
Mercedes Benz	420SEC 4.2 C126	02/86-12/91	FR DS
Mercedes Benz	500SEC 5.0 C126	10/81-10/85	FR DS
Mercedes Benz	500SEC 5.0 C126	10/81-10/85	FR PS
Mercedes Benz	560SEC 5.5 C126	08/86-12/91	FR DS
Mercedes Benz	560SEC 5.5 C126	08/86-12/91	FR PS
Mitsubishi	3000 GT 3.0 (1992-1999)	07/96-10/99	FR DS
Mitsubishi	3000 GT 3.0 (1992-1999)	08/92-10/99	FR DS
Mitsubishi	ASX 1.6 Di-D (2010-2021)	04/15-04/19	FR PS
Mitsubishi	ASX 1.6 Di-D (2010-2021)	04/15-04/19	FR PS
Mitsubishi	ASX 2.0 MIVEC (2010-2021)	07/19-12/21	FR PS
Mitsubishi	ASX 2.2 (2010-2021)	05/13-04/19	FR PS
Mitsubishi	Carisma 1.6 (1995-1999)	08/96-10/97	FR DS
Mitsubishi	Carisma 1.6 (1995-1999)	08/96-10/97	FR DS
Mitsubishi	Carisma 1.6 (1995-1999)	10/95-10/97	FR DS
Mitsubishi	Carisma 1.6 (1995-1999)	10/95-10/97	FR DS
Mitsubishi	Carisma 1.6 (1995-1999)	10/97-08/99	FR DS
Mitsubishi	Carisma 1.6 (1995-1999)	10/97-08/99	FR DS
Mitsubishi	Carisma 1.6 (1995-1999)	10/97-08/99	FR DS
Mitsubishi	Carisma 1.6 (1995-1999)	10/97-08/99	FR DS
Mitsubishi	Carisma 1.6 (1999-2005)	08/99-04/05	FR DS
Mitsubishi	Carisma 1.6 (1999-2005)	08/99-04/05	FR DS
Mitsubishi	Carisma 1.6 (1999-2005)	08/99-12/01	FR DS
Mitsubishi	Carisma 1.6 (1999-2005)	08/99-12/01	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	08/96-10/97	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	08/96-10/97	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	10/95-10/97	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	10/95-10/97	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR DS
Mitsubishi	Carisma 1.8 (1995-1999)	10/97-08/99	FR DS

Mitsubishi	Carisma 1.8 (1999-2005)	08/99-05/03	FR DS
Mitsubishi	Carisma 1.8 (1999-2005)	08/99-05/03	FR DS
Mitsubishi	Carisma 1.8 (1999-2005)	08/99-08/01	FR DS
Mitsubishi	Carisma 1.8 (1999-2005)	08/99-08/01	FR DS
Mitsubishi	Carisma 1.9 (1995-1999)	04/97-07/99	FR DS
Mitsubishi	Carisma 1.9 (1995-1999)	04/97-07/99	FR DS
Mitsubishi	Carisma 1.9 (1999-2005)	07/99-05/02	FR DS
Mitsubishi	Carisma 1.9 DI-D (1999-2005)	05/02-04/05	FR DS
Mitsubishi	Carisma 2.0 Evolution VI (1999-2005)	06/99-12/01	FR DS
Mitsubishi	Colt Mirage 1.3 (1996-2004)	03/96-05/03	FR DS
Mitsubishi	Colt Mirage 1.3 (1996-2004)	03/96-05/03	FR DS
Mitsubishi	Colt Mirage 1.6 (1996-2004)	04/03-07/04	FR DS
Mitsubishi	Colt Mirage 1.6 (1996-2004)	04/03-07/04	FR DS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/94-12/02	FR PS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/94-12/97	FR PS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/97-12/02	FR PS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/99-05/02	FR PS
Mitsubishi	FTO 2.0 MIVEC (1994-2002)	01/99-05/02	FR PS
Mitsubishi	L200 2.5 (2006-2016)	03/06-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	03/06-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	03/06-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	03/06-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	03/09-04/16	FR DS
Mitsubishi	L200 2.5 (2006-2016)	04/08-12/10	FR DS
Mitsubishi	L200 2.5 (2006-2016)	04/08-12/10	FR DS
Mitsubishi	L200 2.5 Power Upgrade Pack (2006-2016)	03/06-10/08	FR DS
Mitsubishi	L200 2.5 Power Upgrade Pack (2006-2016)	03/06-10/08	FR DS
Mitsubishi	Outlander 2.2 Di-D 4Work (2007-2013)	05/10-12/13	FR PS
Mitsubishi	RVR 1.8	01/92-12/00	FR DS
Mitsubishi	RVR 1.8	01/92-12/00	FR DS
Mitsubishi	Space Star 1.3 (1998-2002)	12/98-08/02	FR DS
Mitsubishi	Space Star 1.3 (1998-2002)	12/98-08/02	FR DS
Mitsubishi	Space Star 1.3 (1998-2002)	12/98-08/02	FR DS
Mitsubishi	Space Star 1.3 (2002-2006)	07/02-12/06	FR DS
Mitsubishi	Space Star 1.3 (2002-2006)	07/02-12/06	FR DS
Mitsubishi	Space Star 1.3 (2002-2006)	07/02-12/06	FR DS
Mitsubishi	Space Star 1.6 (1998-2002)	04/01-08/02	FR DS
Mitsubishi	Space Star 1.6 (1998-2002)	04/01-08/02	FR DS
Mitsubishi	Space Star 1.6 (2002-2006)	07/02-12/06	FR DS
Mitsubishi	Space Star 1.6 (2002-2006)	07/02-12/06	FR DS
Mitsubishi	Space Star 1.8 (1998-2002)	12/98-08/02	FR DS
Mitsubishi	Space Star 1.8 (1998-2002)	12/98-08/02	FR DS
Mitsubishi	Space Star 1.8 (2002-2006)	11/03-07/05	FR DS
Mitsubishi	Space Star 1.9 DI-D (2002-2006)	07/02-12/06	FR DS
Mitsubishi	Space Star 1.9 DI-D (2002-2006)	07/02-12/06	FR DS
Mitsubishi	Space Star 1.9 DI-D S (2002-2006)	11/03-12/06	FR DS
Mitsubishi	Space Star 1.9 DI-D S (2002-2006)	11/03-12/06	FR DS

Mitsubishi	Space Star 1.9 DI-D S (2002-2006)	11/03-12/06	FR DS
Nissan	200SX 2.0 S14	09/94-07/01	FR DS
Nissan	200SX 2.0 S14	09/94-07/01	FR DS
Nissan	300ZX 3.0 Turbo Targa Z32	03/90-12/94	FR PS
Nissan	300ZX 3.0 Turbo Targa Z32	03/90-12/94	FR PS
Nissan	300ZX 3.0 Turbo Targa Z32	03/90-12/94	FR DS
Nissan	300ZX 3.0 Turbo Targa Z32	03/90-12/94	FR DS
Nissan	370Z 3.7 Nismo Z34	05/13-12/21	FR DS
Nissan	370Z 3.7 Roadster Z34	09/09-12/14	FR DS
Nissan	370Z 3.7 Roadster Z34	09/09-12/14	FR DS
Nissan	Almera 1.4 N15	05/97-02/00	FR DS
Nissan	Almera 1.4 N15	10/95-02/00	FR DS
Nissan	Almera 1.4 N15	10/95-02/00	FR DS
Nissan	Almera 1.6 N15	05/96-02/00	FR DS
Nissan	Almera 1.6 N15	05/96-02/00	FR DS
Nissan	Almera 1.6 N15	10/95-02/00	FR DS
Nissan	Almera 1.6 N15	10/95-02/00	FR DS
Nissan	Almera 2.0 GTi N15	07/96-02/00	FR DS
Nissan	Almera 2.0 N15	05/96-04/99	FR DS
Nissan	Almera 2.0 N15	10/95-04/99	FR DS
Nissan	Maxima 3.0 A31	06/89-07/94	FR DS
Nissan	Micra 1.0 K12	10/02-09/05	FR DS
Nissan	Micra 1.0 K12	10/02-09/05	FR DS
Nissan	Micra 1.0 K12	10/02-09/05	FR DS
Nissan	Micra 1.0 K12	10/02-09/05	FR DS
Nissan	Micra 1.2 K12	06/05-06/10	FR DS
Nissan	Micra 1.2 K12	06/05-06/10	FR DS
Nissan	Micra 1.2 K12	10/02-04/08	FR DS
Nissan	Micra 1.2 K12	10/02-04/08	FR DS
Nissan	Micra 1.2 K12	10/02-04/11	FR DS
Nissan	Micra 1.2 K12	10/02-04/11	FR DS
Nissan	Micra 1.2 K13 (W02A)	03/11-04/14	FR DS
Nissan	Micra 1.2 K13 (W02A)	03/11-04/14	FR DS
Nissan	Micra 1.2 K13 (W02A)	03/11-12/17	FR DS
Nissan	Micra 1.2 K13 (W02A)	03/11-12/17	FR DS
Nissan	Micra 1.2 K13 (W02A)	09/10-12/17	FR DS
Nissan	Micra 1.2 K13 (W02A)	09/10-12/17	FR DS
Nissan	Micra 1.4 K12	10/02-04/08	FR DS
Nissan	Micra 1.4 K12	10/02-04/08	FR DS
Nissan	Micra 1.4 K12	10/02-12/10	FR DS
Nissan	Micra 1.4 K12	10/02-12/10	FR DS
Nissan	Micra 1.5 dCi 65 K12	04/03-08/06	FR DS
Nissan	Micra 1.5 dCi 65 K12	04/03-08/06	FR DS
Nissan	Micra 1.5 dCi 82 K12	08/03-08/06	FR DS
Nissan	Micra 1.5 dCi 82 K12	08/03-08/06	FR DS
Nissan	Micra 1.5 dCi 86 K12	08/06-04/11	FR DS
Nissan	Micra 1.5 dCi 86 K12	08/06-04/11	FR DS
Nissan	Micra 1.6 K12	07/05-12/09	FR DS
Nissan	Micra 1.6 K12	07/05-12/09	FR DS
Nissan	Micra C+C 1.4 K12	09/05-12/09	FR DS



Nissan	Micra C+C 1.6 K12	09/05-12/09	FR DS
Nissan	Micra C+C 1.6 K12	09/05-12/09	FR DS
Nissan	Primastar 1.9 dCi 100 X83	09/02-04/07	FR PS
Nissan	Primastar 1.9 dCi 80 X83	09/02-12/06	FR PS
Nissan	Primastar 2.0 dCi 115 X83	08/10-05/15	FR PS
Nissan	Primastar 2.0 dCi 115 X83	08/10-05/15	FR PS
Nissan	Primastar 2.0 dCi 115 X83	10/06-05/15	FR PS
Nissan	Primastar 2.0 dCi 115 X83	10/06-05/15	FR PS
Nissan	Primastar 2.0 dCi 115 X83	10/06-05/15	FR PS
Nissan	Primastar 2.0 dCi 115 X83	10/06-05/15	FR PS
Nissan	Primastar 2.0 dCi 90 X83	10/06-04/10	FR PS
Nissan	Primastar 2.0 dCi 90 X83	10/06-04/10	FR PS
Nissan	Primastar 2.0 X83	02/03-12/06	FR PS
Nissan	Primastar 2.0 X83	02/03-12/06	FR PS
Nissan	Primastar 2.5 dCi 135 X83	03/04-12/06	FR PS
Nissan	Primastar 2.5 dCi 150 X83	10/06-06/12	FR PS
Nissan	Primera 1.6 Carburettor P10	09/90-12/91	FR DS
Nissan	Primera 1.6 Carburettor P10	09/90-12/91	RR
Nissan	Primera 1.6 Carburettor P10	09/90-12/91	FR DS
Nissan	Primera 1.6 Carburettor W10	02/91-12/91	RR
Nissan	Primera 1.6 Carburettor W10	02/91-12/91	FR DS
Nissan	Primera 1.6 MPi P10	06/93-10/96	FR DS
Nissan	Primera 1.6 MPi P10	06/93-10/96	RR
Nissan	Primera 1.6 MPi P10	06/93-10/96	FR DS
Nissan	Primera 1.6 MPi W10	06/93-10/96	FR DS
Nissan	Primera 1.6 P11	10/96-09/99	FR DS
Nissan	Primera 1.6 P11	10/96-09/99	FR DS
Nissan	Primera 1.6 P11-144	09/99-05/02	FR DS
Nissan	Primera 1.6 P11-144	09/99-05/02	FR DS
Nissan	Primera 1.6 SPi P10	01/92-06/93	RR
Nissan	Primera 1.6 SPi P10	01/92-06/93	FR DS
Nissan	Primera 1.6 SPi P10	01/92-06/93	FR DS
Nissan	Primera 1.6 SPi W10	01/92-06/93	FR DS
Nissan	Primera 1.6 W11	04/98-09/99	FR DS
Nissan	Primera 1.6 W11	09/99-05/02	FR DS
Nissan	Primera 1.8 Dual Fuel P11-144	10/00-05/02	FR DS
Nissan	Primera 1.8 P11-144	09/99-05/02	FR DS
Nissan	Primera 1.8 P11-144	09/99-05/02	FR DS
Nissan	Primera 1.8 W11	09/99-05/02	FR DS
Nissan	Primera 2.0 Dual Fuel P11	03/99-09/99	FR DS
Nissan	Primera 2.0 Dual Fuel P11	03/99-09/99	FR DS
Nissan	Primera 2.0 Dual Fuel P11	03/99-09/99	FR DS
Nissan	Primera 2.0 eZX P10	09/90-10/96	FR DS
Nissan	Primera 2.0 GT P11	05/97-09/99	FR DS
Nissan	Primera 2.0 GT P11	05/97-09/99	FR DS
Nissan	Primera 2.0 P10	06/92-11/96	FR DS
Nissan	Primera 2.0 P10	06/92-11/96	RR
Nissan	Primera 2.0 P10	06/92-11/96	FR DS
Nissan	Primera 2.0 P10	06/93-10/96	RR
Nissan	Primera 2.0 P10	06/93-10/96	FR DS

Nissan	Primera 2.0 P10	06/93-10/96	RR
Nissan	Primera 2.0 P10	06/93-10/96	FR DS
Nissan	Primera 2.0 P10	06/93-10/96	FR DS
Nissan	Primera 2.0 P10	06/93-10/96	FR DS
Nissan	Primera 2.0 P11	10/96-09/99	FR DS
Nissan	Primera 2.0 P11	10/96-09/99	FR DS
Nissan	Primera 2.0 P11	10/96-09/99	FR DS
Nissan	Primera 2.0 P11	10/96-09/99	FR DS
Nissan	Primera 2.0 P11	10/96-09/99	FR DS
Nissan	Primera 2.0 P11	10/96-09/99	FR DS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR DS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR DS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR DS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR DS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR DS
Nissan	Primera 2.0 P11-144	09/99-05/02	FR DS
Nissan	Primera 2.0 W10	02/91-10/96	FR DS
Nissan	Primera 2.0 W10	02/91-10/96	FR DS
Nissan	Primera 2.0 W10	06/95-11/96	FR DS
Nissan	Primera 2.0 W11	04/98-09/99	FR DS
Nissan	Primera 2.0 W11	04/98-09/99	FR DS
Nissan	Primera 2.0 W11	04/98-09/99	FR DS
Nissan	Primera 2.0 W11	09/99-05/02	FR DS
Nissan	Primera 2.0 W11	09/99-05/02	FR DS
Nissan	Primera 2.0 W11	09/99-05/02	FR DS
Nissan	Skyline 2.5 GT-T R34	01/99-12/01	FR DS
Nissan	Skyline 2.5 GT-T R34	01/99-12/01	FR DS
Nissan	Skyline 2.5 GT-T R34	01/99-12/01	FR PS
Nissan	Skyline 2.5 GT-T R34	01/99-12/01	FR DS
Nissan	Skyline 2.5 GT-T R34	01/99-12/01	FR PS
Nissan	Skyline 2.5 GT-T R34	01/99-12/01	FR DS
Nissan	Skyline 2.5 GT-T R34	01/99-12/01	FR PS
Nissan	Skyline 2.5 GT-T R34	01/99-12/01	FR PS
Nissan	Skyline 2.6 GT-R R34	01/99-12/01	FR DS
Nissan	Skyline 2.6 GT-R R34	01/99-12/01	FR DS
Nissan	Skyline 2.6 GT-R R34	01/99-12/01	FR PS
Nissan	Skyline 2.6 GT-R R34	01/99-12/01	FR PS
Nissan	Skyline 2.6 GT-R R34	01/99-12/01	FR PS
Nissan	Skyline 2.6 GT-R R34	01/99-12/01	FR DS
Nissan	Skyline 2.6 GT-R R34	01/99-12/01	FR DS
Nissan	Skyline 2.6 GT-R R34	01/99-12/01	FR PS
Nissan	Sunny 1.4 MPi N14	02/93-10/95	FR DS
Nissan	Sunny 1.4 MPi N14	02/93-10/95	FR DS
Nissan	Sunny 1.4 MPi N14	02/93-10/95	FR DS
Nissan	Sunny 1.4 N14	12/91-02/93	FR DS
Nissan	Sunny 1.4 N14	12/91-02/93	FR DS
Nissan	Sunny 1.4 N14	12/91-02/93	FR DS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR DS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR DS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR DS

Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR DS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR DS
Nissan	Sunny 1.6 MPi N14	02/93-10/95	FR DS
Nissan	Sunny 1.6 SPi N14	12/91-02/93	FR DS
Nissan	Sunny 1.6 SPi N14	12/91-02/93	FR DS
Nissan	Sunny 1.6 SPi N14	12/91-02/93	FR DS
Nissan	Sunny 1.6 SPi N14	12/91-02/93	FR DS
Nissan	Sunny 2.0 e GTi N14	01/92-08/94	FR DS
Nissan	Sunny 2.0 GTi-R N14	04/92-12/93	FR DS
Nissan	Sunny 2.0 N14	02/93-10/95	FR DS
Nissan	Sunny 2.0 N14	02/93-10/95	FR DS
Nissan	Terrano 2.7 R50	09/95-02/99	FR DS
Nissan	Terrano 2.7 R50	09/95-02/99	FR DS
Nissan	Terrano 2.7 R50	09/95-02/99	FR DS
Nissan	Terrano 2.7 R50	09/95-02/99	FR DS
Nissan	Terrano 3.0 R50	02/99-12/04	FR DS
Nissan	Terrano 3.0 R50	02/99-12/04	FR DS
Nissan	Terrano 3.0 R50	02/99-12/04	FR DS
Nissan	Terrano 3.0 R50	02/99-12/04	FR DS
Nissan	Terrano 3.3 R50	02/99-12/04	FR DS
Nissan	Terrano 3.3 R50	02/99-12/04	FR DS
Nissan	Terrano 3.3 R50	02/99-12/04	FR DS
Nissan	Terrano 3.3 R50	02/99-12/04	FR DS
Nissan	Terrano II 2.4 R20	07/93-10/96	FR DS
Nissan	Terrano II 2.4 R20	07/96-12/99	FR DS
Nissan	Terrano II 2.4 R20	07/96-12/99	FR DS
Nissan	Terrano II 2.4 R20	12/99-12/01	FR DS
Nissan	Terrano II 2.4 R20	12/99-12/01	FR DS
Nissan	Terrano II 2.7 R20	01/00-12/02	FR DS
Nissan	Terrano II 2.7 R20	01/00-12/06	FR DS
Nissan	Terrano II 2.7 R20	01/00-12/06	FR DS
Nissan	Terrano II 2.7 R20	06/96-01/00	FR DS
Nissan	Terrano II 2.7 R20	07/93-10/96	FR DS
Nissan	Terrano II 2.7 R20	07/93-10/96	FR DS
Nissan	Terrano II 2.7 R20	07/96-01/00	FR DS
Nissan	Terrano II 2.7 R20	07/96-01/00	FR DS
Nissan	Terrano II 2.7 R20	09/98-12/06	FR DS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR DS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR DS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR DS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR DS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR DS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR DS
Nissan	Terrano II 3.0 R20	04/02-12/06	FR DS
Nissan	Terrano Regulus 3.0 R50	01/99-12/01	FR DS
Nissan	Terrano Regulus 3.0 R50	01/99-12/01	FR DS
Nissan	Terrano Regulus 3.0 R50	01/99-12/01	FR DS
Nissan	Terrano Regulus 3.0 R50	01/99-12/01	FR DS
Renault	Clio 1.2 MK 2 Phase 1 (1998-2001)	05/98-04/01	FR PS
Renault	Clio 1.2 MK 2 Phase 1 (1998-2001)	05/98-04/01	FR PS









Renault	Trafic 2.0 dCi 115 MK 2 X83 (2001-2010)	09/06-12/10	FR PS
Renault	Trafic 2.0 dCi 115 MK 2 X83 (2001-2010)	09/06-12/10	RR
Renault	Trafic 2.0 dCi 115 MK 2 X83 (2001-2010)	09/06-12/10	RR
Renault	Trafic 2.0 dCi 115 MK 2 X83 (2001-2010)	09/06-12/10	FR PS
Renault	Trafic 2.0 dCi 115 MK 2 X83 (2001-2010)	09/06-12/10	RR
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	FR PS
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	FR PS
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	FR PS
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	RR
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	FR PS
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	RR
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	RR
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	FR PS
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	FR PS
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	RR
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	FR PS
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	RR
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	RR
Renault	Trafic 2.0 dCi 115 MK 3 X83 (2010-2015)	05/10-05/15	FR PS
Renault	Trafic 2.0 dCi 90 MK 2 X83 (2001-2010)	09/06-12/10	RR
Renault	Trafic 2.0 dCi 90 MK 2 X83 (2001-2010)	09/06-12/10	RR
Renault	Trafic 2.0 dCi 90 MK 3 X83 (2010-2015)	05/10-05/15	RR
Renault	Trafic 2.0 MK 2 X83 (2001-2010)	05/01-12/08	FR PS
Renault	Trafic 2.0 MK 2 X83 (2001-2010)	05/01-12/08	FR PS
Renault	Trafic 2.0 MK 2 X83 (2001-2010)	05/01-12/08	FR PS
Renault	Trafic 2.5 dCi 140 MK 2 X83 (2001-2010)	10/03-12/06	RR
Renault	Trafic 2.5 dCi 150 MK 2 X83 (2001-2010)	09/06-12/10	RR
Renault	Trafic 2.5 dCi 150 MK 3 X83 (2010-2015)	05/10-05/15	RR
Saab	900 2.0 (1993-1998)	06/94-06/98	FR PS
Saab	900 2.0 (1993-1998)	06/94-06/98	FR PS
Saab	900 2.0 (1993-1998)	06/94-06/98	FR DS
Saab	900 2.0 (1993-1998)	06/94-06/98	FR DS
Saab	900 2.0 (1993-1998)	10/93-06/98	FR DS
Saab	900 2.0 (1993-1998)	10/93-06/98	FR PS
Saab	900 2.0 (1993-1998)	10/93-06/98	FR DS
Saab	900 2.0 (1993-1998)	10/93-06/98	FR PS
Saab	900 2.0 (1993-1998)	10/93-06/98	FR DS
Saab	900 2.0 (1993-1998)	10/93-06/98	FR PS
Saab	900 2.0 (1993-1998)	10/93-06/98	FR DS
Saab	900 2.0 (1993-1998)	10/93-06/98	FR PS
Saab	900 2.0 (1993-1998)	10/94-06/98	FR PS
Saab	900 2.0 (1993-1998)	10/94-06/98	FR DS
Saab	900 2.0 (1993-1998)	10/94-06/98	FR PS
Saab	900 2.0 (1993-1998)	10/94-06/98	FR DS
Saab	900 2.0 (1993-1998)	10/94-06/98	FR DS
Saab	900 2.0 Turbo (1993-1998)	01/95-06/98	FR PS
Saab	900 2.0 Turbo (1993-1998)	01/95-06/98	FR PS
Saab	900 2.0 Turbo (1993-1998)	01/95-06/98	FR DS
Saab	900 2.0 Turbo (1993-1998)	01/95-06/98	FR DS
Saab	900 2.0 Turbo (1993-1998)	01/95-06/98	FR DS
Saab	900 2.0 Turbo (1993-1998)	01/95-06/98	FR PS









Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	FR PS
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	FR PS
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	FR PS
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	FR DS
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	FR DS
Saab	9-3 2.2 TiD (1998-2002)	03/98-09/00	FR PS
Saab	9-3 2.2 TiD (1998-2002)	09/00-05/02	FR PS
Saab	9-3 2.2 TiD (1998-2002)	09/00-05/02	FR DS
Saab	9-3 2.2 TiD (1998-2002)	09/00-05/02	FR PS
Saab	9-3 2.2 TiD (1998-2002)	09/00-05/02	FR DS
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	FR PS
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	FR DS
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	FR DS
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	FR DS
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	FR PS
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	FR DS
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	FR PS
Saab	9-3 2.2 TiD (1998-2002)	11/99-09/00	FR PS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR PS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR DS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR PS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR DS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR PS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR DS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR DS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR DS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR PS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR PS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR DS
Saab	9-3 2.3 (1998-2002)	03/98-08/98	FR PS
Saab	9-3 2.3 HOT Viggen (1998-2002)	09/99-07/00	FR PS
Saab	9-3 2.3 HOT Viggen (1998-2002)	09/99-07/00	FR PS
Saab	9-3 2.3 HOT Viggen (1998-2002)	09/99-07/00	FR DS
Saab	9-3 2.3 HOT Viggen (1998-2002)	09/99-07/00	FR DS
Saab	9-3 2.3 HOT Viggen (1998-2002)	09/99-07/00	FR DS
Saab	9-3 2.3 HOT Viggen (1998-2002)	09/99-07/00	FR PS
Saab	9-3 2.3 T Viggen (1998-2002)	03/99-09/99	FR DS
Saab	9-3 2.3 T Viggen (1998-2002)	03/99-09/99	FR PS
Saab	9-3 2.3 T Viggen (1998-2002)	03/99-09/99	FR PS
Saab	9-3 2.3 T Viggen (1998-2002)	03/99-09/99	FR DS
Seat	Cordoba 1.4 (1994-1999)	04/95-04/96	FR DS
Seat	Cordoba 1.4 (1994-1999)	04/96-10/99	FR DS
Seat	Cordoba 1.4 (1994-1999)	04/96-10/99	FR DS
Seat	Cordoba 1.4 (1994-1999)	04/96-10/99	FR DS
Seat	Cordoba 1.4 (1994-1999)	04/96-10/99	FR DS
Seat	Cordoba 1.4 (1999-2001)	10/99-12/01	FR DS
Seat	Cordoba 1.4 (1999-2001)	10/99-12/02	FR DS
Seat	Cordoba 1.4 Vario (1999-2001)	05/00-06/01	FR DS
Seat	Cordoba 1.4 Vario (1999-2001)	05/00-06/01	FR DS
Seat	Cordoba 1.6 (1994-1999)	05/94-07/97	FR DS



Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR DS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR DS
Seat	Ibiza 1.4 6K (1993-1999)	05/94-04/96	FR DS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.4 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.6 6K (1993-1999)	10/93-12/96	FR DS
Seat	Ibiza 1.6 6K (1993-1999)	10/93-12/96	FR DS
Seat	Ibiza 1.6 6K (1993-1999)	10/93-12/96	FR DS
Seat	Ibiza 1.6 6K (1993-1999)	10/93-12/96	FR DS
Seat	Ibiza 1.6 6K (1993-1999)	12/96-12/97	FR DS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.6 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.8 6K (1993-1999)	10/93-06/94	FR DS
Seat	Ibiza 1.8 6K (1993-1999)	10/93-06/94	FR DS
Seat	Ibiza 1.8 6K (1993-1999)	10/94-12/96	FR DS
Seat	Ibiza 1.9 6K (1993-1999)	10/93-01/99	FR DS
Seat	Ibiza 1.9 6K (1993-1999)	10/93-01/99	FR DS
Seat	Ibiza 1.9 6K (1993-1999)	10/93-01/99	FR DS
Seat	Ibiza 1.9 6K (1993-1999)	10/93-01/99	FR DS
Seat	Ibiza 1.9 TDi 110 6K (1999-2002)	09/01-05/02	FR DS
Seat	Ibiza 1.9 TDi 90 6K (1993-1999)	07/97-10/99	FR DS
Seat	Ibiza 1.9 TDi 90 6K (1993-1999)	07/97-10/99	FR DS
Seat	Ibiza 1.9 TDi 90 6K (1993-1999)	07/97-10/99	FR DS
Seat	Ibiza 1.9 TDi 90 6K (1993-1999)	07/97-10/99	FR DS
Seat	Ibiza 1.9 TDi 90 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.9 TDi 90 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.9 TDi 90 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 1.9 TDi 90 6K (1999-2002)	10/99-05/02	FR DS
Seat	Ibiza 2.0 6K (1993-1999)	10/93-10/99	FR DS
Seat	Ibiza 2.0 6K (1993-1999)	10/93-10/99	FR DS
Seat	Ibiza 2.0 6K (1993-1999)	12/96-10/99	FR DS
Seat	Inca 1.4 (1996-2004)	05/98-10/99	FR DS
Seat	Inca 1.4 (1996-2004)	05/98-10/99	FR DS
Seat	Inca 1.4 (1996-2004)	05/98-10/99	FR DS
Seat	Inca 1.4 (1996-2004)	05/98-10/99	FR DS
Seat	Inca 1.9 (1996-2004)	04/96-10/99	FR DS
Seat	Inca 1.9 SDi (1996-2004)	10/99-03/04	FR DS
Seat	Inca 1.9 SDi (1996-2004)	10/99-03/04	FR DS
Skoda	Octavia 1.4 1U (2000-2009)	10/00-04/04	FR DS
Skoda	Octavia 1.4 1U (2000-2009)	10/00-04/04	FR DS
Skoda	Octavia 1.6 1U (1998-2000)	06/98-10/00	FR DS
Skoda	Octavia 1.6 1U (1998-2000)	06/98-10/00	FR DS
Skoda	Octavia 1.6 1U (1998-2000)	06/98-10/00	FR DS
Skoda	Octavia 1.6 1U (1998-2000)	06/98-10/00	FR DS







Skoda	Octavia 2.0 1U (2000-2009)	10/00-12/04	FR DS
Skoda	Octavia Tour 1.9 TDi 100 1U (2000-2009)	01/05-12/09	FR DS
Skoda	Octavia Tour 1.9 TDi 100 1U (2000-2009)	01/05-12/09	FR DS
Skoda	Superb 1.9 TDi PD 3U (2002-2008)	01/06-09/07	FR DS
Skoda	Superb 1.9 TDi PD 3U (2002-2008)	01/06-09/07	FR DS
Skoda	Superb 1.9 TDi PD 3U (2002-2008)	07/07-12/08	FR DS
Skoda	Superb 2.0 TDi 3U (2002-2008)	01/06-12/08	FR DS
Smart	City 0.6 Passion (1999-2004)	12/99-04/03	FR PS
Smart	City 0.6 Passion (1999-2004)	12/99-04/03	FR DS
Smart	City 0.6 Pulse (1999-2004)	01/01-04/03	FR PS
Smart	City 0.6 Pulse (1999-2004)	01/01-04/03	FR DS
Smart	City 0.6 Pulse (1999-2004)	12/99-01/01	FR DS
Smart	City 0.6 Pulse (1999-2004)	12/99-01/01	FR PS
Smart	City 0.6 Pure (1999-2004)	12/99-04/03	FR DS
Smart	City 0.6 Pure (1999-2004)	12/99-04/03	FR PS
Smart	City 0.7 Brabus (1999-2004)	03/03-01/04	FR PS
Smart	City 0.7 Brabus (1999-2004)	03/03-01/04	FR DS
Smart	City 0.7 Passion (1999-2004)	03/03-01/04	FR PS
Smart	City 0.7 Passion (1999-2004)	03/03-01/04	FR DS
Smart	City 0.7 Pulse (1999-2004)	03/03-01/04	FR DS
Smart	City 0.7 Pulse (1999-2004)	03/03-01/04	FR PS
Smart	City 0.7 Pure (1999-2004)	03/03-01/04	FR DS
Smart	City 0.7 Pure (1999-2004)	03/03-01/04	FR PS
Smart	City 0.7 Pure (1999-2004)	03/03-01/04	FR DS
Smart	City 0.7 Pure (1999-2004)	03/03-01/04	FR PS
Smart	Fortwo 0.7 Brabus (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Brabus (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Brabus (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Brabus (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Brabus (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Brabus (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Brabus (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Brabus (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Pure (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Pure (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Pure (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Pure (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Pure (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Pure (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	01/04-12/07	FR PS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	01/04-12/07	FR DS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	12/03-12/07	FR DS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	12/03-12/07	FR DS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	12/03-12/07	FR DS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	12/03-12/07	FR PS
Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	12/03-12/07	FR PS

Smart	Fortwo 0.7 Pure/Pulse/Passion (2004-2007)	12/03-12/07	FR PS
Subaru	Forester 2.0 SF (1997-2000)	09/97-04/00	FR DS
Subaru	Forester 2.0 SF (1997-2000)	09/97-04/00	FR DS
Subaru	Forester 2.0 SF (2000-2002)	04/00-10/02	FR DS
Subaru	Forester 2.0 SF (2000-2002)	04/00-10/02	FR DS
Subaru	Forester 2.0 SG (2005-2008)	09/05-12/08	FR DS
Subaru	Forester 2.0 SG (2005-2008)	09/05-12/08	FR DS
Subaru	Forester 2.0 SG (2005-2008)	09/05-12/08	FR DS
Subaru	Forester 2.0 SG (2005-2008)	09/05-12/08	FR DS
Subaru	Forester 2.0 Turbo SF (1997-2000)	10/98-04/00	FR DS
Subaru	Forester 2.0 Turbo SF (1997-2000)	10/98-04/00	FR DS
Subaru	Forester 2.0 Turbo SF (2000-2002)	02/01-10/02	FR DS
Subaru	Forester 2.0 Turbo SF (2000-2002)	02/01-10/02	FR DS
Subaru	Forester 2.0 Turbo SF (2000-2002)	04/00-02/01	FR DS
Subaru	Forester 2.0 Turbo SF (2000-2002)	04/00-02/01	FR DS
Subaru	Forester 2.0 X SG (2002-2005)	10/02-10/05	FR DS
Subaru	Forester 2.0 X SG (2002-2005)	10/02-10/05	FR DS
Subaru	Forester 2.0 X SG (2002-2005)	10/02-10/05	FR DS
Subaru	Forester 2.0 X SG (2002-2005)	10/02-10/05	FR DS
Subaru	Forester 2.0 XT SG (2002-2005)	10/02-10/05	FR DS
Subaru	Forester 2.0 XT SG (2002-2005)	10/02-10/05	FR DS
Subaru	Forester 2.0 XT SG (2002-2005)	10/02-10/05	FR DS
Subaru	Forester 2.0 XT SG (2002-2005)	10/02-10/05	FR DS
Subaru	Forester 2.5 XT SG (2002-2005)	11/04-10/05	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.6 (1993-2000)	01/94-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS

Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 1.8 (1993-2000)	05/93-09/96	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	01/99-11/00	FR DS
Subaru	Impreza 2.0 (1993-2000)	12/95-03/99	FR DS
Subaru	Impreza 2.0 (1993-2000)	12/95-03/99	FR DS
Subaru	Impreza 2.0 P1 (1993-2000)	04/99-11/00	FR DS
Subaru	Impreza 2.0 P1 (1993-2000)	04/99-11/00	FR DS
Subaru	Impreza 2.0 P1 (1993-2000)	04/99-11/00	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	01/93-03/99	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	01/93-03/99	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	01/93-03/99	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	01/93-03/99	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/94-03/99	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR DS
Subaru	Impreza 2.0 Turbo (1993-2000)	03/99-11/00	FR DS
Subaru	Legacy 2.0 (1994-1999)	04/94-10/98	FR DS
Subaru	Legacy 2.0 (1994-1999)	04/94-10/99	FR DS
Subaru	Legacy 2.0 (1998-2003)	09/99-10/99	FR DS
Subaru	Legacy 2.0 (1998-2003)	09/99-10/99	FR DS
Subaru	Legacy 2.2 (1994-1999)	04/94-01/98	FR DS
Subaru	Legacy 2.2 (1994-1999)	04/94-01/98	FR DS
Subaru	Legacy 2.2 (1994-1999)	04/94-01/98	FR DS
Subaru	Legacy 2.2 (1994-1999)	04/94-01/98	FR DS
Subaru	Legacy 2.5 (1994-1999)	01/98-10/98	FR DS
Subaru	Legacy 2.5 (1994-1999)	01/98-12/98	FR DS
Subaru	Legacy 2.5 (1994-1999)	09/96-10/98	FR DS
Subaru	Legacy 2.5 (1994-1999)	09/96-12/98	FR DS
Subaru	Legacy 2.5 (1998-2003)	12/98-10/99	FR DS
Subaru	Legacy 2.5 (1998-2003)	12/98-10/99	FR DS
Subaru	Legacy Outback 2.5 (1994-1999)	01/98-12/98	FR DS
Subaru	Legacy Outback 2.5 (1994-1999)	09/96-12/98	FR DS
Suzuki	Alto 1.0 (2009-2015)	03/09-12/15	FR DS

Suzuki	Alto 1.0 (2009-2015)	03/09-12/15	FR DS
Suzuki	Baleno 1.0 (2016-2019)	02/16-12/19	FR DS
Suzuki	Baleno 1.0 (2016-2019)	02/16-12/19	FR DS
Suzuki	Baleno 1.2 (2016-2019)	02/16-12/19	FR DS
Suzuki	Baleno 1.2 SHVS (2016-2019)	05/16-12/19	FR DS
Suzuki	Swift 1.0 (1992-2003)	01/95-10/03	FR DS
Suzuki	Swift 1.0 (1992-2003)	01/95-10/03	FR DS
Suzuki	Swift 1.0 (1992-2003)	04/96-12/99	FR DS
Suzuki	Swift 1.2 AZ (2010-2017)	08/10-12/17	FR DS
Suzuki	Swift 1.2 AZ (2010-2017)	08/10-12/17	FR DS
Suzuki	Swift 1.2 AZ (2010-2017)	08/10-12/17	FR DS
Suzuki	Swift 1.3 (1986-1992)	04/92-07/92	FR DS
Suzuki	Swift 1.3 (1986-1992)	04/92-07/92	FR DS
Suzuki	Swift 1.3 (1992-2003)	04/92-04/92	FR DS
Suzuki	Swift 1.3 (1992-2003)	04/92-04/92	FR DS
Suzuki	Swift 1.3 (1992-2003)	04/92-04/92	FR DS
Suzuki	Swift 1.3 (1992-2003)	04/92-04/92	FR DS
Suzuki	Swift 1.3 GTi (1986-1992)	04/92-07/92	FR DS
Suzuki	Swift 1.3 GTi (1992-2003)	04/92-12/96	FR DS
Suzuki	Swift 1.6 (1986-1992)	03/90-07/92	FR DS
Suzuki	Swift 1.6 Sport AZ (2010-2017)	10/11-12/17	FR DS
Suzuki	Swift 1.6 Sport AZ (2010-2017)	10/11-12/17	FR DS
Toyota	Avensis 1.6 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 1.6 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 1.6 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 1.6 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 1.8 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	08/00-05/03	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	10/99-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS

Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Avensis 2.0 T220 (1997-2003)	11/97-04/01	FR DS
Toyota	Camry 1.8 SV10	04/83-08/85	FR DS
Toyota	Camry 1.8 SV10	04/83-08/85	FR DS
Toyota	Camry 2.0 SV11	04/84-01/87	FR DS
Toyota	Camry 2.0 SV11	04/84-01/87	FR DS
Toyota	Camry 2.2 SXV10	09/91-09/95	FR DS
Toyota	Camry 2.2 SXV10	09/91-09/95	FR DS
Toyota	Camry 2.2 SXV10	09/91-12/95	FR DS
Toyota	Camry 2.2 SXV10	09/91-12/95	FR DS
Toyota	Camry 3.0 VCV10	10/91-09/95	FR DS
Toyota	Camry 3.0 VCV10	10/91-12/95	FR DS
Toyota	Carina 1.8 AT211	03/96-12/01	FR DS
Toyota	Carina 1.8 AT211	03/96-12/01	FR DS
Toyota	Carina 2.0 CT210	03/96-12/98	FR DS
Toyota	Carina 2.0 ST215	03/96-12/01	FR DS
Toyota	Carina 2.0 ST215	03/96-12/01	FR DS
Toyota	Carina E 1.6 AT190	05/92-03/96	FR DS
Toyota	Carina E 1.6 AT190	05/92-03/96	FR DS
Toyota	Carina E 1.6 AT190	05/92-04/97	FR DS
Toyota	Carina E 1.6 AT190	05/92-04/97	FR DS
Toyota	Carina E 1.6 AT190	05/92-06/95	FR DS
Toyota	Carina E 1.8 AT191	03/95-03/96	FR DS
Toyota	Carina E 1.8 AT191	03/95-03/96	FR DS
Toyota	Carina E 1.8 AT191	03/95-03/96	FR DS
Toyota	Carina E 1.8 AT191	03/96-03/98	FR DS
Toyota	Carina E 1.8 AT191	03/96-03/98	FR DS
Toyota	Carina E 1.8 AT191	03/96-03/98	FR DS
Toyota	Carina E 1.8 AT191	03/96-03/98	FR DS
Toyota	Carina E 1.8 AT191	06/95-03/96	FR DS
Toyota	Carina E 2.0 CT190	03/96-03/98	FR DS
Toyota	Carina E 2.0 CT190	03/96-03/98	FR DS
Toyota	Carina E 2.0 CT190	05/92-03/96	FR DS
Toyota	Carina E 2.0 CT190	05/92-03/96	FR DS
Toyota	Carina E 2.0 GTi ST191	05/92-05/94	FR DS
Toyota	Carina E 2.0 GTi ST191	05/92-06/94	FR DS
Toyota	Carina E 2.0 GTi ST191	06/94-01/96	FR DS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR DS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR DS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR DS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR DS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR DS
Toyota	Carina E 2.0 ST191	05/92-03/98	FR DS
Toyota	Celica 1.8 AT200	07/95-10/99	FR DS
Toyota	Celica 2.0 GT-Four ST205	05/94-10/96	FR DS

Toyota	Celica 2.0 ST202	03/94-10/99	FR DS
Toyota	Celica 2.0 ST202	03/94-10/99	FR DS
Toyota	Celica 2.0 ST202	03/94-10/99	FR DS
Toyota	Celica 2.0 ST202	03/94-10/99	FR DS
Toyota	Corolla 1.4 (E120) ZZE121	09/02-07/07	FR DS
Toyota	Corolla 1.6 (E120) ZZE121	09/02-07/07	FR DS
Toyota	Corolla 1.6 (E120) ZZE121	12/01-07/07	FR DS
Toyota	Corolla 2.0 (E120) CDE120	08/04-07/07	FR DS
Toyota	Corolla 2.0 (E120) CDE120	12/01-09/04	FR DS
Toyota	Hi-Ace 2.4 RZH103/113	07/94-01/96	FR PS
Toyota	Hi-Ace 2.4 RZH103/113	07/94-01/96	FR DS
Toyota	Hi-Ace 2.5 (2001-2006)	11/01-12/06	FR PS
Toyota	Hi-Ace 2.5 (2001-2006)	11/01-12/06	FR DS
Toyota	Hi-Ace 2.5 D-4D 120 (2006-2012)	10/06-06/12	FR DS
Toyota	Hi-Ace 2.5 D-4D 120 (2006-2012)	10/06-06/12	FR PS
Toyota	Hi-Ace 2.5 D-4D 95 (2006-2012)	10/06-06/12	FR PS
Toyota	Hi-Ace 2.5 D-4D 95 (2006-2012)	10/06-06/12	FR DS
Toyota	Hi-Ace 2.5 LH51/61/LH102/113	01/96-12/96	FR PS
Toyota	Hi-Ace 2.5 LH51/61/LH102/113	01/96-12/96	FR DS
Toyota	Hi-Ace 2.5 Turbo (2001-2006)	11/01-12/06	FR DS
Toyota	Hi-Ace 2.5 Turbo (2001-2006)	11/01-12/06	FR PS
Toyota	Hi-Lux 1.8 YN85/90	03/89-12/93	FR DS
Toyota	Hi-Lux 1.8 YN85/90	03/89-12/93	FR PS
Toyota	Hi-Lux 2.2 YN65/67	08/88-12/88	FR PS
Toyota	Hi-Lux 2.2 YN65/67	08/88-12/88	FR DS
Toyota	Hi-Lux 2.5 Dual Cab KDN165	11/01-12/05	FR DS
Toyota	Hi-Lux 2.5 Dual Cab KDN165	11/01-12/05	FR PS
Toyota	Hi-Lux 2.5 Dual Cab LN105/108/110	10/95-12/97	FR DS
Toyota	Hi-Lux 2.5 Dual Cab LN105/108/110	10/95-12/97	FR PS
Toyota	Hi-Lux 2.5 Dual Cab LN165/170	12/97-11/01	FR PS
Toyota	Hi-Lux 2.5 Dual Cab LN165/170	12/97-11/01	FR DS
Toyota	Hi-Lux 2.5 KDN145/50	11/01-12/05	FR DS
Toyota	Hi-Lux 2.5 KDN145/50	11/01-12/05	FR PS
Toyota	Hi-Lux 2.5 KDN165	11/01-12/05	FR PS
Toyota	Hi-Lux 2.5 KDN165	11/01-12/05	FR DS
Toyota	Hi-Lux 2.5 LN105/108/110	03/89-12/97	FR PS
Toyota	Hi-Lux 2.5 LN105/108/110	03/89-12/97	FR DS
Toyota	Hi-Lux 2.5 LN145/150	05/98-11/01	FR DS
Toyota	Hi-Lux 2.5 LN145/150	05/98-11/01	FR PS
Toyota	Hi-Lux 2.5 LN165/170	10/97-11/01	FR PS
Toyota	Hi-Lux 2.5 LN165/170	10/97-11/01	FR DS
Toyota	Hi-Lux 2.5 LN85/95	01/93-12/97	FR DS
Toyota	Hi-Lux 2.5 LN85/95	01/93-12/97	FR PS
Toyota	iQ 1.0 (2009-2015)	01/09-08/15	FR DS
Toyota	iQ 1.0 (2009-2015)	01/09-08/15	FR DS
Toyota	iQ 1.33 (2009-2015)	06/09-08/15	FR DS
Toyota	iQ 1.33 (2009-2015)	06/09-08/15	FR DS
Toyota	Landcruiser 3.0 J12	01/03-10/04	FR PS
Toyota	Landcruiser 3.0 J12	01/03-10/04	FR PS
Toyota	Landcruiser 3.0 J12	01/03-10/04	FR PS

Toyota	Landcruiser 3.0 J12	10/04-11/06	FR PS
Toyota	Landcruiser 3.0 J12	10/04-11/06	FR PS
Toyota	Landcruiser 3.0 J12	10/04-11/06	FR PS
Toyota	Landcruiser 3.0 J12	11/06-06/10	FR PS
Toyota	Landcruiser 3.0 J12	11/06-06/10	FR PS
Toyota	Landcruiser 3.0 J12	11/06-06/10	FR PS
Toyota	Landcruiser 4.7 J10 (UZJ100)	01/98-12/03	FR PS
Toyota	Landcruiser Amazon 4.2 J12	09/03-06/08	FR PS
Toyota	Landcruiser Amazon 4.2 J12	10/02-06/08	FR PS
Toyota	Landcruiser Amazon 4.2 J12	10/02-06/08	FR PS
Toyota	Landcruiser Amazon 4.7 J10 (UZJ100)	04/98-12/03	FR PS
Toyota	Landcruiser Amazon 4.7 J10 (UZJ100)	04/98-12/03	FR PS
Toyota	Landcruiser Amazon 4.7 J12	10/02-06/08	FR PS
Toyota	Power Van 2.4 RCH13/23	01/96-01/98	FR DS
Toyota	Power Van 2.4 RCH13/23	01/96-01/98	FR PS
Toyota	Power Van 2.5 LXH12/22	01/96-01/98	FR PS
Toyota	Power Van 2.5 LXH12/22	01/96-01/98	FR DS
Toyota	Power Van 2.5 LXH12/22	01/98-12/01	FR PS
Toyota	Power Van 2.5 LXH12/22	01/98-12/01	FR DS
Toyota	Yaris 1.0 (1999-2006)	03/99-05/03	FR DS
Toyota	Yaris 1.0 (1999-2006)	03/99-05/03	FR DS
Toyota	Yaris 1.0 (1999-2006)	03/99-05/03	FR DS
Toyota	Yaris 1.0 (1999-2006)	03/99-05/03	FR DS
Toyota	Yaris 1.0 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.0 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.0 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.0 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.3 (1999-2006)	01/01-05/03	FR DS
Toyota	Yaris 1.3 (1999-2006)	01/01-05/03	FR DS
Toyota	Yaris 1.3 (1999-2006)	01/01-05/03	FR DS
Toyota	Yaris 1.3 (1999-2006)	01/01-05/03	FR DS
Toyota	Yaris 1.3 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.3 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.3 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.3 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.3 (1999-2006)	09/99-05/03	FR DS
Toyota	Yaris 1.3 (1999-2006)	09/99-05/03	FR DS
Toyota	Yaris 1.3 (1999-2006)	09/99-05/03	FR DS
Toyota	Yaris 1.3 (1999-2006)	09/99-05/03	FR DS
Toyota	Yaris 1.4 (1999-2006)	03/02-05/03	FR DS
Toyota	Yaris 1.4 (1999-2006)	03/02-05/03	FR DS
Toyota	Yaris 1.4 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.4 (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.5 T Sport (1999-2006)	03/01-05/03	FR DS
Toyota	Yaris 1.5 T Sport (1999-2006)	03/01-05/03	FR DS
Toyota	Yaris 1.5 T Sport (1999-2006)	05/03-02/06	FR DS
Toyota	Yaris 1.5 T Sport (1999-2006)	05/03-02/06	FR DS
Vauxhall	Vivaro 1.9 Di X83 (2001-2006)	03/01-12/06	FR PS
Vauxhall	Vivaro 1.9 Di X83 (2001-2006)	03/01-12/06	FR PS
Vauxhall	Vivaro 1.9 DTi X83 (2001-2006)	03/01-12/06	FR PS

Vauxhall	Vivaro 2.0 CDTi 115 Combi X83 (2006-2015)	03/12-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 Combi X83 (2006-2015)	03/12-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 Combi X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 Combi X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 Combi X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 Combi X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 ecoFLEX X83 (2006-2015)	04/11-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 ecoFLEX X83 (2006-2015)	04/11-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 115 X83 (2006-2015)	10/11-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 Combi X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 Combi X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 Combi X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 Combi X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 CDTi 90 X83 (2006-2015)	10/06-05/15	FR PS
Vauxhall	Vivaro 2.0 X83 (2001-2006)	02/02-12/06	FR PS
Vauxhall	Vivaro 2.5 CDTi 145 Combi X83 (2006-2015)	10/06-12/11	FR PS
Vauxhall	Vivaro 2.5 CDTi 145 X83 (2006-2015)	10/06-12/11	FR PS
Vauxhall	Vivaro 2.5 DTi X83 (2001-2006)	03/03-12/06	FR PS
Volkswagen	Amarok 2.0 TDI 122 (2010-2021)	04/12-04/12	FR PS
Volkswagen	Amarok 2.0 TDI 122 (2010-2021)	07/10-04/12	FR PS
Volkswagen	Amarok 2.0 TDI 163 (2010-2021)	07/10-04/12	FR PS
Volkswagen	Bora 1.6 (1999-2005)	02/99-12/00	FR DS
Volkswagen	Bora 1.6 (1999-2005)	02/99-12/00	FR DS
Volkswagen	Bora 1.6 (1999-2005)	02/99-12/00	FR DS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR DS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR DS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR DS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR DS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR DS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR DS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR DS
Volkswagen	Bora 1.6 (1999-2005)	12/00-02/02	FR DS
Volkswagen	Bora 1.8 T (1999-2005)	07/01-02/02	FR DS
Volkswagen	Bora 1.8 T (1999-2005)	07/01-02/02	FR DS
Volkswagen	Bora 1.8 T (1999-2005)	07/01-02/02	FR DS
Volkswagen	Bora 1.9 SDi (1999-2005)	02/99-02/02	FR DS

































Volkswagen	Vento 1.9 TD (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 1.9 TDi (1992-1998)	04/94-04/98	FR DS
Volkswagen	Vento 1.9 TDi (1992-1998)	04/94-04/98	FR DS
Volkswagen	Vento 1.9 TDi (1992-1998)	04/94-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.0 (1992-1998)	10/92-04/98	FR DS
Volkswagen	Vento 2.8 VR6 (1992-1998)	07/93-04/98	FR DS
Volkswagen	Vento 2.8 VR6 (1992-1998)	10/92-04/98	FR DS
Volvo	440 1.6	11/91-07/97	FR PS
Volvo	440 1.6	11/91-07/97	FR DS
Volvo	440 1.7 Carburettor	08/89-10/90	FR PS
Volvo	440 1.7 Carburettor	08/89-10/90	FR DS
Volvo	440 1.7 Carburettor Catalyst	08/89-12/91	FR PS
Volvo	440 1.7 Carburettor Catalyst	08/89-12/91	FR DS
Volvo	440 1.7 Injection Catalyst	08/89-12/92	FR DS
Volvo	440 1.7 Injection Catalyst	08/89-12/92	FR PS
Volvo	440 1.7 Turbo	12/88-10/90	FR PS
Volvo	440 1.7 Turbo	12/88-10/90	FR PS
Volvo	440 1.7 Turbo	12/88-10/90	FR DS
Volvo	440 1.7 Turbo	12/88-10/90	FR DS
Volvo	440 1.7 Turbo Catalyst	08/89-12/95	FR PS
Volvo	440 1.7 Turbo Catalyst	08/89-12/95	FR DS
Volvo	440 1.7 Turbo Catalyst	08/89-12/95	FR DS
Volvo	440 1.7 Turbo Catalyst	08/89-12/95	FR PS
Volvo	440 1.8	08/94-08/97	FR PS
Volvo	440 1.8	08/94-08/97	FR DS
Volvo	440 1.8	08/94-08/97	FR DS
Volvo	440 1.8	08/94-08/97	FR PS
Volvo	440 1.8	10/91-08/94	FR DS
Volvo	440 1.8	10/91-08/94	FR PS
Volvo	440 1.8	10/91-08/94	FR DS
Volvo	440 1.8	10/91-08/94	FR PS
Volvo	440 2.0	09/92-08/97	FR PS
Volvo	440 2.0	09/92-08/97	FR DS
Volvo	440 2.0	09/92-08/97	FR PS
Volvo	440 2.0	09/92-08/97	FR DS
Volvo	460 1.6	09/93-08/97	FR PS
Volvo	460 1.6	09/93-08/97	FR DS
Volvo	460 1.7 Carburettor	04/90-10/90	FR PS
Volvo	460 1.7 Carburettor	04/90-10/90	FR DS
Volvo	460 1.7 Carburettor Catalyst	04/90-12/91	FR DS
Volvo	460 1.7 Carburettor Catalyst	04/90-12/91	FR PS
Volvo	460 1.7 Injection	04/90-10/90	FR DS
Volvo	460 1.7 Injection	04/90-10/90	FR PS

Volvo	460 1.7 Injection	04/90-10/90	FR DS
Volvo	460 1.7 Injection	04/90-10/90	FR DS
Volvo	460 1.7 Injection	04/90-10/90	FR PS
Volvo	460 1.7 Injection	04/90-10/90	FR DS
Volvo	460 1.7 Injection	04/90-10/90	FR PS
Volvo	460 1.7 Injection	04/90-10/90	FR PS
Volvo	460 1.7 Injection Catalyst	04/90-12/91	FR PS
Volvo	460 1.7 Injection Catalyst	04/90-12/91	FR DS
Volvo	460 1.7 Turbo	04/90-10/90	FR DS
Volvo	460 1.7 Turbo	04/90-10/90	FR DS
Volvo	460 1.7 Turbo	04/90-10/90	FR DS
Volvo	460 1.7 Turbo	04/90-10/90	FR PS
Volvo	460 1.7 Turbo	04/90-10/90	FR DS
Volvo	460 1.7 Turbo	04/90-10/90	FR PS
Volvo	460 1.7 Turbo	04/90-10/90	FR PS
Volvo	460 1.7 Turbo	04/90-10/90	FR PS
Volvo	460 1.7 Turbo Catalyst	04/90-12/95	FR DS
Volvo	460 1.7 Turbo Catalyst	04/90-12/95	FR PS
Volvo	460 1.7 Turbo Catalyst	04/90-12/95	FR PS
Volvo	460 1.7 Turbo Catalyst	04/90-12/95	FR DS
Volvo	460 1.8	08/94-08/97	FR PS
Volvo	460 1.8	08/94-08/97	FR PS
Volvo	460 1.8	08/94-08/97	FR DS
Volvo	460 1.8	08/94-08/97	FR DS
Volvo	460 1.8	10/91-08/94	FR PS
Volvo	460 1.8	10/91-08/94	FR DS
Volvo	460 1.8	10/91-08/94	FR PS
Volvo	460 1.8	10/91-08/94	FR DS
Volvo	460 2.0	09/92-08/97	FR PS
Volvo	460 2.0	09/92-08/97	FR DS
Volvo	460 2.0	09/92-08/97	FR PS
Volvo	460 2.0	09/92-08/97	FR DS
Volvo	740 2.0 Injection	08/87-12/91	FR DS
Volvo	740 2.0 Injection	08/87-12/91	FR DS
Volvo	740 2.0 Injection	08/87-12/91	FR DS
Volvo	740 2.0 Injection	08/87-12/91	FR DS
Volvo	740 2.0 Injection	08/87-12/91	FR PS
Volvo	740 2.0 Injection	08/87-12/91	FR PS
Volvo	740 2.0 Injection	08/87-12/91	FR PS
Volvo	740 2.0 Injection	08/87-12/91	FR PS
Volvo	740 2.3	08/89-12/90	FR PS
Volvo	740 2.3	08/89-12/90	FR PS
Volvo	740 2.3	08/89-12/90	FR DS
Volvo	740 2.3	08/89-12/90	FR DS
Volvo	740 2.3 Carburettor	10/84-12/87	FR DS
Volvo	740 2.3 Carburettor	10/84-12/87	FR DS
Volvo	740 2.3 Carburettor	10/84-12/87	FR DS
Volvo	740 2.3 Carburettor	10/84-12/87	FR PS
Volvo	740 2.3 Carburettor	10/84-12/87	FR PS
Volvo	740 2.3 Carburettor	10/84-12/87	FR DS





Volvo	850 2.0	01/95-10/97	FR PS
Volvo	850 2.0	01/95-10/97	FR DS
Volvo	850 2.0	01/95-10/97	FR DS
Volvo	850 2.0	01/95-10/97	FR PS
Volvo	850 2.0	03/93-10/96	FR DS
Volvo	850 2.0	03/93-10/96	FR DS
Volvo	850 2.0	03/93-10/96	FR DS
Volvo	850 2.0	03/93-10/96	FR PS
Volvo	850 2.0	03/93-10/96	FR DS
Volvo	850 2.0	03/93-10/96	FR PS
Volvo	850 2.0	03/93-10/96	FR DS
Volvo	850 2.0	03/93-10/96	FR PS
Volvo	850 2.0	03/93-10/96	FR DS
Volvo	850 2.0	03/93-10/96	FR PS
Volvo	850 2.0	03/93-10/96	FR PS
Volvo	850 2.0	06/92-10/96	FR DS
Volvo	850 2.0	06/92-10/96	FR PS
Volvo	850 2.0	06/92-10/96	FR DS
Volvo	850 2.0	06/92-10/96	FR PS
Volvo	850 2.0	06/92-10/96	FR DS
Volvo	850 2.0	06/92-10/96	FR DS
Volvo	850 2.0	06/92-10/96	FR DS
Volvo	850 2.0	06/92-10/96	FR PS
Volvo	850 2.0	06/92-10/96	FR PS
Volvo	850 2.0	06/92-10/96	FR DS
Volvo	850 2.0	06/92-10/96	FR PS
Volvo	850 2.0	06/92-10/96	FR PS
Volvo	850 2.3 R	11/95-10/97	FR DS
Volvo	850 2.3 R	11/95-10/97	FR PS
Volvo	850 2.3 R	11/95-10/97	FR PS
Volvo	850 2.3 R	11/95-10/97	FR DS
Volvo	850 2.3 R	11/95-10/97	FR PS
Volvo	850 2.3 R	11/95-10/97	FR DS
Volvo	850 2.3 R	11/95-10/97	FR DS
Volvo	850 2.3 R	11/95-10/97	FR PS
Volvo	850 2.3 T5	08/94-10/97	FR PS
Volvo	850 2.3 T5	08/94-10/97	FR PS
Volvo	850 2.3 T5	08/94-10/97	FR PS
Volvo	850 2.3 T5	08/94-10/97	FR PS
Volvo	850 2.3 T5	08/94-10/97	FR DS
Volvo	850 2.3 T5	08/94-10/97	FR DS
Volvo	850 2.3 T5	08/94-10/97	FR DS
Volvo	850 2.3 Turbo	09/93-08/94	FR PS
Volvo	850 2.3 Turbo	09/93-08/94	FR DS
Volvo	850 2.3 Turbo	09/93-08/94	FR PS
Volvo	850 2.3 Turbo	09/93-08/94	FR DS
Volvo	850 2.3 Turbo	09/93-08/94	FR PS
Volvo	850 2.3 Turbo	09/93-08/94	FR DS



Volvo	960 3.0	09/90-12/96	FR PS
Volvo	960 3.0	09/90-12/96	FR PS
Volvo	C70 2.0 T (1997-2002)	07/00-12/02	FR PS
Volvo	C70 2.0 T (1997-2002)	07/00-12/02	FR DS
Volvo	C70 2.0 T (1997-2002)	12/99-08/01	FR PS
Volvo	C70 2.0 T (1997-2002)	12/99-08/01	FR DS
Volvo	C70 2.0 T (1997-2002)	12/99-12/02	FR DS
Volvo	C70 2.0 T (1997-2002)	12/99-12/02	FR PS
Volvo	C70 2.0 T (1997-2006)	07/00-03/06	FR PS
Volvo	C70 2.0 T (1997-2006)	07/00-03/06	FR DS
Volvo	C70 2.0 T (1997-2006)	12/99-03/06	FR PS
Volvo	C70 2.0 T (1997-2006)	12/99-03/06	FR DS
Volvo	C70 2.0 T (1997-2006)	12/99-08/01	FR PS
Volvo	C70 2.0 T (1997-2006)	12/99-08/01	FR DS
Volvo	C70 2.3 T5 (1997-2002)	06/97-12/02	FR DS
Volvo	C70 2.3 T5 (1997-2002)	06/97-12/02	FR PS
Volvo	C70 2.3 T5 (1997-2002)	06/97-12/02	FR DS
Volvo	C70 2.3 T5 (1997-2002)	06/97-12/02	FR PS
Volvo	C70 2.3 T5 (1997-2006)	04/00-11/02	FR PS
Volvo	C70 2.3 T5 (1997-2006)	04/00-11/02	FR DS
Volvo	C70 2.3 T5 (1997-2006)	04/99-11/02	FR PS
Volvo	C70 2.3 T5 (1997-2006)	04/99-11/02	FR DS
Volvo	C70 2.3 T5 (1997-2006)	04/99-11/02	FR DS
Volvo	C70 2.3 T5 (1997-2006)	04/99-11/02	FR PS
Volvo	C70 2.3 T5 (1997-2006)	11/02-03/06	FR DS
Volvo	C70 2.3 T5 (1997-2006)	11/02-03/06	FR PS
Volvo	C70 2.3 T5 (1997-2006)	11/02-03/06	FR DS
Volvo	C70 2.3 T5 (1997-2006)	11/02-03/06	FR PS
Volvo	C70 2.4 (1997-2002)	04/99-12/99	FR PS
Volvo	C70 2.4 (1997-2002)	04/99-12/99	FR DS
Volvo	C70 2.4 (1997-2002)	04/99-12/99	FR PS
Volvo	C70 2.4 (1997-2002)	04/99-12/99	FR PS
Volvo	C70 2.4 (1997-2002)	04/99-12/99	FR DS
Volvo	C70 2.4 (1997-2002)	04/99-12/99	FR DS
Volvo	C70 2.4 (1997-2002)	04/99-12/99	FR PS
Volvo	C70 2.4 (1997-2002)	04/99-12/99	FR DS
Volvo	C70 2.4 T (1997-2002)	04/99-12/02	FR DS
Volvo	C70 2.4 T (1997-2002)	04/99-12/02	FR PS
Volvo	C70 2.4 T (1997-2002)	04/99-12/02	FR PS
Volvo	C70 2.4 T (1997-2002)	04/99-12/02	FR DS
Volvo	C70 2.4 T (1997-2002)	04/99-12/02	FR PS
Volvo	C70 2.4 T (1997-2002)	04/99-12/02	FR DS
Volvo	C70 2.4 T (1997-2002)	04/99-12/02	FR DS
Volvo	C70 2.4 T (1997-2002)	04/99-12/02	FR PS
Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR DS
Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR PS
Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR DS
Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR PS
Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR DS
Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR DS
Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR DS

Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR PS
Volvo	C70 2.4 T (1997-2006)	04/99-11/02	FR PS
Volvo	C70 2.4 T (1997-2006)	11/02-03/06	FR PS
Volvo	C70 2.4 T (1997-2006)	11/02-03/06	FR PS
Volvo	C70 2.4 T (1997-2006)	11/02-03/06	FR DS
Volvo	C70 2.4 T (1997-2006)	11/02-03/06	FR DS
Volvo	C70 2.5 (1997-2002)	02/99-04/99	FR PS
Volvo	C70 2.5 (1997-2002)	02/99-04/99	FR DS
Volvo	C70 2.5 (1997-2002)	02/99-04/99	FR PS
Volvo	C70 2.5 (1997-2002)	02/99-04/99	FR DS
Volvo	C70 2.5T (1997-2002)	04/98-04/99	FR PS
Volvo	C70 2.5T (1997-2002)	04/98-04/99	FR DS
Volvo	C70 2.5T (1997-2002)	04/98-04/99	FR DS
Volvo	C70 2.5T (1997-2002)	04/98-04/99	FR PS
Volvo	S40 1.6 (1996-2000)	04/99-05/00	FR DS
Volvo	S40 1.6 (2000-2004)	05/00-08/04	FR DS
Volvo	S40 1.8 (1996-2000)	03/96-04/99	FR DS
Volvo	S40 1.8 (1996-2000)	03/96-04/99	FR DS
Volvo	S40 1.8 (1996-2000)	03/96-04/99	FR DS
Volvo	S40 1.8 (1996-2000)	03/96-04/99	FR DS
Volvo	S40 1.8 (1996-2000)	04/98-05/00	FR DS
Volvo	S40 1.8 (1996-2000)	04/99-05/00	FR DS
Volvo	S40 1.8 (1996-2000)	04/99-05/00	FR DS
Volvo	S40 1.8 (2000-2004)	05/00-08/04	FR DS
Volvo	S40 1.8 (2000-2004)	05/00-08/04	FR DS
Volvo	S40 1.8 (2000-2004)	05/00-09/00	FR DS
Volvo	S40 1.8 i (2000-2004)	09/00-08/04	FR DS
Volvo	S40 1.8 i (2000-2004)	09/00-08/04	FR DS
Volvo	S40 1.9 (1996-2000)	01/99-05/00	FR DS
Volvo	S40 1.9 (1996-2000)	12/96-02/99	FR DS
Volvo	S40 1.9 (2000-2004)	05/00-05/03	FR DS
Volvo	S40 1.9 (2000-2004)	05/00-06/04	FR DS
Volvo	S40 1.9 T4 (1996-2000)	06/97-05/00	FR DS
Volvo	S40 1.9 T4 (1996-2000)	06/97-05/00	FR DS
Volvo	S40 1.9 T4 (1996-2000)	06/97-05/00	FR DS
Volvo	S40 1.9 T4 (1996-2000)	06/97-05/00	FR DS
Volvo	S40 1.9 T4 (2000-2004)	05/00-05/03	FR DS
Volvo	S40 1.9 T4 (2000-2004)	05/00-05/03	FR DS
Volvo	S40 2.0 (1996-2000)	03/96-05/00	FR DS
Volvo	S40 2.0 (1996-2000)	03/96-05/00	FR DS
Volvo	S40 2.0 (1996-2000)	03/96-05/00	FR DS
Volvo	S40 2.0 (1996-2000)	03/96-05/00	FR DS
Volvo	S40 2.0 (2000-2004)	05/00-08/04	FR DS
Volvo	S40 2.0 (2000-2004)	05/00-08/04	FR DS
Volvo	S40 2.0 (2000-2004)	05/00-08/04	FR DS
Volvo	S40 2.0 (2000-2004)	05/00-08/04	FR DS
Volvo	S40 2.0 Turbo (1996-2000)	10/97-05/00	FR DS
Volvo	S40 2.0 Turbo (1996-2000)	10/97-05/00	FR DS
Volvo	S40 2.0 Turbo (2000-2004)	05/00-08/04	FR DS
Volvo	S40 2.0 Turbo (2000-2004)	05/00-08/04	FR DS



Volvo	S70 2.5 Dual fuel (1996-1999)	08/97-04/99	FR PS
Volvo	S70 2.5 Dual fuel (1996-1999)	08/97-04/99	FR DS
Volvo	S70 2.5T (1996-1999)	12/96-04/99	FR DS
Volvo	S70 2.5T (1996-1999)	12/96-04/99	FR DS
Volvo	S70 2.5T (1996-1999)	12/96-04/99	FR PS
Volvo	S70 2.5T (1996-1999)	12/96-04/99	FR PS
Volvo	S90 3.0 (1996-1998)	12/96-12/98	FR PS
Volvo	S90 3.0 (1996-1998)	12/96-12/98	FR DS
Volvo	S90 3.0 Automatic (1996-1998)	12/96-12/98	FR PS
Volvo	S90 3.0 Automatic (1996-1998)	12/96-12/98	FR DS
Volvo	S90 3.0 Manual (1996-1998)	12/96-12/98	FR DS
Volvo	S90 3.0 Manual (1996-1998)	12/96-12/98	FR PS
Volvo	V40 1.6 (1996-2000)	04/99-05/00	FR DS
Volvo	V40 1.6 (1996-2000)	04/99-05/00	FR DS
Volvo	V40 1.6 (2000-2004)	05/00-08/04	FR DS
Volvo	V40 1.6 (2000-2004)	05/00-08/04	FR DS
Volvo	V40 1.8 (1996-2000)	03/96-04/99	FR DS
Volvo	V40 1.8 (1996-2000)	03/96-04/99	FR DS
Volvo	V40 1.8 (1996-2000)	03/96-04/99	FR DS
Volvo	V40 1.8 (1996-2000)	03/96-04/99	FR DS
Volvo	V40 1.8 (1996-2000)	04/98-05/00	FR DS
Volvo	V40 1.8 (1996-2000)	04/98-05/00	FR DS
Volvo	V40 1.8 (1996-2000)	04/99-05/00	FR DS
Volvo	V40 1.8 (1996-2000)	04/99-05/00	FR DS
Volvo	V40 1.8 (2000-2004)	05/00-08/04	FR DS
Volvo	V40 1.8 (2000-2004)	05/00-08/04	FR DS
Volvo	V40 1.8 (2000-2004)	05/00-09/00	FR DS
Volvo	V40 1.8 (2000-2004)	05/00-09/00	FR DS
Volvo	V40 1.8 (2000-2004)	05/00-09/00	FR DS
Volvo	V40 1.8 (2000-2004)	05/00-09/00	FR DS
Volvo	V40 1.8 (2000-2004)	09/00-08/04	FR DS
Volvo	V40 1.8 (2000-2004)	09/00-08/04	FR DS
Volvo	V40 1.8 Dual Fuel (2000-2004)	05/00-08/04	FR DS
Volvo	V40 1.8 Dual Fuel (2000-2004)	05/00-08/04	FR DS
Volvo	V40 1.9 (1996-2000)	01/99-05/00	FR DS
Volvo	V40 1.9 (1996-2000)	12/96-02/99	FR DS
Volvo	V40 1.9 (2000-2004)	05/00-05/03	FR DS
Volvo	V40 1.9 (2000-2004)	05/00-06/04	FR DS
Volvo	V40 1.9 T4 (1996-2000)	06/97-05/00	FR DS
Volvo	V40 1.9 T4 (1996-2000)	06/97-05/00	FR DS
Volvo	V40 1.9 T4 (2000-2004)	05/00-05/03	FR DS
Volvo	V40 1.9 T4 (2000-2004)	05/00-05/03	FR DS
Volvo	V40 2.0 (1996-2000)	03/96-05/00	FR DS
Volvo	V40 2.0 (1996-2000)	03/96-05/00	FR DS
Volvo	V40 2.0 (1996-2000)	03/96-05/00	FR DS
Volvo	V40 2.0 (1996-2000)	03/96-05/00	FR DS
Volvo	V40 2.0 (2000-2004)	05/00-08/04	FR DS
Volvo	V40 2.0 (2000-2004)	05/00-08/04	FR DS
Volvo	V40 2.0 (2000-2004)	05/00-08/04	FR DS
Volvo	V40 2.0 (2000-2004)	05/00-08/04	FR DS

Volvo	V40 2.0 Turbo (1996-2000)	10/97-05/00	FR DS
Volvo	V40 2.0 Turbo (1996-2000)	10/97-05/00	FR DS
Volvo	V40 2.0 Turbo (1996-2000)	10/97-05/00	FR DS
Volvo	V40 2.0 Turbo (1996-2000)	10/97-05/00	FR DS
Volvo	V40 2.0 Turbo (2000-2004)	05/00-08/04	FR DS
Volvo	V40 2.0 Turbo (2000-2004)	05/00-08/04	FR DS
Volvo	V40 2.0 Turbo (2000-2004)	05/00-08/04	FR DS
Volvo	V40 2.0 Turbo (2000-2004)	05/00-08/04	FR DS
Volvo	V70 2.0 (1996-2000)	12/96-04/99	FR PS
Volvo	V70 2.0 (1996-2000)	12/96-04/99	FR DS
Volvo	V70 2.0 (1996-2000)	12/96-04/99	FR DS
Volvo	V70 2.0 (1996-2000)	12/96-04/99	FR DS
Volvo	V70 2.0 (1996-2000)	12/96-04/99	FR DS
Volvo	V70 2.0 (1996-2000)	12/96-04/99	FR PS
Volvo	V70 2.0 (1996-2000)	12/96-04/99	FR PS
Volvo	V70 2.0 (1996-2000)	12/96-04/99	FR PS
Volvo	V70 2.3 R (1996-2000)	06/97-04/99	FR DS
Volvo	V70 2.3 R (1996-2000)	06/97-04/99	FR DS
Volvo	V70 2.3 R (1996-2000)	06/97-04/99	FR PS
Volvo	V70 2.3 R (1996-2000)	06/97-04/99	FR PS
Volvo	V70 2.3 R (1996-2000)	06/97-07/98	FR DS
Volvo	V70 2.3 R (1996-2000)	06/97-07/98	FR PS
Volvo	V70 2.3 T5 (1996-2000)	12/96-01/00	FR PS
Volvo	V70 2.3 T5 (1996-2000)	12/96-01/00	FR PS
Volvo	V70 2.3 T5 (1996-2000)	12/96-01/00	FR DS
Volvo	V70 2.3 T5 (1996-2000)	12/96-01/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR PS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS
Volvo	V70 2.4 (1996-2000)	04/99-04/00	FR DS





Volvo	V70 2.5T (1996-2000)	12/96-04/99	FR PS
Volvo	V70 2.5T (1996-2000)	12/96-04/99	FR DS
Volvo	V70 2.5T (1996-2000)	12/96-06/00	FR DS
Volvo	V70 2.5T (1996-2000)	12/96-06/00	FR PS
Volvo	V70 2.5T (1996-2000)	12/96-06/00	FR PS
Volvo	V70 2.5T (1996-2000)	12/96-06/00	FR DS
Volvo	V70 2.5T (1996-2000)	12/96-06/00	FR DS
Volvo	V70 2.5T (1996-2000)	12/96-06/00	FR PS
Volvo	V70 2.5T (1996-2000)	12/96-06/00	FR DS
Volvo	V70 2.5T (1996-2000)	12/96-06/00	FR PS
Volvo	V90 3.0 (1996-1998)	12/96-12/98	FR PS
Volvo	V90 3.0 (1996-1998)	12/96-12/98	FR DS
Volvo	V90 3.0 (1996-1998)	12/96-12/98	FR DS
Volvo	V90 3.0 (1996-1998)	12/96-12/98	FR PS
Volvo	V90 3.0 Automatic (1996-1998)	12/96-12/98	FR PS
Volvo	V90 3.0 Automatic (1996-1998)	12/96-12/98	FR DS
Volvo	V90 3.0 Manual (1996-1998)	12/96-12/98	FR DS
Volvo	V90 3.0 Manual (1996-1998)	12/96-12/98	FR PS